

Document Title	Specification of FlexRay State Manager
Document Owner	AUTOSAR
Document Responsibility	AUTOSAR
Document Identification No	254
Document Classification	Standard

Document Version	2.2.0
Document Status	Final
Part of Release	4.0
Revision	3

Document Change History			
Date	Version	Changed by	Change Description
09.12.2011	2.2.0	AUTOSAR Administration	<ul style="list-style-type: none"> Short term loss of synchronization is reported to DEM or DET. Number of startup frames can be monitored during normal operation. Revised production error handling.
03.11.2010	2.1.0	AUTOSAR Administration	<ul style="list-style-type: none"> The amount of wakeup patterns can be configured Clearing the Coldstart Inhibit Mode can be delayed also for passive wakeup. Removed enabling and disabling of transceiver wakeups
30.11.2009	2.0.0	AUTOSAR Administration	<ul style="list-style-type: none"> Added support of FlexRay Dual Channel Wakeup Added support of FlexRay Single Slot Mode Added support of Passive Mode (Receive only) Improved timeout supervision of FlexRay startup Legal disclaimer revised
23.06.2008	1.0.2	AUTOSAR Administration	Legal disclaimer revised
01.02.2008	1.0.1	AUTOSAR Administration	Chapter 8 API Spelling harmonized
20.11.2007	1.0.0	AUTOSAR Administration	Initial Release

Disclaimer

This specification and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the specification.

The material contained in this specification is protected by copyright and other types of Intellectual Property Rights. The commercial exploitation of the material contained in this specification requires a license to such Intellectual Property Rights.

This specification may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only.

For any other purpose, no part of the specification may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The AUTOSAR specifications have been developed for automotive applications only. They have neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.

Advice for users

AUTOSAR specifications may contain exemplary items (exemplary reference models, "use cases", and/or references to exemplary technical solutions, devices, processes or software).

Any such exemplary items are contained in the specifications for illustration purposes only, and they themselves are not part of the AUTOSAR Standard. Neither their presence in such specifications, nor any later documentation of AUTOSAR conformance of products actually implementing such exemplary items, imply that intellectual property rights covering such exemplary items are licensed under the same rules as applicable to the AUTOSAR Standard.

Table of Contents

1	Introduction and functional overview	6
2	Acronyms and abbreviations	7
3	Related documentation.....	8
3.1	Input documents.....	8
3.2	Related standards and norms	8
4	Constraints and assumptions	9
4.1	Limitations	9
4.2	Applicability to car domains.....	9
5	Dependencies to other modules.....	10
5.1	AUTOSAR BSW Scheduler.....	10
5.2	Communication Manager	10
5.3	AUTOSAR FlexRay Interface.....	10
5.4	AUTOSAR Development Error Tracer.....	10
5.5	AUTOSAR Diagnostic Event Manager	10
5.6	AUTOSAR BSW Mode Manager.....	10
5.7	AUTOSAR FlexRay Network Management.....	10
5.8	File structure	11
5.8.1	Code file structure	11
5.8.2	Header file structure.....	11
6	Requirements traceability	13
7	Functional specification	16
7.1	Background & Rationale.....	16
7.2	Main Task of the FlexRay State Manager	16
7.3	State Machine of the FlexRay State Manager	16
7.3.1	General	16
7.3.2	States	17
7.3.3	Variables	18
7.3.4	State Machine Configuration	19
7.3.5	Conditions	20
7.3.6	Timers	21
7.3.7	Functional Elements.....	21
7.3.8	Wakeup Pattern Transmission	24
7.3.9	Transitions.....	24
7.4	Configuration description.....	30
7.5	Error classification	30
7.6	Error detection.....	31
7.7	Error notification	31
7.8	Debugging	31
8	API specification	33
8.1	Imported types.....	33
8.2	Type definitions	33
8.2.1	FrSM_ConfigType	33

8.2.2	FrSM_BswM_StateType	33
8.3	Function definitions	34
8.3.1	FrSM_Init	34
8.3.2	FrSM_RequestComMode	35
8.3.3	FrSM_GetCurrentComMode	36
8.3.4	FrSM_GetVersionInfo	37
8.3.5	FrSM_AllSlots	38
8.3.6	FrSM_SetEcuPassive	39
8.4	Call-back notifications	39
8.5	Scheduled functions	39
8.5.1	FrSM_MainFunction_<Cluster Id>	40
8.6	Expected Interfaces.....	41
8.6.1	Mandatory Interfaces	41
8.6.2	Optional Interfaces	41
8.6.3	Configurable Interfaces	42
8.6.3.1	<Cdd>_SyncLossErrorIndication	42
9	Sequence diagrams	43
9.1	Initialization	43
9.2	Single Channel Wakeup.....	44
9.3	Single Channel Passive Startup.....	46
9.4	Dual Channel Wakeup	48
9.5	Dual Channel Wakeup Forward	50
9.6	Key Slot Only Mode.....	52
9.7	Transition from full communication to no communication.....	53
10	Configuration specification.....	54
10.1	How to read this chapter	54
10.1.1	Configuration and configuration parameters	54
10.1.2	Variants.....	54
10.1.3	Containers.....	54
10.1.4	Specification template for configuration parameters	55
10.2	Containers and configuration parameters	55
10.2.1	Variants.....	56
10.2.1.1	VARIANT-PRE-COMPILE (Pre-compile Configuration)	56
10.2.1.2	VARIANT-LINK-TIME (Link-time Configuration)	56
10.2.1.3	VARIANT-POST-BUILD (Post-build Configuration)	56
10.2.2	FrSM	57
10.2.3	FrSMConfig.....	57
10.2.4	FrSMGeneral.....	58
10.2.5	FrSMCluster.....	60
10.2.6	FrSMClusterDemEventParameterRefs	65
10.3	Published Information.....	65
11	Changes during SWS Improvements by Technical Office for Set 2.....	67
11.1	Deleted SWS Items	67
11.2	Replaced SWS Items	67
11.3	Changed SWS Items.....	67
11.4	Added SWS Items.....	67
12	Changes to Release 3	68

12.1	Deleted SWS Items	68
12.2	Replaced SWS Items	68
12.3	Changed SWS Items	68
12.4	Added SWS Items	69
13	Not applicable requirements	70

1 Introduction and functional overview

This specification specifies the functionality, API and the configuration of the AUTOSAR Basic Software module "FlexRay State Manager".

In the AUTOSAR Layered Software Architecture, the FlexRay State Manager belongs to the Services Layer, or more precisely, to the Communication Services.




Figure 1 Software Architecture Overview

2 Acronyms and abbreviations

Acronym/ Abbreviation	Description:
API	Application Program Interface
AUTOSAR	Automotive Open System Architecture
BSW	Basic Software
CC	Communication Controller
CHI	Controller Host Interface
ComM	AUTOSAR Communication Manager
DCM	Diagnostic Communication Manager
Dem/DEM	Diagnostic Event Manager
Det/DET	Development Error Tracer
e.g.	[lat.] exempli gratia = [eng.] for example
ECU	Electronic Control Unit
EcuM	ECU State Manager
Fr	FlexRay Driver
FrIf	FlexRay Interface (AUTOSAR BSW module)
FrSM	FlexRay State Manager
FrTrcv	FlexRay Transceiver Driver
i.e.	[lat.] id est = [eng.] that is
Id/ID	Identifier
N/A	Not applicable
NM	Network Management
PDU	Protocol Data Unit
POC	Protocol Operation Control
POCState	Actual CC internal state of the POC. This state might differ from vPOC!State in certain cases, e.g. after FREEZE command invocation (see [11] for details).
RTE	Runtime Environment
RX	Reception
SchM	Schedule Manager
SW	Software
TX	Transmission
UML	Unified Modeling Language
vPOC	Data structure provided from the CC to the host at the CHI , which contains the actual POC status of the CC .
vPOC!Freeze	vPOC!Freeze denotes the Freeze bit that is part of the vPOC data structure. The Freeze bit is used by the CC to indicate that the HALT state has been entered due to an error condition.
vPOC!SlotMode	vPOC!SlotMode denotes the SlotMode field that is part of the vPOC data structure.
WUP	Wake-Up Pattern
XML	Extensible markup language

Term:	Description:
Active wake-up	Wake-up caused by the ECU e.g. by a sensor.
Passive wake-up	Wakeup caused by another ECU and propagated (e.g. by bus or wakeup-line) to the ECU currently in focus.
Remote wake-up	A passive wake-up received by the FlexRay bus or wakeup-line.

3 Related documentation

3.1 Input documents

- [1] List of Basic Software Modules
AUTOSAR_TR_BSWModuleList.pdf
- [2] Layered Software Architecture
AUTOSAR_EXP_LayeredSoftwareArchitecture.pdf
- [3] General Requirements on Basic Software Modules
AUTOSAR_SRS_BSWGeneral.pdf
- [4] Specification of ECU Configuration
UTOSAR_TPS_ECUConfiguration.pdf
- [5] Specification of Communication Stack Types
AUTOSAR_SWS_CommunicationStackTypes.pdf
- [6] Requirements on FlexRay
AUTOSAR_SRS_FlexRay.pdf
- [7] Specification of FlexRay Interface
AUTOSAR_SWS_FlexRayInterface.pdf
- [8] Specification of FlexRay Driver
AUTOSAR_SWS_FlexRayDriver.pdf
- [9] Specification of Communication Manager
AUTOSAR_SWS_ComManager.pdf
- [10] Requirements on Mode Management
AUTOSAR_SRS_ModeManagement.pdf
- [11] Basic Software Module Description Template,
AUTOSAR_TPS_BSWModuleDescriptionTemplate.pdf

3.2 Related standards and norms

- [12] FlexRay Communications System Protocol Specification Version 2.1 Rev A

4 Constraints and assumptions

4.1 Limitations

This specification only defines the straightforward case for starting and stopping the communication on a FlexRay cluster.

For the case of multiple [CC](#) of one ECU assigned to one FlexRay cluster some items are left open for the implementation:

- Which CC is used to transmit the wakeup pattern
- Handling of inconsistent POC states in the CCs

4.2 Applicability to car domains

The FlexRay Communication stack can be used wherever high data rates and fault tolerant communication (in conjunction with [11]) is required. Furthermore, it enables the synchronized operation of several ECUs within a car.

The FlexRay State Manager can be used for all domain applications which use the FlexRay Protocol.

5 Dependencies to other modules

5.1 AUTOSAR BSW Scheduler

The BSW Scheduler calls the main functions of the FrSM, which are necessary for the cyclic processes of the FrSM.

5.2 Communication Manager

The [ComM](#) requests network communication modes and is notified by the FrSM when a communication mode is reached.

5.3 AUTOSAR FlexRay Interface

The FrSM uses the API of the [Frlf](#) to initialize the FlexRay Communication Hardware and to control the operating modes of the FlexRay Controllers and FlexRay Transceivers assigned to the FlexRay Networks.

5.4 AUTOSAR Development Error Tracer

In order to be able to report development errors, the FlexRay State Manager has to have access to the error hook of the Development Error Tracer.

5.5 AUTOSAR Diagnostic Event Manager

In order to be able to report production errors the FlexRay State Manager has to have access to the Diagnostic Event Manager.

5.6 AUTOSAR BSW Mode Manager

In order to be able to report state changed the FlexRay State Manager has to have access to the BSW Mode Manager.

5.7 AUTOSAR FlexRay Network Management

In order to be able to report startup failures the FlexRay State Manager has to have access to the FlexRay Network Management.

5.8 File structure

5.8.1 Code file structure


[FrSm051] [The code file structure shall not be defined within this specification completely. At this point it shall be pointed out that the code-file structure shall include the following files named:

- FrSM_Lcfg.c – for link time configurable parameters and
- FrSM_PBcfg.c – for post build time configurable parameters.

These files shall contain all link time and post-build time configurable parameters.]

(BSW00344, BSW00404, BSW00380, BSW00300)

5.8.2 Header file structure



[FrSm120] [The header file FrSM.h shall export the API of the FrSM module.] ()

[FrSm121] [The header file FrSM.h shall include FrSM_Types.h and FrSM_Cfg.h.]

[FrSm053] [The header file FrSM_Cfg.h shall contain the pre-compile parameters of the FrSM module. | (BSW00345, BSW00412)]

[FrSm054] [The header file FrSM_Types.h shall export the FrSM specific types.] ()

[FrSm055] [The FrSM implementation (FrSM.c) shall include its header file FrSM.h to get access to its own API declaration and to its configuration parameters.] ()

[FrSm056] [If development errors are enabled by configuration (see [FrSm066](#)), the FrSM implementation (FrSM.c) shall include the header file Det.h to get access to the DET API to report development errors.] ()

[FrSm057] [The FrSM implementation (FrSM.c) shall include the header file MemMap.h in order to map its code and data into specific memory sections.] ()

[FrSm058] [The FrSM implementation (FrSM.c) shall include the header file FrIf.h to get access to the FrIf API.] ()

[FrSm059] [The module shall include the Dem.h file.

By this inclusion the APIs to report errors as well as the required Event Id symbols are included. This specification defines the name of the Event Id symbols which are provided by XML to the DEM configuration tool. The DEM configuration tool assigns ECU dependent values to the Event Id symbols and publishes the symbols in Dem_IntErrId.h.] ()

[FrSm139] [The header file FrSM.h shall include a software and specification version number.] ()

[FrSm140] [The FrSM module shall perform a consistency check between code files and header files based on pre-process-checking the version numbers of related code files and header files.] (BSW004)

[FrSm182] [The FrSM module shall perform inter module checks to avoid integration of incompatible files. The imported header files shall be checked by preprocessing directives. The following version numbers shall be verified:

- <MODULENAME>_AR_RELEASE_MAJOR_VERSION
- <MODULENAME>_AR_RELEASE_MINOR_VERSION

where <MODULENAME> is the module abbreviation of the other (external) modules which provide header files included by the FrSM module. If the values are not identical to the expected values, an error shall be reported.] (BSW004)

6 Requirements traceability

Requirement	Description	Satisfied by
BSW00300	:	FrSm051
BSW00314	These requirements are not applicable to this specification.	FrSm186
BSW00323	:	FrSm018, FrSm028, FrSm168
BSW00325	These requirements are not applicable to this specification.	FrSm186
BSW00326	These requirements are not applicable to this specification.	FrSm186
BSW00327	:	FrSm042
BSW00336	These requirements are not applicable to this specification.	FrSm186
BSW00337	:	FrSm042
BSW00338	:	FrSm043
BSW00344	:	FrSm051
BSW00345	:	FrSm053
BSW00347	These requirements are not applicable to this specification.	FrSm186
BSW00359	These requirements are not applicable to this specification.	FrSm186
BSW00360	These requirements are not applicable to this specification.	FrSm186
BSW00369	:	FrSm018, FrSm028, FrSm168
BSW00370	These requirements are not applicable to this specification.	FrSm186
BSW00373	:	FrSm118
BSW00375	These requirements are not applicable to this specification.	FrSm186
BSW00377	These requirements are not applicable to this specification.	FrSm186
BSW00380	:	FrSm051
BSW00381	:	FrSm013
BSW00385	:	FrSm042
BSW00387	These requirements are not applicable to this specification.	FrSm186
BSW004	:	FrSm140, FrSm182
BSW00404	:	FrSm051
BSW00405	:	FrSm013

BSW00406	:	FrSm061, FrSm060, FrSm169, FrSm179
BSW00407	:	FrSm029
BSW00409	:	FrSm042
BSW00412	:	FrSm053
BSW00413	These requirements are not applicable to this specification.	FrSm186
BSW00415	These requirements are not applicable to this specification.	FrSm186
BSW00416	These requirements are not applicable to this specification.	FrSm186
BSW00417	These requirements are not applicable to this specification.	FrSm186
BSW00419	These requirements are not applicable to this specification.	FrSm186
BSW00422	These requirements are not applicable to this specification.	FrSm186
BSW00423	These requirements are not applicable to this specification.	FrSm186
BSW00425	These requirements are not applicable to this specification.	FrSm186
BSW00427	These requirements are not applicable to this specification.	FrSm186
BSW00428	These requirements are not applicable to this specification.	FrSm186
BSW00429	These requirements are not applicable to this specification.	FrSm186
BSW00432	These requirements are not applicable to this specification.	FrSm186
BSW00437	These requirements are not applicable to this specification.	FrSm186
BSW00438	:	FrSm013, FrSm126, FrSm127, FrSm128
BSW00439	These requirements are not applicable to this specification.	FrSm186
BSW00440	These requirements are not applicable to this specification.	FrSm186
BSW00442	:	FrSm133, FrSm134, FrSm135, FrSm136, FrSm137
BSW00443	These requirements are not applicable to this specification.	FrSm186
BSW00444	These requirements are not applicable to this specification.	FrSm186
BSW00446	These requirements are not applicable to this	FrSm186

	specification.	
BSW00449	These requirements are not applicable to this specification.	FrSm186
BSW00450	:	FrSm181
BSW005	These requirements are not applicable to this specification.	FrSm186
BSW09081	:	FrSm020
BSW09084	:	FrSm024
BSW101	:	FrSm126
BSW161	These requirements are not applicable to this specification.	FrSm186
BSW162	These requirements are not applicable to this specification.	FrSm186
BSW164	These requirements are not applicable to this specification.	FrSm186
BSW168	These requirements are not applicable to this specification.	FrSm186
BSW170	These requirements are not applicable to this specification.	FrSm186

7 Functional specification

7.1 Background & Rationale

FlexRay start-up is a complex process that is completely different from CAN. E.g. on CAN every message can wakeup the bus, on FlexRay a special wakeup pattern is needed. In order to make the FlexRay start-up process as reliable as possible, it has to be controlled by a BSW module with in-depth FlexRay knowledge. As the AUTOSAR Communication Manager has a completely abstracted bus view, it is the task of the FlexRay State Manager to map this abstracted view to the states of the FlexRay [POC](#) and to the [CHI](#) commands to change these states.

7.2 Main Task of the FlexRay State Manager

The main task of the FlexRay State Manager module can be summarized as follows:

The FlexRay State Manager module shall provide an abstract interface to the AUTOSAR Communication Manager module to startup or shutdown the communication on a FlexRay cluster.

The FlexRay State Manager module shall not directly access the FlexRay hardware (FlexRay Communication Controller and FlexRay Transceiver), but by means of the FlexRay Interface module.

The FlexRay Interface module redirects the request to the appropriate driver module.

7.3 State Machine of the FlexRay State Manager

7.3.1 General

[FrSm030] [The FlexRay State Manager shall implement one state machine for each FlexRay cluster.

The states of this state machine are to some extent derived from the [POC](#) states of the FlexRay [CC](#). This document is based on the assumption that there is always a unique [POC](#) state for every FlexRay cluster (see Limitations in section 4.1).

The state machine of each cluster is processed by the main function `FrSM_MainFunction_<Cluster Id>` assigned to that cluster (see section 8.5.1). However, as defined in section 8.3.2, some transitions of the state machine are processed in the context of the [FrSM_RequestComMode](#) function in order to achieve a deterministic behavior for shutdown.] ()

7.3.2 States

[FrSm032] [The state machine shall comprise the following states:

<i>FrSM Cluster State</i>	<i>Mapped FlexRay CC state</i>	<i>Description</i>
FRSM_READY	POC :ready	
FRSM_WAKEUP	POC :wake-up	FrSM performs wake-up
FRSM_STARTUP	POC :start-up	FrSM performs startup
FRSM_HALT_REQ	POC :normal active or POC :normal passive	FrSM performs a shutdown
FRSM_ONLINE	POC :normal active	Full Communication
FRSM_ONLINE_PASSIVE	POC :normal passive	Due to clock synchronization errors no data is transmitted or received.
FRSM_KEYSLOT_ONLY	POC :normal active \wedge vPOC!SlotMode \neq AllSlots	Data can only be transmitted in the key slots.
FRSM_LOW_NUMBER_OF_COLDSTARTERS	POC :normal active	Full communication; FlexRay is synchronized based on sync frames only.

] ()

[FrSm176] [For controlling the passive mode (receive-only), the state machine shall additionally comprise the following states which concurrent to the states above:

<i>Passive State</i>	<i>Description</i>
FRSM_ECU_ACTIVE	When the FrSM is concurrently in state FRSM_READY , the transceivers are in set into mode FRTRCV_TRCVMODE_STANDBY, otherwise into mode FRTRCV_TRCVMODE_NORMAL
FRSM_ECU_PASSIVE	When the FrSM is concurrently in state FRSM_READY , the transceivers are in set into mode FRTRCV_TRCVMODE_STANDBY, otherwise into mode FRTRCV_TRCVMODE_RECEIVEONLY.

] ()

[FrSm180] [For reporting these two concurrent states to the BswM, a corresponding value of FrSM_BswM_StateType shall be determined as follows:

<i>FrSM Cluster State</i>	<i>Passive State</i>	<i>FrSM_BswM_StateType value</i>
FRSM_READY	FRSM_ECU_ACTIVE	FRSM_READY
FRSM_READY	FRSM_ECU_PASSIVE	FRSM_READY_ECU_PASSIVE
FRSM_WAKEUP	FRSM_ECU_ACTIVE	FRSM_WAKEUP
FRSM_WAKEUP	FRSM_ECU_PASSIVE	FRSM_WAKEUP_ECU_PASSIVE
FRSM_STARTUP	FRSM_ECU_ACTIVE	FRSM_STARTUP
FRSM_STARTUP	FRSM_ECU_PASSIVE	FRSM_STARTUP_ECU_PASSIVE
FRSM_ONLINE	FRSM_ECU_ACTIVE	FRSM_ONLINE
FRSM_ONLINE	FRSM_ECU_PASSIVE	FRSM_ONLINE_ECU_PASSIVE
FRSM_ONLINE_PASSIVE	FRSM_ECU_ACTIVE	FRSM_ONLINE_PASSIVE
FRSM_ONLINE_PASSIVE	FRSM_ECU_PASSIVE	FRSM_ONLINE_PASSIVE_ECU_PASSIVE
FRSM_KEYSLOT_ONLY	FRSM_ECU_ACTIVE	FRSM_KEYSLOT_ONLY

FRSM_KEYSLOT_ONLY	FRSM_ECU_PASSIVE	FRSM_KEYSLOT_ONLY_ECU_PASSIVE
FRSM_HALT_REQUEST	FRSM_ECU_ACTIVE	FRSM_HALT_REQUEST
FRSM_HALT_REQUEST	FRSM_ECU_PASSIVE	FRSM_HALT_REQUEST_ECU_PASSIVE
FRSM_LOW_NUMBER_OF_COLD-STARTERS	FRSM_ECU_ACTIVE	FRSM_LOW_NUMBER_OF_COLDSTARTERS
FRSM_LOW_NUMBER_OF_COLD-STARTERS	FRSM_ECU_PASSIVE	FRSM_LOW_NUMBER_OF_COLD-STARTERS_ECU_PASSIVE

] ()

7.3.3 Variables

In addition to its state, the state machine description uses the following variables. Note that these variables are only auxiliary means for improving the clearness and the readability of the specification.

<i>FrSM Variable</i>	<i>Type</i>	<i>Description</i>
reqComMode	ComM_ModeType	The communication mode that has been requested by the ComM . The communication modes are abbreviated in this document as follows: NoCom: COMM_NO_COMMUNICATION SilentCom: COMM_SILENT_COMMUNICATION FullCom: COMM_FULL_COMMUNICATION According to the definition of ComM_ModeType these modes are ordered as follows: NoCom < SilentCom < FullCom
startupCounter	uint8	The number of startup attempts that have been performed
wakeupType	Enum	The following values are supported: <ul style="list-style-type: none"> • SingleChannelWakeup • DualChannelWakeup • DualChannelWakeupForward • DualChannelEchoWakeup • NoWakeup
wakeupTransmitted	Boolean	True if vPOC!WakeupStatus = FR_WAKEUP_TRANSMITTED for at least attempt to transmit a wakeup pattern, false otherwise
busTrafficDetected	Boolean	True if vPOC!WakeupStatus = FR_WAKEUP_RECEIVED_HEADER or FR_WAKEUP_RECEIVED_WUP for at least attempt to transmit a wakeup pattern, false otherwise
wakeupCounter	uint16	The number of attempts that have been performed for transmitting a wakeup pattern.

Note that the silent communication mode is not supported on FlexRay; it may not be requested by the [ComM](#) module.

7.3.4 State Machine Configuration

The state machine description uses the following configuration parameters that are defined in chapter 10.2 for each FlexRay cluster:

FrSM Configuration Parameter	Type	Description
FrSMIsWakeupEcu	Boolean	See chapter 10.2
FrSMCheckWakeupReason	Boolean	See chapter 10.2
FrSMIsColdstartEcu	Boolean	See chapter 10.2
FrSMIsDualChannelNode	Boolean	This configuration parameter is derived from the FrIf configuration. If the corresponding FrIf cluster is connected to both channels of the FlexRay cluster, this parameter is TRUE. Otherwise, it is FALSE.
FrSMStartupRepetitionsWithWakeup	Integer	The number of times an ECU may repeat the startup procedure including a wakeup for a FlexRay cluster. If this optional configuration parameter is missing, there shall be no limitation, i.e. the configuration parameter shall be treated as having the value ∞
FrSMStartupRepetitions	Integer	Determines how often the ECU can repeat the startup procedure by reinitializing the FlexRay CC , see chapter 10.2. This value must not be smaller than FrSMStartupRepetitionsWithWakeup . If this optional configuration parameter is missing, there shall be no limitation, i.e. the configuration parameter shall be treated as having the value ∞
FrSMNumWakeupPatterns	Integer	Maximum number of Wakeup Patterns the node may send before going to FRSM_STARTUP .

FrSMDelayStartupWithoutWakeup	Boolean	If true, timer t1 shall be started instead of immediately calling FrIf_AllowColdstart in case of a startup without wakeup.
FrSMMinNumberOfColdstarter	Integer	Minimum number of startup frames that have to be present, see chapter 10.2

7.3.5 Conditions

The state machine description uses the following conditions that are evaluated during runtime for each FlexRay cluster:

FrSM Condition	Type	Description
WUReason	Enum	<p>If FrSMCheckWakeupReason is false, WUReason evaluates to NO_WU_BY_BUS.</p> <p>Otherwise if FrSMCheckWakeupReason is true, determine the wakeup reason by</p> <ul style="list-style-type: none"> calling FrIf_GetTransceiverWUReason for each transceiver of the FlexRay cluster and check for FRTRCV_WU_BY_BUS and calling FrIf_GetWakeupRxStatus for each controller of the cluster to check for wakeups detected by the FlexRay CCs. <p>and evaluate WUReason to</p> <ul style="list-style-type: none"> NO_WU_BY_BUS in case no wakeup has been detected. PARTIAL_WU_BY_BUS in case the ECU is connected to both FlexRay channels of the cluster and wakeup has been detected for exactly one channel ALL_WU_BY_BUS in case wakeup has been detected for all of the FlexRay channels of the cluster to which the ECU is connected.
AllChannelsAwake	Boolean	Determine the WakeupRxStatus by calling FrIf_GetWakeupRxStatus for each of the FlexRay controllers of the FlexRay cluster and return TRUE if the wakeup status is 1 for that FlexRay channel which has not been woken up by this ECU; otherwise return FALSE.
t1_IsActive	Boolean	Evaluates to true if t1 has been started and has not expired yet, otherwise to false
t3_IsNotActive	Boolean	Evaluates to false if t3 is running and has

		not expired, otherwise to true.
wakeupFinished	Boolean	Evaluates to false if the wakeup pattern transmission as defined in section 7.3.8 is still in progress, otherwise to true.
lowNumberOfColdstarters	Boolean	= FrIf_GetNumOfStartupFrames() < FrSMMinNumberOfColdstarter

7.3.6 Timers

The state machine description uses the following timers for each FlexRay cluster:

Timer	Description
t1	The timer t1 models the delay of clearing the coldstart inhibit mode (i.e. calling FrIf_AllowColdstart). The duration of this timer can be statically configured with the configuration parameter FrSMDurationT1.
t2	The timer t2 models the time difference after which the FrSM will repeat the startup of the FlexRay cluster. The duration of this timer can be statically configured with the configuration parameter FrSMDurationT2.
t3	The timer t3 supervises the transition to FullCom . The duration of this timer can be statically configured with the configuration parameter FrSMDurationT3.

[FrSm142] [If the configuration parameter FrSMDurationT1 is set to 0, timer t1 shall not be started. Instead, the call of FrIf_AllowColdstart shall immediately follow the call of FrIf_StartCommunication.] ()

.

[FrSm143] [If the duration FrSMDurationT2 of timer [t2](#) is set to 0, the startup of the FlexRay cluster shall not be supervised.

Note, that no assumption is made whether any of the timers is implemented in software or hardware.] ()

7.3.7 Functional Elements

The functionality being performed in the transitions of the state machine is partitioned into the following functional elements. I.e. the following table contains abbreviations used as actions in the FrSM state machine description, which reference one or more function calls visible at the interfaces of the FrSM module.

Functional Element	Description
FE_WAKEUP	Call FrIf_SendWUP for each controller of the FlexRay cluster.
FE_SET_WU_CHANNEL_INITIAL	In case of a single channel node, do nothing. In case of a dual channel node, call

	FrIf_SetWakeupChannel for each controller of the FlexRay cluster in order to set the wakeup channel to the channel A.
FE_SET_WU_CHANNEL_FORWARD	In case of a single channel node, do nothing. In case of a dual channel node, call FrIf_SetWakeupChannel for each controller of the FlexRay cluster in order to set the wakeup channel to the channel on which no wakeup has been detected while evaluating WUReason .
FE_SET_WU_CHANNEL_ECHO	In case of a single channel node, do nothing. In case of a dual channel node, call FrIf_SetWakeupChannel for each controller of the FlexRay cluster in order to set the wakeup channel to the channel on which wakeup has been detected while evaluating WUReason .
FE_CONFIG	Call FrIf_ControllerInit for each controller of the FlexRay cluster.
FE_START	Call FrIf_StartCommunication for each controller of the FlexRay cluster.
FE_ALLOW_COLDSTART	Call FrIf_AllowColdstart for each controller of the FlexRay cluster if the configuration parameter FrSMIsColdstartEcu is true.
FE_HALT	Call FrIf_HaltCommunication for each controller of the FlexRay cluster.
FE_TRCV_STANDBY	Call FrIf_SetTransceiverMode with FrIf_TrcvMode as FRTRCV_TRCVMODE_STANDBY for each transceiver of the FlexRay cluster.
FE_TRCV_NORMAL	In case the FrSM state machine is in state FRSM_ECU_ACTIVE , call FrIf_SetTransceiverMode with FrIf_TrcvMode as FRTRCV_TRCVMODE_NORMAL and FrIf_ClearTransceiverWakeup for each transceiver of the FlexRay cluster. In case the FrSM state machine is in state FRSM_ECU_PASSIVE , call FrIf_SetTransceiverMode with FrIf_TrcvMode as FRTRCV_TRCVMODE_RECEIVEONLY and FrIf_ClearTransceiverWakeup for each transceiver of the FlexRay cluster.
FE_START_FRIF	Set the FrIf state to ONLINE by calling FrIf_SetState with FrIf_StateTransition as FRIF_GOTO_ONLINE for the cluster.
FE_STOP_FRIF	Set the FrIf state to OFFLINE by calling FrIf_SetState with FrIf_StateTransition as FRIF_GOTO_OFFLINE for the cluster.
FE_DEM_STATUS_FAILED	Report status of production/development error FRSM_E_CLUSTER_STARTUP as failed.
FE_DEM_STATUS_PASSED	Report status of production error FRSM_E_CLUSTER_STARTUP as passed if FRSM_E_CLUSTER_STARTUP is configured.
FE_DEM_SYNC_LOSS	Report the status of the production/development error FRSM_E_CLUSTER_SYNC_LOSS as failed. If the name of an indication function (see section 8.6.3) is configured, call the indication function with the

	parameter SyncLossErrorStatus = true.
FE_DEM_SYNC_LOSS_PASSED	If the name of an indication function (see section 8.6.3) is configured, call the indication function with the parameter SyncLossErrorStatus = false. If FRSM_E_CLUSTER_SYNC_LOSS is configured, report the status of the production error FRSM_E_CLUSTER_SYNC_LOSS as passed.
FE_FULL_COM_IND	Indicate to the ComM that FullCom has been reached by calling ComM_BusSM_ModelIndication (FullCom)
FE_NO_COM_IND	Indicate to the ComM that FullCom has been left by calling ComM_BusSM_ModelIndication (NoCom).
FE_STARTUP_ERROR_IND	Call FrNm_StartupError.

7.3.8 Wakeup Pattern Transmission

[FrSm183] [The FlexRay State Manager shall repeat the transmission of wakeup patterns according to the configuration parameter [FrSMNumWakeupPatterns](#). I.e. the FlexRay State Manager shall perform the following actions while being in state FRSM_WAKEUP:

- Set counter wakeupCounter to 1 when the state FRSM_WAKEUP is entered
- While wakeupCounter ≤ [FrSMNumWakeupPatterns](#) and [busTrafficDetected](#) = false:
 - Wait until the FlexRay controllers of the FlexRay cluster are in state FR_READY
 - When the FlexRay controllers are in state FR_READY, check vPOC!WakeupStatus of the FlexRay controllers and act as follows:

vPOC!WakeupStatus	Actions
FR_WAKEUP_RECEIVED_HEADER, FR_WAKEUP_RECEIVED_WUP	busTrafficDetected := true
FR_WAKEUP_TRANSMITTED	wakeupTransmitted := true
FR_WAKEUP_UNDEFINED FR_WAKEUP_COLLISION_HEADER FR_WAKEUP_COLLISION_WUP FR_WAKEUP_COLLISION_UNKNOWN	No action

- If [busTrafficDetected](#) = false and wakeupCounter < [FrSMNumWakeupPatterns](#), execute [FE_WAKEUP](#)
- Increment the wakeupCounter

] ()

7.3.9 Transitions

[FrSm093] [The following FrSM state machine diagram defines source state and the target state of the transitions, which are defined in detail in the table following this diagram.




Figure 2 FrSM state machine of the FlexRay State Manager

Note that the states are described in section 7.3.2.

The following table defines the events and conditions that trigger the transitions of FrSM state machine and the actions that are executed within the transitions. Each row of the table contains a requirement which should be interpreted as follows. If the FrSM module is in the source state of the transition in column “Transition” as defined in [FrSm093](#) and when the condition in column “Event [Condition]” holds and if the event in column “Event [Condition]” occurs, then the actions in column “Actions” shall be executed and afterwards the FrSM module shall change its state to the target state of the transition in column “Transition” as defined in [FrSm093](#).

In case different actions have to be performed in a transition T, there can be multiple rows in the table. The rows are denoted as T (a), T (b) etc. in this case. Note that the conditions ensure that only one of the possibilities matches.] ()

[FrSm145] [After every transition to a different state, the FrSM shall inform the BswM by calling BswM_FrSM_CurrentState.] ()

[FrSm105] [The FrSM shall execute the actions of the transition in the order that is defined in the following table.] ()

ID	Transition	Event [Condition]	Actions
[FrSm119]	T00	FrSM_Init()	FE_CONFIG
[FrSm072]	T01 (a)	[reqComMode = FullCom \wedge FrSMIsWakeupEcu \wedge WUReason = NO_WU_BY_BUS $\wedge \neg$ FrSMIsDualChannelNode]	FE_TRCV_NORMAL startupCounter := 1 wakeupType := SingleChannelWakeup wakeupTransmitted := false FE_WAKEUP start t1 start t3
[FrSm151]	T01 (b)	[reqComMode = FullCom \wedge FrSMIsWakeupEcu \wedge WUReason = NO_WU_BY_BUS \wedge FrSMIsDualChannelNode]	FE_TRCV_NORMAL startupCounter := 1 wakeupType := DualChannelWakeup FE_SET_WU_CHANNEL_INITIAL wakeupTransmitted := false FE_WAKEUP start t1 start t3
[FrSm152]	T01 (c)	[reqComMode = FullCom \wedge FrSMIsWakeupEcu \wedge WUReason = PARTIAL_WU_BY_BUS]	FE_TRCV_NORMAL startupCounter := 1 wakeupType := DualChannelEchoWakeup FE_SET_WU_CHANNEL_ECHO wakeupTransmitted := false FE_WAKEUP start t1 start t3
[FrSm073]	T02 (a)	[reqComMode = FullCom \wedge (\neg FrSMIsWakeupEcu \vee WUReason = ALL_WU_BY_BUS) $\wedge \neg$ FrSMDelayStartupWithoutWakeup]	FE_TRCV_NORMAL startupCounter := 1 wakeupType := NoWakeup FE_START FE_ALLOW_COLDSTART start t2 start t3
[FrSm184]	T02 (b)	[reqComMode = FullCom \wedge (\neg FrSMIsWakeupEcu \vee WUReason = ALL_WU_BY_BUS) \wedge FrSMDelayStartupWithoutWakeup]	FE_TRCV_NORMAL startupCounter := 1 wakeupType := NoWakeup FE_START start t1 start t2 start t3
[FrSm074]	T03 (a)	[wakeupFinished \wedge reqComMode = FullCom \wedge FrSMNumWakeupPatterns = 1 \wedge wakeupType = SingleChannelWakeup]	FE_START cancel t1 start t1 start t2
[FrSm183]	T03 (b)	[wakeupFinished \wedge reqComMode = FullCom \wedge FrSMNumWakeupPatterns > 1 \wedge wakeupTransmitted]	FE_START cancel t1 start t2 FE_ALLOW_COLDSTART

ID	Transition	Event [Condition]	Actions
		$\vee \neg t1_IsActive)$ $\wedge \text{wakeupType} = \text{SingleChannelWakeup}$]	
[FrSm184]	T03 (c)	[<u>wakeupFinished</u> $\wedge \text{reqComMode} = \text{FullCom}$ $\wedge \text{FrSMNumWakeupPatterns} > 1$ $\wedge \neg \text{wakeupTransmitted}$ $\wedge \text{wakeupType} = \text{SingleChannelWakeup}$]	<u>FE_START</u>
[FrSm153]	T03 (d)	[<u>wakeupFinished</u> $\wedge \text{reqComMode} = \text{FullCom}$ $\wedge \text{wakeupType} = \text{DualChannelWakeup}$]	<u>FE_START</u> start <u>t2</u>
[FrSm154]	T03 (e)	[<u>wakeupFinished</u> $\wedge \text{reqComMode} = \text{FullCom}$ $\wedge \text{wakeupType} = \text{DualChannelWakeup-Forward}$]	<u>FE_START</u> <u>FE_ALLOW_COLDSTART</u> start <u>t2</u>
[FrSm150]	T103	[<u>vPOC!State</u> = Ready $\wedge \neg \text{vPOC!Freeze}$ $\wedge \text{reqComMode} = \text{FullCom}$ $\wedge \text{wakeupType} = \text{DualChannelEchoWakeup}$]	<u>wakeupType</u> := <u>DualChannelWakeup-Forward</u> <u>FE_SET_WU_CHANNEL_FORWARD</u> <u>FE_WAKEUP</u>
[FrSm075]	T04 (a)	<u>t1</u> [<u>reqComMode</u> = FullCom $\wedge \text{wakeupType} = \text{SingleChannel-Wakeup}$ $\wedge \text{vPOC!State} \neq \text{Normal Active}$]	<u>FE_ALLOW_COLDSTART</u>
[FrSm155]	T04 (b)	[<u>reqComMode</u> = FullCom $\wedge \text{wakeupType} = \text{DualChannelWakeup}$ $\wedge \text{AllChannelsAwake}$ $\wedge \text{vPOC!State} \neq \text{Normal Active}$]	<u>FE_ALLOW_COLDSTART</u>
[FrSm076]	T05	<u>t2</u> [<u>startupCounter</u> $\leq \text{FrSMStartupRepetitionsWithWakeup}$ $\wedge \text{reqComMode} = \text{FullCom}$ $\wedge \text{wakeupType} \neq \text{NoWakeup}$ $\wedge \text{vPOC!State} \neq \text{Normal Active}$]	<u>FE_TRCV_NORMAL</u> <u>FE_CONFIG</u> <u>FE_WAKEUP</u> <u>startupCounter</u> := <u>startupCounter</u> + 1
[FrSm077]	T06	<u>t2</u> [(<u>FrSMStartupRepetitionsWithWakeup</u> < <u>startupCounter</u> $\vee \text{wakeupType} = \text{NoWakeup}$) $\wedge \text{startupCounter}$ $\leq \text{FrSMStartupRepetitions}$ $\wedge \text{reqComMode} = \text{FullCom}$ $\wedge \text{vPOC!State} \neq \text{Normal Active}$]	<u>FE_TRCV_NORMAL</u> <u>FE_CONFIG</u> <u>FE_START</u> <u>FE_ALLOW_COLDSTART</u> <u>startupCounter</u> := <u>startupCounter</u> + 1 start <u>t2</u>
[FrSm079]	T08	[<u>vPOC!State</u> = Normal Active $\wedge \neg \text{vPOC!Freeze}$ $\wedge \text{vPOC!SlotMode} = \text{AllSlots}$ $\wedge \text{reqComMode} = \text{FullCom}$]	cancel <u>t1</u> cancel <u>t2</u> <u>FE_START_FRIF</u> <u>FE_DEM_STATUS_PASSED</u> <u>FE_DEM_SYNC_LOSS_PASSED</u> <u>FE_FULL_COM_IND</u> cancel <u>t3</u>
[FrSm156] [] (BSW00339, BSW00386)	T108	[<u>vPOC!State</u> = Normal Active $\wedge \neg \text{vPOC!Freeze}$ $\wedge \text{vPOC!SlotMode} \neq \text{AllSlots}$ $\wedge \text{reqComMode} = \text{FullCom}$]	cancel <u>t1</u> cancel <u>t2</u> <u>FE_START_FRIF</u> <u>FE_DEM_STATUS_PASSED</u> <u>FE_DEM_SYNC_LOSS_PASSED</u> cancel <u>t3</u>
[FrSm080]	T09a T09b	<u>FrSM_RequestComMode()</u> [<u>reqComMode</u> = NoCom]	<u>FE_STOP_FRIF</u> <u>FE_HALT</u> <u>FE_NO_COM_IND</u>

ID	Transition	Event [Condition]	Actions
[FrSm081]	T10a T10b	[(<u>vPOC!State</u> = Halt \vee <u>vPOC!Freeze</u>) \wedge <u>reqComMode</u> = FullCom \wedge <u>FrSmCheckWakeupReason</u>]	<u>FE DEM SYNC LOSS</u> <u>FE STOP FRIF</u> <u>FE NO COM IND</u> <u>FE CONFIG</u> <u>FE START</u> <u>startupCounter</u> := 1 start <u>t2</u> start <u>t3</u>
[FrSm157]	T101	[<u>vPOC!State</u> = Normal Active \wedge \neg <u>vPOC!Freeze</u> \wedge <u>vPOC!SlotMode</u> = AllSlots]]	<u>FE FULL COM IND</u>
[FrSm083]	T11	[<u>vPOC!State</u> = Halt \vee <u>vPOC!Freeze</u>]	<u>FE TRCV STANDBY</u> <u>FE CONFIG</u>
[FrSm084]	T12	[<u>reqComMode</u> = NoCom]	cancel <u>t1</u> cancel <u>t2</u> cancel <u>t3</u> <u>FE DEM SYNC LOSS PASSED</u> <u>FE TRCV STANDBY</u> <u>FE CONFIG</u>
[FrSm085]	T13	[<u>reqComMode</u> = NoCom]	<u>FE DEM SYNC LOSS PASSED</u> <u>FE TRCV STANDBY</u> <u>FE CONFIG</u> cancel <u>t3</u>
[FrSm125]	T14	<u>FrSM_RequestComMode()</u> [<u>reqComMode</u> = NoCom]	<u>FE DEM SYNC LOSS PASSED</u> <u>FE HALT</u> cancel <u>t3</u>
[FrSm086]	T15	[<u>vPOC!State</u> = Normal Active \wedge \neg <u>vPOC!Freeze</u> \wedge <u>vPOC!SlotMode</u> = AllSlots]]	<u>FE DEM SYNC LOSS PASSED</u> <u>FE START FRIF</u> <u>FE FULL COM IND</u> cancel <u>t3</u>
[FrSm158]	T115	[<u>vPOC!State</u> = Normal Active \wedge \neg <u>vPOC!Freeze</u> \wedge <u>vPOC!SlotMode</u> \neq AllSlots]	<u>FE DEM SYNC LOSS PASSED</u> <u>FE START FRIF</u> cancel <u>t3</u>
[FrSm087]	T16a T16b	[<u>vPOC!State</u> = Normal Passive \wedge \neg <u>vPOC!Freeze</u>]	<u>FE DEM SYNC LOSS</u> <u>FE STOP FRIF</u> <u>FE NO COM IND</u> start <u>t3</u>
[FrSm117]	T17	[(<u>vPOC!State</u> = Halt \vee <u>vPOC!Freeze</u>) \wedge <u>reqComMode</u> = FullCom \wedge <u>FrSmCheckWakeupReason</u>]	<u>FE CONFIG</u> <u>wakeupType</u> := NoWakeup <u>FE START</u> <u>startupCounter</u> := 1 start <u>t2</u>
[FrSm0200]	T20a T20b	[(<u>vPOC!State</u> = Halt \vee <u>vPOC!Freeze</u>) \wedge <u>reqComMode</u> = FullCom \wedge \neg <u>FrSmCheckWakeupReason</u> \wedge <u>FrSMIsWakeupEcu</u>]	<u>wakeupType</u> := SingleChannelWakeup <u>FE DEM SYNC LOSSFE STOP FRIF</u> <u>FE NO COM IND</u> <u>FE CONFIG</u> <u>FE WAKEUP</u> <u>startupCounter</u> := 1 start <u>t1</u> start <u>t3</u>
[FrSm0201]	T20c	[(<u>vPOC!State</u> = Halt \vee <u>vPOC!Freeze</u>) \wedge <u>reqComMode</u> = FullCom \wedge \neg <u>FrSmCheckWakeupReason</u> \wedge <u>FrSMIsWakeupEcu</u>]	<u>wakeupType</u> := SingleChannelWakeup <u>FE CONFIG</u> <u>FE WAKEUP</u> <u>startupCounter</u> := 1 start <u>t1</u> start <u>t3</u>

ID	Transition	Event [Condition]	Actions
[FrSm159] [] (BSW00339, BSW00386)	T30	t3	FE_DEM_STATUS_FAILED FE_STARTUP_ERROR_IND
[FrSm160]	T31	[t3_IsNotActive]	FE_STARTUP_ERROR_IND
[FrSm161]	T32	[t3_IsNotActive]	FE_STARTUP_ERROR_IND
[FrSm173]	T33	[t3_IsNotActive]	FE_STARTUP_ERROR_IND
[FrSm187]	T40	[lowNumberOfColdstarters]	
[FrSm188]	T41	[¬ lowNumberOfColdstarters]	

Legend: \wedge AND start t: start timer t
 \vee OR cancel t: stop timer t
 \neg NOT [...] guard condition for transition
 $:=$ assignment t1 [...] t1 has expired

Note: If synchronization is lost after FullCom has been reached, the FrSM module will first try to bring the FlexRay CC to the startup state without allowing cold start.

Rationale: The loss of synchronization may be a local problem of the ECU. Thus the ECU should first try to re-integrate without disturbing the cluster.

Note: If resynchronization cannot be achieved before [t2](#) expires (see [FrSm076](#) and [FrSm077](#)), the same wakeup and startup procedure as for the initial synchronization will be used.

Note: If the startup of a FlexRay cluster is not successful (i.e. timer [t2](#) expires), the FrSM module will repeat the startup procedure depending on the value of the counter [startupCounter](#):

- If [startupCounter](#) does not exceed the threshold [FrSMStartupRepetitionsWithWakeup](#), the startup procedure will be repeated including the wakeup.
- If [startupCounter](#) exceeds the threshold [FrSMStartupRepetitionsWithWakeup](#) but does not exceed the threshold [FrSMStartupRepetitions](#), the startup procedure will be repeated without wakeup.

Note: When the timer [t3](#) expires, the FrSM will report the production error [FRSM_E_CLUSTER_STARTUP](#).

Note: After timer [t3](#) has expired, the FrSM will call FrNm_StartupError until either synchronisation has been achieved or [NoCom](#) is requested (see [FrSm160](#) and [FrSm161](#)).

Note: When the counter [startupCounter](#) exceeds the threshold [FrSMStartupRepetitions](#), an ECU that has been configured as a coldstart node will stop performing coldstart attempts. However, if another ECU performs a coldstart, the ECU will join the coldstart.

Note: If no threshold [FrSMStartupRepetitions](#) has been configured, an ECU that has been configured as a coldstart node will not stop performing coldstart attempts until either synchronisation has been achieved or [NoCom](#) is requested.

Rationale: If the RX path of a FlexRay CC is faulty, an ECU performing a wakeup or coldstart could disturb the FlexRay communication as it will not be able to detect any collision. Thus, an unlimited number of coldstart attempts could lead to a continuous disturbance of the FlexRay communication.

[FrSm149] [When a call of a function of the FlexRay Interface API returns a failure (e.g. E_NOT_OK), the FrSM shall ignore this return value and continue with the transition.] ()

Rationale: When the FlexRay Interface returns E_NOT_OK in a production environment, a production error has been reported to DEM. This will usually trigger the reinitialization of the FlexRay stack.

7.4 Configuration description

The FlexRay State Manager configuration tool reads the ECU configuration description of the FlexRay Interface as the mapping of controllers to clusters is contained in the FlexRay Interface configuration description.

7.5 Error classification

Values for production code Event Ids are assigned in the configuration, see section 10.2.6.

[FrSm042] [Development error values are of type uint8.] (BSW00337, BSW00409, BSW00385, BSW00327)

Type of error	Relevance	Related error code	Value [hex]
Invalid pointer in parameter list. In case of this error, the API service shall return immediately without any further action, beside reporting this development error.	Development	FRSM_E_NULL_PTR	0x01
Invalid network handle parameter	Development	FRSM_E_INV_HANDLE	0x02
FrSM module was not initialized	Development	FRSM_E_UNINIT	0x03
Invalid communication	Development	FRSM_E_INV_MODE	0x04

mode requested			
FlexRay startup could not reach the state <i>normal</i> / <i>active</i> within the configured time.	Production / Development	FRSM_E_CLUSTER_STARTUP	Assigned by DEM
The FlexRay cluster has lost its synchronization.	Production / Development	FRSM_E_CLUSTER_SYNC_LOSS	Assigned by DEM

()

7.6 Error detection

[FrSm043] [The detection of development errors shall be configurable (*ON* / *OFF*) at pre-compile time. The switch *FrSMDevErrorDetect* (see chapter 10) shall activate or deactivate the detection of all development errors.] (BSW00338)

[FrSm044] [If the *FrSMDevErrorDetect* switch is enabled API parameter checking is enabled. The detailed description of the detected errors can be found in chapter 7.5 and chapter 8.] ()

The detection of production code errors cannot be switched off.

7.7 Error notification

[FrSm045] [Detected development errors shall be reported to the *Det_ReportError* service of the Development Error Tracer (DET) if the pre-processor switch *FrSMDevErrorDetect* is set (see chapter 10).] ()

[FrSm046] [Production errors shall be reported to Diagnostic Event Manager.] ()

7.8 Debugging

[FrSm133] [All type definitions of variables which shall be debugged, shall be accessible by the header file *FrSM.h*] (BSW00442)

[FrSm134] [Each variable that shall be accessible by AUTOSAR Debugging, shall be defined as global variable.] (BSW00442)

[FrSm135] [The declaration of variables in the header file shall be such, that it is possible to calculate the size of the variables by C-"*sizeof*".] (BSW00442)

[FrSm136] [Variables available for debugging shall be described in the respective

Basic Software Module Description.] (BSW00442)

[FrSm137] [The states of FrSM state machine shall be available for debugging.]

(BSW00442)

8 API specification

8.1 Imported types

In this chapter all types included from the following files are listed:

[FrSm095] [

Module	Imported Type
ComM	ComM_ModeType
ComStack_Types	NetworkHandleType
Dem	Dem_EventIdType
	Dem_EventStatusType
Fr	Fr_ChannelType
	Fr_POCTestStatusType
FrIf	FrIf_StateTransitionType
FrTrcv	FrTrcv_TrvcModeType
	FrTrcv_TrvcWUReasonType
Std_Types	Std_ReturnType
	Std_VersionInfoType

] ()

8.2 Type definitions

8.2.1 FrSM_ConfigType

Name:	FrSM_ConfigType
Type:	Structure
Range:	Implementation specific.
Description:	This type contains the implementation-specific post build time configuration structure that is for FrSM_Init.

8.2.2 FrSM_BswM_StateType

Name:	FrSM_BswM_StateType																				
Type:	Enumeration																				
Range:	<table> <tr> <td>FRSM_BSWM_READY</td><td>0</td></tr> <tr> <td>FRSM_BSWM_READY_ECU_PASSIVE</td><td>1</td></tr> <tr> <td>FRSM_BSWM_STARTUP</td><td>2</td></tr> <tr> <td>FRSM_BSWM_STARTUP_ECU_PASSIVE</td><td>3</td></tr> <tr> <td>FRSM_BSWM_WAKEUP</td><td>4</td></tr> <tr> <td>FRSM_BSWM_WAKEUP_ECU_PASSIVE</td><td>5</td></tr> <tr> <td>FRSM_BSWM_HALT_REQ</td><td>6</td></tr> <tr> <td>FRSM_BSWM_HALT_REQ_ECU_PASSIVE</td><td>7</td></tr> <tr> <td>FRSM_BSWM_KEYSLLOT_ONLY</td><td>8</td></tr> <tr> <td>FRSM_BSWM_KEYSLLOT_ONLY_ECU_PASSIVE</td><td>9</td></tr> </table>	FRSM_BSWM_READY	0	FRSM_BSWM_READY_ECU_PASSIVE	1	FRSM_BSWM_STARTUP	2	FRSM_BSWM_STARTUP_ECU_PASSIVE	3	FRSM_BSWM_WAKEUP	4	FRSM_BSWM_WAKEUP_ECU_PASSIVE	5	FRSM_BSWM_HALT_REQ	6	FRSM_BSWM_HALT_REQ_ECU_PASSIVE	7	FRSM_BSWM_KEYSLLOT_ONLY	8	FRSM_BSWM_KEYSLLOT_ONLY_ECU_PASSIVE	9
FRSM_BSWM_READY	0																				
FRSM_BSWM_READY_ECU_PASSIVE	1																				
FRSM_BSWM_STARTUP	2																				
FRSM_BSWM_STARTUP_ECU_PASSIVE	3																				
FRSM_BSWM_WAKEUP	4																				
FRSM_BSWM_WAKEUP_ECU_PASSIVE	5																				
FRSM_BSWM_HALT_REQ	6																				
FRSM_BSWM_HALT_REQ_ECU_PASSIVE	7																				
FRSM_BSWM_KEYSLLOT_ONLY	8																				
FRSM_BSWM_KEYSLLOT_ONLY_ECU_PASSIVE	9																				

	FRSM_BSWM_ONLINE	10
	FRSM_BSWM_ONLINE_ECU_PASSIVE	11
	FRSM_BSWM_ONLINE_PASSIVE	12
	FRSM_BSWM_ONLINE_PASSIVE_ECU_PASSIVE	13
	FRSM_LOW_NUMBER_OF_COLDSTARTERS	14
	FRSM_LOW_NUMBER_OF_COLDSTARTERS_ECU_PASSIVE	15
Description:	This type defines the states that are reported to the BswM using BswM_FrSM_CurrentState.	

8.3 Function definitions

This is a list of functions provided for upper layer modules.

8.3.1 FrSM_Init

[FrSm013] [

Service name:	FrSM_Init	
Syntax:	<pre>void FrSM_Init(const FrSM_ConfigType* FrSM_ConfigPtr)</pre>	
Service ID[hex]:	0x01	
Sync/Async:	Synchronous	
Reentrancy:	Non Reentrant	
Parameters (in):	FrSM_ConfigPtr	Pointer to a selected configuration structure
Parameters (inout):	None	
Parameters (out):	None	
Return value:	None	
Description:	Initializes the FlexRay State Manager.	

] (BSW00405, BSW00381, BSW00438)

[FrSm126] [The [FrSM_Init](#) function shall initialize the state machines for all FlexRay clusters and set them into the state [FRSM_READY](#), i.e. perform transition [T00](#).]

(BSW00438, BSW101)

[FrSm127] [The [FrSM_Init](#) function shall internally store the configuration data address to enable subsequent API calls to access the configuration data.]

(BSW00438)

[FrSm128] [If development error detection is enabled (`FrSMDevErrorDetect` is ON), the [FrSM_Init](#) function shall remember internally the successful initialization for other API functions to check for proper module initialization.] (BSW00438)

[FrSm015] [If development error detection is enabled (`FrSMDevErrorDetect` is ON) and `FrSM_ConfigPtr` equals `NULL_PTR`, the [FrSM_Init](#) function shall report the error [FRSM_E_NULL_PTR](#) to the DET and shall not perform the initialization.

However, a value of NULL_PTR for FrSM_ConfigPtr shall not be treated as an error, if a configuration variant (see section 10.1.2) without post-build data is used.] ()

8.3.2 FrSM_RequestComMode

[FrSm020] [

Service name:	FrSM_RequestComMode	
Syntax:	Std_ReturnType FrSM_RequestComMode(NetworkHandleType NetworkHandle, ComM_ModeType ComM_Mode)	
Service ID[hex]:	0x03	
Sync/Async:	Asynchronous	
Reentrancy:	Reentrant for different FlexRay clusters	
Parameters (in):	NetworkHandle	This parameter identifies the FlexRay cluster for which a communication mode is requested.
	ComM_Mode	This parameter holds the requested communication mode.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: Request accepted E_NOT_OK: Request not accepted
Description:	This API function is used by the ComM to startup or shutdown the communication on a FlexRay cluster.	

] (BSW09081)

[FrSm021] [The [FrSM_RequestComMode](#) function shall store the requested communication mode.

The next activation of the [FrSM_MainFunction](#) will then process this request when processing the state machine of the corresponding cluster.

Note, that the state machine definition in section 7.2 refers to this stored request as [reqComMode](#).] ()

[FrSm022] [If [NoCom](#) is requested after [FullCom](#) has been reached (i.e. when the FrSM state machine of the corresponding cluster is in state [FRSM ONLINE](#)), the [FrSM_RequestComMode](#) function shall immediately process the corresponding transition of the state machine (see section 7.2).] ()

Rationale of FrSm022: This shall ensure that the [NoCom](#) request will stop the participation of the ECU in the FlexRay communication at the end of the current FlexRay cycle.

[FrSm141] [If ComM_Mode has the value COMM_SILENT_COMMUNICATION, the FrSM shall not store the requested communication mode and return E_NOT_OK. In

case development error detection is enabled, the FrSM shall additionally raise the development error code [FRSM_E_INV_MODE](#).] ()

[FrSm018] [If development error detection is enabled and the parameter NetworkHandle has an invalid value, the [FrSM_RequestComMode](#) function shall raise the development error code [FRSM_E_INV_HANDLE](#) and the [FrSM_RequestComMode](#) function shall return E_NOT_OK.] (BSW00369, BSW00323)

[FrSm019] [If development error detection is enabled and the parameter ComM_Mode has an invalid value, the [FrSM_RequestComMode](#) function shall raise the development error code [FRSM_E_INV_MODE](#) and the [FrSM_RequestComMode](#) function shall return E_NOT_OK.] ()

[FrSm061] [If development error detection is enabled and the FrSM module has not been initialized using [FrSM_Init](#), the [FrSM_RequestComMode](#) function shall raise the development error code [FRSM_E_UNINIT](#) and the function [FrSM_RequestComMode](#) shall return E_NOT_OK.] (BSW00406)

8.3.3 FrSM_GetCurrentComMode

[FrSm024] [

Service name:	FrSM_GetCurrentComMode	
Syntax:	<pre>Std_ReturnType FrSM_GetCurrentComMode(NetworkHandleType NetworkHandle, ComM_ModeType* ComM_ModePtr)</pre>	
Service ID[hex]:	0x03	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant for different FlexRay clusters	
Parameters (in):	NetworkHandle	Handle of communication network
Parameters (inout):	None	
Parameters (out):	ComM_ModePtr	Pointer to the memory location where the current communication mode shall be stored
Return value:	Std_ReturnType	E_OK: Request accepted E_NOT_OK: Request was not accepted as the FrSM has not been initialized using FrSM_Init .
Description:	This API function can be used to determine the current communication mode of a FlexRay cluster.	

] (BSW09084)

[FrSm025] [The [FrSM_GetCurrentComMode](#) function shall write the current communication mode of the corresponding FlexRay cluster into the given memory location.] ()

[FrSm026] [The [FrSM_GetCurrentComMode](#) function shall determine the communication mode as follows:

- If the FrSM state machine for the FlexRay cluster determined by NetworkHandle is in state [FRSM_ONLINE](#) or [FRSM_LOW_NUMBER_OF_COLDSTARTERS](#), the communication mode is COMM_FULL_COMMUNICATION.
- In any other case, the communication mode is COMM_NO_COMMUNICATION.

] ()

[FrSm027] [If development error detection is enabled and the parameter NetworkHandle has an invalid value, the [FrSM_GetCurrentComMode](#) function shall raise the development error code [FRSM_E_INV_HANDLE](#) and the [FrSM_GetCurrentComMode](#) function shall return E_NOT_OK.] ()

[FrSm028] [If development error detection is enabled and the parameter ComM_ModePtr equals NULL_PTR, the [FrSM_GetCurrentComMode](#) function shall raise the development error code [FRSM_E_NULL_PTR](#) and the [FrSM_GetCurrentComMode](#) function shall return E_NOT_OK.] (BSW00369, BSW00323)

[FrSm060] [If development error detection is enabled and the FrSM module has not been initialized using [FrSM_Init](#), the [FrSM_GetCurrentComMode](#) function shall raise the development error code [FRSM_E_UNINIT](#) and the [FrSM_GetCurrentComMode](#) function shall return E_NOT_OK.] (BSW00406)

8.3.4 FrSM_GetVersionInfo

[FrSm029] [

Service name:	FrSM_GetVersionInfo	
Syntax:	<pre>void FrSM_GetVersionInfo(Std_VersionInfoType* versioninfo)</pre>	
Service ID[hex]:	0x04	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	None	
Parameters (inout):	None	
Parameters (out):	versioninfo	Pointer to where to store the version information of this module.
Return value:	None	
Description:	<p>This service returns the version information of this module. The version information includes:</p> <ul style="list-style-type: none"> - Module Id - Vendor Id - Vendor specific version numbers (BSW00407). <p>This function shall be pre compile time configurable On/Off by the configuration parameter: FRSM_VERSION_INFO_API</p> <p>Hint:</p> <p>If source code for caller and callee of this function is available this function should</p>	

	be realized as a macro. The macro should be defined in the modules header file.
--	---

] (BSW00407)

[FrSm129] [The FrSM_GetVersionInfo function shall return the version info of this module. The version information includes:

- Module Id
- Vendor Id
- Vendor specific version numbers (BSW00407).

] ()

Hint: If source code for caller and callee of this function is available this function should be realized as a macro. The macro should be defined in the modules header file.

[FrSm130] [Configuration of FrSM_GetVersionInfo: This function shall be pre compile time configurable On/Off by the configuration parameter:

FrSMVersionInfoApi] ()

8.3.5 FrSM_AllSlots

[FrSm172] [

Service name:	FrSM_AllSlots	
Syntax:	Std_ReturnType FrSM_AllSlots(NetworkHandleType NetworkHandle)	
Service ID[hex]:	0x05	
Sync/Async:	Asynchronous	
Reentrancy:	Reentrant for different FlexRay clusters	
Parameters (in):	NetworkHandle	This parameter identifies the FlexRay cluster for which a communication mode is requested.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: Request accepted E_NOT_OK: Request not accepted
Description:	This API function can be used to leave the KeySlotOnlyMode.	

] ()

[FrSm171] [The [FrSM_AllSlots](#) function shall call FrIf_AllSlots for each controller of the FlexRay cluster. It shall return E_OK if each of these calls returned E_OK, otherwise [FrSM_AllSlots](#) shall return E_NOT_OK.] ()

[FrSm168] [If development error detection is enabled and the parameter NetworkHandle has an invalid value, the [FrSM_AllSlots](#) function shall raise the development error code FRSM_E_INV_HANDLE and the [FrSM_AllSlots](#) function shall return E_NOT_OK.] (BSW00369, BSW00323)

[FrSm169] [If development error detection is enabled and the FrSM module has not been initialized using FrSM_Init, the [FrSM_AllSlots](#) function shall raise the

development error code FRSM_E_UNINIT and the [FrSM_AllSlots](#) function shall return E_NOT_OK.] (BSW00406)

8.3.6 FrSM_SetEcuPassive

[FrSm174] [

Service name:	FrSM_SetEcuPassive	
Syntax:	Std_ReturnType FrSM_SetEcuPassive(boolean FrSM_Passive)	
Service ID[hex]:	0x06	
Sync/Async:	Synchronous	
Reentrancy:	Non Reentrant	
Parameters (in):	FrSM_Passive	This parameter determines whether all FlexRay clusters are set to passive, i.e. receive only.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: Request accepted E_NOT_OK: Request not accepted
Description:	This API function can be used to set all FlexRay clusters of the ECU to a receive only mode.	

] ()

[FrSm177] [The [FrSM_SetEcuPassive](#) function shall set the state of all FrSM state machines to [FRSM_ECU_PASSIVE](#) if the parameter FrSM_Passive evaluates to true, otherwise it shall set the state of all FrSM state machines to [FRSM_ECU_ACTIVE](#).] ()

[FrSm178] [If the state machine of a FlexRay cluster is not in state [FRSM_READY](#) (i.e. the transceivers of the FlexRay cluster are not in standby mode), the function shall execute [FE_TRCV_NORMAL](#) for this cluster.] ()

[FrSm179] [If development error detection is enabled and the FrSM module has not been initialized using FrSM_Init, the [FrSM_SetEcuPassive](#) function shall raise the development error code FRSM_E_UNINIT and the [FrSM_SetEcuPassive](#) function shall return E_NOT_OK.] (BSW00406)

8.4 Call-back notifications

The FlexRay State Manager does not provide any call-back API services to other BSW modules. Therefore, the header file FrSM_Cbk.h is not needed.

8.5 Scheduled functions

These functions are directly called by Basic Software Scheduler. The following functions shall have no return value and no parameter. All functions shall be non reentrant.

8.5.1 FrSM_MainFunction_<Cluster Id>

[FrSm118] [

Service name:	FrSM_MainFunction_<Cluster Id>
Syntax:	void FrSM_MainFunction_<Cluster Id>(void)
Service ID[hex]:	0x80
Timing:	FIXED_CYCLIC
Description:	--

] (BSW00373)

[FrSm047] [The [FrSM_MainFunction](#) shall determine the [POC](#) status of all FlexRay [CC](#) that are connected to the corresponding FlexRay cluster.

This document is based on the assumption that there is always a unique [POC](#) state for every FlexRay cluster (see Limitations in section 4.1).] ()

[FrSm192] [If the optional configuration parameter FrSMMinNumberOfColdstarter is configured, the [FrSM_MainFunction](#) shall determine the number startup frames by calling FrIf_GetNumOfStartupFrames.] ()

[FrSm048] [After determining the [POC](#) status and optionally the number of startup frames, the [FrSM_MainFunction](#) shall process the state machine of the corresponding cluster.] ()

Note: The [FrSM_MainFunction](#) shall be called cyclically with a cycle time that is shorter than or equal to the FlexRay cycle duration.

Rationale: The [FrSM_MainFunction](#) should be called at least once per FlexRay cycle. As the [POC](#) status only changes once per cycle, multiple invocations per FlexRay cycle have no benefit.

Note: After [FullCom](#) has been reached, the invocation of the [FrSM_MainFunction](#) can optionally be synchronized to the FlexRay global time to ensure that the [FrSM_MainFunction](#) is activated once per FlexRay cycle. However, this is outside of the scope of this specification.

Note: In case of very short FlexRay cycle times the [FrSM_MainFunction](#) can optionally be called with a cycle time that is larger than the FlexRay cycle time. However, this is outside of the scope of this specification as it can lead to increased startup time and to undetected [POC](#) status changes.

[FrSm181] [If the FrSM module has not been initialized using [FrSM_Init](#), the [FrSM_MainFunction](#) function shall return immediately without performing any functionality and without raising any errors.] (BSW00450)

8.6 Expected Interfaces

In this chapter all interfaces required from other modules are listed.

8.6.1 Mandatory Interfaces

This chapter defines all interfaces which are required to fulfill the core functionality of the module.

[FrSm096] [

API function	Description
BswM_FrSM_CurrentState	Function called by FrSM to indicate its current state.
Dem_ReportErrorStatus	Queues the reported events from the BSW modules (API is only used by BSW modules). The interface has an asynchronous behavior, because the processing of the event is done within the Dem main function.
FrIf_AllowColdstart	Wraps the FlexRay Driver API function Fr_AllowColdstart().
FrIf_ClearTransceiverWakeup	Wraps the FlexRay Transceiver Driver API function FrTrcv_ClearTransceiverWakeup(). The enum value "FR_CHANNEL_AB" shall not be used.
FrIf_ControllerInit	Initialized a FlexRay CC.
FrIf_GetPOCStatus	Wraps the FlexRay Driver API function Fr_GetPOCStatus().
FrIf_GetTransceiverWUReason	Wraps the FlexRay Transceiver Driver API function FrTrcv_GetTransceiverWUReason(). The enum value "FR_CHANNEL_AB" shall not be used.
FrIf_GetWakeupRxStatus	Wraps the FlexRay Driver API function Fr_GetWakeupRxStatus and gets the wakeup received information from the FlexRay controller.
FrIf_HaltCommunication	Wraps the FlexRay Driver API function Fr_HaltCommunication().
FrIf_SendWUP	Wraps the FlexRay Driver API function Fr_SendWUP().
FrIf_SetState	Requests FrIf state machine transition.
FrIf_SetTransceiverMode	Wraps the FlexRay Transceiver Driver API function FrTrcv_SetTransceiverMode(). The enum value "FR_CHANNEL_AB" shall not be used.
FrIf_StartCommunication	Wraps the FlexRay Driver API function Fr_StartCommunication().
FrNm_StartupError	This function is called by the FrSM when synchronization of the FlexRay cluster could not be achieved.

] ()

8.6.2 Optional Interfaces

This chapter defines all interfaces, which are required to fulfill an optional functionality of the module.

[FrSm097] [

API function	Description
Det_ReportError	Service to report development errors.
FrIf_GetNumOfStartupFrames	Wraps the FlexRay Driver API function Fr_GetNumOfStartupFrames and gets a list of the the current number of startup frames seen on the cluster. See variable vStartupPairs of [12] for details.

] ()

8.6.3 Configurable Interfaces

8.6.3.1 <Cdd>_SyncLossErrorIndication

[FrSm190] [


Service name:	<Cdd>_SyncLossErrorIndication	
Syntax:	<pre>void <Cdd>_SyncLossErrorIndication(NetworkHandleType NetworkHandle, boolean SyncLossErrorStatus)</pre>	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant for different FlexRay clusters	
Parameters (in):	NetworkHandle	Handle of FlexRay cluster
	SyncLossErrorStatus	true: ECU lost synchronization to the FlexRay cluster. false: ECU can synchronize to the FlexRay cluster or request for full communication has been released after the ECU lost its synchronization to the FlexRay cluster.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	None	
Description:	This function is called with parameter SyncLossErrorStatus = true when the ECU loses its synchronization to the FlexRay cluster. The function is called with parameter SyncLossErrorStatus = false either when the ECU can synchronize to the FlexRay cluster or when the request for full communication has been released after the ECU lost its synchronization to the FlexRay cluster.	

The name of this function can be configured using the configuration parameter FrMmSyncLossErrorIndicationName (see chapter 10). The FlexRay State Manager will call this function when the ECU loses its synchronization to the FlexRay cluster, after it could synchronize to the FlexRay cluster or when the FullCom request is released after the ECU lost its synchronization to the FlexRay cluster.


] ()

9 Sequence diagrams

9.1 Initialization



9.2 Single Channel Wakeup



(continued on next page)

(continued)





Figure 3 Transition from no communication to full communication for the case of an ECU that has a local wakeup reason.

9.3 Single Channel Passive Startup



continued on next page

(continued)





Figure 4 Transition from no communication to full communication for the case of an ECU that has been woken up by bus.

9.4 Dual Channel Wakeup



(continued)





Figure 5 Transition from no communication to full communication for the case of a dual channel ECU with a local wakeup reason.

9.5 Dual Channel Wakeup Forward



(continued)






Figure 6 Transition from no communication to full communication for the case of a dual channel that has been woken up by bus.

9.6 Key Slot Only Mode



9.7 Transition from full communication to no communication



10 Configuration specification

In general, this chapter defines configuration parameters and their clustering into containers. In order to support the specification Chapter 10.1 describes fundamentals.

Chapter 10.2 specifies the structure (containers) and the parameters of the module FlexRay State Manager.

Chapter 10.3 specifies published information of the module FlexRay State Manager.

10.1 How to read this chapter

In addition to this section, it is highly recommended to read the documents:

- AUTOSAR Layered Software Architecture [2]
- AUTOSAR ECU Configuration Specification [4]
This document describes the AUTOSAR configuration methodology and the AUTOSAR configuration metamodel in detail.

The following is only a short survey of the topic and it will not replace the ECU Configuration Specification document.

10.1.1 Configuration and configuration parameters

Configuration parameters define the variability of the generic part(s) of an implementation of a module. This means that only generic or configurable module implementation can be adapted to the environment (software/hardware) in use during system and/or ECU configuration.

The configuration of parameters can be achieved at different times during the software process: before compile time, before link time or after build time. In the following, the term “configuration class” (of a parameter) shall be used in order to refer to a specific configuration point in time.

10.1.2 Variants

Variants describe sets of configuration parameters. E.g., variant 1: only pre-compile time configuration parameters; variant 2: mix of pre-compile- and post build time-configuration parameters. In one variant a parameter can only be of one configuration class.

10.1.3 Containers

Containers structure the set of configuration parameters. This means:

- *all* configuration parameters are kept in containers.

- (sub-) containers can reference (sub-) containers. It is possible to assign a multiplicity to these references. The multiplicity then defines the possible number of instances of the contained parameters.

10.1.4 Specification template for configuration parameters

The following tables consist of three sections:

- the general section
- the configuration parameter section
- the section of included/referenced containers

Pre-compile time - specifies whether the configuration parameter shall be of configuration class *Pre-compile time* or not

Label	Description
X	The configuration parameter shall be of configuration class <i>Pre-compile time</i> .
--	The configuration parameter shall never be of configuration class <i>Pre-compile time</i> .

Link time - specifies whether the configuration parameter shall be of configuration class *Link time* or not

Label	Description
X	The configuration parameter shall be of configuration class <i>Link time</i> .
--	The configuration parameter shall never be of configuration class <i>Link time</i> .

Post Build - specifies whether the configuration parameter shall be of configuration class *Post Build* or not

Label	Description
X	The configuration parameter shall be of configuration class <i>Post Build</i> and no specific implementation is required.
L	<i>Loadable</i> - the configuration parameter shall be of configuration class <i>Post Build</i> and only one configuration parameter set resides in the ECU.
M	<i>Multiple</i> - the configuration parameter shall be of configuration class <i>Post Build</i> and is selected out of a set of multiple parameters by passing a dedicated pointer to the init function of the module.
--	The configuration parameter shall never be of configuration class <i>Post Build</i> .

10.2 Containers and configuration parameters

The following chapters summarize all configuration parameters. The detailed meanings of the parameters are described Chapters 7 and Chapter 8.

[FrSm064] [The [FrSM](#) module shall support tool based configuration.] (BSW159)

[FrSm065] [The configuration tool shall check the consistency of the configuration parameters at system configuration time.] (BSW167)

10.2.1 Variants

10.2.1.1 VARIANT-PRE-COMPILE (Pre-compile Configuration)

[FrSm098] [In the variant VARIANT-PRE-COMPILE all parameters below that are marked as pre-compile configurable with “VARIANT-PRE-COMPILE” shall be configurable in a pre-compile manner, for example as #defines.

The module is most likely delivered as source code.] ()

10.2.1.2 VARIANT-LINK-TIME (Link-time Configuration)

[FrSm099] [The variant VARIANT-LINK-TIME shall include all configuration options of the variant VARIANT-PRE-COMPILE. Additionally all parameters that are marked as link-time configurable with “VARIANT-LINK-TIME” shall be configurable at link time for example by linking a special configured parameter object file.

The module is most likely delivered as object code.] (BSW00342)

10.2.1.3 VARIANT-POST-BUILD (Post-build Configuration)

[FrSm100] [The variant VARIANT-POST-BUILD shall include all configuration options of the variant VARIANT-LINK-TIME. Additionally all parameters that are marked as post-build configurable with “VARIANT-POST-BUILD” shall be configurable post build for example by flashing configuration data.

The module is most likely delivered as object code.] (BSW00342)

10.2.2 FrSM

Module Name	FrSM
Module Description	Configuration of the FlexRay State Manager

Included Containers		
Container Name	Multiplicity	Scope / Dependency
FrSMConfig	1	This container comprises the cluster specific configuration of the FlexRay State Manager.
FrSMGeneral	1	This container contains the general configuration parameters of the FlexRay State Manager.




Figure 7 FlexRay State Manager Configuration

10.2.3 FrSMConfig

SWS Item	FrSm146_Conf :
Container Name	FrSMConfig{FRSM_CONFIG} [Multi Config Container]
Description	This container comprises the cluster specific configuration of the FlexRay State Manager.
Configuration Parameters	

Included Containers		
Container Name	Multiplicity	Scope / Dependency
FrSMCluster	1..*	This container specifies a FlexRay cluster and all related data. A FlexRay cluster may consist of more than one controller per ECU.

10.2.4 FrSMGeneral

SWS Item	FrSm107_Conf :
Container Name	FrSMGeneral{FRSM_GENERAL}
Description	This container contains the general configuration parameters of the FlexRay State Manager.
Configuration Parameters	

SWS Item	FrSm066_Conf :		
Name	FrSMDevErrorDetect {FRSM_DEV_ERROR_DETECT}		
Description	Enables and disables the development error detection and notification mechanism.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	false		
ConfigurationClass	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: Module		

SWS Item	FrSm167_Conf :		
Name	FrSMSyncLossErrorIndicationName {FRSM_SYNC_LOSS_ERROR_INDICATION_NAME}		
Description	Name of <Cdd>_SyncLossErrorIndication function that shall be called on loss of synchronization. If this parameter is omitted no indication shall take place.		
Multiplicity	0..1		
Type	EcucFunctionNameDef		
Default value	--		
maxLength	--		
minLength	--		
regularExpression	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	--	
Scope / Dependency	scope: Module		

SWS Item	FrSm108_Conf :		
Name	FrSMVersionInfoApi {FRSM_VERSION_INFO_API}		
Description	Enables and disables the version info API		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	false		
ConfigurationClass	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: Module		

No Included Containers




Figure 8 FrSMGeneral Container

10.2.5 FrSMCluster

SWS Item	FrSm067_Conf :
Container Name	FrSMCluster{FRSM_CLUSTER}
Description	This container specifies a FlexRay cluster and all related data. A FlexRay cluster may consist of more than one controller per ECU.
Configuration Parameters	

SWS Item	FrSm001_Conf :		
Name	FrSMCheckWakeupReason {FRSM_CHECK_WAKEUP_REASON}		
Description	If FrSMCheckWakeupReason is true, the FrSM will check the wakeup reason in order to skip the wakeup in case of wakeup by bus. If FrSMCheckWakeupReason is false, the FrSM will always try to perform a wakeup.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	FrSm166_Conf :		
Name	FrSMDelayStartupWithoutWakeup {FRSM_DELAY_STARTUP_WITHOUT_WAKEUP}		
Description	If true, timer t1 shall be started instead of immediately calling FrIf_AllowColdstart in case of a startup without wakeup.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	FrSm102_Conf :		
Name	FrSMDurationT1 {FRSM_DURATION_T1}		
Description	The duration of timer t1 in seconds. A value of 0 shall imply that the timer is not used.		
Multiplicity	1		
Type	EcucFloatParamDef		
Range	0 .. INF		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module dependency: FrSMMainFunctionCycleTime (As timers are checked during the call of FrSM_MainFunction, the effective timer duration will always be a multiple of FrSMMainFunctionCycleTime).		

SWS Item	FrSm89_Conf :		
Name	FrSMDurationT2 {FRSM_DURATION_T2}		

Description	The duration of timer t2 in seconds. A value of 0 shall imply that the timer is not used. The value of this parameter shall be larger than the value of FrSMDurationT1 parameter.		
Multiplicity	1		
Type	EcucFloatParamDef		
Range	0 .. INF		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module dependency: FrSMMainFunctionCycleTime (As timers are checked during the call of FrSM_MainFunction, the effective timer duration will always be a multiple of FrSMMainFunctionCycleTime).		

SWS Item	FrSm162_Conf :		
Name	FrSMDurationT3 {FRSM_DURATION_T3}		
Description	The duration of timer t3 in seconds. The value of this parameter shall be larger than the value of FrSMDurationT1 parameter. A value of 0 shall imply that the timer is not used. It shall only be possible to configure a value 0 if no FrNm is used.		
Multiplicity	1		
Type	EcucFloatParamDef		
Range	0 .. INF		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module dependency: FrSMMainFunctionCycleTime (As timers are checked during the call of FrSM_MainFunction, the effective timer duration will always be a multiple of FrSMMainFunctionCycleTime).		

SWS Item	FrSm068_Conf :		
Name	FrSMIsColdstartEcu {FRSM_IS_COLDSTART_ECU}		
Description	True: The ECU is a coldstart node for this FlexRay cluster. False: The ECU is no coldstart node for this FlexRay cluster.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	FrSm109_Conf :		
Name	FrSMIsWakeupEcu {FRSM_IS_WAKEUP_ECU}		
Description	True: FrSM shall perform a wakeup for this cluster. False: FrSM shall never perform a wakeup for this FlexRay cluster.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	FrSm115_Conf :		
Name	FrSMMainFunctionCycleTime {FRSM_MAIN_FUNCTION_CYCLE_TIME}		
Description	This parameter defines the cycle time in seconds of the periodic calling of FrSM main function.		
Multiplicity	1		
Type	EcucFloatParamDef		
Range	0 .. INF		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	--	
Scope / Dependency	scope: Module		

SWS Item	FrSm168_Conf :		
Name	FrSMMinNumberOfColdstarter {FRSM_MIN_NUMBER_OF_COLDSTARTER}		
Description	This parameter defines the number of coldstarter that should not be underrun. If this parameter is not configured the mainfunction shall not check the number of startup frames.		
Multiplicity	0..1		
Type	EcucIntegerParamDef		
Range	0 .. 255		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	FrSm165_Conf :		
Name	FrSMNumWakeupPatterns {FRSM_NUM_WAKEUP_PATTERNS}		
Description	Maximum number of Wakeup Patterns the node may send before going to FRSM_STARTUP.		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	0 .. 65535		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	FrSm069_Conf :		
Name	FrSMStartupRepetitions {FRSM_STARTUP_REPETITIONS}		
Description	The number of times an ECU may repeat the startup procedure for a FlexRay cluster.		
Multiplicity	0..1		
Type	EcucIntegerParamDef		
Range	0 .. 65535		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module dependency: This value must be greater or equal to FrSMStartupRepetitionsWithWakeup		

SWS Item	FrSm094_Conf :		
Name	FrSMStartupRepetitionsWithWakeup {FRSM_STARTUP_REPETITIONS_WITH_WAKEUP}		
Description	The number of times an ECU may repeat the startup procedure including a wakeup for a FlexRay cluster.		
Multiplicity	0..1		
Type	EcucIntegerParamDef		
Range	0 .. 65535		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	FrSm070_Conf :		
Name	FrSMComMNetworkHandleRef {FRSM_COMM_NETWORK_HANDLE_REF}		
Description	Reference to the unique handle to identify one certain FlexRay network correspond to one of the network handles of the ComM configuration.		
Multiplicity	1		
Type	Reference to [ComMChannel]		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	FrSm116_Conf :		
Name	FrSMFrIfClusterRef {FRSM_FRIF_CLUSTER_REF}		
Description	References the cluster configuration in the FlexRay Interface configuration. Note that the assigned controllers and transceivers are defined in the FrIf configuration and can be accessed via this reference.		
Multiplicity	1		
Type	Reference to [FrIfCluster]		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	--	
Scope / Dependency	scope: Module		

Included Containers		
Container Name	Multiplicity	Scope / Dependency
FrSMClusterDemEventParameterRefs	0..1	Container for the references to DemEventParameter elements which shall be invoked using the API Dem_ReportErrorStatus in case the corresponding error occurs. The EventId is taken from the referenced DemEventParameter's DemEventId value. The standardized errors are provided in this container and can be extended by vendor specific error references.




Figure 9

FrSMCluster Container

10.2.6 FrSMClusterDemEventParameterRefs

SWS Item	FrSm163_Conf :
Container Name	FrSMClusterDemEventParameterRefs
Description	Container for the references to DemEventParameter elements which shall be invoked using the API Dem_ReportErrorStatus in case the corresponding error occurs. The EventId is taken from the referenced DemEventParameter's DemEventId value. The standardized errors are provided in this container and can be extended by vendor specific error references.
Configuration Parameters	

SWS Item	FrSm164_Conf :		
Name	FRSM_E_CLUSTER_STARTUP		
Description	Reference to the DemEventParameter which shall be issued when the error "FRSM_E_CLUSTER_STARTUP" has occurred. If the reference is not configured the error shall be reported as DET error.		
Multiplicity	0..1		
Type	Reference to [DemEventParameter]		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	--	
Scope / Dependency			

SWS Item	FrSm169_Conf :		
Name	FRSM_E_CLUSTER_SYNC_LOSS		
Description	Reference to the DemEventParameter which shall be issued when the error "FRSM_E_CLUSTER_SYNC_LOSS" has occurred. If the reference is not configured the error shall be reported as DET error.		
Multiplicity	0..1		
Type	Reference to [DemEventParameter]		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	--	
Scope / Dependency			

No Included Containers

10.3 Published Information

[FrSm185] [The standardized common published parameters as required by BSW00402 in the General Requirements on Basic Software Modules [3] shall be published within the header file of this module and need to be provided in the BSW

Module Description. The according module abbreviation can be found in the List of Basic Software Modules [1].] ()

Additional module-specific published parameters are listed below if applicable.”

11 Changes during SWS Improvements by Technical Office for Set 2

11.1 Deleted SWS Items

<i>SWS Item</i>	<i>Rationale</i>
FrSm034	Redundant to requirements in chapter 10
FrSm037	Redundant to requirements in chapter 10
FrSm103	Redundant to requirements in chapter 10
FrSm104	Requirement ID removed from explanation

11.2 Replaced SWS Items

<i>SWS Item</i>	<i>Replaced by SWS Item</i>	<i>Rationale</i>
FrSm014	FrSm126 , FrSm127 , FrSm128	Made requirement atomic
FrSm038	FrSm123 , FrSm124	Made requirement atomic
FrSm052	FrSm120 , FrSm121	Made requirement atomic

11.3 Changed SWS Items

<i>SWS Item</i>	<i>Rationale</i>
FrSm012	Note separated from requirement
FrSm021	Explanation separated from requirement
FrSm047	Explanation separated from requirement

11.4 Added SWS Items

<i>SWS Item</i>	<i>Rationale</i>
FrSm122	Identified requirement
FrSm125	Identified requirement
FrSm130	Identified requirement for configuration

12 Changes to Release 3

12.1 Deleted SWS Items

SWS Item	Rationale
FrSm039	Requirement ID removed from explanation
FrSm040	Redundant
FrSm092	Redundant
FrSm114	Unique Service ID for FrSM_MainFunction
FrSm041	Requirement ID removed from explanation
FrSm1202	Requirement ID removed from explanation

12.2 Replaced SWS Items

SWS Item	Replaced by SWS Item	Rationale

12.3 Changed SWS Items

SWS Item	Rationale
All	Replaced FrSm with FrSM
FrSm032	Added description of states
FrSm042	Changed name of development errors
FrSm054	Added "shall"
FrSm055	Added "shall"
FrSm056	Added "shall"
FrSm057	Added "shall"
FrSm058	Added "shall"
FrSm071	Configurable Number of Wakeup Patterns
FrSm072	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm073	Dual-Channel support, supervision with timer T3, Single Slot Mode support Configurable Number of Wakeup Patterns
FrSm074	Dual-Channel support, supervision with timer T3, Single Slot Mode support Configurable Number of Wakeup Patterns
FrSm075	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm076	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm077	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm079	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm080	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm081	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm085	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm085	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm086	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm087	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm093	Improved description
FrSm119	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm125	Dual-Channel support, supervision with timer T3, Single Slot Mode support

12.4 Added SWS Items

SWS Item	Rationale
FrSm133	Debugging
FrSm134	Debugging
FrSm135	Debugging
FrSm136	Debugging
FrSm137	Debugging
FrSm139	Consistency check of version numbers
FrSm140	Consistency check of version numbers
FrSm142	Made requirement atomic
FrSm143	Made requirement atomic
FrSm145	BswM
FrSm149	Behavior in case of failures
FrSm150	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm151	Dual-Channel support, supervision with timer T3, Single Slot Mode support Configurable Number of Wakeup Patterns
FrSm152	Dual-Channel support, supervision with timer T3, Single Slot Mode support Configurable Number of Wakeup Patterns
FrSm153	Dual-Channel support, supervision with timer T3, Single Slot Mode support Configurable Number of Wakeup Patterns
FrSm154	Dual-Channel support, supervision with timer T3, Single Slot Mode support Configurable Number of Wakeup Patterns
FrSm155	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm156	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm157	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm158	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm159	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm160	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm161	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm168	Single Slot Mode
FrSm169	Single Slot Mode
FrSm171	Single Slot Mode
FrSm172	Single Slot Mode
FrSm173	Dual-Channel support, supervision with timer T3, Single Slot Mode support
FrSm174	Passive Mode
FrSm176	Passive mode
FrSm176	Passive Mode
FrSm178	Passive Mode
FrSm179	Passive Mode
FrSm180	Passive mode
FrSm183	Configurable Number of Wakeup Patterns
FrSm184	Configurable Number of Wakeup Patterns
FrSm185	Rework of Published Information

13 Not applicable requirements

[FrSm186] [These requirements are not applicable to this specification.] (BSW170, BSW00419, BSW00387, BSW00375, BSW00416, BSW00437, BSW168, BSW00423, BSW00425, BSW00427, BSW00428, BSW00429, BSW00432, BSW00336, BSW00422, BSW00417, BSW161, BSW162, BSW005, BSW00415, BSW164, BSW00325, BSW00326, BSW00413, BSW00347, BSW00314, BSW00370, BSW00439, BSW00449, BSW00377, BSW00359, BSW00360, BSW00440, BSW00443, BSW00444, BSW00446)