


<b>Document Title</b>	Requirements on Port Driver
<b>Document Owner</b>	AUTOSAR
Document Responsibility	AUTOSAR
<b>Document Identification No</b>	196

Document Status	Final
Part of AUTOSAR Standard	Classic Platform
Part of Standard Release	4.3.1

Document Change History			
Date	Release	Changed by	Change Description
2017-12-08	4.3.1	AUTOSAR Release Management	minor corrections / clarifications /     editorial changes; For details please     refer to the ChangeDocumentation
2016-11-30	4.3.0	AUTOSAR Release Management	Editorial changes
2014-10-31	4.2.1	AUTOSAR Release Management	Editorial changes
2013-03-15	4.1.1	AUTOSAR Administration	<ul><li>TPS_STDT_0078 formatting</li><li>Traceability of BSWAndRTE_Features</li></ul>
2010-09-30	3.1.5	AUTOSAR Administration	Legal disclaimer revised
2008-08-13	3.1.1	AUTOSAR Administration	Legal disclaimer revised
2007-12-21	3.0.1	AUTOSAR Administration	<ul><li>Document meta information extended</li><li>Small layout adaptations made</li></ul>
2007-01-24	2.1.15	AUTOSAR Administration	<ul><li> "Advice for users" revised</li><li> "Revision Information" added</li></ul>
2006-11-28	2.1	AUTOSAR Administration	Legal disclaimer revised
2006-05-16	2.0	AUTOSAR Administration	<ul> <li>Release as a separate document.         The SRS SPAL V1.0.0 has been split into 12 independent documents for Release 2.0     </li> <li>minor changes regarding formal issues</li> </ul>
2005-05-31	1.0	AUTOSAR Administration	Initial release as a part of the SRS SPAL V1.0.0







#### **Disclaimer**

This work (specification and/or software implementation) and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the work.

The material contained in this work is protected by copyright and other types of intellectual property rights. The commercial exploitation of the material contained in this work requires a license to such intellectual property rights.

This work may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only. For any other purpose, no part of the work may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The work has been developed for automotive applications only. It has neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.



#### **Table of Content**

1	Scop	e of document	5
2	How	to Read this Document	6
		Conventions usedRequirements structure	
3	Acror	nyms and abbreviations	8
4	Func	tional Overview	9
5	Requ	irement Specification	10
	5.1.1 5.1.2 5.2	Functional Requirements Configuration Normal Operation Non-Functional Requirements Process Requirements	10 11 11
6	Refe	rences	13
	6.1	Deliverables of AUTOSAR	13



## 1 Scope of document

This document specifies requirements on the module PORT Driver.

#### Constraints

First scope for specification of requirements on basic software modules is systems, which are not safety relevant. For this reason safety requirements are assigned to medium priority



#### 2 How to Read this Document

Each requirement has its unique identifier starting with the prefix "BSW" (for "Basic Software"). For any review annotations, remarks or questions please refer to this unique ID rather than chapter or page numbers!

#### 2.1 Conventions used

- The representation of requirements in AUTOSAR documents follows the table specified in [TPS\_STDT\_0078].
- In requirements, the following specific semantics are used

The key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "MAY", and "OPTIONAL" in this document are to be interpreted. Note that the requirement level of the document in which they are used modifies the force of these words.

- MUST: This word, or the terms "REQUIRED" or "SHALL", mean that the definition is an absolute requirement of the specification.
- MUST NOT: This phrase, or the phrase "SHALL NOT", means that the definition is an absolute prohibition of the specification.
- SHOULD: This word, or the adjective "RECOMMENDED", mean that there may
  exist valid reasons in particular circumstances to ignore a particular item, but the
  full implications must be understood and carefully weighed before choosing a
  different course.
- SHOULD NOT: This phrase, or the phrase "NOT RECOMMENDED" mean that
  there may exist valid reasons in particular circumstances when the particular
  behavior is acceptable or even useful, but the full implications should be
  understood and the case carefully weighed before implementing any behavior
  described with this label.
- MAY: This word, or the adjective "OPTIONAL", means that an item is truly optional. One vendor may choose to include the item because a particular marketplace requires it or because the vendor feels that it enhances the product while another vendor may omit the same item. An implementation, which does not include a particular option, MUST be prepared to interoperate with another implementation, which does include the option, though perhaps with reduced functionality. In the same vein an implementation, which does include a particular option, MUST be prepared to interoperate with another implementation, which does not include the option (except, of course, for the feature the option provides.)

#### 2.2 Requirements structure

Each module specific chapter contains a short functional description of the Basic Software Module. Requirements of the same kind within each chapter are grouped under the following headlines (where applicable):



#### Functional Requirements:

- Configuration (which elements of the module need to be configurable)
- Initialisation
- Normal Operation
- Shutdown Operation
- Fault Operation
- ...

### Non-Functional Requirements:

- Timing Requirements
- Resource Úsage
- Usability
- Output for other WPs (e.g. Description Templates, Tooling,...)
- ...



## 3 Acronyms and abbreviations

Acronyms and abbreviations that have a local scope are not contained in the AUTOSAR glossary. These must appear in a local glossary.

Acronym:	Description:
ADC	Analogue to Digital Converter
DIO	Digital Input Output
ICU	Input Capture Unit
MCAL	Microconroller Abstraction Layer
MCU	Microcontroller Unit
OS	Operating System
PWM	Pulse Width Modulation
SCI	Serial Communication Interface
SPAL	The name of this working group (Standard Peripheral Abstraction
	Layer)
SPI	Serial Peripheral Interface
WP	Work Package

Abbreviation:	Description:
STD	Standard
REQ	Requirement
UNINIT	Uninitialized (= not initialized)

As this is a document from professionals for professionals, all other terms are expected to be known.



### 4 Functional Overview

This module initializes the whole port structure of the microcontroller. Many ports and port pins can be assigned to various functionalities like e.g.

- General purpose I/O
- ADC
- SPI
- SCI
- PWM

For this reason there has to be an overall configuration and initialization of this port structure. The configuration and usage of those port pins is microcontroller and ECU dependent.

The following expressions are used within the Port driver:

Expression	Explanation
Physical Level (Input):	Two states possible: LOW/HIGH
Physical Level (Output):	three states possible: LOW/HIGH/High Impedance
Logical Level:	This level is seen within the software: TRUE/FALSE



## **5** Requirement Specification

### **5.1 Functional Requirements**

### 5.1.1 Configuration

# 5.1.1.1 [SRS\_Port\_12001] The Port driver shall allow the static configuration of the following options for each port

Valid	
The Port driver shall allow the static configuration of the following options for each port. The granularity of configuration (whole port or single port pin) is microcontroller dependent.	
Mandatory parameters:	
pin usage (e.g. DIO, ADC, SPI,)	
pin direction (input, output)	
pin level init value	
pin direction changeable during runtime (yes/no)	
Optional parameters (only if supported by hardware):	
activation of internal pull-ups/pull-downs	
slew rate control	
input thresholds	
pin driver mode (push-pull/open drain)	
further microcontroller specific properties	
Level inversion features shall not be configurable, but be set to the default	
value (not inverted).  Level inversion is task of the I/O Hardware Abstraction.	
Basic configuration;	
Pin direction changeable during runtime: this is information necessary for	
port refreshing and runtime direction change, see [SRS_Port_12405] Set	
port pin direction and [SRS_Port_12406] Refresh port direction.	

(RS\_BRF\_01864)

# 5.1.1.2 [SRS\_Port\_12302] The port driver shall allow the static configuration of the port pin names

Type:	Valid	
Description:	The port driver shall allow the static configuration of the following symbolic	
	names:	
	port pin names	
Rationale:	Provide human readable symbolic names for microcontroller ports and port	
	pins.	
Use Case:	Examples:	
	PORT_A_PIN_0	
Dependencies:		
Supporting Material:		

[(RS\_BRF\_01864)



#### 5.1.2 Normal Operation

# 5.1.2.1 [SRS\_Port\_12405] The Port driver shall provide a service for setting the direction of port pins during runtime

Type:	valid
Description:	The Port driver shall provide a service for setting the direction of port pins during runtime.  The Port driver shall only allow to change the direction of those port pins that are configured as changeable.
Rationale:	
Use Case:	Single wire bidirectional communication with ASICs.
Dependencies:	[SRS_Port_12001] Configuration of port pin properties
Supporting Material:	

[(RS\_BRF\_01056,RS\_BRF\_01864)

# 5.1.2.2 [SRS\_Port\_12406] The Port driver shall provide a service to refresh the direction of all configured ports

Type:	Valid
Description:	The Port driver shall provide a service to refresh the direction of all configured ports to the configured direction.  The Port driver shall exclude those port pins from refreshing that are configured as "pin direction changeable during runtime".
Rationale:	Make system more robust against EMC and application software bugs (port data direction register corruption).
Use Case:	
Dependencies:	[SRS_Port_12001] Configuration of port pin properties
Supporting Material:	

[(RS\_BRF\_01056,RS\_BRF\_01864)

### 5.2 Non-Functional Requirements

# 5.2.1.1 [SRS\_Port\_12423] All re-entrant functions of the Port Driver shall perform port register access actions in an atomic way

Type:	Valid
Description:	All re-entrant functions of the Port Driver shall perform port register access actions in an atomic way.
Rationale:	Avoid data integrity problems within concurrent access of Port Driver API functions.
Use Case:	A specific microcontroller (or a specific compiler) does not provide atomic access to single port pins. For that reason, the implementation has to use read-modify-write operations on the whole port. Concurrent access to pins of the same port will lead to data integrity problems if concurrent access it not blocked.
Dependencies:	



Supporting Material:
----------------------

J(RS\_BRF\_01864)

### 5.2.2 Process Requirements

# 5.2.2.1 [SRS\_Port\_12300] Ports and port pins that are not used shall be set to a defined state

Туре:	Valid
Description:	Ports and port pins that are not used (neither as general purpose I/O nor as special purpose I/O) shall be set to a defined state by the Port module configuration.
Rationale:	Ensure that all ports and port pins are in a defined state.
Use Case:	
Dependencies:	
Supporting Material:	

J(RS\_BRF\_01864)



#### 6 References

#### 6.1 Deliverables of AUTOSAR

**[DOC\_LAYERED\_ARCH]** Layered Software Architecture, AUTOSAR\_EXP\_LayeredSoftwareArchitecture.pdf

[AUTOSAR\_GLOSSARY] Glossary, AUTOSAR\_TR\_Glossary.pdf

**[SRS\_BSW\_GENERAL]** General Requirements on Basic Software Modules, AUTOSAR\_SRS\_BSWGeneral.pdf

[SRS\_BSW\_SPAL] General Requirements on SPAL, AUTOSAR\_SRS\_SPALGeneral.pdf

**[TPS\_STDT\_0078]** Software Standardization Template AUTOSAR\_TPS\_StandardizationTemplate.pdf