

<b>Document Title</b>	Guidelines for using Adaptive Platform interfaces
<b>Document Owner</b>	AUTOSAR
<b>Document Responsibility</b>	AUTOSAR
<b>Document Identification No</b>	929

<b>Document Status</b>	published
<b>Part of AUTOSAR Standard</b>	Adaptive Platform
<b>Part of Standard Release</b>	R20-11

<b>Document Change History</b>			
<b>Date</b>	<b>Release</b>	<b>Changed by</b>	<b>Change Description</b>
2020-11-30	R20-11	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>The name of the chapter "Core Types" to "Adaptive Core" and some minor changes in the chapter</li> <li>Moderate changes in the State Management chapter</li> <li>Minor changes in the Persistency Chapter</li> </ul>
2019-11-28	R19-11	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>Persistency and Platform Health Management chapters added</li> <li>Changed Document Status from Final to published</li> </ul>
2019-03-29	19-03	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>Clause 4 revised to reflect the updated design on State Management</li> </ul>
2018-10-31	18-10	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>Initial release</li> </ul>

## Disclaimer

This work (specification and/or software implementation) and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the work.

The material contained in this work is protected by copyright and other types of intellectual property rights. The commercial exploitation of the material contained in this work requires a license to such intellectual property rights.

This work may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only. For any other purpose, no part of the work may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The work has been developed for automotive applications only. It has neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.

## Table of Contents

1	Introduction to this document .....	4
1.1	Contents.....	4
1.2	Prereads.....	4
1.3	Relationship to other AUTOSAR specifications .....	4
2	Adaptive Core .....	5
2.1	Error handling .....	5
2.1.1	ErrorCode .....	5
2.1.2	Result.....	5
2.2	Reserved symbols .....	9
2.2.1	Preprocessor macros .....	9
3	Execution Management .....	9
3.1	Execution State.....	9
3.2	Deterministic Execution .....	10
4	State Management.....	13
4.1	Interaction with AUTOSAR Adaptive (Platform) Applications .....	13
4.1.1	Basic State Management functionality .....	13
4.1.2	Advanced State Management functionality.....	14
5	Persistency cluster.....	17
5.1	Overview .....	17
5.1.1	Key Value Storage.....	17
5.1.2	File storage .....	17
5.2	Example usage of KVS API.....	18
5.3	Example usage of File Storage API .....	19
5.4	Redundancy feature .....	19
5.5	Reset Storage.....	20
5.6	Update and Removal of Persistent Data .....	20
6	Platform Health Management.....	21
6.1	Shutdown functionality.....	21
7	References.....	22

# 1 Introduction to this document

## 1.1 Contents

While SWS of FC is a specification for ARA interfaces, some of the interfaces require “guidelines” on how to use them. The guidelines are indeed related to the specification, but some are indirect and having such information within each SWS bloats SWS hence making it difficult for readers to grasp the usage. Another important perspective is that these guidelines are a kind of requirement against AA to follow, but SWS of FC are specification requirements for FCs. Therefore, it does not fit well to have these contents in SWS, and this is the purpose of this “Guidelines for using Adaptive Platform Interfaces.”

The main contents of this document will be the guidelines for applications to follow as mentioned in the background above. Not necessarily all FCs will have contents in this document; they will be added when it deems valid.

The contents are organized per relevant topic, but in general, this will be grouped by FC, each having its independent chapter. Also, note that the contents may be provided in separate AUTOSAR AP documents. If this is the case, such documents will be listed or referenced from this guideline.

## 1.2 Prereads

This document is a supplementary document to the SWS of AP. Therefore, the relevant SWS of the topic in these guidelines should be read in parallel. Also, the first AP document to be read is [1], which gives the architectural overview of AP.

## 1.3 Relationship to other AUTOSAR specifications

Refer to Contents and Prereads.

## 2 Adaptive Core

### 2.1 Error handling

Handling errors is a crucial topic for any software development. For safety-critical software, it is even more important, because lives can depend on it. However, current standards for the development of safety-critical software places significant restrictions on the build toolchain, especially with regard to C++ exceptions. For ASIL applications, using C++ exceptions is usually not possible due to the lack of exceptions support with ASIL-certified C++ compilers.

The Adaptive Platform introduces a concept that enables error handling without C++ exceptions and defines a number of C++ data types to aid in this.

From an application programmer's point of view, the central types implementing this concept are `ara::core::ErrorCode` and `ara::core::Result`.

#### 2.1.1 ErrorCode

An instance of `ara::core::ErrorCode` represents a specific error condition within a software. It is similar to `std::error_code`, but differs in significant aspects from it.

An `ErrorCode` always contains an enumeration value (type-erased into an integral type) and a reference to an *error domain*. The enumeration value describes the specific type of error, and the error domain reference defines the context where that error is applicable. Additional optional members are a user-defined message string and a vendor-defined supplementary error description value.

#### 2.1.2 Result

Class `ara::core::Result` follows the "ValueOrError" concept from the C++ proposal p0786 (see <https://wg21.link/P0786>). It either contains a value or an error. Due to their templated nature, both value and error can be of any type. However, *ErrorType* defaults to `ara::core::ErrorCode`, and it is expected that this assignment is kept throughout the Adaptive Platform.

Because the *ErrorType* is defaulted to `ara::core::ErrorCode`, most declarations of `ara::core::Result` only need to give the *ValueType*, e.g.

`ara::core::Result<int>` for a `Result` type that contains either an `int` variable, or an `ErrorCode`.

ARA interfaces use `ara::core::Result` as the return type for functions that can encounter recoverable errors. This type can be used to either generate a C++ exception from the object if the user chooses to use exceptions, or retrieve error information via observer methods without using exceptions.

This section guides you on how to handle such `Result` objects returned from ARA interface in your application code, and also gives guidance on how to create new `Result` objects within your own Adaptive Application.

### 2.1.2.1 Creation of a Result

For creating a `Result` with an embedded *value*, there are constructors allowing implicit conversion from a *ValueType*. This makes defining a `Result` with a value quite straightforward:

```
Result<int> res1(42);  
Result<int> res2 = 42;
```

Returning a value from a function declared to return a `Result` is similarly straightforward:

```
Result<int> myfunction()  
{  
    return 42;  
}
```

Putting an *error* inside a `Result` requires calling an explicit constructor, e.g.:

```
ErrorCode ec = MyEnum::some_error;  
Result<int> res2(ec);
```

Alternatively, construction of `Result` objects is also possible with static member functions, for instance:

```
Result<int> res1 = Result<int>::FromValue(42);  
Result<int> res2 = Result<int>::FromError(ec);
```

These forms can be advantageous when *ValueType* or *ErrorType* are expensive to copy because they allow in-place construction. For instance, returning a `Result` containing an instance of `BigClass` which is constructed with two constructor arguments “a1” and “a2” could look like this:

```
return Result<BigClass>::FromValue(a1, a2);
```

For *ErrorType*, this also allows implicit construction of the `ErrorCode` instance, including an optional supplementary data value:

```
return Result<BigClass>::FromError(  
    MyEnum::some_error,           // ErrorCode enum value  
    0x12345678                    // support data value  
);
```

With this form of construction, only one constructor call is performed, unlike the regular (unnamed) constructor call, where at least two constructor calls are performed, because the pre-created value must then be copied or moved into the `Result` instance.

### 2.1.2.2 Retrieving values and errors

When trying to retrieve the value or error that is contained within a `Result`, one first has to consider which one of these (value or error) is actually available. In general, this is not known, so one has to take care to handle both cases.

When working without exceptions, the `Result` object is queried to check whether it contains a value or an error:

```
Result<int> some_function() { ... }

Result<int> res = some_function();
if (res.HasValue()) {
    int theValue = res.Value();
} else {
    ErrorCode const& ec = res.Error();
}
```

This code also works in a completely exception-free environment, including with a compiler that does not support exceptions at all.

When working with an exception-based workflow, the query code looks quite similar to regular exception-based code:

```
Result<int> some_function() { ... }

int theValue = some_function().ValueOrThrow();
```

Here, the `Result` object that is returned by `some_function()` is immediately reduced to its *ValueType* (`int`) by calling its `ValueOrThrow()` member function. If the `Result` did, in fact, contain an `ErrorCode`, this would immediately throw an exception type that corresponds to the embedded `ErrorCode` object. Naturally, a `try...catch` block should be added at a suitable location in the code.

### 2.1.2.3 Advanced topics

The two basic methods for retrieving the embedded value or error are called just as such: `Result::Value()` and `Result::Error()`. However, when calling any of these, one has to be certain that the `Result` object does indeed contain what is implied by calling one of these functions. In the previous section, this was done by first calling `Result::HasValue()`, and calling `Value()` or `Error()` depending on the outcome of that call.

A more convenient way of accessing the embedded value has already also been mentioned in the previous section: By calling `Result::ValueOrThrow`, no `if`-statement is needed, and the invocation collapses into a single-line statement (excluding the `try...catch` block, which might exist elsewhere).

Other convenience methods exist, for instance `Result::ValueOr`, which retrieves the value, if it exists, or takes a default value otherwise (i.e., in case of any error), e.g.:

```
int res = some_function().ValueOr(42);
```

A generalization of `Result::ValueOr` is called `Result::Resolve`, which does not take a default value as an argument, but a `Callable`, which is to create the default value on-demand:

```
int res = some_function()
    .Resolve([](ErrorCode const& ec){ return 42; });
```

For this particular example, using `Result::Resolve` instead of `Result::ValueOr` does not make much sense. However, it can be advantageous when the default value is expensive to create. By using `Result::Resolve`, the default value is only created when it is actually needed.

Another convenience method is `Result::Bind`, which allows to transform the contained value into another value, or even into another type. For instance:

```
Result<String> res = some_function()
    .Bind([](int v){ return v + 1; })
    .Bind([](int v){ return std::to_string(v); })
    .Bind([](String const& s) { return "\"" + s + "\""; });
```

The first call to `Result::Bind` takes the `int` value contained in the `Result` object, adds one to it, puts that into a new `Result` object, and returns it.

The second call to `Result::Bind` takes the incremented `int` value from the new `Result` object, converts it into a `String`, and returns a new `Result<String>` object with it.

The third and final call to `Result::Bind` takes the `String` object contained in the new `Result` object, adds quote characters to it, and returns a new `Result` object with it.

If the `Result` does not contain a value, then none of these `Callables` are invoked, and the `Result` object is only type-converted, but retains the original `ErrorCode`.

The `Callables` passed to `Result::Bind` must take a suitable type as a parameter and can return either a *ValueType* directly (as shown above, and either the same *ValueType* as before, or a new, different *ValueType*), or a `Result<ValueType>`.



## 2.2 Reserved symbols

### 2.2.1 Preprocessor macros

The Adaptive Platform generally avoids the use of C/C++ preprocessor macros.

However, in case macros are introduced at some later point in time, any such macro will start with the prefix ARA. Macros with this prefix should thus not be defined by developers of an Adaptive Application.

## 3 Execution Management

### 3.1 Execution State

The Execution State characterizes the internal lifecycle of any Process. Each Process needs to report changes in its Execution State to Execution Management, using the `ExecutionClient::ReportExecutionState()` interface (see [2]).




Figure 3-1 Execution States

Upon Process startup, Execution Management shall consider Process initialization complete when the state `kRunning` is reported (see [SWS\_EM\_01004 and SWS\_EM\_01402]). Please note that Service Discovery can introduce nondeterministic delays and thus is advised to be done after reporting `kRunning` state; thus, the Process may not have completed all its initialization when the `kRunning` state is reported by the Process.

Execution Management initiates Process termination by sending the SIGTERM signal to a Process.

On receipt of SIGTERM, the Process is expected to save persistent data and free all internally used resources. The Process indicates completion of the Terminating state by termination with exit status 0 (`EXIT_SUCCESS`). Execution Management does not require an explicit notification of actual Process termination by the process itself.

### 3.2 Deterministic Execution

Execution Management supports a fully deterministic multithreaded execution of a Process, so processing a given set of input data always produces a consistent output within a bounded time, i.e. the behavior is reproducible.

Expected use cases of the AUTOSAR Adaptive Platform where such determinism is required include redundant execution in a Software Lockstep framework for systems with high safety goals (up to ASIL D) and reuse of verified software. For more details see [2], section “Deterministic Execution”.

A Process that can be executed fully deterministically must be designed, implemented and integrated in a way such that it is independent of processor load caused by other functions and calculations, sporadic unrelated events, race conditions, deviating random numbers, etc.

Non-deterministic behavior may arise from different reasons; for example insufficient computing resources, or uncoordinated access of data, potentially by multiple threads running on multiple processor cores. The order in which the threads access such data will affect the result, which makes it non-deterministic.

Full deterministic execution includes:

- Time Determinism: The output of the calculation is always produced before a given deadline. The resource demands of the Process need to be described in a standardized way, so the integrator can assign sufficient resources to the Process (see subsection “Real-Time Resources” in [2]).
- Data Determinism: Given the same input and internal state, the calculation always produces the same output. The rest of this section will describe how to achieve Data Determinism.

Execution Management} provides `DeterministicClient` library functions to support deterministic execution:

- Control of a process-internal cycle by wait point API `WaitForNextActivation()` ([SWS\_EM\_01301]). The Process shall execute one cycle when the API returns and then call the API again to wait for the next activation. A return value of the API controls the internal lifecycle (e.g. init, run, terminate) of the Process, which must be prepared accordingly ([SWS\_EM\_01302], [SWS\_EM\_01303] and [SWS\_EM\_01304]).
- A blocking deterministic worker pool API `RunWorkerPool()` ([SWS\_EM\_01305]) for the execution of a set of container elements ([SWS\_EM\_01306]) which are processed in parallel or sequentially by the same worker runnable object (i.e. application function).
- APIs `GetActivationTime()` ([SWS\_EM\_01310]) and `GetNextActivationTime()` ([SWS\_EM\_01311]) to provide activation time stamps which don't change until the Process reaches its next wait point.
- API `GetRandom()` to provide random numbers ([SWS\_EM\_01308]). If used from within the worker pool, the random numbers are assigned to specific container elements to allow deterministic redundant execution.

To ensure deterministic behavior, only a “deterministic subset” of all available APIs may be used by the deterministic user Process, including the worker runnable objects:

- The Process is not allowed to create threads on its own by using normal POSIX mechanisms or access any other POSIX APIs directly, to avoid the risk of inducing indeterministic behavior.
- Only a “deterministic subset” of all available ara::com mechanisms are allowed to be used by the Process. A detailed list of such APIs and mechanisms will be provided at a later point in time.
- Only the following ara::exec interfaces may be used:
  - DeterministicClient
  - ExecutionClient
- No other ARA interfaces are allowed to be accessed by the user Process.

If the worker pool API `RunWorkerPool()` is used, the worker runnable object which processes the container elements, i.e. the jobs to be computed, needs to satisfy certain implementation rules to ensure Data Determinism:

- The runnable object is not allowed to exchange any information while it is running, i.e. it doesn't access data which can be altered by other instances of the runnable object to avoid race conditions.

Rationale: The runnable object instances can physically run in parallel or sequentially in any order. The timing between individual workers is not guaranteed. The Operating System is scheduling threads individually. Concurrent influencing of the same data will result in indeterminate results.

- No locks and synchronization points except common joins for all workers by returning from `RunWorkerPool()` (e.g. no Semaphores/Mutexes, no locking/blocking).

Rationale: locking/blocking makes Process runtime in-deterministic. Workers are provided to increase the utilization of runtime. If synchronization is needed, a return from `RunWorkerPool()` is necessary.

The worker pool cannot be used to process multiple different tasks in parallel. The use of multiple potentially different explicit functions (worker runnable objects) could add unnecessary complexity and can lead to extremely heterogeneous runtime utilization, as each worker may have different computing time. This would complicate the planning of resource deployment, which is necessary for black-box integration.

Example of the implementation of Worker Pool Users, i.e. of a worker runnable object:

```
class MyWorker1
: public DeterministicClient::WorkerrunnableBase<myContainer::
  value_type, MyWorker1>
{
public:
  void worker_runnable(myContainer::value_type& container_element,
    DeterministicClient::WorkerThread& t)
  {
    // Get a unique and deterministic pseudo-random number}
    uint64_t random_number = t.GetRandom();
  }
};
```

Worker-thread object:

```
class DeterministicClient::WorkerThread
{
  // returns a deterministic pseudo-random number}
  // which is unique for each container element}
  uint64_t GetRandom();

  ...
};
```

## 4 State Management

### 4.1 Interaction with AUTOSAR Adaptive (Platform) Applications

#### 4.1.1 Basic State Management functionality

State Management provides a set of 'Trigger' and 'Notifier' fields via `ara::com`. The SM essentially listens to the 'Triggers', and perform implementation-specific state machine processing internally, and provides the effect to the 'Notifier' fields if there is any. The State Management also interacts with other FCs through the standard interface provided by them.

The following effects can be achieved by using this mechanism:

- FunctionGroups can be requested to be set to a dedicated state
- (Partial) Networks can be requested to be de- / activated
- The machine can be requested to be shutdown or restarted
- Other Adaptive (Platform) Applications can be influenced in their behavior
- Project specific actions could be performed.

Some of these functions are critical. Therefor the access to the Trigger fields has to be secured properly by Integrator via Identity and Access Management not to change the internal state of State Management (and therefor the depending effects) accidentally.

The internal states of State Management are propagated to the system through its provided 'Notifier' fields. The read access to these fields is less critical and so each Adaptive (Platform) Application can register to their events to be informed whenever State Managements internal states change. So each Adaptive (Platform) Application can carry out an operation(s) (when needed) when the state of State Management changes.





Figure 4-1 A basic application State transition example

### 4.1.2 Advanced State Management functionality

Some use cases within AUTOSAR Adaptive require to support a synchronized behavior in the states managed by State Management. One example might be a low-power mode: State Management can only switch finally to a low-power state when all Adaptive (Platform) Applications which are involved in this low-power mode scenario are finally prepared for low-power (e.g. have persisted its information).

To achieve such kind of synchronized communication AUTOSAR adaptive provides a mechanism called CommunicationGroup. This mechanism provides a template for the messages and reply messages, from which the corresponding ara::com methods and events are generated by the tooling. For Details see TPS\_ManifestSpecification and SWS\_CommunicationManagement.




**Figure 4-2 CoomunicationGroup ServiceInterface**

Therefore each Adaptive (Platform) Application which is required to support such a synchronized working mode has to offer the method and the event generated in the context of CommunicationGroupClient.

StateMangement provides two predefined sets of messages and reply messages:

- PowerMode
- DiagnosticReset

For details see SWS\_StateManagement.



**Figure 4-3 Distributing PowerMode example**

StateManagement offers methods and events in the context of CommunicationGroupServer. So it can broadcast the PowerMode to all Processes, which are part of the CommunicationGroup (means offering the methods and events of the CommunicationGroupClient). Each Process has to give its answer to the request by writing to the response field, thus StateManagement can collect all answers.

StateManagement can retrieve a list of all clients in the CommunicationGroup, thus it can check if all clients did answer (in time). Depending on the result (all clients answered, not all clients answered (in time), the answer was different from "success", ...)

StateManagement has to do a project-specific reaction.

The messages and reply messages for the DiagnosticReset are meant as a tool for Diagnostic reset requests, where it should be possible to communicate to running Processes (without the need to terminate and restart them). If and how this tool is used is project-specific.



## 5 Persistency cluster

### 5.1 Overview

Persistency is one of the foundation clusters of the adaptive AUTOSAR platform which provides static APIs to the application to store and retrieve the user data. It supports two different storage mechanisms: Key-Value Storage and File Storage.

Both storage mechanisms might use a file system of the operating system, and in this case rely on this file system to be able to synchronize changes immediately. This has to be ensured by a proper integration of the file system, e.g. by using appropriate mount options. See also Appendix C of the SWS Persistency.




Figure 5-1 Persistency functionality overview

#### 5.1.1 Key Value Storage

It is a simple key based data base that helps the user to store their smaller data in the data base.

#### 5.1.2 File storage

It is a file based storage and the data is stored in the files under a folder and It supports storing huge data into files.

An application needs to design Key Value Storage and File Storage as a port interface in order to access the Key Value Storage and File storage features. After designing the persistency port interfaces, further configuration information will be provided during the deployment stage (Ex: storage location, database mapping to storage location, redundancy-crc, and redundancy M/N configurations, etc.)

Based on the logging implementation inside persistency, the cluster can log the run time-related warnings errors and fatal information also error information can be informed to PHM.

Note: AUTOSAR\_SWS\_Persistency does not specify the above details as it is an implementation specific

## 5.2 Example usage of KVS API

Deploy the database in a specific location and map the short name of the database with location during deployment of the database.

### Write operation sequence

1. open the database with the instance specifier  

```
ara::core::Result<SharedHandle<KeyValueStorage>> kvs =
ara::per::OpenKeyValueStorage(*MakeInstanceSpecifier(kDatabaseName));
```

[Parse the ara::core::Result<kvs> to check success or error in case of failure of open database operation]
2. Parse the KeyValueStorage object (kvs) from ara::core::Result  

```
KeyValueStorage db = std::move(kvs).Value();
```
3. Invoke the SetValue with key and value that needs to be persisted in the database  

```
ara::core::Result result = db->SetValue(kDoubleKeyName, DoubleValue);
```

[Parse the result to check the status of the write operation]  
Hint: In order to effectively use the underlying storage device it is designed that all the user requests are stored intermediately in the RAM and the data will be persisted to file system only after invoking the below sync call. Hence it is suggested that after opening the database, perform multiple SetValue() operations then persist the data finally via sync call.
4. Invoke the below API to persist data to the nonvolatile storage(Flash/Hard disk)  

```
ara::core::Result result = db->SyncToStorage();
```

[Parse the result to check the status of the sync operation]
5. There is a possibility that a user can go to last sync state by calling the API DiscardPendingChanges () which will discard the transaction of syncing the locally stored the key value pairs with the underlying data base.  

```
ara::core::Result result = db->DiscardPendingChanges ();
```

### Read operation sequence:

1. Open the database with the instance specifier  

```
ara::core::Result<SharedHandle<KeyValueStorage>> kvs =
ara::per::OpenKeyValueStorage(*MakeInstanceSpecifier(kDatabaseName));
```

[This returns ara::core::Result which contains kvsobject or error in case of failure]
2. Parse the Kvs object from ara::core::Result  

```
KeyValueStorage db = std::move(kvs).Value();
```
3. Invoke the GetValue with key and value that needs to be retrieved from the database

**Version-1:** `ara::core::String first_value = db->GetValue<String>(kStringKeyName);` **(or)**  
**Version-2:** `ara::core::result = db->GetValue(kDoubleKeyName, DoubleValue));`  
 [Parse the result to check the status of the read operation and get the value assigned to a key]

### 5.3 Example usage of File Storage API

#### Write operation

1. Open File storage with the short name of the portprototype

```
ara::core::Result<SharedHandle<FileStorage>> proxy =
OpenFileStorage(*MakeinstanceSpecifier(folder_));
Parse the proxy to check success or error in case of failure
```

2. Parse the File Storage object from `ara::core::Result<SharedHandle<FileStorage>>`  
`FileStorage FS = std::move(proxy).Value;`
3. Invoke the `OpenFileWriteOnly` with the file name which is short name of the portprototype to get the writeaccessor object  
`ara::core::Result<UniqueHandle<ReadWriteAccessor>> file = FS.->OpenFileWriteOnly(filename_);`
4. Perform the formatted writing via overloading operator  
`(*std::move(file).Value()) << "Overwriting!";`

#### Read operation

1. Open File storage with the short name of the portprototype

```
ara::core::Result<SharedHandle<FileStorage>> proxy =
OpenFileStorage(*MakeinstanceSpecifier(folder_));
Parse the proxy to check success or error in case of failure
```

2. Parse the FileStorage object from `ara::core::Result<SharedHandle<FileStorage>>`  
`FileStorage FS = std::move(proxy).Value;`
3. Invoke the `OpenFileReadWrite()` with the file name to get the readwriteaccessor object  
`ara::core::Result<UniqueHandle<ReadWriteAccessor>> file = FS.->OpenFileReadWrite (filename_);`
4. Perform the read operation  
`rwa = std::move(file).Value();`  
`pos_type pos = rwa ->getline(buf); ->read the value in the buffer until default delimiter.`

### 5.4 Redundancy feature

This feature ensures persistent data safety for both KVS and File Storage. There are 2 possible ways to ensure data safety (integrity).

1. CRC
2. M/N approach.

It is a configurable parameter. Based on the project need, either one or both can be configured. With respect to CRC, all the AUTOSAR CRCs are supported to configure. In addition to the detection of integrity M/N approach helps to recover the data if there are sufficient redundant copies available.

**Recover Storage:** It is part of Redundancy Feature if integrity checks fail for KVS or File storage or File, user can use RecoverKeyValueStorage/RecoverFileStorage/RecoverFile APIs to recover the data based on best effort recovery mechanism. Upon invocation of Recover APIs, a valid database/File storage/File could be retrieved which might have lost some key value pairs/Files as it is a best effort recovery mechanism

## 5.5 Reset Storage

This feature resets a key-value storage/File storage/File to the initial state, containing only keys/Files which were deployed from the manifest, with their initial values and It will fail with a kResourceBusyError when the key-value storage/FileStorage/File is currently open and with a kInitValueNotAvailableError when deployment does not define an initial content for the key-value storage/File storage/File.

Reset APIs:

- ResetKeyValueStorage()- Reset KeyValueStorage to the initial state with keys deployed from manifest
- ResetAllFiles()- Reset the whole file storage, including all files from the deployed content from manifest
- ResetFile() - reset a single file to its initial content which was deployed from the manifest

## 5.6 Update and Removal of Persistent Data

There are APIs which will perform the specific action (update/reset/remove) on the persistent data of the application based on the invocation of APIs

UpdatePersistency(Update all persistency file and key-value storages after a new manifest was installed) and ResetPersistency(Remove all file and key-value storages/restore to initial contents). An application may also register a callback function(RegisterApplicationDataUpdateCallback)that is called after the update of any Key-Value Storage and File Storage. These callback function will be called from the context of UpdatePersistency(), OpenKeyValueStorage(), or OpenFileStorage().

## **6 Platform Health Management**

### **6.1 Shutdown functionality**

In the sense of a safe system, the integrator shall ensure that the applications configured to be supervised by Platform Health Management are terminated before triggering shut down of the Platform Health Management. Please refer to [3]

## 7 References

- [1] Explanations of Adaptive Platform Design, AUTOSAR\_EXP\_PlatformDesign.pdf.
- [2] Specification of Execution Management, AUTOSAR\_SWS\_StateManagement.pdf.
- [3] Specification of Platform Health Management, AUTOSAR\_SWS\_PlatformHealthManagement.pdf.
- [4] Explanation of ara::com API, AUTOSAR\_EXP\_ARAComAPI.pdf.