

<b>Document Title</b>	Specification of Operating System
<b>Document Owner</b>	AUTOSAR
<b>Document Responsibility</b>	AUTOSAR
<b>Document Identification No</b>	34

<b>Document Status</b>	published
<b>Part of AUTOSAR Standard</b>	Classic Platform
<b>Part of Standard Release</b>	R25-11

Document Change History			
Date	Release	Changed by	Description
2025-11-27	R25-11	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>Removal of "Service Interfaces"</li> <li>Removal of feature "ControlIdle"</li> <li>Timing protection extension for aperiodic servers</li> <li>Several ARTI updates</li> <li>Minor correction / clarification / editorial changes</li> </ul>
2024-11-27	R24-11	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>Clarification on PRO_IGNORE, new PRO_PREVENT_ARRIVAL_RATE</li> <li>Clarification of CallTrustedFunction, added new column to table 7.1</li> <li>Remove option to restart a OS-Application</li> <li>Minor correction / clarification / editorial changes</li> </ul>





2023-11-23	R23-11	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>Renaming of restart symbols</li> <li>Added new API <code>isOsStarted</code>, configuration change in OS-Application/EcuPartition/Core assignment</li> <li>Memory mapping update</li> <li>Minor correction / clarification / editorial changes</li> </ul>
2022-11-24	R22-11	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>Several minor issues and clarifications (IOC error codes, applicability of multi-core, ARTI updates)</li> <li>Additional memory allocation keywords</li> <li>Added further uptraces to SRS requirements</li> <li>Removal of <code>StartNonAutosarCore</code> API</li> </ul>
2021-11-25	R21-11	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>Further updates to ARTI sections</li> <li>API changes and clarifications (<code>SetScheduleTableAsync</code>, <code>GetNumberOfActivatedCores</code>)</li> <li>New configuration options for placement of callouts.</li> <li>Update of <code>RES_SCHEDULER</code> handling.</li> <li>Minor correction / clarification / editorial changes</li> </ul>
2020-11-30	R20-11	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>Updates to ARTI description and configuration</li> <li>loc: correction regarding N:M communication</li> <li>Minor correction / clarification / editorial changes</li> </ul>





2019-11-28	R19-11	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>• Various updates for ARTI</li> <li>• Enhanced memory mapping for IOC</li> <li>• Some type improvements for multi-core</li> <li>• Minor correction / clarification / editorial changes</li> <li>• Changed Document Status from Final to published</li> </ul>
2018-10-31	4.4.0	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>• New asynchronous services</li> <li>• ARTI support (DRAFT)</li> <li>• Editorial changes / clarifications</li> </ul>
2017-12-08	4.3.1	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>• minor corrections / clarifications / editorial changes; For details please refer to the ChangeDocumentation</li> </ul>
2016-11-30	4.3.0	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>• Added new API for peripheral access</li> <li>• Added new API for interrupt handling</li> <li>• Minor updates/clarification of descriptions</li> <li>• Editorial changes</li> </ul>
2015-07-31	4.2.2	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>• Allow calls to ControlIdle from all cores</li> <li>• Minor updates/clarification of descriptions</li> <li>• Editorial changes</li> </ul>
2014-10-31	4.2.1	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>• Add support for AsilQmProtection</li> <li>• Minor updates/clarification of descriptions</li> <li>• Editorial changes</li> </ul>
2014-03-31	4.1.3	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>• Changed multiplicity of attributes in locSender/ReceiverProperties</li> <li>• Minor updates/clarification of descriptions</li> <li>• Editorial changes</li> </ul>





2013-10-31	4.1.2	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>Clarification on E_OS_NESTING_DEADLOCK</li> <li>Update of table 2</li> <li>Corrected multiplicity of ECUC_Os_00393</li> <li>Minor updates/clarification of descriptions</li> <li>Editorial changes</li> <li>Removed chapter(s) on change documentation</li> </ul>
2013-03-15	4.1.1	AUTOSAR Administration	<ul style="list-style-type: none"> <li>Add support for ECU degradation</li> <li>Changed service interface description to a formal format</li> <li>Several minor changes and clarifications</li> </ul>
2011-12-22	4.0.3	AUTOSAR Administration	<ul style="list-style-type: none"> <li>Included Multi-Core support from former "Specification of Multi-Core OS Architecture"</li> </ul>
2010-09-30	3.1.5	AUTOSAR Administration	<ul style="list-style-type: none"> <li>Clarification in 7.8.1 (meaning of "do nothing") and 7.1.2.1 ("OSEK declarations")</li> <li>Minor changes as typos and rewording</li> </ul>
2010-02-02	3.1.4	AUTOSAR Administration	<ul style="list-style-type: none"> <li>Extension of services (Chapter 12)</li> <li>States in OS- Applications</li> <li>Active termination of other OS-Applications in possible (Chapter8)</li> <li>Legal disclaimer revised</li> <li>Chapter 10.4 revised</li> </ul>
2009-02-04	3.1.2	AUTOSAR Administration	<ul style="list-style-type: none"> <li>Changes in OS configuration:</li> <li>removed "OsAppModelId" Parameter from OsAppModeContainer</li> <li>added optional references from OsAppModeContainer to OsAlarm, OsTask and OsScheduleTable</li> </ul>
2008-08-13	3.1.1	AUTOSAR Administration	<ul style="list-style-type: none"> <li>Legal Disclaimer revised</li> </ul>





2008-02-01	3.0.2	AUTOSAR Administration	<ul style="list-style-type: none"> <li>Added "OsScheduleTableDuration" parameter to configuration specification chapter</li> </ul>
2007-12-21	3.0.1	AUTOSAR Administration	<ul style="list-style-type: none"> <li>Changed methods for timing protection</li> <li>Moved configuration from OIL to AUTOSAR XML</li> <li>Clarified description for synchronization and ScheduleTables</li> <li>Document meta information extended</li> <li>Small layout adaptations made</li> </ul>
2007-01-24	2.1.15	AUTOSAR Administration	<ul style="list-style-type: none"> <li>Added support for SoftwareFreeRunningTimer (SWFRT) incl. 2 new APIs</li> <li>Added API to start a ScheduleTable synchron</li> <li>Misc. Corrections, Clarification and further explanations</li> <li>Legal disclaimer revised</li> <li>Release Notes added</li> <li>"Advice for users" revised</li> <li>"Revision Information" added</li> </ul>
2006-05-16	2.0	AUTOSAR Administration	<ul style="list-style-type: none"> <li>Document structure adapted to common Release 2.0 SWS Template.</li> <li>Major changes in chapter 10</li> <li>Structure of document changed partly</li> <li>Other changes see chapter 14</li> </ul>
2005-05-31	1.0	AUTOSAR Administration	<ul style="list-style-type: none"> <li>Initial Release</li> </ul>

## **Disclaimer**

This work (specification and/or software implementation) and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the work.

The material contained in this work is protected by copyright and other types of intellectual property rights. The commercial exploitation of the material contained in this work requires a license to such intellectual property rights.

This work may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only. For any other purpose, no part of the work may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The work has been developed for automotive applications only. It has neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.

## Table of Contents

1	Introduction and functional overview	17
2	Acronyms and Abbreviations	18
2.1	Glossary of Terms	18
3	Related documentation	22
3.1	Input documents & related standards and norms	22
3.2	Related specification	22
4	Constraints and assumptions	23
4.1	Existing Standards	23
4.2	Terminology	23
4.3	Interaction with the RTE	23
4.4	Operating System Abstraction Layer (OSAL)	24
4.5	Multi-Core Hardware assumptions	24
4.5.1	CPU Core features	24
4.5.2	Memory features	25
4.5.3	Multi-Core Limitations	25
4.6	Limitations	25
4.6.1	Hardware	25
4.6.2	Programming Language	26
4.6.3	Miscellaneous	26
4.7	Applicability to car domains	26
5	Dependencies to other modules	27
5.1	File structure	27
5.1.1	Code file structure	27
5.1.2	Header file structure	27
5.1.3	ARTI File Structure	27
6	Requirements Tracing	28
7	Functional specification	36
7.1	Core OS	36
7.1.1	Background & Rationale	36
7.1.2	Requirements	36
7.1.2.1	Restrictions on OSEK OS	37
7.1.2.2	Undefined Behaviour in OSEK OS	38
7.1.2.3	Extensions to OSEK OS	38
7.2	Software Free Running Timer	39
7.3	ScheduleTables	39
7.3.1	Background & Rationale	39
7.3.2	Requirements	40

7.3.2.1	Structure of a ScheduleTable . . . . .	40
7.3.2.2	Constraints on Expiry Points . . . . .	41
7.3.2.3	Processing ScheduleTables . . . . .	42
7.3.2.4	Repeated ScheduleTable Processing . . . . .	44
7.3.2.5	Controlling ScheduleTable Processing . . . . .	45
7.4	ScheduleTable Synchronization . . . . .	47
7.4.1	Background & Rationale . . . . .	47
7.4.2	Requirements . . . . .	49
7.4.2.1	Implicit Synchronization . . . . .	49
7.4.2.2	Explicit Synchronization . . . . .	50
7.4.2.3	Performing Synchronization . . . . .	56
7.5	Stack Monitoring Facilities . . . . .	58
7.5.1	Background & Rationale . . . . .	58
7.5.2	Requirements . . . . .	58
7.6	OS-Application . . . . .	59
7.6.1	Background & Rationale . . . . .	59
7.6.2	Requirements . . . . .	61
7.7	Protection Facilities . . . . .	63
7.7.1	Memory Protection . . . . .	63
7.7.1.1	Background & Rationale . . . . .	63
7.7.1.2	Requirements . . . . .	64
7.7.2	Timing Protection . . . . .	66
7.7.2.1	Background & Rationale . . . . .	66
7.7.2.2	Requirements . . . . .	72
7.7.2.3	Implementation Notes . . . . .	75
7.7.3	Service Protection . . . . .	75
7.7.3.1	Background & Rationale . . . . .	75
7.7.3.2	Invalid Object Parameter or Out of Range Value . . . . .	76
7.7.3.3	Service Calls Made from Wrong Context . . . . .	76
7.7.3.4	Services with Undefined Behaviour . . . . .	78
7.7.3.5	Service Restrictions for Non-Trusted OS-Applications . . . . .	81
7.7.3.6	Service Calls on Objects in Different OS-Applications . . . . .	82
7.7.4	Protecting the Hardware used by the OS . . . . .	83
7.7.4.1	Background & Rationale . . . . .	83
7.7.4.2	Requirements . . . . .	83
7.7.4.3	Implementation Notes . . . . .	84
7.7.5	Providing Trustedfunctions . . . . .	84
7.7.5.1	Background & Rationale . . . . .	84
7.7.5.2	Requirements . . . . .	85
7.8	Protection Error Handling . . . . .	86
7.8.1	Background & Rationale . . . . .	86
7.8.2	Requirements . . . . .	88
7.9	Operating System for Multi-Core . . . . .	90

7.9.1 Background & Rationale . . . . .	90
7.9.1.1 Requirements . . . . .	91
7.9.2 Scheduling . . . . .	91
7.9.2.1 Requirements . . . . .	92
7.9.3 Locatable entities (LE) . . . . .	92
7.9.3.1 Requirements . . . . .	93
7.9.4 Multi-Core start-up concept . . . . .	93
7.9.4.1 Requirements . . . . .	95
7.9.5 Cores under control of the AUTOSAR OS . . . . .	97
7.9.5.1 Requirements . . . . .	97
7.9.6 Multi-Core shutdown concept . . . . .	97
7.9.6.1 Synchronized shutdown concept . . . . .	98
7.9.6.2 Individual shutdown concept . . . . .	99
7.9.6.3 Shutdown in case of fatal internal errors . . . . .	99
7.9.7 OS service functionality (overview) . . . . .	99
7.9.8 GetTaskID . . . . .	101
7.9.9 Interrupt disabling . . . . .	101
7.9.9.1 Requirements . . . . .	102
7.9.10 Task activation . . . . .	102
7.9.10.1 Requirements . . . . .	103
7.9.11 Task Chaining . . . . .	103
7.9.11.1 Requirements . . . . .	103
7.9.12 Event setting . . . . .	104
7.9.12.1 Requirements . . . . .	104
7.9.13 Activating additional cores . . . . .	104
7.9.14 Start of the OS . . . . .	105
7.9.14.1 Requirements . . . . .	105
7.9.15 Task termination . . . . .	106
7.9.15.1 Requirements . . . . .	106
7.9.16 Termination of OS-Applications . . . . .	106
7.9.16.1 Requirements . . . . .	107
7.9.17 Shutdown of the OS . . . . .	107
7.9.17.1 Requirements . . . . .	107
7.9.18 Waiting for Events . . . . .	108
7.9.18.1 Requirements . . . . .	108
7.9.19 Calling trusted functions . . . . .	108
7.9.19.1 Requirements . . . . .	109
7.9.20 Invoking reschedule . . . . .	109
7.9.20.1 Requirements . . . . .	109
7.9.21 Resource handling . . . . .	109
7.9.22 The CoreID . . . . .	110
7.9.22.1 Requirements . . . . .	111
7.9.23 Counters, background & rationale . . . . .	111

7.9.24 Multi-Core restrictions on Counters . . . . .	112
7.9.24.1 Requirements . . . . .	112
7.9.25 Synchronization of Counters . . . . .	114
7.9.26 Alarms . . . . .	114
7.9.26.1 Requirements . . . . .	114
7.9.27 ScheduleTables . . . . .	115
7.9.27.1 Requirements . . . . .	116
7.9.28 The spinlock mechanism . . . . .	116
7.9.28.1 Requirements . . . . .	119
7.9.29 Offline checks . . . . .	120
7.9.29.1 Requirements . . . . .	121
7.9.30 Auto start Objects . . . . .	122
7.9.30.1 Requirements . . . . .	122
7.10 Inter-OS-Application Communicator (IOC) . . . . .	122
7.10.1 Background & Rationale . . . . .	122
7.10.2 IOC - General purpose . . . . .	125
7.10.3 IOC functionality . . . . .	126
7.10.3.1 Communication . . . . .	126
7.10.3.2 Notification . . . . .	126
7.10.4 IOC interface . . . . .	127
7.10.5 IOC internal structure . . . . .	127
7.10.6 IOC configuration and generation . . . . .	128
7.10.7 IOC integration examples . . . . .	129
7.10.7.1 Example 1 - 1:1 sender/receiver communication without notification . . . . .	129
7.10.7.2 Example 2 - N:1 client/server communication with receiver notification by RTE . . . . .	131
7.11 System Scalability . . . . .	132
7.11.1 Background & Rationale . . . . .	132
7.11.2 Requirements . . . . .	132
7.12 Hook Functions . . . . .	133
7.12.1 Background & Rationale . . . . .	133
7.12.2 Requirements . . . . .	134
7.13 Hardware peripheral access . . . . .	135
7.13.1 Background & Rationale . . . . .	135
7.13.2 Requirements . . . . .	136
7.14 Interrupt source API . . . . .	137
7.14.1 Background & Rationale . . . . .	137
7.14.2 Requirements . . . . .	137
7.15 Error classification . . . . .	138
7.16 ARTI Debug Information . . . . .	139
7.16.1 OS ARTI Objects . . . . .	140
7.17 ARTI Hook Macros . . . . .	141
7.17.1 Class AR_CP_OS_APPLICATION . . . . .	142

7.17.2 Class AR_CP_OS_TASK . . . . .	143
7.17.3 Class AR_CP_OS_CAT2ISR . . . . .	149
7.17.4 Class AR_CP_OS_SERVICECALLS . . . . .	153
7.17.5 Class AR_CP_OS_SPINLOCK . . . . .	156
7.17.6 Class AR_CP_OS_HOOK . . . . .	157
<b>8 API specification</b> . . . . .	159
<b>8.1 Constants</b> . . . . .	159
8.1.1 Error codes of type <code>StatusType</code> . . . . .	159
<b>8.2 Macros</b> . . . . .	160
<b>8.3 Type definitions</b> . . . . .	160
8.3.1 <code>ApplicationType</code> (for OS-Applications) . . . . .	160
8.3.2 <code>ApplicationStateType</code> . . . . .	161
8.3.3 <code>ApplicationStateRefType</code> . . . . .	161
8.3.4 <code>TrustedFunctionIndexType</code> . . . . .	162
8.3.5 <code>TrustedFunctionParameterRefType</code> . . . . .	162
8.3.6 <code>AccessType</code> . . . . .	162
8.3.7 <code>ObjectAccessType</code> . . . . .	163
8.3.8 <code>ObjectTypeType</code> . . . . .	163
8.3.9 <code>MemoryStartAddressType</code> . . . . .	164
8.3.10 <code>MemorySizeType</code> . . . . .	164
8.3.11 <code>ISRTyp</code> e . . . . .	164
8.3.12 <code>ScheduleTableType</code> . . . . .	165
8.3.13 <code>ScheduleTableStatusType</code> . . . . .	165
8.3.14 <code>ScheduleTableStatusRefType</code> . . . . .	166
8.3.15 <code>ProtectionReturnType</code> . . . . .	166
8.3.16 <code>RestartType</code> . . . . .	166
8.3.17 <code>PhysicalTimeType</code> . . . . .	167
8.3.18 <code>CoreIdType</code> . . . . .	167
8.3.19 <code>SpinlockIdType</code> . . . . .	168
8.3.20 <code>TryToGetSpinlockType</code> . . . . .	168
8.3.21 <code>AreaIdType</code> . . . . .	168
8.3.22 <code>CounterType</code> . . . . .	169
<b>8.4 Function definitions</b> . . . . .	169
8.4.1 <code>GetApplicationID</code> . . . . .	169
8.4.2 <code>GetCurrentApplicationID</code> . . . . .	170
8.4.3 <code>GetISRID</code> . . . . .	171
8.4.4 <code>CallTrustedFunction</code> . . . . .	172
8.4.5 <code>CheckISRMemoryAccess</code> . . . . .	174
8.4.6 <code>CheckTaskMemoryAccess</code> . . . . .	175
8.4.7 <code>CheckObjectAccess</code> . . . . .	177
8.4.8 <code>CheckObjectOwnership</code> . . . . .	178
8.4.9 <code>StartScheduleTableRel</code> . . . . .	179
8.4.10 <code>StartScheduleTableAbs</code> . . . . .	180

8.4.11 StopScheduleTable . . . . .	182
8.4.12 NextScheduleTable . . . . .	183
8.4.13 StartScheduleTableSynchron . . . . .	185
8.4.14 SyncScheduleTable . . . . .	186
8.4.15 SetScheduleTableAsync . . . . .	187
8.4.16 GetScheduleTableStatus . . . . .	189
8.4.17 IncrementCounter . . . . .	190
8.4.18 GetCounterValue . . . . .	191
8.4.19 GetElapsedValue . . . . .	192
8.4.20 TerminateApplication . . . . .	194
8.4.21 GetApplicationState . . . . .	195
8.4.22 GetNumberOfActivatedCores . . . . .	196
8.4.23 GetCoreID . . . . .	197
8.4.24 StartCore . . . . .	198
8.4.25 GetSpinlock . . . . .	199
8.4.26 ReleaseSpinlock . . . . .	200
8.4.27 TryToGetSpinlock . . . . .	202
8.4.28 ShutdownAllCores . . . . .	204
8.4.29 ReadPeripheral8, ReadPeripheral16, ReadPeripheral32 .	205
8.4.30 WritePeripheral8, WritePeripheral16, WritePeripheral32 .	207
8.4.31 ModifyPeripheral8, ModifyPeripheral16, ModifyPeripheral32 .	209
8.4.32 EnableInterruptSource . . . . .	211
8.4.33 DisableInterruptSource . . . . .	211
8.4.34 ClearPendingInterrupt . . . . .	212
8.4.35 ActivateTaskAsyn . . . . .	213
8.4.36 SetEventAsyn . . . . .	213
8.4.37 isOsStarted . . . . .	214
8.4.38 BudgetReplenish . . . . .	215
8.5 IOC . . . . .	215
8.5.1 Imported types . . . . .	215
8.5.2 Type definitions . . . . .	216
8.5.3 Constants . . . . .	216
8.5.4 Function definitions . . . . .	217
8.5.4.1 IocInit (DRAFT) . . . . .	217
8.5.4.2 IocSend/IocWrite . . . . .	218
8.5.4.3 IocSendGroup/IocWriteGroup . . . . .	221
8.5.4.4 IocReceive/IocRead . . . . .	225
8.5.4.5 IocReceiveGroup/IocReadGroup . . . . .	228
8.5.4.6 IocEmptyQueue . . . . .	231
8.6 Expected Interfaces . . . . .	232
8.6.1 Mandatory Interfaces . . . . .	232

8.6.2 Optional Interfaces . . . . .	232
8.6.2.1 ReceiverPullCB . . . . .	232
8.7 Hook functions . . . . .	233
8.7.1 ProtectionHook . . . . .	234
8.7.2 Application specific StartupHook . . . . .	235
8.7.3 Application specific ErrorHook . . . . .	235
8.7.4 Application specific ShutdownHook . . . . .	236
8.8 Service Interfaces . . . . .	237
9 Sequence diagrams . . . . .	238
9.1 Sequence chart for calling trusted functions . . . . .	238
9.2 Sequence chart for usage of ErrorHook . . . . .	239
9.3 Sequence chart for ProtectionHook . . . . .	240
9.4 Sequence chart for StartupHook . . . . .	241
9.5 Sequence chart for ShutdownHook . . . . .	241
9.6 Sequence diagrams of Sender Receiver communication over the IOC . . . . .	242
9.6.1 Last-is-best communication . . . . .	242
9.6.2 Queued communication without pull callback . . . . .	243
9.6.3 Queued communication with pull callback . . . . .	244
10 Configuration specification . . . . .	246
10.1 How to read this chapter . . . . .	246
10.1.1 Rules for parameters . . . . .	246
10.2 Containers and configuration parameters . . . . .	246
10.2.1 Os . . . . .	247
10.2.2 OsAlarmSetEvent . . . . .	249
10.2.3 OsAlarm . . . . .	250
10.2.4 OsAlarmAction . . . . .	253
10.2.5 OsAlarmActivateTask . . . . .	253
10.2.6 OsAlarmAutostart . . . . .	254
10.2.7 OsAlarmCallback . . . . .	256
10.2.8 OsAlarmIncrementCounter . . . . .	258
10.2.9 OsApplication . . . . .	258
10.2.10 OsApplicationHooks . . . . .	265
10.2.11 OsApplicationTrustedFunction . . . . .	267
10.2.12 OsAppMode . . . . .	268
10.2.13 OsCounter . . . . .	268
10.2.14 OsEvent . . . . .	272
10.2.15 OsDriver . . . . .	273
10.2.16 OsHooks . . . . .	274
10.2.17 OsLsr . . . . .	277
10.2.18 OsLsrResourceLock . . . . .	280
10.2.19 OsLsrTimingProtection . . . . .	282
10.2.20 OsOS . . . . .	284

10.2.21 OsPeripheralArea . . . . .	289
10.2.22 OsResource . . . . .	291
10.2.23 OsScheduleTable . . . . .	294
10.2.24 OsScheduleTableAutostart . . . . .	298
10.2.25 OsScheduleTableEventSetting . . . . .	299
10.2.26 OsScheduleTableExpiryPoint . . . . .	301
10.2.27 OsScheduleTableTaskActivation . . . . .	301
10.2.28 OsScheduleTblAdjustableExpPoint . . . . .	302
10.2.29 OsScheduleTableTaskReplenish . . . . .	303
10.2.30 OsScheduleTableSync . . . . .	304
10.2.31 OsSpinlock . . . . .	305
10.2.32 OsTask . . . . .	308
10.2.33 OsTaskAutostart . . . . .	312
10.2.34 OsTaskResourceLock . . . . .	313
10.2.35 OsTaskTimingProtection . . . . .	314
10.2.36 OsTimeConstant . . . . .	317
10.3Containers and configuration parameter extensions of the IOC . . . . .	318
10.3.1 Osloc . . . . .	319
10.3.2 OslocCommunication . . . . .	320
10.3.3 OslocSenderProperties . . . . .	321
10.3.4 OslocReceiverProperties . . . . .	322
10.3.5 OslocDataProperties . . . . .	325
10.4Containers and configuration parameters for ARTI . . . . .	328
10.4.1 ArtiHardware . . . . .	328
10.4.2 ArtiHardwareCoreClass . . . . .	329
10.4.3 ArtiHardwareCoreInstance . . . . .	333
10.4.4 ArtiOs . . . . .	338
10.4.5 ArtiOsAlarmClass . . . . .	340
10.4.6 ArtiOsAlarmInstance . . . . .	341
10.4.7 ArtiOsClass . . . . .	345
10.4.8 ArtiOsContextClass . . . . .	347
10.4.9 ArtiOsContextInstance . . . . .	348
10.4.10 ArtiOsInstance . . . . .	350
10.4.11 ArtiOsIsrClass . . . . .	354
10.4.12 ArtiOsIsrInstance . . . . .	355
10.4.13 ArtiOsMessageContainerClass . . . . .	359
10.4.14 ArtiOsMessageContainerInstance . . . . .	360
10.4.15 ArtiOsResourceClass . . . . .	363
10.4.16 ArtiOsResourceInstance . . . . .	365
10.4.17 ArtiOsScheduleTableClass . . . . .	369
10.4.18 ArtiOsScheduleTableInstance . . . . .	370
10.4.19 ArtiOsSpinlockClass . . . . .	374
10.4.20 ArtiOsSpinlockInstance . . . . .	376

10.4.21 ArtiOsStackClass . . . . .	379
10.4.22 ArtiOsStackInstance . . . . .	380
10.4.23 ArtiOsTaskClass . . . . .	384
10.4.24 ArtiOsTaskInstance . . . . .	387
10.5 Published Information . . . . .	393
11 Generation of the OS . . . . .	394
11.1 Read in configuration . . . . .	394
11.2 Consistency check . . . . .	394
11.3 Generating operating system . . . . .	397
12 Application Notes . . . . .	399
12.1 Hooks . . . . .	399
12.2 Providing Trusted Functions . . . . .	399
12.3 Software Components and OS-Applications . . . . .	401
12.4 Global Time Synchronization . . . . .	401
12.5 Working with FlexRay . . . . .	401
12.6 Migration from OIL to XML . . . . .	403
12.7 Debug support . . . . .	403
12.8 Integration hints for peripheral protection . . . . .	404
12.9 Termination of OS-Applications . . . . .	404
13 Outlook on Memory Protection Configuration . . . . .	406
13.1 Configuration Approach . . . . .	406
A Not applicable requirements . . . . .	407
B History of Constraints and Specification Items . . . . .	408
B.1 Differences between R24-11 and R25-11 . . . . .	408
B.1.1 Added Specification Items in R25-11 . . . . .	408
B.1.2 Changed Specification Items in R25-11 . . . . .	408
B.1.3 Deleted Specification Items in R25-11 . . . . .	408
B.1.4 Added Constraints in R25-11 . . . . .	408
B.1.5 Changed Constraints in R25-11 . . . . .	408
B.1.6 Deleted Constraints in R25-11 . . . . .	408
B.2 Differences between R23-11 and R24-11 . . . . .	409
B.2.1 Added Specification Items in R24-11 . . . . .	409
B.2.2 Changed Specification Items in R24-11 . . . . .	409
B.2.3 Deleted Specification Items in R24-11 . . . . .	409
B.2.4 Added Constraints in R24-11 . . . . .	409
B.2.5 Changed Constraints in R24-11 . . . . .	409
B.2.6 Deleted Constraints in R24-11 . . . . .	409
B.3 Differences between R22-11 and R23-11 . . . . .	410
B.3.1 Added Specification Items in R23-11 . . . . .	410
B.3.2 Changed Specification Items in R23-11 . . . . .	410
B.3.3 Deleted Specification Items in R23-11 . . . . .	410

B.3.4 Added Constraints in R23-11 . . . . .	410
B.3.5 Changed Constraints in R23-11 . . . . .	410
B.3.6 Deleted Constraints in R23-11 . . . . .	410

## 1 Introduction and functional overview

This document describes the essential requirements on the AUTOSAR Operating System to satisfy the top-level requirements presented in the AUTOSAR SRS [1].

In general, operating systems can be split up in different groups according to their characteristics, e.g. statically configured vs. dynamically managed. To classify the AUTOSAR OS, here are the basic features of the OS

- is configured and scaled statically
- is amenable to reasoning of real-time performance
- provides a priority-based scheduling policy
- provides protective functions (memory, timing etc.) at run-time
- is hostable on low-end controllers and without external resources

This feature set defines the type of OS commonly used in the current generation of automotive ECUs, except for Telematic/Infotainment systems. It is assumed that Telematic/Infotainment systems will continue to use proprietary OSs under the AUTOSAR framework (e.g. Windows CE, VxWorks, QNX, etc.). In the case where AUTOSAR components are needed to run on these proprietary OSs, the interfaces defined in this document should be provided as an Operating System Abstraction Layer (OSAL).

This document uses the industry standard [2] (ISO 17356-3) as the basis for the AUTOSAR OS. The reader should be familiar with this standard before reading this document.

This document describes extensions to, and restrictions of [2].

## 2 Acronyms and Abbreviations

The glossary below includes acronyms and abbreviations relevant to the AUTOSAR Operating System module that are not included in the [3, AUTOSAR glossary].

Abbreviation	Description
AR	AUTOSAR
IOC	Inter OS-Application communicator
LE	A locatable entity is a distinct piece of software that has the same effect regardless of which core it is located.
MC	Multi-Core
NMI	Non maskable interrupt
RTOS	Real Time Operating System
SLA	Software Layered Architecture
SWC	Software Component
SWFRT	Software FreeRunningTimer

**Table 2.1: Acronyms and abbreviations**

### 2.1 Glossary of Terms

Term	Definition	
Access Right	An indication that an object (e.g. Task, ISR, hook function) of an OS-Application has the permission of access or manipulation with respect to memory, OS services or (set of) OS objects.	
Cardinality	The number of items in a set.	
Counter	An operating system object that registers a count in ticks. There are two types of counters:	
	Hardware Counter	A Counter that is advanced by hardware (e.g. timer). The count value is maintained by the peripheral "in hardware".
	Software Counter	A Counter which is incremented by making the <code>IncrementCounter</code> API call (see [SWS_Os_00399]). The count value is maintained by the operating system "in software".
Deadline	The time at which a Task/Category 2 ISR must reach a certain point during its execution defined by system design relative to the stimulus that triggered activation. See figure 2.1	
Delay	<p>The number of ticks between two adjacent expiry points on a ScheduleTable. A pair of expiry points X and Y are said to be adjacent when:</p> <ul style="list-style-type: none"> <li>• There is no expiry point Z such that X.Offset &lt; Z.Offset &lt; Y.Offset. In this case the Delay = Y.Offset-X.Offset</li> <li>• X and Y are the Final Expiry Point and the Initial Expiry Point respectively. In this case Delay = (Duration-X.Offset)+Y.Offset</li> </ul> <p>When used in the text, Delay is a relative number of ticks measured from a specified expiry point. For example: X.Delay is the delay from X to the next expiry point.</p>	
Deviation	The minimum number of ticks between the current position on an explicitly synchronized ScheduleTable and the value of the synchronization count modulo the duration of the ScheduleTable.	
Duration	The number of ticks from a notional zero at which a ScheduleTable wraps.	





Term	Definition					
Execution Time	<p><b>Tasks:</b> The net time a Task spends in the RUNNING state without entering the SUSPENDED or WAITING state excluding all preemptions due to ISRs which preempt the Task. An extended Task executing the <code>WaitEvent</code> API call to wait on an Event which is already set notionally enters the WAITING state. For multiple activated basic Tasks the net time is per activation of a Task.</p> <p><b>ISRs:</b> The net time from the first to the last instruction of the user provided Category 2 interrupt handler excluding all preemptions due to higher priority ISRs executing in preference.</p> <p>Execution time includes the time spent in the error, pretask and posttask hooks and the time spent making OS service calls.</p>					
Execution Budget	Maximum permitted execution time for a Task/ISR.					
Expiry Point	<p>The offset on a ScheduleTable, measured from zero, at which the OS activates Tasks and/or sets Events.</p> <table border="1"> <tr> <td>Initial Expiry Point</td><td>The expiry point with the smallest offset</td></tr> <tr> <td>Final Expiry Point</td><td>The expiry point with the largest offset</td></tr> </table>		Initial Expiry Point	The expiry point with the smallest offset	Final Expiry Point	The expiry point with the largest offset
Initial Expiry Point	The expiry point with the smallest offset					
Final Expiry Point	The expiry point with the largest offset					
Hook Function	<p>A Hook function is implemented by the user and invoked by the operating system in the case of certain incidents. In order to react to these on system or application level, there are two kinds of hook functions</p> <table border="1"> <tr> <td>Application-specific</td><td>Hook functions within the scope of an individual OS-Application.</td></tr> <tr> <td>System-specific</td><td>Hook functions within the scope of the complete system (in general provided by the integrator).</td></tr> </table>		Application-specific	Hook functions within the scope of an individual OS-Application.	System-specific	Hook functions within the scope of the complete system (in general provided by the integrator).
Application-specific	Hook functions within the scope of an individual OS-Application.					
System-specific	Hook functions within the scope of the complete system (in general provided by the integrator).					
Initial Offset	The smallest expiry point offset on a ScheduleTable. This can be zero.					
Interarrival Time	<p><b>Basic Tasks:</b> The time between successively entering the READY state from the SUSPENDED state. Activation of a Task always represents a new arrival. This applies in the case of multiple activations, even if an existing instance of the Task is in the RUNNING or READY state.</p> <p><b>Extended Tasks:</b> The time between successively entering the READY state from the SUSPENDED or WAITING states. Setting an Event for a Task in the WAITING state represents a new arrival if the Task is waiting on the Event. Waiting for an Event in the RUNNING state which is already set represents a new arrival.</p> <p><b>ISRs:</b> The time between successive occurrences of an interrupt. See figure 2.1</p>					
Interrupt Lock Time	The time for which a Task/ISR executes with Category 1 interrupts disabled/suspended and/or Category 2 interrupts disabled/suspended .					
Interrupt Source Enable	The switch which enables a specific interrupt source in the hardware.					
Interrupt Vector Table	Conceptually, the interrupt vector table contains the mapping from hardware interrupt requests to (software) interrupt service routines. The real content of the Interrupt Vector Table is very hardware specific, e.g. it can contain the start addresses of the interrupt service routines.					
Final Delay	The difference between the Final Expiry Point offset and the duration on a ScheduleTable in ticks. This value defines the delay from the Final Expiry Point to the logical end of the ScheduleTable for single-shot and "nexted" ScheduleTables.					
Forced OS-Application Termination	The operating system frees all system objects, e.g. forcibly terminates Tasks, disables interrupts, etc., which are associated to the OS-Application. OS-Application and internal variables are potentially left in an undefined state.					
Forced Termination	The OS terminates the Task/Category 2 ISR and does "unlock" its held resources. For details see <a href="#">[SWS_Os_00108]</a> and <a href="#">[SWS_Os_00109]</a> .					
Linker File	File containing linking settings for the linker. The syntax of the linker file depends on the specific linker and, consequently, definitions are stored "linker-specific" in the linker file.					
Lock Budget	Maximum permitted Interrupt Lock Time or Resource Lock Time.					
Master core	A master core is a core from which the AUTOSAR system is bootstrapped.					
Memory Protection Unit	<p>A Memory Protection Unit (MPU) enables memory partitioning with individual protection attributes. This is distinct from a Memory Management Unit (MMU) that provides a mapping between virtual addresses and physical memory locations at runtime.</p> <p>Note that some devices may realize the functionality of an MPU in an MMU.</p>					
Mode	Describes the permissions available on a processor.					





Term	Definition	
	Privileged	In general, in "privileged mode" unrestricted access is available to memory as well as the underlying hardware.
	Non-privileged	In "non-privileged mode" access is restricted.
Modulus	The number of ticks required to complete a full wrap of an OSEK Counter. This is equal to <a href="#">OsCounterMaxAllowedValue +1</a> ticks of the Counter.	
OS-Application	A collection of OS objects	
	Trusted	An OS-Application that may be executed in privileged mode and may have unrestricted access to the API and hardware resources. Only trusted applications can provide trusted functions.
	Non-trusted	An OS-Application that is executed in non-privileged mode has restricted access to the API and hardware resources.
OS object	Object that belongs to a single OS-Application: Task, ISR, Alarm, Event, ScheduleTable, Resource, Trustedfunction, Counter, application-specific hook.	
OS Service	OS services are the API of the operating system.	
Protection Error	Systematic error in the software of an OS-Application.	
	Memory access violation	A protection error caused by access to an address in a manner for which no access right exists.
	Timing fault	A protection error that violates the timing protection.
	Illegal service	A protection error that violates the service protection, e.g. unauthorized call to OS service.
	Hardware exception	division by zero, illegal instruction etc.
Resource Lock Time	The time an OSEK Resource is held by a Task/ISR (excluding the preemptions of the Task/ISR by higher prior Tasks/ISRs).	
Response Time	The time between a Task/ISR being made ready to execute and generating a specified response. The time includes all preemptions. See figure <a href="#">2.1</a>	
Scalability Class	The features of the OS (e.g. Memory Protection or Timing Protection), described by this document, can be grouped together to customize the operating system to the needs of the application. There are 4 defined groups of features which are named scalability classes. For details see Chapter <a href="#">7.11</a>	
ScheduleTable	Encapsulation of a statically defined set of expiry points.	
Section	Part of an object file in which instructions or data are combined to form a unit (contiguous address space in memory allocated for data or code). A section in an object file (object file format) has a name and a size. From the linker perspective, two different sides can be distinguished:	
	Input section	memory section in an input object file of the linker.
	Output section	memory section in an output object file of the linker.
Set (of OS objects)	This document uses the term set, indicating a collection of the same type of OS objects, in the strict mathematical sense, i.e.: - a set contains zero or more OS objects (this means a set can be empty) - the OS objects in the set are unique (this means there cannot be duplicate OS objects in the set)	
Spinlock	A spinlock is a locking mechanism where the Task waits in a loop ( <i>spins</i> ) repeatedly checking for a shared variable to become a certain value. The value indicates whether the lock is free or not. In Multi-Core systems the comparison and changing of the variable typically requires an atomic operation. As the Task remains active but is not doing anything useful, a spinlock is a busy waiting mechanism	
Spinlock variable	A spinlock variable is a shared variable used by a spinlock to indicate whether a spinlock is free or occupied.	
Symbol	Address label that can be imported/used by software modules and resolved by the linker. The precise syntax of the labels is linker-specific. Here, these address labels are used to identify the start and end of memory sections.	
	Start symbol	Tags the start of a memory section
	End symbol	Tags the end of a memory section





Term	Definition	
Synchronization of ScheduleTables with a synchronization Counter	Synchronization with a synchronization Counter is achieved, if the expiry points of the Schedule Table are processed within an absolute deviation from the synchronization Counter that is smaller than or equal to a precision threshold.	
Synchronization Counter	The "Synchronization Counter", distinct from an OS Counter object, is an external Counter, external to the OS, against which expiry points of a ScheduleTable are synchronized	
Task	A Task is the object which executes (user) code and which is managed by the OS. E.g. the OS switches between different Tasks ( <i>schedules</i> ). There are 2 types of Tasks; for more details see [2].	
	Basic Task	A Task which cannot block by itself. This means that it cannot wait for (OS) Event(s).
	Extended Task	A Task which can block by itself and wait for (OS) Event(s).
Time Frame	The minimum inter-arrival time for a Task/ISR.	
Trustedfunction	A service provided by a trusted OS-Application that can be used by other OS-Applications (trusted or non-trusted).	
Worst case execution time (WCET)	The longest possible execution time.	
Write access	Storing a value in a register or memory location. All memory accesses that have the consequence of writing (e.g. reads that have the side effect of writing to a memory location) are treated as write accesses.	

Table 2.2: Glossary of terms




Figure 2.1: Definition of Timing Terminology

## 3 Related documentation

### 3.1 Input documents & related standards and norms

- [1] Requirements on Operating System  
AUTOSAR\_CP\_RS\_OS
- [2] ISO 17356-3: Road vehicles – Open interface for embedded automotive applications – Part 3: OSEK/VDX Operating System (OS)
- [3] Glossary  
AUTOSAR\_FO\_TR\_Glossary
- [4] General Specification of Basic Software Modules  
AUTOSAR\_CP\_SWS\_BSWGeneral
- [5] Virtual Functional Bus  
AUTOSAR\_CP\_TR\_VFB
- [6] General Requirements on Basic Software Modules  
AUTOSAR\_CP\_RS\_BSWGeneral
- [7] Aperiodic Task Scheduling for Hard Real Time System
- [8] Hard Real Time Computing Systems: Predictable Scheduling Algorithms and Applications
- [9] RT-Xen: Towards real-time hypervisor scheduling in Xen
- [10] ISO 17356-6: Road vehicles – Open interface for embedded automotive applications – Part 6: OSEK/VDX Implementation Language (OIL)
- [11] Specification of AUTOSAR Run-Time Interface  
AUTOSAR\_CP\_SWS\_ARTI
- [12] Software Component Template  
AUTOSAR\_CP\_TPS\_SoftwareComponentTemplate
- [13] Specification of Memory Mapping  
AUTOSAR\_CP\_SWS\_MemoryMapping

### 3.2 Related specification

AUTOSAR provides a *General Specification on Basic Software Modules* [4, SWS BSW General], which is also valid for AUTOSAR Operating System.

Thus, the specification [4, SWS BSW General] shall be considered as additional and required specification for AUTOSAR Operating System.

All OSEK OS related types, defines and functions can be found in [2]

## 4 Constraints and assumptions

### 4.1 Existing Standards

This document makes the following assumptions about the referenced related standards and norms:

- [2] provides a sufficiently flexible scheduling policy to schedule AUTOSAR systems.
- [2] is a mature specification and implementations are used in millions of ECUs worldwide.
- [2] does not provide enough support for isolating multi-source software components at runtime.
- [2] does not provide enough runtime support for demonstrating the absence of some classes of fault propagation in a safety-case.

### 4.2 Terminology

The specification uses the following operators when requirements specify multiple terms:

- **NOT** : negation of a single term e.g. NOT Weekend
- **AND** : conjunction of two terms e.g. Weekend AND Saturday
- **OR** : disjunction of two terms e.g. Monday OR Tuesday

A requirement comprising multiple terms is evaluated left to right. The precedence rules are:

- Highest Precedence **NOT**
- Lowest Precedence **AND OR**

The expression NOT X AND Y means (NOT X) AND (Y)

Where operators of the same precedence are used in the same sentence, commas are used to disambiguate. The expression X AND Y, OR Z means (X AND Y) OR Z.

### 4.3 Interaction with the RTE

The configuration of an AUTOSAR system [5] maps the *runnables* of a *software component* to (one or more) *Tasks* that are scheduled by the operating system. All runnables in a *Task* share the same protection boundary. In AUTOSAR, a software component must not include an interrupt handler. A software component is therefore implemented as runnables executing within the body of a *Task*, or set of *Tasks*, only.

Runnables get access to hardware-sourced data through the AUTOSAR RTE. The RTE provides the runtime interface between runnables and the basic software modules. The basic software modules also comprise a number of Tasks and ISRs that are scheduled by the operating system.

It is assumed that the software component templates and the description of the basic software modules provide sufficient information about the required runtime behavior to be able to specify the attributes of Tasks required to configure the OS.

## 4.4 Operating System Abstraction Layer (OSAL)

Systems that do not use the OS defined in AUTOSAR can provide a platform for the execution of AUTOSAR software components using an Operating System Abstraction Layer. The interface to the OSAL is exactly that defined for the AUTOSAR OS.

## 4.5 Multi-Core Hardware assumptions

There are currently several existing and suggested HW-architectures<sup>1</sup> for Multi-Core microprocessors. There is considerable variation in the features offered by these architectures. Therefore this section attempts to capture a common set of architectural features required for Multi-Core.

Hardware assumptions shall remain assumptions and shall not become official AUTOSAR requirements.

### 4.5.1 CPU Core features

1. More than one core on the same piece of silicon.
2. The HW offers a method that can be used by the SW to identify a core.
3. The hardware supports atomic read and atomic write operations for a fixed word length depending on the hardware.
4. The hardware supports some atomic Test-And-Set functionality or similar functionalities that can be used to build a critical section shared between cores. Additional atomic operations may exist.
5. The cores may have the same instruction set; at least a common basic instruction set is available on all cores. Core specific add-ons may exist, but they are not considered.
6. The cores have the same data representation. For example, the same size of integer, same byte and bit order, etc.

---

<sup>1</sup>In this context "architecture" encompasses: the connections between cores and memory, and to peripherals and how interrupts work.

7. If per-core caches exist, AUTOSAR requires support for RAM - cache coherency in HW or in SW. In software means that the cache-controller can be programmed by the SW in a way that it invalidates cache lines or excludes certain memory regions from caching.
8. In case of an exception (such as an illegal memory reference or divide by zero) the exception occurs on the core that introduced the exception.
9. For notification purposes, it is possible to trigger an interrupt/trap on any core.

#### 4.5.2 Memory features

- Shared RAM is available to all cores; at least all cores can share a substantial part of the memory.
- Flash shall be shared between all cores at least. However, performance can be improved if Flash/RAM can be partitioned so that there are separate pathways from cores to Flash.
- A single address space is assumed, at least in the shared parts of the memory address space.
- The AUTOSAR Multi-Core architecture shall be capable to run on systems that do and do not support memory protection. If memory protection exists, all cores are covered by a hardware-based memory protection.

#### 4.5.3 Multi-Core Limitations

- In AUTOSAR R4.0, it is not supported to activate additional cores under control of AUTOSAR after the Operating System was started.
- The scheduling algorithm does not assign Tasks dynamically to cores.
- The AUTOSAR OS Resource algorithm is not supported across cores. Resources can be used locally, between Tasks that are bound to the same core but not between Tasks/ISRs which are bound to different cores.

### 4.6 Limitations

#### 4.6.1 Hardware

The core AUTOSAR operating system assumes free access to hardware resources, which are managed by the OS itself. This includes, but is not limited to, the following hardware:

- interrupt control registers

- processor status words
- stack pointer(s)

Specific (extended) features of the core operating system extend the requirements on hardware resource. The following list outlines the features that have requirements on the hardware. Systems that do not use these OS features do not have these hardware requirements.

- Memory Protection: A hardware memory protection unit is required. All memory accesses that have the consequence of writing (e.g. reads that have the side effect of writing to a memory location) shall be treated as writes.
- Time Protection: Timer Hardware for monitoring execution times and arrival rates.
- *Privileged* and *non-privileged* modes on the MCU: to protect the OS against internal corruption caused by writes to OS controlled registers. This mode must not allow OS-Applications to circumvent protection (e.g. write registers which govern memory protection, write to processor status word etc.). The privileged mode must be under full control of the protected OS which uses the mode internally and to transfer control back and forth from a non-trusted OS-Application to a trusted OS-Application. The microprocessor must support a controlled means which moves a processor into this privileged mode.
- Local/Global Time Synchronization: A global time source is needed.

In general hardware failures in the processor are not detected by the operating system. In the event of hardware failure, correct operation of the OS cannot be guaranteed.

The resources managed by a specific OS implementation have to be defined within the appropriate configuration file of the OS.

#### 4.6.2 Programming Language

The API of the operating system is defined as C function calls or macros. If other languages are used, they must adapt to the C interface.

#### 4.6.3 Miscellaneous

The operating system does not provide services for dynamic memory management.

### 4.7 Applicability to car domains

The operating system has the same design constraints regarding size and scalability under which [2] was designed. The immediate domain of applicability is therefore currently body, chassis and power train ECUs. However, there is no reason that the OS cannot be used to implement ECUs for infotainment applications.

## 5 Dependencies to other modules

- It is assumed that the operating system may use timer units directly to drive counters.
- If the user needs to drive scheduling directly from global time, then a global time interrupt is required.
- If the user needs to synchronize the processing of a `ScheduleTable` to a global time, the operating system needs to be told the global time using the `Sync-ScheduleTable` service.
- The IOC described in this document provides communication between OS-Applications. The IOC generation is based on configuration information which is generated by the RTE generator. On the other hand the RTE uses functions generated by the IOC to transmit data.
- The Operating System depends on the definition of partitions and cores in the virtual module EcuC if OS-Applications are used.

### 5.1 File structure

#### 5.1.1 Code file structure

The code file structure of the Operating System module is not fixed, besides the requirements in the [6, General SRS].

#### 5.1.2 Header file structure

The IOC generator generates an additional header file `loc.h`. Users of the `loc.h` shall include the `loc.h` file. If an implementation of the IOC requires additional header files, it is free to include them. The header files are self-contained, that means they will include all other header files, which they require.

#### 5.1.3 ARTI File Structure

To support ARTI based debugging and tracing, all source files of the OS module with ARTI hook macros shall include an "`Os_Arti.h`" file. This file (along with the corresponding `Arti.h` and `Arti.c` file) will be provided by the ARTI hook implementer, i.e. the tracing tool. When building the final executable, the linker will pull in the compiled `Arti.c` file, too.

The usage of the ARTI hook macros is configurable. If the OS is configured to not use ARTI, the inclusion of "`Os_Arti.h`" may be omitted, and the ARTI hooks macros may be expanded to empty macros (*nothing*).

## 6 Requirements Tracing

The following tables reference the requirements specified in [6, SRS BSW General] and [1, SRS OS] and links to the fulfillment of these. Please note that if column “Satisfied by” is empty for a specific requirement this means that this requirement is not fulfilled by this document.

Requirement	Description	Satisfied by
[RS_ARTIFO_00014]	ARTI Hooks shall be implemented with minimal intrusion	[SWS_Os_00836] [SWS_Os_00837]
[RS_ARTIFO_00015]	ARTI Hooks shall follow a fixed format	[SWS_Os_00839] [SWS_Os_00841] [SWS_Os_00842] [SWS_Os_00844] [SWS_Os_00846] [SWS_Os_00857]
[RS_Arti_00001]	The ARTI template shall support core specific ARTI additions	[SWS_Os_00859]
[RS_Arti_00002]	The ARTI template shall support a parameter for the current application	[SWS_Os_00859]
[RS_Arti_00003]	The ARTI template shall support a parameter for the current task	[SWS_Os_00859]
[RS_Arti_00004]	The ARTI template shall support a parameter for the last error	[SWS_Os_00859]
[RS_Arti_00005]	The ARTI template shall support OS specific ARTI additions	[SWS_Os_00859]
[RS_Arti_00007]	The ARTI template shall support task specific ARTI additions	[SWS_Os_00859]
[RS_Arti_00009]	The ARTI description shall include a core class definition.	[SWS_Os_00859]
[RS_Arti_00011]	The ARTI description for a core class shall include a "current task" reference to the interpret the parameter value	[SWS_Os_00859]
[RS_Arti_00012]	The ARTI description shall include instance definitions for all cores of the ECU.	[SWS_Os_00859]
[RS_Arti_00014]	The ARTI description for a core instance shall include a "current task" reference to evaluate the parameter value	[SWS_Os_00859]
[RS_Arti_00016]	The ARTI description shall include an OS class definition.	[SWS_Os_00859]
[RS_Arti_00018]	The ARTI description shall include an instance definition for the OS of the ECU.	[SWS_Os_00859]
[RS_Arti_00022]	The ARTI description shall include a task class definition.	[SWS_Os_00859]
[RS_Arti_00023]	The ARTI description shall include instance definitions for all tasks of the ECU.	[SWS_Os_00859]
[RS_Arti_00029]	AUTOSAR shall support recording timing events of application states	[SWS_Os_00838]
[RS_Arti_00030]	AUTOSAR shall support recording timing events of tasks	[SWS_Os_00840] [SWS_Os_00864] [SWS_Os_00865] [SWS_Os_00866] [SWS_Os_00867] [SWS_Os_00868]





Requirement	Description	Satisfied by
[RS_Arti_00031]	AUTOSAR shall support recording timing events of category 2 interrupt states	[SWS_Os_00849]
[RS_Arti_00032]	AUTOSAR shall support recording timing events of service calls	[SWS_Os_00843]
[RS_Arti_00033]	AUTOSAR shall support recording timing events of spinlock states	[SWS_Os_00845]
[RS_Arti_00034]	AUTOSAR shall support recording timing events of protection hooks	[SWS_Os_00856] [SWS_Os_00857]
[SRS_BSW_00101]	The Basic Software Module shall be able to initialize variables and hardware in a separate initialization function	[SWS_Os_00374]
[SRS_BSW_00159]	All modules of the AUTOSAR Basic Software shall support a tool based configuration	[SWS_Os_00172] [SWS_Os_00370] [SWS_Os_00393] [SWS_Os_00850]
[SRS_BSW_00167]	All AUTOSAR Basic Software Modules shall provide configuration rules and constraints to enable plausibility checks	[SWS_Os_00045] [SWS_Os_00050] [SWS_Os_00173] [SWS_Os_00177] [SWS_Os_00179] [SWS_Os_00303] [SWS_Os_00311] [SWS_Os_00320] [SWS_Os_00328] [SWS_Os_00343] [SWS_Os_00344] [SWS_Os_00361] [SWS_Os_00461] [SWS_Os_00562]
[SRS_BSW_00323]	All AUTOSAR Basic Software Modules shall check passed API parameters for validity	[SWS_Os_00100] [SWS_Os_00268] [SWS_Os_00270] [SWS_Os_00274] [SWS_Os_00275] [SWS_Os_00276] [SWS_Os_00277] [SWS_Os_00279] [SWS_Os_00280] [SWS_Os_00282] [SWS_Os_00283] [SWS_Os_00285] [SWS_Os_00292] [SWS_Os_00293] [SWS_Os_00304] [SWS_Os_00309] [SWS_Os_00330] [SWS_Os_00332] [SWS_Os_00348] [SWS_Os_00349] [SWS_Os_00350] [SWS_Os_00368] [SWS_Os_00369] [SWS_Os_00376] [SWS_Os_00381] [SWS_Os_00387] [SWS_Os_00388] [SWS_Os_00391] [SWS_Os_00452] [SWS_Os_00454] [SWS_Os_00455] [SWS_Os_00456] [SWS_Os_00458] [SWS_Os_00483] [SWS_Os_00484] [SWS_Os_00493] [SWS_Os_00494] [SWS_Os_00495] [SWS_Os_00507] [SWS_Os_00509] [SWS_Os_00566]
[SRS_BSW_00336]	Basic SW module shall be able to shutdown	[SWS_Os_00001] [SWS_Os_00713]
[SRS_BSW_00345]	BSW Modules shall support pre-compile configuration	[SWS_Os_00001]
[SRS_BSW_00351]	Encapsulation of compiler specific methods to map objects	[SWS_Os_00815]
[SRS_BSW_00459]	It shall be possible to concurrently execute a service offered by a BSW module in different partitions	[SWS_Os_00589]
[SRS_BSW_00480]	Null pointer errors shall follow a naming rule	[SWS_Os_91025]





Requirement	Description	Satisfied by
[SRS_Os_00097]	The OS shall provide an API that is backward compatible to the API of OSEK OS	[SWS_Os_00001] [SWS_Os_00071] [SWS_Os_00239] [SWS_Os_00367] [SWS_Os_00424] [SWS_Os_00425] [SWS_Os_00439] [SWS_Os_00476] [SWS_Os_00539] [SWS_Os_00541] [SWS_Os_00854] [SWS_Os_00855] [SWS_Os_91034]
[SRS_Os_00098]	The Operating System shall provide statically configurable schedule tables based on time tables as an optional service	[SWS_Os_00002] [SWS_Os_00006] [SWS_Os_00007] [SWS_Os_00009] [SWS_Os_00194] [SWS_Os_00278] [SWS_Os_00281] [SWS_Os_00289] [SWS_Os_00291] [SWS_Os_00347] [SWS_Os_00351] [SWS_Os_00353] [SWS_Os_00358] [SWS_Os_00401] [SWS_Os_00402] [SWS_Os_00403] [SWS_Os_00404] [SWS_Os_00407] [SWS_Os_00408] [SWS_Os_00409] [SWS_Os_00410] [SWS_Os_00411] [SWS_Os_00412] [SWS_Os_00413] [SWS_Os_00427] [SWS_Os_00428] [SWS_Os_00442] [SWS_Os_00443] [SWS_Os_00444] [SWS_Os_00510] [SWS_Os_00783] [SWS_Os_00784] [SWS_Os_00785] [SWS_Os_00876]
[SRS_Os_00099]	The Operating System shall provide a mechanism which allows switching between different schedule tables	[SWS_Os_00191] [SWS_Os_00284] [SWS_Os_00324] [SWS_Os_00414] [SWS_Os_00453]
[SRS_Os_11000]	The OS may offer support to protect the memory sections of an OS-Application against read accesses by all other OS-Applications	[SWS_Os_00026] [SWS_Os_00027]
[SRS_Os_11001]	The OS shall provide partitions which allow for fault isolation capabilities	[SWS_Os_00016] [SWS_Os_00054] [SWS_Os_00056] [SWS_Os_00058] [SWS_Os_00060] [SWS_Os_00085] [SWS_Os_00097] [SWS_Os_00112] [SWS_Os_00198] [SWS_Os_00209] [SWS_Os_00211] [SWS_Os_00225] [SWS_Os_00226] [SWS_Os_00236] [SWS_Os_00237] [SWS_Os_00261] [SWS_Os_00262] [SWS_Os_00265] [SWS_Os_00266] [SWS_Os_00271] [SWS_Os_00272] [SWS_Os_00273] [SWS_Os_00308] [SWS_Os_00312] [SWS_Os_00313] [SWS_Os_00314] [SWS_Os_00364] [SWS_Os_00423] [SWS_Os_00445] [SWS_Os_00446] [SWS_Os_00449] [SWS_Os_00450] [SWS_Os_00451] [SWS_Os_00464] [SWS_Os_00496] [SWS_Os_00499] [SWS_Os_00500] [SWS_Os_00504] [SWS_Os_00512] [SWS_Os_00513] [SWS_Os_00540] [SWS_Os_00772] [SWS_Os_00773] [SWS_Os_00774] [SWS_Os_00775] [SWS_Os_00776] [SWS_Os_00777] [SWS_Os_00778] [SWS_Os_00779] [SWS_Os_00780] [SWS_Os_00781] [SWS_Os_00787] [SWS_Os_00788] [SWS_Os_00797] [SWS_Os_00798] [SWS_Os_00799] [SWS_Os_00861] [SWS_Os_91000] [SWS_Os_91007]





Requirement	Description	Satisfied by
[SRS_Os_11002]	The operating system shall provide the ability to synchronize the processing of schedule tables with a global system time base	<a href="#">[SWS_Os_00013]</a> <a href="#">[SWS_Os_00199]</a> <a href="#">[SWS_Os_00201]</a> <a href="#">[SWS_Os_00206]</a> <a href="#">[SWS_Os_00227]</a> <a href="#">[SWS_Os_00290]</a> <a href="#">[SWS_Os_00300]</a> <a href="#">[SWS_Os_00323]</a> <a href="#">[SWS_Os_00354]</a> <a href="#">[SWS_Os_00362]</a> <a href="#">[SWS_Os_00389]</a> <a href="#">[SWS_Os_00415]</a> <a href="#">[SWS_Os_00416]</a> <a href="#">[SWS_Os_00417]</a> <a href="#">[SWS_Os_00418]</a> <a href="#">[SWS_Os_00419]</a> <a href="#">[SWS_Os_00420]</a> <a href="#">[SWS_Os_00421]</a> <a href="#">[SWS_Os_00422]</a> <a href="#">[SWS_Os_00429]</a> <a href="#">[SWS_Os_00430]</a> <a href="#">[SWS_Os_00431]</a> <a href="#">[SWS_Os_00435]</a> <a href="#">[SWS_Os_00436]</a> <a href="#">[SWS_Os_00437]</a> <a href="#">[SWS_Os_00438]</a> <a href="#">[SWS_Os_00440]</a> <a href="#">[SWS_Os_00457]</a> <a href="#">[SWS_Os_00462]</a> <a href="#">[SWS_Os_00463]</a> <a href="#">[SWS_Os_00505]</a> <a href="#">[SWS_Os_00559]</a>
[SRS_Os_11003]	The operating system shall be able to monitor stack usage and check for a stack overflow on a per executable object basis	<a href="#">[SWS_Os_00067]</a> <a href="#">[SWS_Os_00068]</a> <a href="#">[SWS_Os_00396]</a>
[SRS_Os_11005]	The operating system shall prevent an OS-Application from modifying the memory of other OS-Applications	<a href="#">[SWS_Os_00083]</a> <a href="#">[SWS_Os_00195]</a> <a href="#">[SWS_Os_00207]</a> <a href="#">[SWS_Os_00208]</a> <a href="#">[SWS_Os_00267]</a> <a href="#">[SWS_Os_00269]</a> <a href="#">[SWS_Os_00355]</a> <a href="#">[SWS_Os_00356]</a> <a href="#">[SWS_Os_00795]</a> <a href="#">[SWS_Os_00806]</a> <a href="#">[SWS_Os_00807]</a> <a href="#">[SWS_Os_91010]</a> <a href="#">[SWS_Os_91011]</a> <a href="#">[SWS_Os_91012]</a> <a href="#">[SWS_Os_91013]</a> <a href="#">[SWS_Os_91014]</a> <a href="#">[SWS_Os_91015]</a> <a href="#">[SWS_Os_91016]</a> <a href="#">[SWS_Os_91017]</a> <a href="#">[SWS_Os_91018]</a>
[SRS_Os_11006]	The operating system shall allow tasks and ISRs within an OS-Application to exchange data	<a href="#">[SWS_Os_00086]</a> <a href="#">[SWS_Os_00087]</a> <a href="#">[SWS_Os_00196]</a>
[SRS_Os_11007]	The operating system shall allow OS-Applications to execute shared code	<a href="#">[SWS_Os_00081]</a>
[SRS_Os_11008]	Timing Fault Detection and Prevention of Propagation	<a href="#">[SWS_Os_00028]</a> <a href="#">[SWS_Os_00033]</a> <a href="#">[SWS_Os_00037]</a> <a href="#">[SWS_Os_00048]</a> <a href="#">[SWS_Os_00064]</a> <a href="#">[SWS_Os_00089]</a> <a href="#">[SWS_Os_00397]</a> <a href="#">[SWS_Os_00465]</a> <a href="#">[SWS_Os_00466]</a> <a href="#">[SWS_Os_00467]</a> <a href="#">[SWS_Os_00469]</a> <a href="#">[SWS_Os_00470]</a> <a href="#">[SWS_Os_00471]</a> <a href="#">[SWS_Os_00472]</a> <a href="#">[SWS_Os_00473]</a> <a href="#">[SWS_Os_00474]</a> <a href="#">[SWS_Os_00475]</a> <a href="#">[SWS_Os_00863]</a> <a href="#">[SWS_Os_00871]</a>
[SRS_Os_11009]	The operating system shall prevent the corruption of the OS by any call of a system service	<a href="#">[SWS_Os_00051]</a> <a href="#">[SWS_Os_00052]</a> <a href="#">[SWS_Os_00069]</a> <a href="#">[SWS_Os_00070]</a> <a href="#">[SWS_Os_00088]</a> <a href="#">[SWS_Os_00092]</a> <a href="#">[SWS_Os_00093]</a>
[SRS_Os_11010]	The operating system shall prevent an OS-Application modifying OS objects that are not owned by that OS-Application	<a href="#">[SWS_Os_00017]</a> <a href="#">[SWS_Os_00056]</a> <a href="#">[SWS_Os_00256]</a> <a href="#">[SWS_Os_00448]</a>





Requirement	Description	Satisfied by
[SRS_Os_11011]	The OS shall protect itself against OS-Applications attempting to modify control registers directly which are managed by the OS	[SWS_Os_00096] [SWS_Os_00245] [SWS_Os_00808] [SWS_Os_00809] [SWS_Os_00810] [SWS_Os_00811] [SWS_Os_00812] [SWS_Os_00813] [SWS_Os_00814] [SWS_Os_91019] [SWS_Os_91020] [SWS_Os_91021]
[SRS_Os_11012]	The OS shall provide scalability for its protection features	[SWS_Os_00240] [SWS_Os_00241]
[SRS_Os_11013]	The OS shall be capable of notifying the occurrence of a protection error at runtime	[SWS_Os_00033] [SWS_Os_00037] [SWS_Os_00044] [SWS_Os_00051] [SWS_Os_00056] [SWS_Os_00064] [SWS_Os_00068] [SWS_Os_00070] [SWS_Os_00088] [SWS_Os_00093] [SWS_Os_00210] [SWS_Os_00246] [SWS_Os_00538] [SWS_Os_00860] [SWS_Os_00871]
[SRS_Os_11014]	In case of a protection error, the OS shall provide an error reaction on OS-, OS-Application and task/ ISR-level	[SWS_Os_00033] [SWS_Os_00037] [SWS_Os_00106] [SWS_Os_00107] [SWS_Os_00108] [SWS_Os_00109] [SWS_Os_00110] [SWS_Os_00243] [SWS_Os_00244] [SWS_Os_00506] [SWS_Os_00553] [SWS_Os_00556] [SWS_Os_00863]
[SRS_Os_11016]	The OS implementation shall offer scalability which is configurable by a generation tool	[SWS_Os_00240] [SWS_Os_00241] [SWS_Os_00242] [SWS_Os_00327] [SWS_Os_00514] [SWS_Os_00515] [SWS_Os_00516] [SWS_Os_00517] [SWS_Os_00518] [SWS_Os_00519] [SWS_Os_00520] [SWS_Os_00521] [SWS_Os_00522] [SWS_Os_00523] [SWS_Os_00524] [SWS_Os_00525] [SWS_Os_00526] [SWS_Os_00527] [SWS_Os_00528] [SWS_Os_00530] [SWS_Os_00532] [SWS_Os_00534] [SWS_Os_00536] [SWS_Os_00537] [SWS_Os_00542] [SWS_Os_00543] [SWS_Os_00544] [SWS_Os_00545] [SWS_Os_00763] [SWS_Os_00764] [SWS_Os_00800]
[SRS_Os_11018]	The OS shall provide interrupt mask functions	[SWS_Os_00299]
[SRS_Os_11019]	The AUTOSAR OS generation tool shall create the interrupt vector table	[SWS_Os_00336]
[SRS_Os_11020]	The OS shall provide a standard interface to tick a software counter	[SWS_Os_00286] [SWS_Os_00321] [SWS_Os_00529] [SWS_Os_00531]
[SRS_Os_11021]	The OS shall provide a mechanism to cascade multiple software counters from a single hardware counter.	[SWS_Os_00301]
[SRS_Os_11022]	The OS shall provide a mechanism to terminate OS-Application	[SWS_Os_00258] [SWS_Os_00287] [SWS_Os_00447] [SWS_Os_00502] [SWS_Os_00535] [SWS_Os_00554]
[SRS_Os_12001]	The OS shall create an ARTI module description file	[SWS_Os_00858]
[SRS_Os_12002]	The OS code shall incorporate ARTI hooks	[SWS_Os_00836] [SWS_Os_00837]
[SRS_Os_12003]	ARTI module description file shall support all ORTI containers	[SWS_Os_00829]





Requirement	Description	Satisfied by
[SRS_Os_13000]	Deferrable Server	[SWS_Os_00869] [SWS_Os_00870] [SWS_Os_00872] [SWS_Os_00873]
[SRS_Os_80001]	The OS shall be able to manage multiple closely coupled CPU Cores	[SWS_Os_00568] [SWS_Os_00569] [SWS_Os_00579] [SWS_Os_00583] [SWS_Os_00596] [SWS_Os_00600] [SWS_Os_00606] [SWS_Os_00616] [SWS_Os_00627] [SWS_Os_00628] [SWS_Os_00672] [SWS_Os_00673] [SWS_Os_00674] [SWS_Os_00675]
[SRS_Os_80003]	The multi core extension shall provide the same degree of predictability as the single core	[SWS_Os_00570] [SWS_Os_00571] [SWS_Os_00573]
[SRS_Os_80005]	OsApplications and as a result TASKS and OsISRs shall be assigned statically to cores	[SWS_Os_00570] [SWS_Os_00571] [SWS_Os_00572] [SWS_Os_00573] [SWS_Os_00667] [SWS_Os_00826] [SWS_Os_CONSTR_00001] [SWS_Os_CONSTR_00002]
[SRS_Os_80006]	Initialization/Start-up of the system shall be synchronized	[SWS_Os_00572] [SWS_Os_00574] [SWS_Os_00575] [SWS_Os_00576] [SWS_Os_00577] [SWS_Os_00578] [SWS_Os_00579] [SWS_Os_00580] [SWS_Os_00581] [SWS_Os_00582] [SWS_Os_00607] [SWS_Os_00608] [SWS_Os_00609] [SWS_Os_00610] [SWS_Os_00625] [SWS_Os_00668] [SWS_Os_00669] [SWS_Os_00670] [SWS_Os_00676] [SWS_Os_00677] [SWS_Os_00678] [SWS_Os_00679] [SWS_Os_00681]
[SRS_Os_80007]	Shutdown procedure shall be triggered by any core	[SWS_Os_00586] [SWS_Os_00587] [SWS_Os_00588] [SWS_Os_00616] [SWS_Os_00617] [SWS_Os_00621] [SWS_Os_00713] [SWS_Os_00714] [SWS_Os_00715] [SWS_Os_00716] [SWS_Os_00762]
[SRS_Os_80008]	It shall be a common OS configuration across multiple cores	[SWS_Os_00567] [SWS_Os_00582] [SWS_Os_00851] [SWS_Os_00852] [SWS_Os_00853]
[SRS_Os_80011]	The number of cores that the operating system manages shall be configurable offline	[SWS_Os_00583] [SWS_Os_00790] [SWS_Os_00825] [SWS_Os_00862] [SWS_Os_91002]
[SRS_Os_80013]	The behaviour of services shall be identical to single core systems	[SWS_Os_00569] [SWS_Os_00589] [SWS_Os_00590] [SWS_Os_00591] [SWS_Os_00592] [SWS_Os_00593] [SWS_Os_00594] [SWS_Os_00595] [SWS_Os_00607] [SWS_Os_00618] [SWS_Os_00619] [SWS_Os_00623] [SWS_Os_00629] [SWS_Os_00630] [SWS_Os_00631] [SWS_Os_00635] [SWS_Os_00636] [SWS_Os_00637] [SWS_Os_00638] [SWS_Os_00639] [SWS_Os_00640] [SWS_Os_00643] [SWS_Os_00645] [SWS_Os_00646] [SWS_Os_00647] [SWS_Os_00663] [SWS_Os_00664] [SWS_Os_00665]





Requirement	Description	Satisfied by
[SRS_Os_80015]	The MC extensions shall provide a mechanism to activate tasks on different cores	[SWS_Os_00596] [SWS_Os_00598] [SWS_Os_00599] [SWS_Os_00600] [SWS_Os_00816] [SWS_Os_00818] [SWS_Os_00819] [SWS_Os_91022] [SWS_Os_91023]
[SRS_Os_80016]	Event mechanism shall work across cores	[SWS_Os_00602] [SWS_Os_00604] [SWS_Os_00605] [SWS_Os_00817]
[SRS_Os_80018]	A method to synchronize tasks on more than one core shall be provided	[SWS_Os_00632] [SWS_Os_00633] [SWS_Os_00634] [SWS_Os_00641] [SWS_Os_00642] [SWS_Os_00644] [SWS_Os_00648] [SWS_Os_00649] [SWS_Os_00650] [SWS_Os_00652] [SWS_Os_00653] [SWS_Os_00654] [SWS_Os_00655] [SWS_Os_00656] [SWS_Os_00657] [SWS_Os_00658] [SWS_Os_00659] [SWS_Os_00660] [SWS_Os_00661]
[SRS_Os_80020]	A data exchange mechanism shall be provided	[SWS_Os_00611] [SWS_Os_00671] [SWS_Os_00718] [SWS_Os_00719] [SWS_Os_00720] [SWS_Os_00721] [SWS_Os_00722] [SWS_Os_00723] [SWS_Os_00724] [SWS_Os_00725] [SWS_Os_00726] [SWS_Os_00727] [SWS_Os_00728] [SWS_Os_00729] [SWS_Os_00730] [SWS_Os_00731] [SWS_Os_00732] [SWS_Os_00733] [SWS_Os_00734] [SWS_Os_00735] [SWS_Os_00736] [SWS_Os_00737] [SWS_Os_00738] [SWS_Os_00739] [SWS_Os_00740] [SWS_Os_00741] [SWS_Os_00742] [SWS_Os_00743] [SWS_Os_00744] [SWS_Os_00745] [SWS_Os_00746] [SWS_Os_00747] [SWS_Os_00748] [SWS_Os_00749] [SWS_Os_00750] [SWS_Os_00751] [SWS_Os_00752] [SWS_Os_00753] [SWS_Os_00754] [SWS_Os_00755] [SWS_Os_00756] [SWS_Os_00757] [SWS_Os_00758] [SWS_Os_00759] [SWS_Os_00760] [SWS_Os_00761] [SWS_Os_00803] [SWS_Os_00804] [SWS_Os_00805] [SWS_Os_00820] [SWS_Os_00822] [SWS_Os_00824] [SWS_Os_00827] [SWS_Os_00828] [SWS_Os_00830] [SWS_Os_00831] [SWS_Os_00832] [SWS_Os_00833] [SWS_Os_00834] [SWS_Os_00835] [SWS_Os_91003] [SWS_Os_91004] [SWS_Os_91005] [SWS_Os_91006] [SWS_Os_91026]





Requirement	Description	Satisfied by
[SRS_Os_80021]	The MC extension of the AUTOSAR environment shall support a mutual exclusion mechanism between cores that shall not cause deadlocks	<a href="#">[SWS_Os_00612]</a> <a href="#">[SWS_Os_00613]</a> <a href="#">[SWS_Os_00614]</a> <a href="#">[SWS_Os_00615]</a> <a href="#">[SWS_Os_00620]</a> <a href="#">[SWS_Os_00622]</a> <a href="#">[SWS_Os_00624]</a> <a href="#">[SWS_Os_00648]</a> <a href="#">[SWS_Os_00649]</a> <a href="#">[SWS_Os_00650]</a> <a href="#">[SWS_Os_00651]</a> <a href="#">[SWS_Os_00652]</a> <a href="#">[SWS_Os_00653]</a> <a href="#">[SWS_Os_00654]</a> <a href="#">[SWS_Os_00655]</a> <a href="#">[SWS_Os_00656]</a> <a href="#">[SWS_Os_00657]</a> <a href="#">[SWS_Os_00658]</a> <a href="#">[SWS_Os_00659]</a> <a href="#">[SWS_Os_00660]</a> <a href="#">[SWS_Os_00661]</a> <a href="#">[SWS_Os_00662]</a> <a href="#">[SWS_Os_00666]</a> <a href="#">[SWS_Os_00686]</a> <a href="#">[SWS_Os_00687]</a> <a href="#">[SWS_Os_00688]</a> <a href="#">[SWS_Os_00689]</a> <a href="#">[SWS_Os_00690]</a> <a href="#">[SWS_Os_00691]</a> <a href="#">[SWS_Os_00692]</a> <a href="#">[SWS_Os_00693]</a> <a href="#">[SWS_Os_00694]</a> <a href="#">[SWS_Os_00695]</a> <a href="#">[SWS_Os_00696]</a> <a href="#">[SWS_Os_00697]</a> <a href="#">[SWS_Os_00698]</a> <a href="#">[SWS_Os_00699]</a> <a href="#">[SWS_Os_00700]</a> <a href="#">[SWS_Os_00701]</a> <a href="#">[SWS_Os_00703]</a> <a href="#">[SWS_Os_00704]</a> <a href="#">[SWS_Os_00705]</a> <a href="#">[SWS_Os_00706]</a> <a href="#">[SWS_Os_00707]</a> <a href="#">[SWS_Os_00708]</a> <a href="#">[SWS_Os_00709]</a> <a href="#">[SWS_Os_00710]</a> <a href="#">[SWS_Os_00711]</a> <a href="#">[SWS_Os_00712]</a> <a href="#">[SWS_Os_00791]</a> <a href="#">[SWS_Os_00792]</a> <a href="#">[SWS_Os_00801]</a>

**Table 6.1: Requirements Tracing**

## 7 Functional specification

### 7.1 Core OS

#### 7.1.1 Background & Rationale

The OSEK/VDX Operating System [2] is widely used in the automotive industry and has been proven in use in all classes of ECUs found in modern vehicles. The concepts that OSEK OS has introduced are widely understood and the automotive industry has many years of collective experience in engineering OSEK OS based systems.

OSEK OS is an event-triggered operating system. This provides high flexibility in the design and maintenance of AUTOSAR based systems. Event triggering gives freedom for the selection of the events to drive scheduling at runtime, for example angular rotation, local time source, global time source, error occurrence etc.

For these reasons the core functionality of the AUTOSAR OS shall be based upon the OSEK OS. In particular OSEK OS provides the following features to support concepts in AUTOSAR:

- fixed priority-based scheduling
- facilities for handling interrupts
- only interrupts with higher priority than Tasks
- some protection against incorrect use of OS services
- a startup interface through `StartOS` and the `StartupHook`
- a shutdown interface through `ShutdownOS` and the `ShutdownHook`

OSEK OS provides many features in addition to these. Readers should consult the specification [2] for details.

Basing AUTOSAR OS on OSEK OS means that legacy applications will be backward compatible - i.e. applications written for OSEK OS will run on AUTOSAR OS. However, some of the features introduced by AUTOSAR OS require restrictions on the use of existing OSEK OS features or extend existing OSEK OS features.

#### 7.1.2 Requirements

##### **[SWS\_Os\_00001]**

*Upstream requirements:* [SRS\\_Os\\_00097](#), [SRS\\_BSW\\_00336](#), [SRS\\_BSW\\_00345](#)

[The Operating System module shall provide an API that is backward compatible with the OSEK OS API [2].]

### 7.1.2.1 Restrictions on OSEK OS

It is too inefficient to achieve timing and memory protection for alarm callbacks. They are therefore not allowed in specific scalability classes ([[SWS\\_Os\\_00242](#)])

#### [[SWS\\_Os\\_00242](#)]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

[The Operating System module shall only allow Alarm Callbacks in Scalability Class 1.]

OSEK OS is required to provide functionality to handle inter-task (internal) communication according to the OSEK COM specification when internal communication only is required in the system. In AUTOSAR, internal communication is provided by the AUTOSAR RTE or by AUTOSAR COM at least one of which will be present for all AUTOSAR ECUs.

AUTOSAR OS, when used in an AUTOSAR system, therefore does not need to support internal communication.

An OSEK OS must implement internal communication if the symbol `LOCALMESSAGESONLY` is defined. AUTOSAR OS can deprecate the need to implement OSEK COM functionality and maintain compatibility with OSEK suite of specifications by ensuring that AUTOSAR OS always exists in an environment where `LOCALMESSAGESONLY` is undefined.

OSEK OS has one special Resource called `RES_SCHEDULER`. This Resource has 2 specific aspects:

1. It is always present in the system, even if it is not configured. This means that the `RES_SCHEDULER` is always known by the OS.
2. It has always the highest Task priority. This means a Task which allocates this Resource cannot be preempted by other Tasks.

Since special cases are always hard to handle (e.g. in this case with respect to timing protection) AUTOSAR OS handles `RES_SCHEDULER` as any other Resource. This means that the `RES_SCHEDULER` is not automatically created.

Note that on multi-core systems the scheduling happens per core. Chapter [7.9.21](#) contains more information regarding handling of Resources in such systems.

In OSEK OS users must declare Operating System objects with specific macros (e.g. `DeclareTask()`, ...) An AUTOSAR OS implementation shall not depend on such declarations and shall (for backwards compatibility) supply macros without functionality.

### 7.1.2.2 Undefined Behaviour in OSEK OS

There are a number of cases where the behaviour of OSEK OS is undefined. These cases represent a barrier to portability. AUTOSAR OS tightens the OSEK OS specification by defining the required behaviour.

#### [SWS\_Os\_00304]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If in a call to `SetRelAlarm` the parameter "increment" is set to zero, the service shall return `E_OS_VALUE` in standard and extended status .〕

#### [SWS\_Os\_00424]

*Upstream requirements:* [SRS\\_Os\\_00097](#)

〔The first call to `StartOS` (for starting the Operating System) shall not return.〕

#### [SWS\_Os\_00425]

*Upstream requirements:* [SRS\\_Os\\_00097](#)

〔If `ShutdownOS` is called and `ShutdownHook` returns then the Operating System module shall disable all interrupts and enter an endless loop.〕

### 7.1.2.3 Extensions to OSEK OS

#### [SWS\_Os\_00299]

*Upstream requirements:* [SRS\\_Os\\_11018](#)

〔The Operating System module shall provide the services `DisableAllInterrupts`, `EnableAllInterrupts`, `SuspendAllInterrupts`, `ResumeAllInterrupts` prior to calling `StartOS` and after calling `ShutdownOS`.〕

It is assumed that the static variables of the functions mentioned in [SWS\_Os\_00299] are initialized.

#### [SWS\_Os\_00301]

*Upstream requirements:* [SRS\\_Os\\_11021](#)

〔The Operating System module shall provide the ability to increment a software Counter as an alternative action on alarm expiry.〕

The Operating System module provides API service `IncrementCounter` (see [SWS\_Os\_00399]) to increment a software Counter.

#### [SWS\_Os\_00476]

*Upstream requirements:* [SRS\\_Os\\_00097](#)

〔The Operating System module shall allow to automatically start preconfigured absolute alarms during the start of the Operating System.〕

[\[SWS\\_Os\\_00476\]](#) is an extension to OSEK OS which allows this only for relative alarms.

### **[SWS\_Os\_00566]**

*Upstream requirements: [SRS\\_BSW\\_00323](#)*

〔The Operating System API shall check in extended mode all pointer arguments for a `NULL_PTR` and return `E_OS_IILLEGAL_ADDRESS` in this case unless `NULL_PTR` is explicitly allowed as a valid pointer address value in the API parameter specification.〕

## **7.2 Software Free Running Timer**

Due to the fact that the number of timers is often very limited, some functionality and configuration is added to extend the reuse of timers. E.g. this allows timer measurements.

### **[SWS\_Os\_00374]**

*Upstream requirements: [SRS\\_BSW\\_00101](#)*

〔The Operating System module shall handle all the initialization and configuration of timers used directly by the Operating System module and not handled by the GPT driver.〕

The Operating System module provides API service `GetCounterValue` (see [\[SWS\\_Os\\_00383\]](#)) to read the current count value of a `Counter` (returning either the hardware timer ticks if `Counter` is driven by hardware or the software ticks when user drives `Counter`).

The Operating System module provides API service `GetElapsedValue` (see [\[SWS\\_Os\\_00392\]](#)) to get the number of ticks between the current tick value and a previously read tick value.

**[SWS\_Os\_00384]** 〔The Operating System module shall adjust the read out values of hardware timers (which drive counters) in such that the lowest value is zero and consecutive reads return an increasing count value until the timer wraps at its modulus.〕

## **7.3 ScheduleTables**

### **7.3.1 Background & Rationale**

It is possible to implement a statically defined `Task` activation mechanism using an OSEK `Counter` and a series of auto started alarms. In the simple case, this can be achieved by specifying that the `Alarms` are not modified once started. Run-time modifications can only be made if relative synchronization between alarms can be

guaranteed. This typically means modifying the alarms while associated Counter tick interrupts are disabled.

ScheduleTables address the synchronization issue by providing an encapsulation of a statically defined set of expiry points. Each expiry point defines:

- one or more actions that must occur when it is processed where an action is the activation of a Task or the setting of an event.
- An offset in ticks from the start of the ScheduleTable

Each ScheduleTable has a duration in ticks. The duration is measured from zero and defines the modulus of the ScheduleTable.

At runtime, the Operating System module will iterate over the ScheduleTable, processing each expiry point in turn. The iteration is driven by an OSEK Counter. It therefore follows that the properties of the Counter have an impact on what is possible to configure on the ScheduleTable.

## 7.3.2 Requirements

### 7.3.2.1 Structure of a ScheduleTable




Figure 7.1: Anatomy of a ScheduleTable

### [SWS\_Os\_00401]

Upstream requirements: [SRS\\_Os\\_00098](#)

「A ScheduleTable shall have at least one expiry point.」

**[SWS\_Os\_00402]**

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔An expiry point shall contain a (possibly empty) set of `Tasks` to activate.〕

**[SWS\_Os\_00403]**

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔An expiry point shall contain a (possibly empty) set of `Events` to set.〕

**[SWS\_Os\_00876] Replenish of execution budget by expiry point**

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔An expiry point shall contain a (possibly empty) set of `Tasks` to replenish their execution budget. The replenishment is allowed only for tasks with `OsTaskTimingProtectionDeferrableServer`=TRUE and is done by means of `BudgetReplenish` (see [\[SWS\\_Os\\_91035\]](#))]〕

Note: For details about the background of [\[SWS\\_Os\\_00876\]](#) see [7.7.2.1.1](#).

**[SWS\_Os\_00404]**

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔An expiry point shall contain an offset in ticks from the start of the `ScheduleTable`.〕

### 7.3.2.2 Constraints on Expiry Points

There is no use case for an empty expiry point, so each one must define at least one action.

**[SWS\_Os\_00407]**

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔An expiry point shall activate at least one `Task` OR set at least one event OR replenish a `Tasks` execution budget.〕

The OS needs to know the order in which expiry points are processed. It is therefore necessary to ensure that the expiry points on a `ScheduleTable` can be totally ordered. This is guaranteed by forcing each expiry point on a `ScheduleTable` to have a unique offset.

**[SWS\_Os\_00442]**

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔Each expiry point on a given `ScheduleTable` shall have a unique offset.〕

Iteration over expiry points on a `ScheduleTable` is driven by an OSEK Counter. The characteristics of the Counter - `OsCounterMinCycle` and `OsCounterMaxAllowedValue` - place constraints on expiry point offsets.

**[SWS\_Os\_00443]**

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔The Initial Offset shall be zero OR in the range `OsCounterMinCycle .. OsCounterMaxAllowedValue` of the underlying Counter.〕

Similarly, constraints apply to the delays between of adjacent expiry points and the delay to the logical end of the `ScheduleTable`.

**[SWS\_Os\_00408]**

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔The delay between adjacent expiry points shall be in the range `OsCounterMinCycle .. OsCounterMaxAllowedValue` of the underlying Counter.〕

### 7.3.2.3 Processing `ScheduleTables`

**[SWS\_Os\_00002]**

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔The Operating System module shall process each expiry point on a `ScheduleTable` from the Initial Expiry Point to the Final Expiry Point in order of increasing offset.〕

**[SWS\_Os\_00007]**

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔The Operating System module shall permit multiple `ScheduleTables` to be processed concurrently.〕

**[SWS\_Os\_00409]**

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔A `ScheduleTable` of the Operating System module shall be driven by exactly one Counter.〕

**[SWS\_Os\_00410]**

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔The Operating System module shall be able to process at least one `ScheduleTable` per Counter at any given time.〕

**[SWS\_Os\_00411]**

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔The Operating System module shall make use of ticks so that one tick on the Counter corresponds to one tick on the `ScheduleTable`.〕

It is possible to activate a Task and set (one or more unique) Events for the same Task at the same expiry point. The ordering of Task activations and event settings


performed from the expiry point could lead to different implementations exhibiting different behaviour (for example, activating a suspended Task and then setting and event on the Task would succeed but if the ordering was reversed then the event setting would fail). To prevent such non-determinism, it is necessary to enforce a strict ordering of actions on the expiry point.

### [SWS\_Os\_00412]

*Upstream requirements: SRS\_Os\_00098*

[If an expiry point contains actions to activate a Task and to set one or several Event(s) of the same Task, then the Operating System module shall process this Task activation before the related Event(s) are set. No further assumptions about the order for the processing of expiry points can be made.]

A ScheduleTable always has a defined state and the following figure illustrates the different states (for a non-synchronized ScheduleTable) and the transitions between them.



**Figure 7.2: States of a ScheduleTable**

If a ScheduleTable is not active - this means that is not processed by the Operating System - the state is SCHEDULETABLE\_STOPPED. After starting a ScheduleTables enters the SCHEDULETABLE\_RUNNING state where the OS processes the expiry points. If the service to switch a ScheduleTable is called a ScheduleTable enters the SCHEDULETABLE\_NEXT state and waits until the "current" ScheduleTable ends.

### 7.3.2.4 Repeated ScheduleTable Processing

A ScheduleTable may or may not repeat after the final expiry point is processed. This allows two types of behaviour:

1. single-shot - the ScheduleTable processes each expiry point in sequence and then stops at the end. This is useful for triggering a phased sequence of actions in response to some trigger
2. repeating - the ScheduleTable processes each expiry point in turn, after processing the final expiry point, it loops back to the initial expire point. This is useful for building applications that perform repeated processing or system which need to synchronize processing to a driver source.

A repeating ScheduleTable means that each expiry point is repeated at a period equal to the ScheduleTable duration.

#### [SWS\_Os\_00413]

*Upstream requirements: [SRS\\_Os\\_00098](#)*

〔The ScheduleTable shall be configurable as either single-shot or repeating.〕

#### [SWS\_Os\_00009]

*Upstream requirements: [SRS\\_Os\\_00098](#)*

〔If the ScheduleTable is single-shot, the Operating System module shall stop the processing of the ScheduleTable Final Delay ticks after the Final Expiry Point is processed.〕

#### [SWS\_Os\_00427]

*Upstream requirements: [SRS\\_Os\\_00098](#)*

〔If the ScheduleTable is single-shot, the Operating System module shall allow a Final Delay between 0 .. [OsCounterMaxAllowedValue](#) of the underlying Counter.〕

#### [SWS\_Os\_00444]

*Upstream requirements: [SRS\\_Os\\_00098](#)*

〔For periodic ScheduleTables the value of Final Delay shall be in the range [OsCounterMinCycle](#) .. [OsCounterMaxAllowedValue](#) of the underlying Counter.〕

#### [SWS\_Os\_00194]

*Upstream requirements: [SRS\\_Os\\_00098](#)*

〔After processing the Final Expiry Point, and if the ScheduleTable is repeating, the Operating System shall process the next Initial Expiry Point, after Final Delay plus Initial Offset ticks have elapsed.〕


### 7.3.2.5 Controlling ScheduleTable Processing

The application is responsible for starting and stopping the processing of a ScheduleTable.

The Operating System module provides the service [StartScheduleTableAbs](#) (see [\[SWS\\_Os\\_00358\]](#)) to start the processing of a ScheduleTable at an absolute value "Start" on the underlying Counter. (The Initial Expiry Point has to be processed when the value of the underlying Counter equals Start + InitialOffset).

The Operating System module provides the service [StartScheduleTableRel](#) (see [\[SWS\\_Os\\_00347\]](#)) to start the processing of a ScheduleTable at "Offset" relative to the "Now" value on the underlying Counter (The Initial Expiry Point shall be processed when the value of the underlying Counter equals Now + Offset + InitialOffset).

The figure below illustrates the two different methods for a ScheduleTable driven by a Counter with a modulus of 65536 (i.e. an [OsCounterMaxAllowedValue](#) = 65535).



**Figure 7.3: Starting a ScheduleTable at an Absolute and a Relative Count**

The Operating System module provides the service [StopScheduleTable](#) (see [\[SWS\\_Os\\_00006\]](#)) to cancel the processing of a ScheduleTable immediately at any point while the ScheduleTable is running.

### [SWS\_Os\_00428]

*Upstream requirements: [SRS\\_Os\\_00098](#)*

[If ScheduleTable processing has been cancelled before reaching the Final Expiry Point and is subsequently restarted then [\[SWS\\_Os\\_00358\]](#)/[\[SWS\\_Os\\_00347\]](#) means that the re-start occurs from the start of the ScheduleTable.]

The Operating System module provides the service [NextScheduleTable](#) (see [\[SWS\\_Os\\_00191\]](#)) to switch the processing from one ScheduleTable to another ScheduleTable.

**[SWS\_Os\_00414]**

*Upstream requirements:* [SRS\\_Os\\_00099](#)

When a ScheduleTable switch is requested, the OS shall continue to process expiry points on the current ScheduleTable. After the Final Expiry Point there will be a delay equivalent to Final Delay ticks before processing the switched-to ScheduleTable. The initial expiry point will be processed after initial offset.]

The Operating System module provides the service [GetScheduleTableStatus](#) (see [\[SWS\\_Os\\_00227\]](#)) to query the state of a ScheduleTable.

ScheduleTables can be configured (see chapter 10) to start automatically during start of the Operating System module (like Tasks and Alarms in OSEK OS). OSEK OS defines a specific order: Autostart of Tasks is performed before autostart of alarms. AUTOSAR OS extends this with ScheduleTables.

**[SWS\_Os\_00510]**

*Upstream requirements:* [SRS\\_Os\\_00098](#)

The Operating System module shall perform the autostart of ScheduleTables during startup after the autostart of Tasks and Alarms.]

## 7.4 ScheduleTable Synchronization

### 7.4.1 Background & Rationale

The absolute time at which the Initial Expiry Point on a ScheduleTable is processed is under user control. However, if the ScheduleTable repeats then it is not guaranteed that the absolute count value at which the initial expiry point was first processed is the same count value at which it is subsequently processed. This is because the duration of the ScheduleTable need not be equal to the Counter modulus.

In many cases it may be important that ScheduleTable expiry points are processed at specific absolute values of the underlying Counter. This is called synchronization. Typical use-cases include:

- Synchronization of expiry points to degrees of angular rotation for motor management
- Synchronizing the computation to a global (network) time base. Note that in AUTOSAR, the Operating System does not provide a global (network) time source because
  1. a global time may not be needed in many cases
  2. other AUTOSAR modules, most notably FlexRay, provide this independently to the Operating System

3. if the Operating System is required to synchronize to multiple global (network) time sources (for example when building a gateway between two time-triggered networks) the Operating System cannot be the source of a unique global time.

AUTOSAR OS provides support for synchronization in two ways:

- implicit synchronization - the Counter driving the ScheduleTable is the Counter with which synchronization is required. This is typically how synchronization with time-triggered networking technologies (e.g. FlexRay, TTP) is achieved - the underlying hardware manages network time synchronization and simply presents time as an output/compare timer interface to the Operating System. The following figure shows the possible states for ScheduleTables with implicit synchronization.





Figure 7.4: States of an implicit synchronized ScheduleTable

- explicit synchronization - the ScheduleTable is driven by an Operating System Counter which is not the Counter with which synchronization is required. The Operating System provides additional functionality to keep ScheduleTable processing driven by the Operating System Counter synchronized with the synchronization Counter. This is typically how synchronization with periodically broadcast global times works. The next figure shows the states of such ScheduleTables.



**Figure 7.5: States of an explicit synchronized ScheduleTable (not all conditions for transitions are shown in the picture)**

## 7.4.2 Requirements

### [SWS\_Os\_00013]

*Upstream requirements: SRS\_Os\_11002*

「The Operating System module shall provide the ability to synchronize the processing of ScheduleTable to known Counter values.」

### 7.4.2.1 Implicit Synchronization

The Operating System module does not need to provide any additional support for implicit synchronization of ScheduleTables. However, it is necessary to constrain configuration and runtime control of the ScheduleTable so that ticks on the configured ScheduleTable can be aligned with ticks on the Counter. This requires the range of the ScheduleTable to be identical to the range of the Counter (the equality of tick resolution of each is guaranteed by the requirements on the ScheduleTable / Counter interaction):

### [SWS\_Os\_00429]

*Upstream requirements: SRS\_Os\_11002*

「A ScheduleTable of the Operating System module that is implicitly synchronized shall have a Duration equal to `OsCounterMaxAllowedValue` + 1 of its associated OSEK OS Counter.」


To synchronize the processing of the ScheduleTable it must be started at a known counter value. The implication of this is that a ScheduleTable requiring implicit synchronization must only be started at an absolute counter value and cannot be started at a relative count value.

### [SWS\_Os\_00430]

*Upstream requirements: SRS\_Os\_11002*

「The Operating System module shall prevent a ScheduleTable that is implicitly synchronized from being started at a relative count value.」

When the ScheduleTable is started at an absolute counter value each expiry point will be processed when the counter equals the value specified in the service call plus expiry point's offset. The common use-case is to ensure that the offsets specified in the ScheduleTable configuration correspond to absolute values of the underlying Counter. This is achieved trivially using `StartScheduleTableAbs(Tbl,0)` as shown below.



**Figure 7.6: Example for implicit synchronized ScheduleTable**

#### 7.4.2.2 Explicit Synchronization

An explicitly synchronized ScheduleTable requires additional support from the Operating System module. The ScheduleTable is driven by an Operating System module's Counter as normal (termed the "drive Counter") but processing needs to be synchronized with a different Counter (termed the "synchronization Counter") which is not an Operating System module's Counter object.

The following constraints must be enforced between the ScheduleTable, the Operating System module's Counter and the synchronization Counter:

Constraint1:

**[SWS\_Os\_00431]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

[A ScheduleTable that is explicitly synchronized shall have a duration no greater than modulus of the drive Counter.]

Constraint2:

**[SWS\_Os\_00462]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

[A ScheduleTable that is explicitly synchronized shall have a duration equal to the modulus of the synchronization Counter.]

Constraint3:

**[SWS\_Os\_00463]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

[The synchronization Counter shall have the same resolution as the drive Counter associated with the ScheduleTable. This means that a tick on the ScheduleTable has the same duration as a tick on the synchronization Counter.]

Note that it is in the responsibility of the Operating System module user to verify that Constraints 2 and 3 are satisfied by their system.

The function of explicit synchronization is for the Operating System module to keep processing each expiry point at absolute value of the synchronization Counter equal to the expiry point's offset. This means that explicit synchronization always assumes that the notional zero of the ScheduleTable has to be synchronized with absolute value zero on the synchronization Counter.

To achieve this, the Operating System module must be told the value of the synchronization Counter by the user. As the modulus of the synchronization Counter and the ScheduleTable are identical, the Operating System module can use this information to calculate drift. The Operating System module then automatically adjusts the delay between specially configured expiry points, retarding them or advancing them as appropriate, to ensure that synchronization is maintained.

#### 7.4.2.2.1 Startup

There are two options for starting an explicitly synchronized ScheduleTable:

1. Asynchronous start: Start the ScheduleTable at an arbitrary value of the synchronization Counter.
2. Synchronous start: Start the ScheduleTable at absolute value zero of the synchronization Counter only after a synchronization count has been provided. This may mean waiting for first synchronization indefinitely.

Asynchronous start is provided by the existing absolute and relative ScheduleTable start services. Both of these services set the point at which the initial expiry point is processed with respect to the driver Counter not the synchronization Counter. This allows the ScheduleTable to start running before the value of the synchronization Counter is known.

Synchronous start requires an additional service that starts the ScheduleTable only after the Operating System module is told the value of the synchronization Counter.

The Operating System module provides the service [StartScheduleTableSynchron](#) (see [\[SWS\\_Os\\_00201\]](#)) to start an explicitly synchronized ScheduleTable synchronously. The Initial Expiry Point will be processed after (Duration - Value) + Initial Offset ticks of the driver Counter have elapsed where Value is the absolute value of the synchronization Counter provided to the ScheduleTable.

#### **[SWS\_Os\_00435]**

*Upstream requirements: [SRS\\_Os\\_11002](#)*

[If an explicitly synchronized ScheduleTable was started synchronously, then the Operating System module shall guarantee that it has state "waiting" when the call of service [StartScheduleTableSynchron](#) returns.]

#### **7.4.2.2.2 Providing a Synchronization Count**

The Operating System module must be told the value of the synchronization Counter. Since the ScheduleTable duration is equal to the modulus of the synchronization Counter, the Operating System module can use this to determine the drift between the current count value on the ScheduleTable time and the synchronization count and decide whether (or not) any action to achieve synchronization is required.

The Operating System module provides the service [SyncScheduleTable](#) (see [\[SWS\\_Os\\_00199\]](#)) to provide the ScheduleTable with a synchronization count and start synchronization.


#### **7.4.2.2.3 Specifying Synchronization Bounds**

A ScheduleTable defaults to denying adjustment at all expiry points. Adjustment is allowed only when explicitly configured. The range of adjustment that the Operating System module can make at an adjustable expiry point is controlled by specifying:


- `OsScheduleTableMaxShorten` : the maximum value that can be subtracted from the expiry offset
- `OsScheduleTableMaxLengthen`: the maximum value that can be added to the expiry point offset

The following figure illustrates the behaviour depending on `OsScheduleTable-MaxShorten` and `OsScheduleTableMaxLengthen`:

## Expected Delays



## Maximum Shorten



## Maximum Lengthen




Figure 7.7: Adjustment of Expiry Points

**[SWS\_Os\_00415]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔An expiry point shall permit the configuration of an `OsScheduleTableMaxShorten` that defines the maximum number of ticks that can be subtracted from expiry point offset.〕

**[SWS\_Os\_00416]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔An expiry point shall permit the configuration of an `OsScheduleTableMaxLengthen` that defines the maximum number of ticks that can be added to expiry point offset.〕

When performing synchronization it is important that the expiry points on the `ScheduleTable` are processed according to the total ordering defined by their offsets. This means that the range of permitted values for `OsScheduleTableMaxShorten` and `OsScheduleTableMaxLengthen` must ensure that the next expiry point is not retarded into the past or advanced beyond more than one iteration of the `ScheduleTable`.

**[SWS\_Os\_00436]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔The value of (Offset - `OsScheduleTableMaxShorten`) of an expiry point shall be greater than (Offset + `OsCounterMinCycle`) of the previous expiry point.〕

**[SWS\_Os\_00559]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔The value of `OsScheduleTableMaxLengthen` shall be smaller than the duration of the `ScheduleTable`.〕

**[SWS\_Os\_00437]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔The value of (`OsScheduleTableMaxLengthen` + `delay_from_previous_EP`) of an expiry point shall be less than the `OsCounterMaxAllowedValue` of the underlying Counter.〕

Explicitly synchronized `ScheduleTables` allow the tolerance of some drift between the `ScheduleTable` value and the synchronization counter value. This tolerance can be zero, indicating that the `ScheduleTable` is not considered synchronized unless the values are identical.

**[SWS\_Os\_00438]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔A `ScheduleTable` shall define a precision bound with a value in the range 0 to duration.〕

#### 7.4.2.3 Performing Synchronization

The Operating System module uses the synchronization count to support (re-)synchronization of a `ScheduleTable` at each expiry point by calculating an adjustment to the delay to the next expiry point. This provides faster re-synchronization of the `ScheduleTable` than doing the action on the final expiry point.

##### **[SWS\_Os\_00206]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔When a new synchronization count is provided, the Operating System module shall calculate the current deviation between the explicitly synchronized scheduled table and the synchronization count.〕

It is meaningless to try and synchronize an explicitly synchronized `ScheduleTable` before a synchronization count is provided.

##### **[SWS\_Os\_00417]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔The Operating System module shall start to synchronize an explicitly synchronized `ScheduleTable` after a synchronization count is provided AND shall continue to adjust expiry points until synchronized.〕

##### **[SWS\_Os\_00418]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔The Operating System module shall set the state of an explicitly synchronized `ScheduleTable` to "running and synchronous" if the deviation is less than or equal to the configured `OsScheduleTblExplicitPrecision` threshold.〕

##### **[SWS\_Os\_00419]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔The Operating System module shall set the state of an explicitly synchronized `ScheduleTable` to "running" if the deviation is greater than the configured `OsScheduleTblExplicitPrecision` threshold.〕

##### **[SWS\_Os\_00420]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔IF the deviation is non-zero AND the next expiry point is adjustable AND the table is behind the sync Counter (`TableTicksAheadOfSyncCounter <= TableTicksBehindOfSyncCounter`) THEN the OS shall set the next EP to expire delay -  $\min(\text{MaxShorten}, \text{Deviation})$  ticks from the current expiry.〕

### [SWS\_Os\_00421]

Upstream requirements: [SRS\\_Os\\_11002](#)

[IF the deviation is non-zero AND the next expiry point is adjustable AND the table is ahead of the sync Counter (TableTicksAheadOfSyncCounter > TableTicksBehindOf SyncCounter) THEN the OS shall set the next EP to expire delay + min(MaxLengthen, Deviation) ticks from the current expiry.]

Figure 7.8 shows explicit synchronization of a `ScheduleTable`. It assumes the following:

- EP1-3 have `OsScheduleTableMaxLengthen`=2
- EP1-3 have `OsScheduleTableMaxShorten` =1




Figure 7.8: Explicit ScheduleTable Synchronization

The Operating System module provides the service `SetScheduleTableAsync` (see [\[SWS\\_Os\\_00422\]](#)) to cancel synchronization being performed at adjustable expiry points on a `ScheduleTable`.

The Operating System module provides the service `GetScheduleTableStatus` (see [\[SWS\\_Os\\_00227\]](#)) to query the state of a `ScheduleTable` also with respect to synchronization.

## 7.5 Stack Monitoring Facilities

### 7.5.1 Background & Rationale

On processors that do not provide any memory protection hardware it may still be necessary to provide a "best effort with available resources" scheme for detectable classes of memory faults. Stack monitoring will identify where a Task or ISR has exceeded a specified stack usage at context switch time. This may mean that there is considerable time between the system being in error and that fault being detected. Similarly, the error may have been cleared at the point the fault is notified (the stack may be less than the specified size when the context switch occurs).

It is not usually sufficient to simply monitor the entire stack space for the system because it is not necessarily the Task/ISR that was executing that used more than stack space than required - it could be a lower priority object that was pre-empted.

Significant debugging time can be saved by letting the Operating System correctly identify the Task/Category 2 ISR in error.

Note that for systems using an MPU and scalability class 3 or 4 a stack overflow may cause a memory exception before the stack monitoring is able to detect the fault.

### 7.5.2 Requirements

#### [SWS\_Os\_00067]

*Upstream requirements:* [SRS\\_Os\\_11003](#)

〔The Operating System module shall provide a stack monitoring which detects possible stack faults of Task(s)/Category 2 ISR(s).〕

#### [SWS\_Os\_00068]

*Upstream requirements:* [SRS\\_Os\\_11003](#), [SRS\\_Os\\_11013](#)

〔If a stack fault is detected by stack monitoring AND no [ProtectionHook](#) is configured, the Operating System module shall call the [ShutdownOS](#) service with the status [E\\_OS\\_STACKFAULT](#).〕

#### [SWS\_Os\_00396]

*Upstream requirements:* [SRS\\_Os\\_11003](#)

〔If a stack fault is detected by stack monitoring AND a [ProtectionHook](#) is configured the Operating System module shall call the [ProtectionHook](#) with the status [E\\_OS\\_STACKFAULT](#).〕

## 7.6 OS-Application

### 7.6.1 Background & Rationale

An AUTOSAR OS must be capable of supporting a collection of Operating System objects (Tasks, ISRs, Alarms, ScheduleTables, Counters) that form a cohesive functional unit. This collection of objects is termed an OS-Application.

The Operating System module is responsible for scheduling the available processing resource between the OS-Applications that share the processor. If OS-Application(s) are used, all Tasks, ISRs, Counters, Alarms and ScheduleTables must belong to an OS-Application. All objects which belong to the same OS-Application have access to each other. The right to access objects from other OS-Applications may be granted during configuration. An Event is accessible if the Task for which the event can be set is accessible. Access means that these Operating System objects are allowed as parameters to API services.

There are two classes of OS-Application:

1. **Trusted** OS-Applications are allowed to run with monitoring or protection features disabled at runtime. They may have unrestricted access to memory, the Operating System module's API, and need not have their timing behaviour enforced at runtime. They are allowed to run in privileged mode when supported by the processor. The Operating System module assumes that trusted OS-Applications (and trusted functions) do not cause a memory related protection fault. If such a fault happens the system stability is likely gone and a shutdown may be the only option.
2. **Non-Trusted** OS-Applications are not allowed to run with monitoring or protection features disabled at runtime. They have restricted access to memory, restricted access to the Operating System module's API and have their timing behaviour enforced at runtime. They are not allowed to run in privileged mode when supported by the processor.

It is assumed that the Operating System module itself is trusted.

There are services offered by the AUTOSAR OS which give the caller information about the access rights and the membership of objects. These services are intended to be used in case of an inter-OS-Application call for checking access rights and arguments.

Note that Resource objects do not belong to any OS-Application, but access to them must be explicitly granted. (The same principle applies to spinlocks in Multi-Core systems)

The running OS-Application is defined as the OS-Application to which the currently running Task or ISR belongs. In case of a hook routine the Task or ISR which caused the call of the hook routine defines the running OS-Application.





Figure 7.9: UML-model of OS-Application

OS-Applications have a state which defines the scope of accessibility of its Operating System objects from other OS-Applications. Each OS-Application is always in one of the following states:

- Active and accessible (**APPLICATION\_ACCESSIBLE**): Operating System objects may be accessed from other OS-Applications. This is the default state at startup.
- Terminated and not accessible (**APPLICATION\_TERMINATED**): Operating System objects cannot be accessed from other OS-Applications. State will not change.

The following figure shows the states and the possible transitions:



**Figure 7.10: States of OS-Applications**

## 7.6.2 Requirements

### [SWS\_Os\_00445]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

「The Operating System module shall support OS-Applications which are a configurable selection of Trusted Functions, Tasks, ISRs, Alarms, ScheduleTables, Counters, hooks (for startup, error and shutdown).」

### [SWS\_Os\_00446]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

「The Operating System module shall support the notion of trusted and non-trusted OS-Applications.」

### [SWS\_Os\_00464]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

「Trusted OS-Applications may offer services ("trusted services") to other (even non-trusted) OS-Applications.」

The Operating System module provides the services [GetApplicationID](#) and [GetCurrentApplicationID](#) (see [\[SWS\\_Os\\_00016\]](#)) to determine the configured resp. currently executing OS-Application (a unique identifier shall be allocated to each application).

The Operating System module provides the service [CheckObjectOwnership](#) (see [\[SWS\\_Os\\_00017\]](#)) to determine to which OS-Application a given Task, ISR, Counter, Alarm or ScheduleTable belongs.

The Operating System module provides the service [CheckObjectAccess](#) (see [\[SWS\\_Os\\_00256\]](#)) to determine which OS-Applications are allowed to use the IDs of a Task, Resource, Counter, Alarm or ScheduleTable in API calls.

The Operating System module provides the service [TerminateApplication](#) (see [\[SWS\\_Os\\_00258\]](#)) to terminate the OS-Application to which the calling Task/Category

2 ISR/application specific error hook belongs. (This is an OS-Application level variant of the [TerminateTask](#) service)

The Operating System provides the service [TerminateApplication](#) (see [\[SWS\\_Os\\_00258\]](#)) to terminate another OS-Application AND calls to this service shall be ignored if the caller does not belong to a trusted OS-Application.

### **[SWS\_Os\_00447]**

*Upstream requirements:* [SRS\\_Os\\_11022](#)

〔If the Operating System module terminates an OS-Application, then it shall:

- terminate all running, ready and waiting Tasks/ISRs of the OS-Application AND
- disable all interrupts of the OS-Application AND
- stop all active alarms of the OS-Applications AND
- stop all ScheduleTables of the OS-Application.

〕

### **[SWS\_Os\_00448]**

*Upstream requirements:* [SRS\\_Os\\_11010](#)

〔The Operating System module shall prevent access of OS-Applications, trusted or non-trusted, to objects not belonging to this OS-Application, except access rights for such objects are explicitly granted by configuration.〕

The Operating System provides the service [GetApplicationState](#) (see [\[SWS\\_Os\\_00499\]](#)) to request the current state of an OS-Application.

### **[SWS\_Os\_00500]**

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔The Operating System module shall set the state of all OS-Applications after the call of [StartOS](#) and before any [StartupHook](#) is called to APPLICATION\_ACCESSIBLE.〕

### **[SWS\_Os\_00502]**

*Upstream requirements:* [SRS\\_Os\\_11022](#)

〔If an OS-Application is terminated (e.g. through a service call or via protection hook) then the Operating System module shall set the state of this OS-Application to APPLICATION\_TERMINATED.〕

### **[SWS\_Os\_00504]**

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔The Operating System module shall deny access to Operating System objects from other OS-Applications to an OS-Application which is not in state APPLICATION\_ACCESSIBLE.〕

**[SWS\_Os\_00509]**

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If a service call is made on an Operating System object that is owned by another OS-Application without state APPLICATION\_ACCESSIBLE, then the Operating System module shall return E\_OS\_ACCESS.〕

An example for [\[SWS\\_Os\\_00509\]](#) is a call to [ActivateTask](#) for a Task in an OS-Application that already terminated.

## 7.7 Protection Facilities

Protection is only possible for Operating System managed objects. This means that:

- It is not possible to provide protection during runtime of Category 1 ISRs, because the operating system is not aware of any Category 1 ISRs being invoked. Therefore, if any protection is required, Category 1 ISRs have to be avoided. If Category 1 interrupts AND OS-Applications are used together then all Category 1 ISR must belong to a trusted OS-Application.
- It is not possible to provide protection between functions called from the body of the same Task/Category 2 ISR.

### 7.7.1 Memory Protection

#### 7.7.1.1 Background & Rationale

Memory protection will only be possible on processors that provide hardware support for memory protection.

The memory protection scheme is based on the (data, code and stack) sections of the executable program.

**Stack:** An OS-Application comprises a number of Tasks and ISRs. The stack for these objects, by definition, belongs only to the owner object and there is therefore no need to share stack data between objects, even if those objects belong to the same OS-Application.

Memory protection for the stacks of Tasks and ISRs is useful mainly for two reasons:

1. Provide a more immediate detection of stack overflow and underflow for the Task or ISR than can be achieved with stack monitoring
2. Provide protection between constituent parts of and OS-Application, for example to satisfy some safety constraints.

**Data:** OS-Applications can have private data sections and Tasks/ISRs can have private data sections. OS-Application's private data sections are shared by all Tasks/ISRs belonging to that OS-Application.

**Code:** Code sections are either private to an OS-Application or can be shared between all OS-Applications (to use shared libraries). In the case where code protection is not used, executing incorrect code will eventually result in a memory, timing or service violation.

### 7.7.1.2 Requirements

#### Data Sections and Stack

##### **[SWS\_Os\_00198]**

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔The Operating System module shall prevent write access to its own data sections and its own stack from non-trusted OS-Applications.〕

##### **[SWS\_Os\_00795]**

*Upstream requirements:* [SRS\\_Os\\_11005](#)

〔The OS shall offer the possibility to restrict write access of trusted OS-Applications in the same way as it is done for non-trusted OS-Applications.〕

This can be configured with the [OsTrustedApplicationWithProtection](#).

#### Private data of an OS-Application

##### **[SWS\_Os\_00026]**

*Upstream requirements:* [SRS\\_Os\\_11000](#)

〔The Operating System module may prevent read access to an OS-Application's data section attempted by other non-trusted OS-Applications.〕

##### **[SWS\_Os\_00086]**

*Upstream requirements:* [SRS\\_Os\\_11006](#)

〔The Operating System module shall permit an OS-Application read and write access to that OS-Application's own private data sections.〕

##### **[SWS\_Os\_00207]**

*Upstream requirements:* [SRS\\_Os\\_11005](#)

〔The Operating System module shall prevent write access to the OS-Application's private data sections from other non-trusted OS-Applications.〕

#### Private Stack of Task/ISR

**[SWS\_Os\_00196]**

*Upstream requirements:* [SRS\\_Os\\_11006](#)

〔The Operating System module shall permit a Task/Category 2 ISR read and write access to that Task's/Category 2 ISR's own private stack.〕

**[SWS\_Os\_00208]**

*Upstream requirements:* [SRS\\_Os\\_11005](#)

〔The Operating System module may prevent write access to the private stack of Tasks/Category 2 ISRs of a non-trusted application from all other Tasks/ISRs in the same OS-Application.〕

**[SWS\_Os\_00355]**

*Upstream requirements:* [SRS\\_Os\\_11005](#)

〔The Operating System module shall prevent write access to all private stacks of Tasks/Category 2 ISRs of an OS-Application from other non-trusted OS-Applications.〕

**Private data of a Task/ISR****[SWS\_Os\_00087]**

*Upstream requirements:* [SRS\\_Os\\_11006](#)

〔The Operating System module shall permit a Task/Category 2 ISR read and write access to that Task's/Category 2 ISR's own private data sections.〕

**[SWS\_Os\_00195]**

*Upstream requirements:* [SRS\\_Os\\_11005](#)

〔The Operating System module may prevent write access to the private data sections of a Task/Category 2 ISR of a non-trusted application from all other Tasks/ISRs in the same OS-Application.〕

**[SWS\_Os\_00356]**

*Upstream requirements:* [SRS\\_Os\\_11005](#)

〔The Operating System module shall prevent write access to all private data sections of a Task/Category 2 ISR of an OS-Application from other non-trusted OS-Applications.〕

**Code Sections****[SWS\_Os\_00027]**

*Upstream requirements:* [SRS\\_Os\\_11000](#)

〔The Operating System module may provide an OS-Application the ability to protect its code sections against executing by non-trusted OS-Applications.〕

**[SWS\_Os\_00081]**

*Upstream requirements:* [SRS\\_Os\\_11007](#)

〔The Operating System module shall provide the ability to provide shared library code in sections that are executable by all OS-Applications.〕

**Peripherals****[SWS\_Os\_00209]**

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔If `OsTrustedApplicationWithProtection == FALSE` then the Operating System module shall permit trusted OS-Applications read and write access to peripherals.〕

**[SWS\_Os\_00083]**

*Upstream requirements:* [SRS\\_Os\\_11005](#)

〔The Operating System module shall allow non-trusted OS-Applications to write to their assigned peripherals only (incl. reads that have the side effect of writing to a memory location).〕

**Memory Access Violation****[SWS\_Os\_00044]**

*Upstream requirements:* [SRS\\_Os\\_11013](#)

〔If a memory access violation is detected, the Operating System module shall call the `ProtectionHook` with status code `E_OS_PROTECTION_MEMORY`.〕

## 7.7.2 Timing Protection

### 7.7.2.1 Background & Rationale

A timing fault in a real-time system occurs when a `Task` or interrupt misses its deadline at runtime.

AUTOSAR OS does not offer deadline monitoring for timing protection. Deadline monitoring is insufficient to correctly identify the `Task/ISR` causing a timing fault in an AUTOSAR system. When a deadline is violated this may be due to a timing fault introduced by an unrelated `Task/ISR` that interferes/blocks for too long. The fault in this case lies with the unrelated `Task/ISR` and this will propagate through the system until a `Task/ISR` misses its deadline. The `Task/ISR` that misses a deadline is therefore not necessarily the `Task/ISR` that has failed at runtime, it is simply the earliest point that a timing fault is detected.

If action is taken based on a missed deadline identified with deadline monitoring this would potentially use false evidence of error to terminate a correct OS-Application in

favor of allowing an incorrect OS-Application to continue running. The problem is best illustrated by example. Consider a system with the following configuration:

TaskID	Priority	Execution Time	Deadline (=Period)
A	High	1	5
B	Medium	3	10
C	Low	5	15

Assuming that all Tasks are ready to run at time zero, the following execution trace would be expected and all Tasks would meet their respective deadlines.





Figure 7.11: Example execution trace

Now consider the case when Tasks A and B behave incorrectly. The figure below shows both Task A and Task B executing for longer than specified and Task B arriving 2 ticks earlier than specified. Both Tasks A and B meet their deadlines. Task C however, behaves correctly but it fails to meet its deadline because of the incorrect execution of Tasks A and B. This is fault propagation - a fault in an unrelated part of the system is causing a correctly functioning part of the system to fail.



**Figure 7.12: Insufficiency of Deadline Monitoring**

Whether a Task or ISR meets its deadline in a fixed priority preemptive operating system like AUTOSAR OS is determined by the following factors:

- the execution time of Task/ISRs in the system
- the blocking time that Task/ISRs suffers from lower priority Tasks/ISRs locking shared resources or disabling interrupts
- the interarrival rate of Task/ISRs in the system

For safe and accurate timing protection it is necessary for the operating system to control these factors at runtime to ensure that Tasks/ISRs can meet their respective deadlines.

AUTOSAR OS prevents timing errors from (1) by using *execution time protection* to guarantee a statically configured upper bound, called the Execution Budget, on the execution time of:

- Tasks
- Category 2 ISRs

AUTOSAR OS prevents timing errors from (2) by using *locking time protection* to guarantee a statically configured upper bound, called the Lock Budget, on the time that:

- Resources are held by Tasks/Category 2 ISRs
- OS interrupts are suspended by Tasks/Category 2 ISRs
- ALL interrupts are suspended/disabled by Tasks/Category 2 ISRs


AUTOSAR OS prevents timing errors from (3) by using *inter-arrival time protection* to guarantee a statically configured lower bound, called the Time Frame, on the time between:

- A Task being permitted to transition into the READY state due to:
  - Activation (the transition from the SUSPENDED to the READY state)
  - Release (the transition from the WAITING to the READY state)
- A Category 2 ISR arriving. An arrival occurs when the Category 2 ISR is recognized by the OS

Inter-arrival time protection for basic Tasks controls the time between successive activations, irrespective of whether activations are queued or not. In the case of queued activations, activating a basic Task which is in the READY or RUNNING state is a new activation because it represents the activation of a new instance of the Task. Inter-arrival time protection therefore interacts with queued activation to control the rate at which the queue is filled.

Inter-arrival time protection for extended Tasks controls the time between successive activations and releases. When a Task is in the WAITING state and multiple Events are set with a single call to `SetEvent` this represents a single release. When a Task waits for one or more Events which are already set this represents a notional Wait/Release/Start transition and therefore is considered as a new release.

The following figure shows how execution time protection and inter-arrival time protection interact with the task state transition model for AUTOSAR OS.



**Figure 7.13: Time protection interaction with the task state transition model with `OsTaskTimingProtectionDeferrableServer=FALSE`**

## Notes:

1. Inter-arrival time enforcement on Category 2 ISRs can be used to protect an ECU from a "babbling idiot" source of interrupts (e.g. a CAN controller taking an interrupt each time a frame is received from another ECU on the network).
2. Timing protection only applies to Tasks or Category 2 ISRs. There is no protection for Category 1 ISRs. If timing protection error occurs during a category 1 ISR, consistency of the Operating System module cannot be guaranteed. Therefore we discourage timing protection in systems with category 1 interrupts.
3. Timing protection does not apply before the Operating System module is started.
4. In the case of trusted OS-Applications it is essential that all timing information is correct, otherwise the system may fail at run-time. For a non-trusted OS-Application, timing protection can be used to enforce timing boundaries between executable objects.

#### 7.7.2.1.1 Deferrable Server

If timing protection is enabled the normal behavior for the OS after detection of a timing violation is to call the [ProtectionHook](#). By this the user is informed and can decide on a proper reaction. Unfortunately the reaction is often limited to a killing of the faulty entity.

Another option for the Timing Protection is to somehow "freeze" a task when it exhausts its execution budget. Instead of calling the [ProtectionHook](#) and applying one of the current destructive reactions, such as abruptly terminating the task or shutting down the entire OS, the new reaction consists in quietly descheduling the task and placing it in a state where it cannot be scheduled until its budget is replenished again.


This approach is also known as "Deferrable Server", an effective and easy-to-implement variant of a real-time scheduling mechanism known as "Aperiodic Server". For further details see [7], [8], [9]. Under certain assumptions, the approach also supports the implementation of the "Polling Server", another well-known variant of the "Aperiodic Server" mechanism.

If a task uses [OsTaskTimingProtectionDeferrableServer](#), then it gets an additional task state BUDGET\_EXHAUSTED which will be entered if the tasks budget is exhausted. It will stay in this state until its budget is replenished ("refilled"). The refilling can be realized via API (see [BudgetReplenish](#)), via Alarm action or via an expiry point in a ScheduleTable. The user is responsible for the refilling, e.g. by having an Alarm which cyclically replenish the execution budget of the deferred server task. The following details explain the possible state changes for Deferrable Servers and what's happening:

1. When the Operating System starts each Deferrable Server gets its initial execution budget (configured in [OsTaskExecutionBudget](#))

2. This budget is used while Deferrable Server is in task state RUNNING
3. When Deferrable Server is preempted (becoming READY), blocked (becoming WAITING) or terminates (becoming SUSPENDED) the current execution budget is kept.
4. When Deferrable Server is RUNNING and the budget is exhausted ( $\leq$ zero ; see also [SWS\_Os\_00871]) the Operating System changes the task state to BUDGET\_EXHAUSTED and schedules another Task.
5. A Deferrable Server in BUDGET\_EXHAUSTED can only leave this task state when another entity replenishes the budget. Replenish means that the OsTaskExecutionBudget is added to the current budget. This can happen via API or an alarm action or an expiry point of a ScheduleTable. (see [SWS\_Os\_00872], [SWS\_Os\_00874]).

The following figure shows the possible Task states for Tasks with `OsTaskTimingProtectionDeferrableServer=TRUE`



**Figure 7.14: Task states and transitions for Deferrable Server Tasks**

Using Deferrable Server mechanism has some restrictions regarding configurability. See [SWS\_Os\_00877], [SWS\_Os\_00879], [SWS\_Os\_00880] and [SWS\_Os\_00881] for details.

Note: In this context the term "Server" is used in accordance with the real-time scheduling terminology to refer to a task used to handle aperiodic requests and subject to execution budget monitoring. It has nothing to do with the "Server" of a Client/Server interface in AUTOSAR.

### 7.7.2.2 Requirements

#### [SWS\_Os\_00028]

*Upstream requirements:* [SRS\\_Os\\_11008](#)

〔In a non-trusted OS-Application, the Operating System module shall apply timing protection to every Task/Category 2 ISR of this non-trusted OS-Application.〕

#### [SWS\_Os\_00089]

*Upstream requirements:* [SRS\\_Os\\_11008](#)

〔In a trusted OS-Application, the Operating System module shall provide the ability to apply timing protection to Tasks/Category 2 ISRs of this OS-Application.〕

#### [SWS\_Os\_00397]

*Upstream requirements:* [SRS\\_Os\\_11008](#)

〔If no OS-Application is configured, the Operating System module shall be able to apply timing protection to Tasks/Category 2 ISRs.〕

### Timing Protection: Tasks

#### [SWS\_Os\_00064]

*Upstream requirements:* [SRS\\_Os\\_11008](#), [SRS\\_Os\\_11013](#)

〔If a Task's `OsTaskExecutionBudget` is reached and the `OsTaskTimingProtectionDeferrableServer` is not configured for that Task (as per default), then the Operating System module shall call the `ProtectionHook` with `E_OS_PROTECTION_TIME`.〕

#### [SWS\_Os\_00473]

*Upstream requirements:* [SRS\\_Os\\_11008](#)

〔The Operating System module shall reset a Task's `OsTaskExecutionBudget` on a transition to the SUSPENDED or WAITING states if the `OsTaskTimingProtectionDeferrableServer` is not configured for that Task (as per default).〕

#### [SWS\_Os\_00465]

*Upstream requirements:* [SRS\\_Os\\_11008](#)

〔The Operating System module shall limit the inter-arrival time of Tasks to one per `OsTaskTimeFrame`.〕

#### [SWS\_Os\_00469]

*Upstream requirements:* [SRS\\_Os\\_11008](#)

〔The Operating System module shall start an `OsTaskTimeFrame` when a Task is activated successfully.〕

**[SWS\_Os\_00472]**

*Upstream requirements:* [SRS\\_Os\\_11008](#)

〔The Operating System module shall start an [OsTaskTimeFrame](#) when a Task is released successfully.〕

**[SWS\_Os\_00466]**

*Upstream requirements:* [SRS\\_Os\\_11008](#)

〔If an attempt is made to activate a Task before the end of an [OsTaskTimeFrame](#) then the Operating System module shall not perform the activation AND shall call the [ProtectionHook](#) with [E\\_OS\\_PROTECTION\\_ARRIVAL](#).〕

**[SWS\_Os\_00467]**

*Upstream requirements:* [SRS\\_Os\\_11008](#)

〔If an attempt is made to release a Task before the end of an [OsTaskTimeFrame](#) then the Operating System module shall not perform the release AND shall call the [ProtectionHook](#) with [E\\_OS\\_PROTECTION\\_ARRIVAL](#).〕

**Timing Protection: Tasks with Deferrable Server option****[SWS\_Os\_00869] Additional Task state**

*Upstream requirements:* [SRS\\_Os\\_13000](#)

〔The AUTOSAR OS shall support an additional task state [BUDGET\\_EXHAUSTED](#) for Tasks configured with [OsTaskTimingProtectionDeferrableServer=TRUE](#). This state can be entered only if the timing protection is active and only by the Tasks configured with [OsTaskTimingProtectionDeferrableServer](#). In this state a Task is not running and cannot be scheduled.〕

**[SWS\_Os\_00870] Behavior of Tasks in state BUDGET\_EXHAUSTED**

*Upstream requirements:* [SRS\\_Os\\_13000](#)

〔Any functionality (API or alarm action or expiry point) which tries to activate the Task (or set an Event of a Task) in state [BUDGET\\_EXHAUSTED](#) shall behave as if the Task would be in state [READY](#) except that [BUDGET\\_EXHAUSTED](#) can be left only as specified by [\[SWS\\_Os\\_00872\]](#).〕

Example: If a user calls [SetEvent](#) for a Task which is currently in [BUDGET\\_EXHAUSTED](#), the function shall set the events and return [E\\_OK](#).

**[SWS\_Os\_00872] Leaving state BUDGET\_EXHAUSTED**

*Upstream requirements:* [SRS\\_Os\\_13000](#)

〔The [BUDGET\\_EXHAUSTED](#) state can only be left by calling [BudgetReplenish](#) or using an Alarm with action [OsAlarmBudgetReplenish](#) or a related action at an expiry point of a ScheduleTable. If the replenish succeeded (the current execution budget of the Task is  $>0$ ) then the Task will change to state [READY](#). Afterwards a rescheduling may happen.〕

**[SWS\_Os\_00871] Entering BUDGET\_EXHAUSTED**

*Upstream requirements:* [SRS\\_Os\\_11008](#), [SRS\\_Os\\_11013](#)

〔If a Task is in state `RUNNING` and `OsTaskExecutionBudget` has been exhausted and `OsTaskTimingProtectionDeferrableServer=TRUE` is configured for that Task: As soon as the Task is neither suspending/disabling any interrupts nor holding any OS resource or spinlock, the Operating System module shall deschedule it, put it in the new state `BUDGET_EXHAUSTED` and schedule another Task.〕

[[SWS\\_Os\\_00871](#)] effectively mean that the Tasks current budget can be lower than zero. This can e.g. happen when the budget is exhausted but a switch to the `BUDGET_EXHAUSTED` state is delayed because the Task still holds a OS resource (or similar object).

**Timing Protection: ISRs****[SWS\_Os\_00210]**

*Upstream requirements:* [SRS\\_Os\\_11013](#)

〔If a Category 2 ISR's `OsIsrExecutionBudget` is reached then the Operating System module shall call the `ProtectionHook` with `E_OS_PROTECTION_TIME`.〕

**[SWS\_Os\_00474]**

*Upstream requirements:* [SRS\\_Os\\_11008](#)

〔The Operating System module shall reset an ISR's `OsIsrExecutionBudget` when the ISR returns control to the OS or terminates.〕

**[SWS\_Os\_00470]**

*Upstream requirements:* [SRS\\_Os\\_11008](#)

〔The Operating System module shall limit the inter-arrival time of Category 2 ISRs to one per `OsIsrTimeFrame`.〕

**[SWS\_Os\_00471]**

*Upstream requirements:* [SRS\\_Os\\_11008](#)

〔The Operating System module shall measure the start of an `OsIsrTimeFrame` from the point at which it recognizes the interrupt (i.e. in the Operating System interrupt wrapper).〕

**[SWS\_Os\_00048]**

*Upstream requirements:* [SRS\\_Os\\_11008](#)

〔If Category 2 interrupt occurs before the end of the `OsIsrTimeFrame` then the Operating System module shall not execute the user provided ISR AND shall call the `ProtectionHook` with `E_OS_PROTECTION_ARRIVAL`.〕

**Timing Protection: Resource Locking and Interrupt Disabling**

**[SWS\_Os\_00033]**

*Upstream requirements:* [SRS\\_Os\\_11008](#), [SRS\\_Os\\_11013](#), [SRS\\_Os\\_11014](#)

〔If a Task/Category 2 ISR holds an OSEK Resource and exceeds the [OsTaskResourceLockBudget](#) (or [OsIsrResourceLockBudget](#)) , the Operating System module shall call the [ProtectionHook](#) with [E\\_OS\\_PROTECTION\\_LOCKED](#).〕

**[SWS\_Os\_00037]**

*Upstream requirements:* [SRS\\_Os\\_11008](#), [SRS\\_Os\\_11013](#), [SRS\\_Os\\_11014](#)

〔If a Task/Category 2 ISR disables interrupts (via [Suspend/DisableAll](#)/[OS|Interrupts\(\)](#)) and exceeds the configured [OsIsrAllInterruptLockBudget](#) (or [OsIsrOsInterruptLockBudget](#) or [OsTaskAllInterruptLockBudget](#) or [OsTaskOsInterruptLockBudget](#)) the Operating System module shall call the [ProtectionHook](#) with [E\\_OS\\_PROTECTION\\_LOCKED](#).〕

### 7.7.2.3 Implementation Notes

Execution time enforcement requires hardware support, e.g. a timing enforcement interrupt. If an interrupt is used to implement the time enforcement, the priority of this interrupt has to be high enough to "interrupt" the supervised Tasks or ISRs.

Depending on the real hardware support this could mean that [DisableAllInterrupts](#) and [SuspendAllInterrupts](#) disable not all interrupts (e.g. all interrupts except of the interrupt used for timing protection) or that the usage of Category 1 ISRs - which bypass the Operating System (and also the timing protection) - is limited somehow.

The implementation has to document such implementation specific behaviour (e.g. the limitations when timing protection is used).

## 7.7.3 Service Protection

### 7.7.3.1 Background & Rationale

As OS-Applications can interact with the Operating System module through services, it is essential that the service calls will not corrupt the Operating System module itself. Service Protection guards against such corruption at runtime.

There are a number of cases to consider with Service Protection: An OS-Application makes an API call

1. with an invalid handle or out of range value.
2. in the wrong context, e.g. calling [ActivateTask](#) in the [StartupHook](#).
3. or fails to make an API call that results in the OSEK OS being left in an undefined state, e.g. it terminates without a [ReleaseResource](#) call

4. that impacts on the behaviour of every other OS-Application in the system, e.g. [ShutdownOS](#)
5. to manipulate Operating System objects that belong to another OS-Application (to which it does not have the necessary permissions), e.g. an OS-Application tries to execute [ActivateTask](#) on a Task it does not own.

The OSEK OS already provides some service protection through the status codes returned from service calls and this will provide the basis for service protection. This means that service protection will only apply for the extended status of OSEK OS.

However, OSEK OS does not cover all the cases outlined above. The following sections describe - besides the mandatory extended status - the additional protection requirements to be applied in each of these cases.

### 7.7.3.2 Invalid Object Parameter or Out of Range Value

#### 7.7.3.2.1 Background & Rationale

The current OSEK OS service calls already return `E_OS_ID` on invalid objects (i.e. objects not defined in the OIL file) and `E_OS_VALUE` for out of range values (e.g. setting an alarm cycle time less than [OsCounterMinCycle](#)).

#### 7.7.3.2.2 Requirements

##### [SWS\_Os\_00051]

*Upstream requirements: [SRS\\_Os\\_11009](#), [SRS\\_Os\\_11013](#)*

〔If an invalid address (address is not writable by this OS-Application) is passed as an out-parameter to an Operating System service, the Operating System module shall return the status code `E_OS_ILLEGAL_ADDRESS`.〕

### 7.7.3.3 Service Calls Made from Wrong Context

#### 7.7.3.3.1 Background & Rationale

The current OSEK OS defines the valid calling context for service calls (see [2]), however protects against only a small set of these invalid calls, e.g. calling [Terminate-Task](#) from a Category 2 ISR.

Service	Task	Cat1 ISR	Cat2 ISR	ErrorHook	Pre/PostTaskHook	StartupHook	ShutdownHook	A <small>larm</small> Callback	ProtectionHook	inside trusted function
ActivateTask	OK		OK							OK
ActivateTaskAsyn	OK		OK							OK
TerminateTask	OK		C							
ChainTask	OK		C							
Schedule	OK		C							
GetTaskID	OK		OK	OK				OK	OK	
GetTaskState	OK		OK	OK	OK				OK	
DisableAllInterrupts	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
EnableAllInterrupts	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
SuspendAllInterrupts	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
ResumeAllInterrupts	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
SuspendOSInterrupts	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
ResumeOSInterrupts	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
GetResource	OK		OK							OK
ReleaseResource	OK		OK							OK
SetEvent	OK		OK							OK
SetEventAsyn	OK		OK							OK
ClearEvent	OK		C							
GetEvent	OK		OK	OK						OK
WaitEvent	OK		C							
GetAlarmBase	OK		OK	OK	OK					OK
GetAlarm	OK		OK	OK	OK					OK
SetRelAlarm	OK		OK							OK
SetAbsAlarm	OK		OK							OK
CancelAlarm	OK		OK							OK
GetActiveApplicationMode	OK		OK	OK	OK	OK	OK			OK
StartOS										
ShutdownOS	OK		OK	OK		OK				OK
GetApplicationID	OK		OK	OK	OK	OK	OK	OK	OK	
GetISRID	OK		OK	OK				OK	OK	
CallTrustedFunction	OK		OK							OK
CheckISRMemoryAccess	OK		OK	OK				OK	OK	
CheckTaskMemoryAccess	OK		OK	OK				OK	OK	
CheckObjectAccess	OK		OK	OK				OK	OK	
CheckObjectOwnership	OK		OK	OK				OK	OK	
StartScheduleTableRel	OK		OK							OK
StartScheduleTableAbs	OK		OK							OK
StopScheduleTable	OK		OK							OK
NextScheduleTable	OK		OK							OK
StartScheduleTableSynchron	OK		OK							OK
SyncScheduleTable	OK		OK							OK
GetScheduleTableStatus	OK		OK							OK





SetScheduleTableAsync	OK		OK						OK
IncrementCounter	OK		OK						OK
GetCounterValue	OK		OK						OK
GetElapsedValue	OK		OK						OK
TerminateApplication	OK		OK	OK <sup>1</sup>					
GetApplicationState	OK		OK	OK	OK	OK		OK	OK
GetCurrentApplicationID	OK		OK	OK	OK	OK		OK	OK
ReadPeripheral8	OK		OK						OK
ReadPeripheral16	OK		OK						OK
ReadPeripheral32	OK		OK						OK
WritePeripheral8	OK		OK						OK
WritePeripheral16	OK		OK						OK
WritePeripheral32	OK		OK						OK
ModifyPeripheral8	OK		OK						OK
ModifyPeripheral16	OK		OK						OK
ModifyPeripheral32	OK		OK						OK
DisableInterruptSource	OK		OK						OK
EnableInterruptSource	OK		OK						OK
ClearPendingInterrupt	OK		OK						
isOsStarted	OK	OK	OK	OK	OK	OK	OK	OK	OK
BudgetReplenish	OK		OK						OK

**Table 7.1: Allowed Calling Context for OS Service Calls**

In the table above "C" indicates that validity is only "Checked in Extended status by `E_OS_CALLEVEL`".

### 7.7.3.3.2 Requirements

#### [SWS\_Os\_00088]

*Upstream requirements: [SRS\\_Os\\_11009](#), [SRS\\_Os\\_11013](#)*

〔If an OS-Application makes a service call from the wrong context AND is currently not inside a Category 1 ISR the Operating System module shall not perform the requested action (the service call shall have no effect) and return `E_OS_CALLEVEL` or the "invalid value" of the service.〕

### 7.7.3.4 Services with Undefined Behaviour

#### 7.7.3.4.1 Background & Rationale

There are a number of situations where the behaviour of OSEK OS is undefined in extended status. This is unacceptable when protection is required as it would allow the

<sup>1</sup>Only in case of self termination.

Operating System module to be corrupted through its own service calls. The implementation of service protection for the Operating System module must therefore describe and implement a behaviour that does not jeopardize the integrity of the system or of any OS-Application which did not cause the specific error.

#### 7.7.3.4.2 Requirements

Tasks ends without calling a [TerminateTask](#) or [ChainTask](#)

##### [SWS\_Os\_00052]

*Upstream requirements: [SRS\\_Os\\_11009](#)*

〔If a Task returns from its entry function without making a [TerminateTask](#) or [ChainTask](#) call, the Operating System module shall terminate the Task (and call the [OsPostTaskHook](#) if configured).〕

##### [SWS\_Os\_00069]

*Upstream requirements: [SRS\\_Os\\_11009](#)*

〔If a Task returns from its entry function without making a [TerminateTask](#) or [ChainTask](#) call AND the error hook is configured, the Operating System module shall call the [ErrorHook](#) (this is done regardless of whether the Task causes other errors, e.g. [E\\_OS\\_RESOURCE](#)) with status [E\\_OS\\_MISSINGEND](#) before the Task leaves the RUNNING state.〕

##### [SWS\_Os\_00070]

*Upstream requirements: [SRS\\_Os\\_11009](#), [SRS\\_Os\\_11013](#)*

〔If a Task returns from the entry function without making a [TerminateTask](#) or [ChainTask](#) call and still holds OSEK Resources, the Operating System module shall release them.〕

##### [SWS\_Os\_00239]

*Upstream requirements: [SRS\\_Os\\_00097](#)*

〔If a Task returns from the entry function without making a [TerminateTask](#) or [ChainTask](#) call and interrupts are still disabled, the Operating System module shall enable them.〕

Category 2 ISR ends with locked interrupts or allocated resources

**[SWS\_Os\_00368]**

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If a Category 2 ISR calls `DisableAllInterrupts` / `SuspendAllInterrupts` / `SuspendOSInterrupts` and ends (returns) without calling the corresponding `EnableAllInterrupts` / `ResumeAllInterrupts` / `ResumeOSInterrupts`, the Operating System module shall perform the missing service and shall call the `ErrorHook` (if configured) with the status `E_OS_DISABLEDINT`.〕

**[SWS\_Os\_00369]**

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If a Category 2 ISR calls `GetResource` and ends (returns) without calling the corresponding `ReleaseResource`, the Operating System module shall perform the `ReleaseResource` call and shall call the `ErrorHook` (if configured) with the status `E_OS_RESOURCE`.〕

`PostTaskHook` called during `ShutdownOS`

**[SWS\_Os\_00071]**

*Upstream requirements:* [SRS\\_Os\\_00097](#)

〔If the `PostTaskHook` is configured, the Operating System module shall not call the hook if `ShutdownOS` is called.〕

Tasks/ISRs calls `EnableAllInterrupts`/`ResumeAllInterrupts`/`ResumeOSInterrupts` without a corresponding disable

**[SWS\_Os\_00092]**

*Upstream requirements:* [SRS\\_Os\\_11009](#)

〔If `EnableAllInterrupts` / `ResumeAllInterrupts` / `ResumeOSInterrupts` are called and no corresponding `DisableAllInterrupts` / `SuspendAllInterrupts` / `SuspendOSInterrupts` was done before, the Operating System module shall not perform this Operating System service.〕

Tasks/ISRs calling OS services when `DisableAllInterrupts`/`SuspendAllInterrupts`/`SuspendOSInterrupts` called

**[SWS\_Os\_00093]**


*Upstream requirements:* [SRS\\_Os\\_11009](#), [SRS\\_Os\\_11013](#)

〔If interrupts are disabled/suspended by a Task/ISR/Hook and the Task/ISR/Hook calls any Operating System service (excluding the interrupt services) then the Operating System module shall ignore the service AND shall return `E_OS_DISABLEDINT` if the service returns a `StatusType` value.〕

### 7.7.3.5 Service Restrictions for Non-Trusted OS-Applications

#### 7.7.3.5.1 Background & Rationale

The Operating System service calls available are restricted according to the calling context (see [7.7.3.3](#)). In a protected system, additional constraints need to be placed to prevent non-trusted OS-Applications executing API calls that can have a global effect on the system. Each level of restriction is a proper subset of the previous level as shown in the figure below.



**Figure 7.15: API Restrictions**

There are two defined integrity levels:

1. Trusted
2. Non-Trusted

that correspond exactly with trusted and non-trusted OS-Applications.

### 7.7.3.5.2 Requirements

#### [SWS\_Os\_00054]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔The Operating System module shall ignore calls to [Shutdownos](#) from non-trusted OS-Applications.〕

### 7.7.3.6 Service Calls on Objects in Different OS-Applications

#### 7.7.3.6.1 Background

Section [7.7.3.2](#) stated that `E_OS_ID` is returned by OSEK OS service calls when the object is invalid. Under the protection scheme a service call can be invalid because the caller does not have valid permissions for the object (a new meaning for multi-OS-Application systems).

This is a similar case to an object not being accessible in OSEK OS (for example, when a Task tries to get a Resource which exists in the system but has not been configured as used by the Task).

#### 7.7.3.6.2 Requirements

#### [SWS\_Os\_00056]

*Upstream requirements:* [SRS\\_Os\\_11001](#), [SRS\\_Os\\_11010](#), [SRS\\_Os\\_11013](#)

〔If an OS-object identifier is the parameter of an Operating System module's system service, and no sufficient access rights have been assigned to this OS-object at configuration time (parameter `Os[...].AccessingApplication`, e.g. [OsTaskAccessingApplication](#)) to the calling Task/Category 2 ISR, the Operating System module's system service shall return `E_OS_ACCESS`.〕

#### [SWS\_Os\_00449]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔[CheckTaskMemoryAccess](#) and [CheckISRMemoryAccess](#) check the memory access. Memory access checking is possible for all OS-Applications and from all OS-Applications and does not need granted rights.〕

[SWS\_Os\_00449] is an exception to [SWS\_Os\_00056].

#### [SWS\_Os\_00450]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔[CheckObjectAccess](#) checks the access rights for Operating System objects. Checking object access is possible for all OS-Applications and from all OS-Applications and does not need granted rights.〕

[SWS\_Os\_00450] is an exception to [SWS\_Os\_00056].

## 7.7.4 Protecting the Hardware used by the OS

### 7.7.4.1 Background & Rationale

Where a processor supports privileged and non-privileged mode it is usually the case that certain registers, and the instructions to modify those registers, are inaccessible outside the privileged mode.

On such hardware, executing the Operating System module in privileged mode and Tasks/ISRs in non-privileged mode protects the registers fundamental to Operating System module operation from inadvertent corruption by the objects executing in non-privileged mode. The Operating System module's services will need to execute in privileged mode as they will need to modify the registers that are protected outside this mode.

The Operating System module can use the control registers of the MPU, timer unit(s), interrupt controller, etc. and therefore it is necessary to protect those registers against non-trusted OS-Applications.

### 7.7.4.2 Requirements

#### [SWS\_Os\_00058]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔If supported by hardware, the Operating System module shall execute non-trusted OS-Applications in non-privileged mode.〕

#### [SWS\_Os\_00096]

*Upstream requirements:* [SRS\\_Os\\_11011](#)

〔As far as supported by hardware, the Operating System module shall not allow non-trusted OS-Applications to access control registers managed by the Operating System module.〕

#### [SWS\_Os\_00245]

*Upstream requirements:* [SRS\\_Os\\_11011](#)

〔If an instruction exception occurs (e.g. division by zero) the Operating System module shall call the protection hook with `E_OS_PROTECTION_EXCEPTION`.〕

### 7.7.4.3 Implementation Notes

When the Operating System module is running non-trusted OS-Applications, the Operating System module's treatment of interrupt entry and hook routines must be carefully managed.

Interrupt handling: Where the MCU supports different modes (as discussed in this section) `ISRs` will require the Operating System module to do extra work in the `ISR()` wrapper. `ISRs` will typically be entered in privileged mode. If the handler is part of a non-trusted OS-Application then the `ISR()` wrapper must make sure that a switch to non-privileged mode occurs before the handler executes.

## 7.7.5 Providing Trustedfunctions

### 7.7.5.1 Background & Rationale

An OS-Application can invoke a `Trustedfunction` provided by (another) trusted OS-Application. That can require a switch from non-privileged to privileged mode. This is typically achieved by these operations:

- Each trusted OS-Application may export services which are callable from other OS-Applications.
- During configuration these trusted services must be configured to be called from a non-trusted OS-Application.
- The call from the non-trusted OS-Application to the trusted service is using a mechanism (e.g. trap/software interrupt) provided by the Operating System. The service is passed as an identifier that is used to determine, in the trusted environment, if the service can be called.
- The Operating System offers services to check if a memory region is write/read/execute accessible from an OS-Application. It also returns information if the memory region is part of the stack space.

The Operating System software specification does not provide support for *non-trusted services*.

**Please note:** During the execution of a trusted function a protection violation or the self-termination of the calling OS-Application can be fatal. In such cases the fault reaction (e.g. restart or terminate OS-Application) impacts also the ongoing trusted function call. It is assumed that the code of the trusted function itself is free of such direct violations, but there are some cases where a violation nevertheless may occur. These are:

- **(A) Timing violation inside the trusted function:** It might happen that during the execution of a trusted function a timing violation happens. E.g. the configured execution budget of the caller is exhausted inside the trusted function. In such

cases the violation can be delayed until the function returns to the non-trusted caller (see also [SWS\_Os\_00565]).

- **(B) Parallel violations within the OS-Application which called the trusted function:** It might happen that a Task which executes the trusted function is preempted by another Task (or Category 2 ISR) of the same OS-Application. Then this other Task (or Category 2 ISR) is causing a violation, e.g. via a memory fault or a timing violation.
- **(C) Self termination of the OS-Application:** Each application can perform a self-termination, e.g. initiated by another Task of the same OS-Application. In case of an ongoing trusted function call of the OS-Application this may also impact the (trusted) OS-Application which offers the trusted function.
- **(D) Foreign termination of the OS-Application:** Each trusted OS-Application can request a termination of another OS-Application. If the to be terminated OS-Application is currently executing a trusted function it may have also impact on this trusted OS-Application. It is assumed that a (trusted) OS-Application never terminates another OS-Application with an on-going trusted function call.

Situations like (B) or (C) can be solved by avoiding preemptions in the OS-Application when a trusted function is ongoing. This can be reached by using locks which are preventing the scheduling (on the same core). The disadvantage of this approach is that it impacts the overall timing (i.e. also of other OS-Applications which use the same core). So a violation caused by another entity is avoided, but maybe at the cost of a timing violation which then may also require a restart or reset. On the other hand a careful design could solve the issue without locking, e.g. by only performing calls to trusted function from tasks with the highest priority of the OS-Application. Therefore the OS offers a (global) switch (see [OsLockTrustedFunctionCall](#)) to allow adaption of the required behaviour.

For [OsLockTrustedFunctionCall](#) == TRUE the OS will lock parallel activities of the OS-Application to avoid situations like (B) or (C).

For [OsLockTrustedFunctionCall](#) == FALSE no locks are performed by the OS and parallel activities may happen in the OS-Application.

### 7.7.5.2 Requirements

#### [SWS\_Os\_00451]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

[The Operating System module shall allow exporting services from trusted OS-Applications.]

The Operating System module provides the service [CallTrustedFunction](#) (see [SWS\_Os\_00097]) to call a trusted function from a (trusted or non-trusted) OS-Application.

**[SWS\_Os\_00100]**

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If [CallTrustedFunction](#) is called and the called trusted function is not configured the Operating System module shall call the [ErrorHook](#) with [E\\_OS\\_SERVICEID](#).〕

The Operating System module provides the services [CheckISRMemoryAccess](#) and [CheckTaskMemoryAccess](#) (see [\[SWS\\_Os\\_00512\]](#) and [\[SWS\\_Os\\_00513\]](#)) for OS-Applications to check if a memory region is write/read/execute accessible from a Task/Category 2 ISR and also return information if the memory region is part of the stack space.

## 7.8 Protection Error Handling

### 7.8.1 Background & Rationale

The Operating System can detect protection errors based on statically configured information on what the constituent parts of an OS-Application can do at runtime. See section [7.7](#).

Unlike monitoring, protection facilities will trap the erroneous state at the point the error occurs, resulting in the shortest possible time between transition into an erroneous state and detection of the fault. The different kinds of protection errors are described in the glossary. If a protection error occurs before the Operating System module is started the behaviour is not defined. If a protection error happens during shutdown, e.g. in the application-specific shutdown hook, an endless loop between the shutdown service and the protection hook may occur.

In the case of a protection error, the Operating System module calls a user provided [ProtectionHook](#) for the notification of protection errors at runtime. The [ProtectionHook](#) runs in the context of the Operating System module and must therefore be trusted code.

The Operating System module itself needs only to detect an error and provide the ability to act. The [ProtectionHook](#) can select the right action, which will be performed after returning from the [ProtectionHook](#), depending on the return value of the [ProtectionHook](#). The options are:

1. do nothing
2. for arrival rate errors: do not perform the requested action (task activation / ISR 2 call / event setting)
3. forcibly terminate the faulty Task/Category 2 ISR
4. forcibly terminate all Tasks and ISRs in the faulty OS-Application
5. shutdown the Operating System module.

Requirements [SWS\_Os\_00243] and [SWS\_Os\_00244] define the order of the default reaction if no faulty Task/Category 2 ISR or OS-Application can be found, e.g. in the system specific hook routines. Also OS-Applications are only mandatory in Scalability Classes 3 and 4, therefore in other Scalability Classes OS-Applications need not be defined.

Note that forcibly terminating interrupts is handled differently in "forcibly terminate the faulty ISR" and "forcibly terminate the OS-Application". If a faulty ISR is forcibly terminated, the current invocation of the ISR is terminated. A subsequent invocation is allowed. If the OS-Application is forcibly terminated, then the interrupt source is also disabled, preventing subsequent interrupts.

#### **Notes regarding the return value PRO\_IGNORE:**

The meaning of "do nothing" (PRO\_IGNORE) means that the error reaction is ignored. The PRO\_IGNORE is only allowed in specific situations (currently: arrival rate errors). After the error is detected (e.g. as specified in [SWS\_Os\_00466] or [SWS\_Os\_00467]) the protection hook is called. If the hook returns with PRO\_IGNORE the OS does continue its normal operation. If a service call was the root cause of the violation (e.g. an ActivateTask) and protection hook returns PRO\_IGNORE the service call shall continue its operation (e.g. to activate a Task) and return E\_OK (if successful and possible).

Example 1: A Task calls ActivateTask(B) and causes an arrival rate violation. The activation is not performed ([SWS\_Os\_00466]) and protection hook is called. When returning PRO\_IGNORE the OS continues and the ActivateTask service activates B and returns E\_OK.

Example 2: A Task A calls SetEvent for Task B (which currently waits for the event). The OS detects ([SWS\_Os\_00467]) an arrival rate violation and performs a call of the protection hook. When the call returns with PRO\_IGNORE, the SetEvent service continues and sets the event. Task B changes to READY state and a rescheduling might happen. The SetEvent service call will return E\_OK to Task A.

#### **Notes regarding the return value PRO\_PREVENT\_ARRIVAL\_RATE:**

The PRO\_PREVENT\_ARRIVAL\_RATE is used to prevent arrival rate errors.

Example 1 : A Task calls ActivateTask(B) and causes an arrival rate violation. The activation is not performed ([SWS\_Os\_00466]) and protection hook is called. When returning PRO\_PREVENT\_ARRIVAL\_RATE the OS will not perform the task activation (it prevents the arrival rate error). The ActivateTask service will return in such cases E\_OK, so no error hooks are called.

Example 2: A Task A calls SetEvent for Task B (which currently waits for the event). The OS detects ([SWS\_Os\_00467]) an arrival rate violation and performs a call of the protection hook. When the call returns with PRO\_PREVENT\_ARRIVAL\_RATE, the event setting will not be performed and the SetEvent service call will return E\_OK. Also here no additional error hooks will be called.

## 7.8.2 Requirements

### [SWS\_Os\_00211]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔The Operating System module shall execute the [ProtectionHook](#) with the same permissions as the Operating System module.〕

### [SWS\_Os\_00107]

*Upstream requirements:* [SRS\\_Os\\_11014](#)

〔If no [ProtectionHook](#) is configured and a protection error occurs, the Operating System module shall call [ShutdownOS](#).〕

### [SWS\_Os\_00106]

*Upstream requirements:* [SRS\\_Os\\_11014](#)

〔If the [ProtectionHook](#) returns [PRO\\_IGNORE](#) and was called with [E\\_OS\\_PROTECTION\\_ARRIVAL](#) the Operating System module shall perform the requested action.〕

### [SWS\_Os\_00863] Prevent arrival rate errors

*Upstream requirements:* [SRS\\_Os\\_11014](#), [SRS\\_Os\\_11008](#)

〔If the [ProtectionHook](#) returns [PRO\\_PREVENT\\_ARRIVAL\\_RATE](#) and was called with [E\\_OS\\_PROTECTION\\_ARRIVAL](#) the Operating System module shall not perform the action which caused the arrival rate error.〕

### [SWS\_Os\_00553]

*Upstream requirements:* [SRS\\_Os\\_11014](#)

〔If the [ProtectionHook](#) returns [PRO\\_TERMINATETASKISR](#) the Operating System module shall forcibly terminate the faulty Task/Category 2 ISR.〕

### [SWS\_Os\_00554]

*Upstream requirements:* [SRS\\_Os\\_11022](#)

〔If the [ProtectionHook](#) returns [PRO\\_TERMINATEAPPL](#) the Operating System module shall forcibly terminate the faulty OS-Application.〕

### [SWS\_Os\_00556]

*Upstream requirements:* [SRS\\_Os\\_11014](#)

〔If the [ProtectionHook](#) returns [PRO\\_SHUTDOWN](#) the Operating System module shall call the [ShutdownOS](#).〕

### [SWS\_Os\_00506]

*Upstream requirements:* [SRS\\_Os\\_11014](#)

〔If the [ProtectionHook](#) is called with [E\\_OS\\_PROTECTION\\_ARRIVAL](#) the only valid return values are [PRO\\_IGNORE](#) or [PRO\\_PREVENT\\_ARRIVAL\\_RATE](#) or

PRO\_SHUTDOWN<sup>2</sup>. Returning other values will result in a call to [ShutdownOS](#).]

**[SWS\_Os\_00475]**

*Upstream requirements:* [SRS\\_Os\\_11008](#)

〔If the [ProtectionHook](#) returns PRO\_IGNORE and the [ProtectionHook](#) was not called with E\_OS\_PROTECTION\_ARRIVAL then the Operating System module shall call [ShutdownOS](#).〕

**[SWS\_Os\_00243]**

*Upstream requirements:* [SRS\\_Os\\_11014](#)

〔If the [ProtectionHook](#) returns PRO\_TERMINATETASKISR and no Task or ISR can be associated with the error, the running OS-Application is forcibly terminated by the Operating System module. If even no OS-Application can be assigned, [ShutdownOS](#) is called.〕

**[SWS\_Os\_00244]**

*Upstream requirements:* [SRS\\_Os\\_11014](#)

〔If the [ProtectionHook](#) returns PRO\_TERMINATEAPPL and no OS-Application can be assigned, [ShutdownOS](#) is called.〕

**[SWS\_Os\_00108]**

*Upstream requirements:* [SRS\\_Os\\_11014](#)

〔If the Operating System module forcibly terminates a Task, it terminates the Task, releases all allocated OSEK resources and calls [EnableAllInterrupts](#) / [ResumeOSInterrupts](#) / [ResumeAllInterrupts](#) if the Task called [DisableAllInterrupts](#) / [SuspendOSInterrupts](#) / [SuspendAllInterrupts](#) before without the corresponding [EnableAllInterrupts](#) / [ResumeOSInterrupts](#) / [ResumeAllInterrupts](#) call.〕

**[SWS\_Os\_00109]**

*Upstream requirements:* [SRS\\_Os\\_11014](#)

〔If the Operating System module forcibly terminates an interrupt service routine, it clears the interrupt request, aborts the interrupt service routine (The interrupt source stays in the current state.) and releases all OSEK resources the interrupt service routine has allocated and calls [EnableAllInterrupts](#) / [ResumeOSInterrupts](#) / [ResumeAllInterrupts](#) if the interrupt called [DisableAllInterrupts](#) / [SuspendOSInterrupts](#) / [SuspendAllInterrupts](#) before without the corresponding [EnableAllInterrupts](#) / [ResumeOSInterrupts](#) / [ResumeAllInterrupts](#) call.〕

**[SWS\_Os\_00110]**

*Upstream requirements:* [SRS\\_Os\\_11014](#)

〔If the Operating System module shall forcibly terminate an OS-Application, it: shall

---

<sup>2</sup>The reason for this case is that the Task which is supervised is not necessary active (and can not be e.g. terminated) and it can be that the caller of the activation is the real problem.

- forcibly terminate all Tasks/ISRs of the OS-Application AND
- cancel all alarms of the OS-Application AND
- stop ScheduleTables of the OS-Application AND
- disable interrupt sources of Category 2 ISRs belonging to the OS-Application

]

**[SWS\_Os\_00860]***Upstream requirements: SRS\_Os\_11013*

[If the call to the [ProtectionHook](#) is caused by a trusted function which causes a E\_OS\_PROTECTION\_EXCEPTION or E\_OS\_PROTECTION\_MEMORY, the only valid return value shall be PRO\_SHUTDOWN. Returning other values shall also result in a shutdown of the OS.]

## 7.9 Operating System for Multi-Core

This chapter specifies some extensions that allow to use an AUTOSAR system on Multi-Core micro-processors. It describes the main philosophy as well as additional extensions to the existing OS functionality regarding Multi-Core. The following chapter contains a specification of a new mechanism within the OS called IOC (Inter OS-Application Communicator) that supports the communication between OS-Applications located on the same or on different cores

### 7.9.1 Background & Rationale

The existing AUTOSAR-OS is based on the OSEK/VDX Operating System which is widely used in the automotive industry. The AUTOSAR Multi-Core OS is derived from the existing AUTOSAR OS.

The Multi-Core OS in AUTOSAR is not a virtual ECU concept, instead it shall be understood as an OS that shares the same configuration and most of the code but operates on different data structures for each core.

To reduce the memory footprint all cores should use the same code base. Sometimes it can be beneficial to spend some more ROM/Flash, e.g. to use a local ROM, and "double" parts of the code to get faster ROM/Flash access.

### 7.9.1.1 Requirements


#### [SWS\_Os\_00567]

*Upstream requirements: SRS\_Os\_80008*

[The generated part of the OS is derived from a single configuration that contains the relevant information for all cores. This implies, that IDs (e.g. TaskID, ResourceID, ...) are unique across cores. Every ID shall refer exactly to one entity independent from the core on which the entity is accessed. This applies also to objects that cannot be shared between cores.]

### 7.9.2 Scheduling

The priority of the Tasks drives the scheduling. Since multiple cores run truly parallel, several Tasks can execute at the same time.



**Figure 7.16: Priorities are assigned to Tasks. The cores schedule independently from each other. The Tasks T2, T3 and T5 are executed in true parallelism. Tasks with the same priority on the same core will be executed in order of activation; Tasks with the same priority on different cores may not be executed in the order of activation, since the cores schedule independent from each other.**

The OS can be entered on each core in parallel. This optimizes scalability towards multiple cores. The cores schedule independently. This implies that the schedule on

one core does not consider the scheduling on the other cores<sup>3</sup>. A low priority Task on one core may run in parallel with a high priority Task on another core.

Tasks and ISRs cannot dynamically change cores by means of the scheduling algorithm.

### 7.9.2.1 Requirements

#### [SWS\_Os\_00568]

*Upstream requirements:* [SRS\\_Os\\_80001](#)

「Implementations shall be able to independently execute a Task or an ISR on each started AUTOSAR OS core in parallel.」

#### [SWS\_Os\_00569]

*Upstream requirements:* [SRS\\_Os\\_80001](#), [SRS\\_Os\\_80013](#)

「The scheduling strategy as defined in AUTOSAR OS shall apply for each individual core in a Multi-Core system, for the Tasks and ISR assigned to the core.」

### 7.9.3 Locatable entities (LE)

A locatable entity is an entity that has to be located entirely on one core. The assignment of LEs to cores is defined at configuration time ([OsAppEcucPartitionRef](#)).

In this release of the AUTOSAR standard OS-Applications shall be the LEs. Because every Task has to run on some core, the usage of OS-Applications becomes obligatory in AUTOSAR R4.0 for Multi-Core systems. BSW modules are not allowed to ignore OS-Applications, even if they do not use any protection mechanisms. This is independent from the SC class.

As is stated in the AUTOSAR Specification of the Operating System, if OS-Applications are used, all Tasks, ISR etc. must belong to an OS-Application. This implies, that no AUTOSAR software exists outside of an OS-Application in Multi-Core systems.

On single-core systems OS-Applications are available only for SC3 and SC4 because the mechanism is used to support memory protection and implies the usage of extended mode. In Multi-core systems OS-Applications are always available independent of memory protection and on SC1 standard mode shall be possible.

---

<sup>3</sup>This also applies to Tasks with the same priority, bound to different cores. It also means that non-preemptive Tasks cannot be preempted on the core they are running, but Tasks on other cores can run in parallel.

### 7.9.3.1 Requirements

#### [SWS\_Os\_00570]

*Upstream requirements:* [SRS\\_Os\\_80003](#), [SRS\\_Os\\_80005](#)

〔All Tasks that are assigned to the same OS-Application shall execute on the same core.〕

#### [SWS\_Os\_00571]

*Upstream requirements:* [SRS\\_Os\\_80003](#), [SRS\\_Os\\_80005](#)

〔All ISRs that are assigned to the same OS-Application shall execute on the same core.〕

#### [SWS\_Os\_00572]

*Upstream requirements:* [SRS\\_Os\\_80005](#), [SRS\\_Os\\_80006](#)

〔ISR balancing (if supported by the HW) shall be switched off at boot time by the OS.〕

#### [SWS\_Os\_00764]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔The OS module shall support OS-Applications in case of Multi-Core also for SC1 and SC2.〕

#### [SWS\_Os\_00763]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔In an SC1 system standard mode shall be possible.〕

#### [SWS\_Os\_00573]

*Upstream requirements:* [SRS\\_Os\\_80003](#), [SRS\\_Os\\_80005](#)

〔The binding of OS-Applications to cores shall be derived from the referenced Ecuc-Partition.〕

The configuration item `OsAppEcucPartitionRef` within the OS-Application container shall be used to define the core to which the EcucPartition and hence the OS-Application is bound. The OS generator will map the configuration parameter "CORE" to a certain core, so that all OS-Applications with the same configuration parameter reside on the same core.

### 7.9.4 Multi-Core start-up concept

The way cores are started depends heavily on the hardware. Typically the hardware only starts one core, referred as the master core, while the other cores (slaves) remain in halt state until they are activated by the software.

In contrast to such a master-slave system other boot concepts with cores that start independently from each other are conceivable. However it is possible to emulate master-slave behavior on such systems by software.

The AUTOSAR Multi-Core OS specification requires a system with master-slave start-up behavior, either supported directly by the hardware or emulated in software. The master core is defined to be the core that requires no software activation, whereas a slave core requires activation by software.

In Multi-Core configurations, each slave core that is used by AUTOSAR must be activated before `StartOS` is entered on the core. Depending on the hardware, it may be possible to only activate a subset of the available cores from the master. The slave cores might activate additional cores before calling `StartOS`. All cores that belong to the AUTOSAR system have to be activated by the designated AUTOSAR API function. Additionally, the `StartOS` function has to be called on all these cores.

If a core is activated it executes some HW and compiler specific operations, before the "main" function is called. In case the same "main" function is executed on each core, the cores have to be differentiated by their specific core Id within the function.

Example:

```
1 void main ()
2 {
3     StatusType rv;
4
5     /* ... */
6
7     switch (GetCoreID ())
8     {
9
10     case OS_CORE_ID_MASTER:
11         /* ... */
12
13         StartCore(OS_CORE_ID_0, &rv);
14         StartOS(OSDEFAULTAPPMODE);
15         break;
16
17     case OS_CORE_ID_0:
18         /* ... */
19
20         StartCore(OS_CORE_ID_1, &rv);
21         StartOS(DONOTCARE);
22         break;
23
24     otherwise:
25
26         StartOS(DONOTCARE);
27
28     }
29 }
```

`StartOS` synchronizes all cores twice. The first synchronization point is located before the `StartupHooks` are executed, the second after the OS-Application specific `StartupHook`s have finished and before the scheduler is started. The exact point where the second synchronization occurs depends on the implementation, but it shall be before the scheduling is started. This release of the AUTOSAR specification does not support timeouts during the synchronization phase. Cores that are activated with `StartCore` but do not call `StartOS` may cause the system to hang. It is in the responsibility of the integrator to avoid such behavior.

As shown in figure 7.17, the `StartupHook` is called on every core right after the first synchronization. However, there is only one `StartupHook` in the system. If, for example, core-individual functionality must be executed during `StartupHook` the `GetCoreID` function can be used to discriminate the individual cores. After the global `StartupHook` has finished each core performs the `StartupHook`s of its OS-Applications. Since OS-Applications are bound to cores the OS-Application specific `StartupHook`s are executed only on the core to which the corresponding OS-Application is bound.




Figure 7.17: This figure shows an example of an initialization process with 4 cores

#### 7.9.4.1 Requirements

##### [SWS\_Os\_00574]

*Upstream requirements:* [SRS\\_Os\\_80006](#)

「The master core shall be able to activate cores.」

##### [SWS\_Os\_00575]

*Upstream requirements:* [SRS\\_Os\\_80006](#)

「Any slave core shall be able to activate cores.」

**[SWS\_Os\_00576]**

*Upstream requirements:* [SRS\\_Os\\_80006](#)

〔It shall be allowed to use only a subset of the cores available on a  $\mu$ C for the AUTOSAR system.〕

**[SWS\_Os\_00577]**

*Upstream requirements:* [SRS\\_Os\\_80006](#)

〔The cores shall boot in master-slave mode. If this is not supported by the hardware, it shall be that the cores boot in parallel and emulate the behavior of a master-slave system.〕

**[SWS\_Os\_00578]**

*Upstream requirements:* [SRS\\_Os\\_80006](#)

〔In case of an emulation a slave core (CoreS), which is controlled by the AUTOSAR OS (AUTOSAR core), shall not enter the main function before another core has activated the slave core by means of [StartCore](#)(CoreS).〕

**[SWS\_Os\_00579]**

*Upstream requirements:* [SRS\\_Os\\_80001](#), [SRS\\_Os\\_80006](#)

〔All cores that belong to the AUTOSAR system shall be synchronized within the [Starttos](#) function before the scheduling is started and after the global [StartupHook](#) is called.〕

**[SWS\_Os\_00580]**

*Upstream requirements:* [SRS\\_Os\\_80006](#)

〔All cores that belong to the AUTOSAR system shall be synchronized within the [Starttos](#) before the global [StartupHook](#) is called.〕

**[SWS\_Os\_00581]**

*Upstream requirements:* [SRS\\_Os\\_80006](#)

〔The global [StartupHook](#) shall be called on all cores immediately after the first synchronization point.〕

**[SWS\_Os\_00582]**

*Upstream requirements:* [SRS\\_Os\\_80006](#), [SRS\\_Os\\_80008](#)

〔The OS-Application-specific [StartupHook](#)s shall be called after the global [StartupHook](#) but only on the cores to which the OS-Application is bound.〕

### 7.9.5 Cores under control of the AUTOSAR OS

The AUTOSAR OS controls several cores as stated above. It need not control all cores of a  $\mu$ C, however. The maximum number of controlled cores shall be configured within the [OsOS](#) section of the configuration.

The AUTOSAR OS API provides a [StartCore](#) function to start the cores under its control. The [StartCore](#) function takes a scalar value parameter of type [CoreIdType](#), specifying the core that shall be started. [StartCore](#) can be called more than once on the master core and also on slave cores. Each core can only be started once, however. For example:

```
1 StartusType rv1, rv2;
2 StartCore(OS_CORE_ID_1, &rv1);
3 StartCore(OS_CORE_ID_2, &rv2);
4 if (rv1 != E_OK) || (rv2 != E_OK)
5     EnterPanicMode();
6 StartOS(OSDEFAULTAPPMODE);
```

The [StartOS](#) function shall be called on all cores that have been activated by [StartCore](#). It is not allowed to call [StartCore](#) from a core that has already called [StartOS](#).

Cores that belong to the AUTOSAR system shall be started by the designated AUTOSAR OS API service [StartCore](#).

#### 7.9.5.1 Requirements

##### [SWS\_Os\_00583]

*Upstream requirements:* [SRS\\_Os\\_80001](#), [SRS\\_Os\\_80011](#)

[The number of cores that can be controlled by the AUTOSAR OS shall be configured offline.

A new configuration item ([OsNumberOfCores](#)) within the [OsOS](#) container is used to specify the maximum number of cores that are controlled by the AUTOSAR OS. If no value for [OsNumberOfCores](#) has been specified the number of cores shall be one.]

### 7.9.6 Multi-Core shutdown concept

AUTOSAR supports two shutdown concepts, the synchronized shutdown and the individual shutdown concept. While the synchronized shutdown is triggered by the new API function [ShutdownAllCores](#), the individual shutdown is invoked by the existing API function [ShutdownOS](#).

### 7.9.6.1 Synchronized shutdown concept

If a Task with the proper rights calls `ShutdownAllCores`, a signal is sent to all other cores to induce the shutdown procedure. Once the shutdown procedure has started on a core, interrupts and Tasks are not further processed, and no scheduling will take place, therefore it makes no sense to activate any Task, however no error will be generated. It is in the responsibility of the application developer/system integrator to make sure that any preparations for shutdown on application and basic software level are completed before calling `ShutdownAllCores` (e.g. by means of the ECU state manager).

During the shutdown procedure every core executes its OS-Application specific `ShutdownHook` functions, followed by a synchronization point. After all cores have reached the synchronization point the global `ShutdownHook` function is executed by all cores in parallel.




Figure 7.18: Example of a shutdown procedure

#### [SWS\_Os\_00586]

*Upstream requirements:* [SRS\\_Os\\_80007](#)

「During the shutdown, the OS-Application specific `ShutdownHook` shall be called on the core on which the corresponding OS-Application is bound.」

#### [SWS\_Os\_00587]

*Upstream requirements:* [SRS\\_Os\\_80007](#)

「Before calling the global `ShutdownHook`, all cores shall be synchronized.」

#### [SWS\_Os\_00588]

*Upstream requirements:* [SRS\\_Os\\_80007](#)

「The global `ShutdownHook` shall be called on all cores.」

### 7.9.6.2 Individual shutdown concept

If a Task calls [ShutdownOS](#) the OS will be shut down on the core on which [ShutdownOS](#) has been called. Every core shall be able to invoke [ShutdownOS](#). Similar to [StartOS](#) this function will shutdown the individual core. To shutdown the whole ECU [ShutdownOS](#) has to be called on every core. The function will not return.

Individual shutdown is not supported in AUTOSAR R4.x (AUTOSAR mode management will not use it).

### 7.9.6.3 Shutdown in case of fatal internal errors

In multicore systems it can happen that a fatal internal OS error is detected only on one core. In such cases a local shutdown of that core does not make sense.

#### [SWS\_Os\_00762]

*Upstream requirements: [SRS\\_Os\\_80007](#)*

[In cases where the OS detects a fatal internal error all cores shall be shut down.]

## 7.9.7 OS service functionality (overview)

Within this chapter we describe which existing single core AUTOSAR OS functionality has been extended. The following table gives an overview of all standard OS API functions. The column "Multi-Core support" contains one of the following values:

- **Extended:** The function that has been extended substantially to support special Multi-Core functionality.
- **Adapted:** the function required some minor changes but basically remains unchanged.
- **Unchanged:** the behavior of the function has not changed.
- **New:** the function is a new AUTOSAR OS API-function.

Service	Multi-Core support	Annotation
ActivateTask	Extended	Cross core use shall be supported.
CallTrustedFunction	Adapted	Function must be bound to the same core.
CancelAlarm	Extended	Cross core use shall be supported.
ChainTask	Extended	Cross core use shall be supported.
CheckISRMemoryAccess	Unchanged	
CheckObjectAccess	Unchanged	
CheckObjectOwnership	Unchanged	
CheckTASKMemoryAccess	Unchanged	





Service	Multi-Core support	Annotation
ClearEvent	Unchanged	
DisableAllInterrupts	Unchanged	Works only on the same core.
EnableAllInterrupts	Unchanged	Works only on the same core.
GetActiveApplicationMode	Unchanged	
GetAlarm	Extended	Cross core use shall be supported.
GetAlarmBase	Extended	Cross core use shall be supported.
GetApplicationID	Unchanged	
GetApplicationState	Extended	Cross core use shall be supported.
GetCoreID	New	ID of the current core.
GetCounterValue	Adapted	Cross core is not allowed.
GetElapsedValue	Adapted	Cross core is not allowed.
GetEvent	Unchanged	
GetISRID	Unchanged	
GetNumberOfActivatedCores	New	Number of cores running the AUTOSAR OS.
GetResource	Adapted	Nestable with spinlocks.
GetScheduleTableStatus	Extended	Cross core use shall be supported.
GetSpinlock	New	Occupy a spinlock.
GetTaskID	Unchanged	Works only on the same core.
GetTaskState	Extended	Cross core use shall be supported.
IncrementCounter	Adapted	Cross core is not allowed.
NextScheduleTable	Unchanged	
ReleaseResource	Adapted	Nestable with spinlocks.
ReleaseSpinlock	New	Release a spinlock.
ResumeAllInterrupts	Unchanged	Works only on the same core.
ResumeOSInterrupts	Unchanged	Works only on the same core.
Schedule	Adapted	Check for unreleased spinlocks
SetAbsAlarm	Extended	Cross core use shall be supported
SetEvent	Extended	Cross core use shall be supported.
SetRelAlarm	Extended	Cross core use shall be supported
SetScheduleTableAsync	Unchanged	
ShutdownAllCores	New	Synchronized shutdown.
ShutdownOS	Extended	Support for MC systems
StartCore	New	Start additional core
StartOS	Extended	Support for MC systems
StartScheduleTableAbs	Extended	Cross core use shall be supported.
StartScheduleTableRel	Extended	Cross core use shall be supported.
StartScheduleTableSynchron	Unchanged	
StopScheduleTable	Extended	Cross core use shall be supported.
SuspendAllInterrupts	Unchanged	Works only on the same core
SuspendOSInterrupts	Unchanged	Works only on the same core
SyncScheduleTable	Unchanged	
TerminateApplication	Extended	Check for unreleased spinlocks. Cross core use shall be supported.
TerminateTask	Adapted	Check for unreleased spinlocks





Service	Multi-Core support	Annotation
TryToGetSpinlock	New	Try to occupy a spinlock
WaitEvent	Adapted	Check for unreleased spinlocks
isOsStarted	Adapted	In case of multi-core it returns just the value for the core which called the service
BudgetReplenish	Unchanged	Works only on the same core

**Table 7.2: Gives an overview of changes to the OS Service Calles**

Service	Task	Cat1 ISR	Cat2 ISR	Error Hook	Pre-/Post-TaskHook	Startup Hook	Shutdown Hook	Alarm Call-back	Protection-Hook	inside trusted function
GetNumberOfActivated-Cores	Ok		Ok							Ok
GetCoreID	Ok	Ok	Ok	Ok	Ok	Ok	Ok	Ok	Ok	Ok
StartCore										
GetSpinlock	Ok		Ok							Ok
ReleaseSpinlock	Ok		Ok							Ok
TryToGetSpinlock	Ok		Ok							Ok
GetNumberOfActivated-Cores	Ok		Ok							Ok
ShutdownAllCores	Ok		Ok	Ok		Ok				Ok

**Table 7.3: Allowed Calling Context for OS Service Calls**

### [SWS\_Os\_00589]

*Upstream requirements: [SRS\\_Os\\_80013](#), [SRS\\_BSW\\_00459](#)*

〔All functions that are not allowed to operate cross core shall return `E_OS_CORE` in extended status if called with parameters that require a cross core operation.〕

### 7.9.8 GetTaskID

`GetTaskID` can be called both from Task and Category 2 ISR level. When called from an interrupt routine, on Single-Core systems, `GetTaskID` returns either the interrupted Task or indicates that no Task is running. On Multi-Core systems it

- indicates that no Task is running on the core or,
- returns the ID of the interrupted Task on the core.

### 7.9.9 Interrupt disabling

Note: All types of interrupts can only be disabled on the local core. This implies that the interrupt flags on other cores remain in their current state. Scheduling continues on the other cores. Running ISRs on other cores continue executing.

### 7.9.9.1 Requirements

#### [SWS\_Os\_00590]

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔The OS service `DisableAllInterrupts` shall only affect the core on which it is called.〕

#### [SWS\_Os\_00591]

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔The OS service `EnableAllInterrupts` shall only affect the core on which it is called.〕

#### [SWS\_Os\_00592]

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔The OS service `SuspendAllInterrupts` shall only affect the core on which it is called.〕

#### [SWS\_Os\_00593]

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔The OS service `ResumeAllInterrupts` shall only affect the core on which it is called.〕

#### [SWS\_Os\_00594]

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔The OS service `SuspendOSInterrupts` shall only affect the core on which it is called.〕

#### [SWS\_Os\_00595]

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔The OS service `ResumeOSInterrupts` shall only affect the core on which it is called.〕

### 7.9.10 Task activation

Task activation shall be extended to work across cores. This document will not specify any implementation details. This functions timing behavior can be slower when working across cores. If a Task has to be activated on another core, a scheduling decision is necessary on that core. If the core has not been started an error is generated.

### 7.9.10.1 Requirements

#### [SWS\_Os\_00596]

*Upstream requirements:* [SRS\\_Os\\_80001](#), [SRS\\_Os\\_80015](#)

〔It shall be possible to activate a `Task` that is part of an OS-Application located on another core, as long as the assigned access rights allow it.〕

#### [SWS\_Os\_00598]

*Upstream requirements:* [SRS\\_Os\\_80015](#)

〔The call of `ActivateTask` across cores shall behave synchronously, i.e. a call returns after the `Task` has been activated or an error has been detected. It shall not be possible to continue execution on the calling core before `ActivateTask` is accomplished on the remote core.〕

#### [SWS\_Os\_00599]

*Upstream requirements:* [SRS\\_Os\\_80015](#)

〔In case of an error when calling `ActivateTask` across cores, the error handler shall be called on the core on which `ActivateTask` was originally called.〕

#### [SWS\_Os\_00816]

*Upstream requirements:* [SRS\\_Os\\_80015](#)

〔The operating system shall provide an asynchronous version of `ActivateTask` which does not return errors to the caller, but only calls the (global) error hook (if configured). The function name shall be `ActivateTaskAsyn`.〕

### 7.9.11 Task Chaining

`Task` chaining shall be extended to work across cores. This document will not specify any implementation details. This function's timing behavior can be slower when working across cores. If a `Task` has to be activated on another core, a scheduling decision is necessary on that core. If the core has not been activated, an error is generated.

### 7.9.11.1 Requirements

#### [SWS\_Os\_00600]

*Upstream requirements:* [SRS\\_Os\\_80001](#), [SRS\\_Os\\_80015](#)

〔It shall be possible to chain a `Task` that is part of an OS-Application located on another core, as long as the assigned access rights allow it.〕

### 7.9.12 Event setting

[SetEvent](#) shall be extended to work across cores. This document will not specify any implementation details. This function's timing behavior can be slower when working across cores. If the core has not been activated, an error is generated.

#### 7.9.12.1 Requirements

##### **[SWS\_Os\_00602]**

*Upstream requirements: [SRS\\_Os\\_80016](#)*

〔It shall be possible to set an [Event](#) that is part of an OS-Application located on another core, as long as the assigned access rights allow it.〕

##### **[SWS\_Os\_00604]**

*Upstream requirements: [SRS\\_Os\\_80016](#)*

〔The call of [SetEvent](#) across cores shall behave synchronously, i.e. a call returns after the [Event](#) has been set or an error has been detected. It shall not be possible to continue execution on the calling core before [SetEvent](#) is accomplished on the remote core.〕

##### **[SWS\_Os\_00605]**

*Upstream requirements: [SRS\\_Os\\_80016](#)*

〔In case of an error when calling [SetEvent](#) across cores, the error handler shall be called on the core on which [SetEvent](#) was originally called.〕

##### **[SWS\_Os\_00817]**

*Upstream requirements: [SRS\\_Os\\_80016](#)*

〔The operating system shall provide an asynchronous version of [SetEvent](#) which does not return errors to the caller, but only calls the (global) error hook (if configured). The function name shall be [SetEventAsyn](#).〕

### 7.9.13 Activating additional cores

The mechanism by which additional cores can be activated as described in section 7.9.5

### 7.9.14 Start of the OS

It is necessary to extend the functionality of [StartOS](#). This is because [StartOS](#) is called once on each core. The user provides the so called application mode <sup>4</sup> to the Operating System through the call parameter of [StartOS](#) (AppMode). The application mode defines which of the configured (startup) objects (Tasks, Alarms, Schedule Tables) the OS automatically starts.

On a Multi-Core system all cores shall run in the same application mode. If [StartOS](#) is called with the Appmode DONOTCARE, the AppMode of the other cores is used. At least one core has to define an AppMode other than DONOTCARE.

If the application mode is the same on all cores, [StartOS](#) will proceed its task. More details can be found in chapter [7.9.4](#).

#### 7.9.14.1 Requirements

##### [SWS\_Os\_00606]

*Upstream requirements:* [SRS\\_Os\\_80001](#)

〔The AUTOSAR specification does not support the activation of AUTOSAR cores after calling [StartOS](#) on that core. If [StartCore](#) is called after [StartOS](#) it shall return with E\_OS\_ACCESS in extended status.〕

##### [SWS\_Os\_00607]

*Upstream requirements:* [SRS\\_Os\\_80006](#), [SRS\\_Os\\_80013](#)

〔[StartOS](#) shall start the OS on the core on which it is called.〕

##### [SWS\_Os\_00608]

*Upstream requirements:* [SRS\\_Os\\_80006](#)

〔If more than one core calls [StartOS](#) with an AppMode other than DONOTCARE, the AppModes shall be the same. [StartOS](#) shall check this at the first synchronization point. In case of violation, [StartOS](#) shall not start the scheduling, shall not call any [StartupHooks](#), and shall enter an endless loop on every core.〕

##### [SWS\_Os\_00609]

*Upstream requirements:* [SRS\\_Os\\_80006](#)

〔If [StartOS](#) is called with the AppMode DONOTCARE the application mode of the other core(s) (differing from DONOTCARE) shall be used.〕

##### [SWS\_Os\_00610]

*Upstream requirements:* [SRS\\_Os\\_80006](#)

〔At least one core shall define an AppMode other than DONOTCARE.〕

<sup>4</sup>This is the application mode of the Operating System and shall not be confused by other application modes defined in the AUTOSAR mode management.

**[SWS\_Os\_00611]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔If the IOC is configured, [StartOS](#) shall initialize the data structures of the IOC.〕

**[SWS\_Os\_00830] DRAFT**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔If the IOC is configured and the OS Generator is invoked in "Default mode", [StartOS](#) shall invoke the [IocInit](#) (See [\[SWS\\_Os\\_00835\]](#)) to initialize the data structures of the IOC.〕

### 7.9.15 Task termination

The termination of [Tasks](#) requires an additional check: It is not allowed to terminate a Task while a spinlock is occupied. If [TerminateTask](#) / [ChainTask](#) is called with an occupied spinlock an error is returned.

#### 7.9.15.1 Requirements

If [TerminateTask](#) (or [ChainTask](#)) is called while the calling [Task](#) holds a spinlock, the behavior is undefined in standard status.

**[SWS\_Os\_00612]**

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔In extended status [TerminateTask](#) / [ChainTask](#) shall return with an error ([E\\_OS\\_SPINLOCK](#)), which can be evaluated in the application.〕

**[SWS\_Os\_00613]**

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔Spinlocks occupied by [Tasks](#) that are terminated in response to a protection hook shall be automatically released. This applies also to the case in which an OS-Application is terminated.〕

### 7.9.16 Termination of OS-Applications

Similar to [Tasks](#) an OS-Application cannot be terminated while any of its [Tasks](#) occupy a spinlock. In such cases, the lock is automatically released. To avoid an avalanche of error handling, no calls to the [ErrorHook](#) are made.

It might be possible that [TerminateApplication](#)(A) is called in parallel from different cores. The implementation has to support such a call pattern by executing the first

arriving call of [TerminateApplication](#)(A) and ignoring any subsequent calls until the termination is completed.

### 7.9.16.1 Requirements

#### [SWS\_Os\_00614]

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔[TerminateApplication](#) shall check if any of the Tasks in the OS-Application have occupied a spinlock. If so, the spinlocks shall be released.〕

#### [SWS\_Os\_00615]

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔If [TerminateApplication](#)(A) is called in parallel from different cores, the [OsApplication](#) A is terminated by the first call, any subsequent calls will return with [E\\_OK](#) in standard and extended status without doing anything, until the termination is completed.〕

### 7.9.17 Shutdown of the OS

Every core shall be able to invoke shutdown by using the [ShutdownOS](#) function. By calling [ShutdownOS](#) only the calling core will enter the shutdown procedure.

If the user wants to shutdown all cores (more or less in parallel) [ShutdownAllCores](#) shall be used. [ShutdownOS](#) and [ShutdownAllCores](#) will not return.

The OS service [ShutdownOS](#) is not used by the AUTOSAR mode management in AUTOSAR R4.0. The function is offered for users that run the OS on cores without RTE and without mode management.

### 7.9.17.1 Requirements

#### [SWS\_Os\_00616]

*Upstream requirements:* [SRS\\_Os\\_80001](#), [SRS\\_Os\\_80007](#)

〔[ShutdownOS](#) shall be callable from each core running an AUTOSAR OS.〕

#### [SWS\_Os\_00617]

*Upstream requirements:* [SRS\\_Os\\_80007](#)

〔[ShutdownOS](#) shall shutdown the core on which it was called.〕

**[SWS\_Os\_00618]**

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔The OS shall not start `Tasks` of an OS-Application once the shutdown procedure has been entered on a particular core.〕

**[SWS\_Os\_00619]**

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔The AUTOSAR OS function `ShutdownOS` shall be callable in parallel on multiple cores.〕

**[SWS\_Os\_00620]**

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔`ShutdownOS` shall release all spinlocks which are occupied by the calling core.〕

**[SWS\_Os\_00621]**

*Upstream requirements:* [SRS\\_Os\\_80007](#)

〔`ShutdownAllCores` shall be callable from each core running an AUTOSAR OS.〕

### 7.9.18 Waiting for Events

The Event waiting mechanism must be adapted to the new Multi-Core spinlock functionality:

A Task might be de-scheduled when calling `WaitEvent`, in which case it would not be able to release the spinlock. `WaitEvent` must therefore check if the calling Task holds a spinlock. As with Resources, spinlocks cannot be occupied by Tasks in wait state.

#### 7.9.18.1 Requirements

**[SWS\_Os\_00622]**

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔The AUTOSAR Operating System `WaitEvent` API service shall check if it has been called while the calling Task has occupied a spinlock. In extended status an error `E_OS_SPINLOCK` shall be returned and the Task shall not enter the wait state.〕

### 7.9.19 Calling trusted functions

Functions can be declared as trusted as part of an OS-Application. They can then only be executed through the `CallTrustedFunction` API function. Assuming that

the access rights are configured accordingly, a `Task` from OS-Application A can call a trusted function from OS-Application B.

On a Multi-Core system, these trusted function calls from one OS-Application to another are limited to the same core.

### 7.9.19.1 Requirements

#### [SWS\_Os\_00623]

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔The OS API function `CallTrustedFunction` shall return `E_OS_ACCESS` in extended status if the target trusted function is part of an OS-Application on another core.〕

### 7.9.20 Invoking reschedule

The `Schedule` API service must be adapted to the new Multi-Core spinlock functionality in the same manner as `WaitEvent`.

A `Task` shall not actively force a de-scheduling while it occupies spinlocks.

### 7.9.20.1 Requirements

#### [SWS\_Os\_00624]

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔The AUTOSAR Operating System `Schedule` API service shall check if it has been called while the calling `Task` has occupied a spinlock. In extended status an error `E_OS_SPINLOCK` shall be returned and the scheduler shall not be called.〕

### 7.9.21 Resource handling

The `GetResource` function allows mutual exclusion between `Tasks` on the same core. The OS generator shall check offline that the `Tasks` are not on different cores.(see [7.9.29](#)) and the `GetResource` function will check this requirement online.

The priority ceiling protocol (used by `GetResource`) temporarily changes the priority of a `Task`. Such an approach fails on Multi-Core systems as the priorities are local to each core. Therefore the ceiling protocol is not sufficient to protect a critical section against access from different cores.

**[SWS\_Os\_00801]**

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔If Spinlocks and Resources are locked by a Task/ISR they have to be unlocked in strict LIFO order. `ReleaseResource` shall return `E_OS_NOFUNC` if the unlock order is violated. No other functionality shall be performed.〕

**[SWS\_Os\_00851]**

*Upstream requirements:* [SRS\\_Os\\_80008](#)

〔If `OsUseResScheduler` is TRUE, the OS generation tool shall create a virtual instance of `RES_SCHEDULER` for each configured core.〕

**[SWS\_Os\_00852]**

*Upstream requirements:* [SRS\\_Os\\_80008](#)

〔It shall be possible for tasks running on different cores to occupy their own instance of `RES_SCHEDULER` at the same time.〕

**[SWS\_Os\_00853]**

*Upstream requirements:* [SRS\\_Os\\_80008](#)

〔The ceiling priority of each instance of `RES_SCHEDULER` shall prevent the execution of any other task on the core on which it is occupied but shall have no effect on the scheduling on any other core.〕

**[SWS\_Os\_00854]**

*Upstream requirements:* [SRS\\_Os\\_00097](#)

〔If `OsUseResScheduler` is FALSE AND the configuration contains a resource called `RES_SCHEDULER`, the configured resource shall behave the same as any other configured resource.〕

**[SWS\_Os\_00855]**

*Upstream requirements:* [SRS\\_Os\\_00097](#)

〔It shall be possible to configure a LINKED resource that links to `RES_SCHEDULER`. In a multi-core configuration with `OsUseResScheduler`=TRUE, the linkage shall be to the instance of `RES_SCHEDULER` on the core to which the LINKED resource is assigned.〕

### 7.9.22 The CoreID

Every HW assigns a unique physical Id to a core. The physical core Id is the only way to distinguish between cores. The physical core Ids of a  $\mu$ C are not necessarily consecutive and do not necessarily start with zero.

The SW requires a mechanism to identify a core, e.g. to use core specific variables. Because the physical core Id usually cannot be used as a direct array index for core specific variables, a logical CoreID is necessary to map physical core Ids to array

indexes. In the SW it is not necessary to know the physical core Id, the logical CoreID is sufficient.

The mapping of OS-Applications and other SW objects to cores is specified in the configuration files. All such mappings shall be HW independent and therefore shall not be based on the physical core Id but on the logical CoreID.

The function `GetCoreID` internally maps the physical core Id to the logical CoreID. The value is defined in the configuration parameter `EcucCoreId`. `GetCoreID` can be either a C function or a macro.

### 7.9.22.1 Requirements

#### [SWS\_Os\_00625]

*Upstream requirements:* [SRS\\_Os\\_80006](#)

〔The AUTOSAR Operating System API function `GetCoreID` shall be callable before `StartOS`.〕

#### [SWS\_Os\_00627]

*Upstream requirements:* [SRS\\_Os\\_80001](#)

〔An implementation shall define a set of constants `OS_CORE_ID_<No>` of the type `CoreIdType` with `<No>` a value from 0 to `OsNumberOfCores`-1.〕

#### [SWS\_Os\_00628]


*Upstream requirements:* [SRS\\_Os\\_80001](#)

〔An implementation shall offer a constant `OS_CORE_ID_MASTER` of the type `CoreIdType` that refers to the master core.〕

### 7.9.23 Counters, background & rationale

A Counter is represented by a counter value, measured in "ticks", and some counter specific constants.

Similarly to Single-Core situation, each operating system (on each core) offers at least one Counter that is derived from a timer. Therefore, it is possible to define several Counters which belong to different OS-Applications and either resides on the same or different cores.



**Figure 7.19: Examples of allowed configurations for Counters, Alarms, Schedule-tables and ISRs**

### 7.9.24 Multi-Core restrictions on Counters

The AUTOSAR OS can only increment Counters on the core on which it resides. A Counter which is assigned to an OS-Application X cannot be incremented by an OS-Application Y if X and Y are assigned to different cores.

#### 7.9.24.1 Requirements

##### [SWS\_Os\_00629]

*Upstream requirements: SRS\_Os\_80013*

「A Counter belonging to an OS-Application shall be incremented by the core on which the OS-Application resides. The Counter shall not be incremented by other cores.」

##### [SWS\_Os\_00630]

*Upstream requirements: SRS\_Os\_80013*

「It shall not be allowed to drive a ScheduleTable from a Counter, which is assigned to a different core.」


**[SWS\_Os\_00631]**

*Upstream requirements: SRS\_Os\_80013*

[It shall not be allowed to drive an Alarm from a Counter, which is assigned to a different core.]

There are two different reasons for these restrictions:

- Race conditions can occur when cross-core modification of Counter is allowed (one core waits for a Counter to be modified by another core).
- The core which is incrementing the Counter has to check if Alarms which are based on the Counter have expired. Handling of expired Alarms is more complex when different cores manipulate the same Alarms, because mutual exclusion becomes necessary.



**Figure 7.20: Example of disallowed configurations for Counters, Alarms, Schedule-tables and Call-backs**

### 7.9.25 Synchronization of Counters

Counters are used to drive Alarms and ScheduleTables. To synchronize Alarms and ScheduleTables that reside on different cores, the corresponding Counters have to be synchronized. For example, if the hardware supports this, it is possible that corresponding free running hardware counters on different cores use the same timer (same counter value maintained by the peripheral) and therefore provide the same timebase on different cores. Software Counters can then get advanced by alarms attached to these core local corresponding hardware counters, e.g. to drive synchronized ScheduleTables on different cores. The quality of the synchronicity depends on the hardware architecture and on the system configuration. .

### 7.9.26 Alarms

The Alarm mechanism of the AUTOSAR Operating System provides services to activate Tasks, set Events, increment Counters, or call an Alarm call-back ([OsAlarm-CallbackName](#)).

As stated above, Alarms can only be bound to a Counter which resides on the same core. Tasks can be activated and Events can be set with an Alarm action regardless of the core to which the Task is bound. The access rights defined by OS-Applications have to be respected, however. Additionally it shall be allowed to manipulate Alarms when they are bound to other cores. The API-services [SetRelAlarm](#), [SetAbsAlarm](#), and [CancelAlarm](#) can be used to manipulate parameters of Alarms on other cores.

#### 7.9.26.1 Requirements

##### [SWS\_Os\_00632]

*Upstream requirements:* [SRS\\_Os\\_80018](#)

〔If an Alarm expires, it shall be allowed to activate a Task on a different core.〕

##### [SWS\_Os\_00633]

*Upstream requirements:* [SRS\\_Os\\_80018](#)

〔If an Alarm expires, it shall be allowed to set an Event on a different core.〕

##### [SWS\_Os\_00634]

*Upstream requirements:* [SRS\\_Os\\_80018](#)

〔The AUTOSAR Operating System shall process an Alarm on the core on which its corresponding OS-Application resides.〕

**[SWS\_Os\_00635]**

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔Alarm callbacks shall be executed on the core to which the Alarm is bound. This is only applicable to SC1 systems, because otherwise Alarm Callback are not allowed ([SWS\_Os\_00242]).〕

**[SWS\_Os\_00636]**

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔[SetRelAlarm](#) shall also work on an Alarm that is bound to another core.〕

**[SWS\_Os\_00637]**

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔[SetAbsAlarm](#) shall also work on an Alarm that is bound to another core.〕

**[SWS\_Os\_00638]**

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔[CancelAlarm](#) shall also work on an Alarm that is bound to another core.〕

**[SWS\_Os\_00639]**

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔[GetAlarmBase](#) shall also work on an Alarm that is bound to another core.〕

**[SWS\_Os\_00640]**

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔[GetAlarm](#) shall also work on an Alarm that is bound to another core.〕

### 7.9.27 ScheduleTables

Similarly to Alarms, ScheduleTables can be used to activate Tasks and set Events. As with Alarms, a ScheduleTable can only be bound to a Counter which resides on the same core.

To simplify system startup, it should be possible to start ScheduleTables on other cores. The system designer is responsible for the correct handling of ScheduleTables. For example, ScheduleTables can be controlled from one core.

### 7.9.27.1 Requirements

#### [SWS\_Os\_00641]

*Upstream requirements:* [SRS\\_Os\\_80018](#)

〔A ScheduleTable shall be able to activate a Task bound on a core other than the one upon which the ScheduleTables resides.〕

#### [SWS\_Os\_00642]

*Upstream requirements:* [SRS\\_Os\\_80018](#)

〔A ScheduleTable shall be able to set an Event on a core other than the one upon which the ScheduleTables resides〕

#### [SWS\_Os\_00643]

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔The AUTOSAR Operating System shall process a ScheduleTable on the core on which its corresponding OS-Application resides.〕

#### [SWS\_Os\_00644]

*Upstream requirements:* [SRS\\_Os\\_80018](#)

〔The API call [StartScheduleTableAbs](#) shall be able to start ScheduleTables of OS-Applications residing on other cores.〕

#### [SWS\_Os\_00645]

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔The API call [StartScheduleTableRel](#) shall be able to start ScheduleTables of OS-Applications residing on other cores.〕

#### [SWS\_Os\_00646]

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔The API call [StopScheduleTable](#) shall be able to stop ScheduleTables of OS-Applications residing on other cores.〕

#### [SWS\_Os\_00647]

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔The API service [GetScheduleTableStatus](#) shall be able to get the status of a ScheduleTable that is part of an OS-Application residing on a different core.〕

### 7.9.28 The spinlock mechanism


With the Multi-Core concept, a new mechanism is needed to support mutual exclusion for Tasks on different cores. This new mechanism shall not be used between Tasks

on the same core because it makes no sense. In such cases the AUTOSAR Operating System returns an error.

A *SpinlockType*, which is similar to OSEK's [ResourceType](#), shall be used. Spinlocks are configured offline.

A spinlock is a busy waiting mechanism that polls a (lock) variable until it becomes available. Typically, this requires an atomic *test and set* functionality, the details of which are implementation specific.


Once a lock variable is occupied by a Task/Category 2 ISR, other Tasks/Category 2 ISRs on other cores shall be unable to occupy the lock variable. The spinlock mechanism will not de-schedule these other Tasks while they poll the lock variable. However it might happen that a Task/ISR with a higher priority becomes ready while the lock variable is being polled. In such cases the spinning Task will be interfered. This is illustrated in figure 7.21.



**Figure 7.21: A deadlock situation caused by interference, the high priority Task spins indefinitely because the low priority Task has occupied the spinlock. In such cases the second `GetSpinlock` call will return with an error.**


A user can protect a Task against such a situation by, for example, rapping the spinlock with [SuspendAllInterrupts](#), so that it cannot be interfered by other Tasks. The OS can do this automatically for the caller - see [OsSpinlockLockMethod](#).

A second deadlock situation can be created by nested spinlocks calls, as illustrated in figure 7.22.



**Figure 7.22: This figure shows a typical deadlock caused by two spinlocks taken in different order by Tasks on two different cores**

To avoid deadlocks it is not allowed to nest different spinlocks. Optionally if spinlocks shall be nested, a unique order has to be defined. Spinlocks can only be taken in this order whereas it is allowed to skip individual spinlocks. Cycles are not allowed within the defined order. This is illustrated in figure 7.23.



**Figure 7.23: Usage of spinlocks**

This figure 7.23 shows an example in which two Tasks have access to a set of spinlocks S1 – S6. It is allowed to occupy the spinlocks in the predefined order and it is allowed to skip spinlocks. If multiple spinlocks are occupied at the same time, locking and unlocking has to occur in strict LIFO order

The spinlock mechanism is not deadlock free by itself. The order in which spinlocks from Tasks/ISRs are requested has to be mentioned in the configuration description. If a Task occupies a spinlock, scheduling shall be restricted.

Note: AUTOSAR does not prescribe which algorithms are used to implement spinlocks. Since users may want to analyze the timing behavior (e.g. lock times) an implementation shall document the real behavior.

### 7.9.28.1 Requirements

#### [SWS\_Os\_00648]

*Upstream requirements:* [SRS\\_Os\\_80018](#), [SRS\\_Os\\_80021](#)

「The AUTOSAR Operating System shall provide a spinlock mechanism that works across cores.」

#### [SWS\_Os\_00649]

*Upstream requirements:* [SRS\\_Os\\_80018](#), [SRS\\_Os\\_80021](#)

「The AUTOSAR Operating System shall provide a [GetSpinlock](#) function which occupies a spinlock. If the spinlock is already occupied, [GetSpinlock](#) shall keep on trying to occupy the spinlock until it succeeds.」

#### [SWS\_Os\_00650]

*Upstream requirements:* [SRS\\_Os\\_80018](#), [SRS\\_Os\\_80021](#)

「[GetSpinlock](#) shall be callable from Task level.」

#### [SWS\_Os\_00651]

*Upstream requirements:* [SRS\\_Os\\_80021](#)

「[GetSpinlock](#) shall be callable from Category 2 ISR level.」

The behavior of [GetSpinlock](#) is undefined if called from a category 1 ISR

#### [SWS\_Os\_00652]

*Upstream requirements:* [SRS\\_Os\\_80018](#), [SRS\\_Os\\_80021](#)

「The AUTOSAR Operating System shall provide a [TryToGetSpinlock](#) function which occupies a spinlock. If the spinlock is already occupied by a Task, [TryToGetSpinlock](#) shall return.」

#### [SWS\_Os\_00653]

*Upstream requirements:* [SRS\\_Os\\_80018](#), [SRS\\_Os\\_80021](#)

「[TryToGetSpinlock](#) shall be callable from Task level.」

#### [SWS\_Os\_00654]

*Upstream requirements:* [SRS\\_Os\\_80018](#), [SRS\\_Os\\_80021](#)

「[TryToGetSpinlock](#) shall be callable from Category 2 ISR level.」

#### [SWS\_Os\_00655]

*Upstream requirements:* [SRS\\_Os\\_80018](#), [SRS\\_Os\\_80021](#)

「The AUTOSAR Operating System shall provide a [ReleaseSpinlock](#) function which releases an occupied spinlock. If the spinlock is not occupied an error shall be returned.」

**[SWS\_Os\_00656]**

*Upstream requirements:* [SRS\\_Os\\_80018](#), [SRS\\_Os\\_80021](#)

〔[ReleaseSpinlock](#) shall be callable from Task level.〕

**[SWS\_Os\_00657]**

*Upstream requirements:* [SRS\\_Os\\_80018](#), [SRS\\_Os\\_80021](#)

〔[ReleaseSpinlock](#) shall be callable from Category 2 ISR level.〕

**[SWS\_Os\_00658]**

*Upstream requirements:* [SRS\\_Os\\_80018](#), [SRS\\_Os\\_80021](#)

〔The AUTOSAR Operating System shall generate an error if a Task tries to occupy a spinlock that is assigned to a Task/Category 2 ISR on the same core (including itself).〕

**[SWS\_Os\_00659]**

*Upstream requirements:* [SRS\\_Os\\_80018](#), [SRS\\_Os\\_80021](#)

〔The AUTOSAR Operating System shall generate an error if an Category 2 ISR tries to occupy a spinlock that is assigned to a Task/Category 2 ISR on the same core.〕

**[SWS\_Os\_00660]**

*Upstream requirements:* [SRS\\_Os\\_80018](#), [SRS\\_Os\\_80021](#)

〔A unique order in which multiple spinlocks can be occupied by a Task/Category 2 ISR on one core should be configurable in the AUTOSAR Operating System. This might be realized by the configuration item ([OsSpinlockSuccessor](#){NEXT\_SPINLOCK}) where NEXT\_SPINLOCK refers to the consecutive spinlock. (See [OsSpinlockSuccessor](#))〕

**[SWS\_Os\_00661]**

*Upstream requirements:* [SRS\\_Os\\_80018](#), [SRS\\_Os\\_80021](#)

〔The AUTOSAR Operating System shall generate an error if a Task/Category 2 ISR on a core, where the same or a different Task/ISR already holds a spinlock, tries to seize another spinlock that has not been configured as a direct or indirect successor of the latest acquired spinlock (by means of the [OsSpinlockSuccessor](#) configuration parameter) or if no successor is configured.〕

### 7.9.29 Offline checks

AUTOSAR Resources cannot be shared between Tasks/ISRs on different cores. The OS generator has to check if a user tries to assign a Resource to Tasks on different cores and stop the generation process with an error.

Counters cannot be accessed from OS-Applications on different cores. The OS generator has to reject configurations that violate this rule.

The linked list of spinlocks must be free of cycles to allow correct nesting of spinlocks in order to prevent deadlocks.

The OS generator tool must check that an OS-Application does not get assigned to a non-existing core. Additional checks at configuration time, e.g. by an AUTOSAR description editor are recommended.

### 7.9.29.1 Requirements

#### [SWS\_Os\_00662]

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔The OS generator tool shall return with an error if it detects a `Resource` referred to by any `Tasks` or `ISRs` assigned to different cores.〕

#### [SWS\_Os\_00663]

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔The OS generator tool shall return with an error if an `Alarm` is assigned to a `Counter` on a different core.〕

#### [SWS\_Os\_00664]

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔The OS generator tool shall return with an error if a `Counter` on a different core shall be incremented as an `Alarm` action.〕

#### [SWS\_Os\_00665]

*Upstream requirements:* [SRS\\_Os\\_80013](#)

〔The OS generator tool shall return with an error if a `ScheduleTable` is assigned to a `Counter` on a different core.〕

#### [SWS\_Os\_00666]

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔The OS generator tool shall return with an error if the linked list of spinlocks is not free of cycles.〕

#### [SWS\_Os\_00667]

*Upstream requirements:* [SRS\\_Os\\_80005](#)

〔The OS generator tool shall check the assignment of `OsApplications` (including the `Tasks` assigned to the `OsApplication`) to cores and return an error in case any of these cores does not exist.〕

### 7.9.30 Auto start Objects

Before scheduling starts the AUTOSAR Operating System<sup>5</sup> activates all auto-start objects that are configured. This mechanism shall work similar on a Multi-Core system. Before scheduling starts, the Multi-Core OS shall activate all configured auto-start objects on the respective core. Due to the fact that OS-Applications are defined as the locatable entity no further configuration container is required. Auto-start objects are already configured as part of an OS-Application.

#### 7.9.30.1 Requirements

##### **[SWS\_Os\_00668]**

*Upstream requirements:* [SRS\\_Os\\_80006](#)

〔The AUTOSAR Operating System shall automatically activate all auto-start Tasks configured for the current AppMode, with respect to the core, before the initial start of the scheduling.〕

##### **[SWS\_Os\_00669]**

*Upstream requirements:* [SRS\\_Os\\_80006](#)

〔The AUTOSAR Operating System shall automatically activate all auto-start Alarms configured for the current AppMode, with respect to the core, before the initial start of the scheduling.〕

##### **[SWS\_Os\_00670]**

*Upstream requirements:* [SRS\\_Os\\_80006](#)

〔The AUTOSAR Operating System shall automatically activate all auto-start ScheduleTables configured for the current AppMode, with respect to the core, before the initial start of the scheduling.〕

## 7.10 Inter-OS-Application Communicator (IOC)

### 7.10.1 Background & Rationale

IOC stands for Inter OS-Application Communicator.

The "IOC" is responsible for the communication between OS-Applications and in particular for the communication crossing core or memory protection boundaries. Its internal functionality is closely connected to the Operating System.

---

<sup>5</sup>StartOS




Figure 7.24: IOC overall view

There are use cases where 1 to N IOC code instances needs to be generated on top of the OS code which is used by multiple different Software Clusters. As those Software Clusters use different IOC configurations, as a consequence the OS code shall not include any code depending on a specific IOC configuration.

To ensure compatibility between IOC and OS code, there is still a dependency in that it is necessary to use the same OS configuration for the generation of the different IOC code Instances. Furthermore, the OS and IOC code should be generated from an OS Generator coming from the same vendor.

### [SWS\_Os\_00671]

*Upstream requirements: [SRS\\_Os\\_80020](#)*

「The IOC implementation shall be part of the Operating System

The IOC is a third type of communication, in addition to

- Intra OS-Application communication: Always handled within the RTE
- Inter ECU communication: Already available via well-defined interfaces to the communication stack (COM)

」

**IOC mode:** This is the mode where the OS generator is invoked with a configuration parameter to generate the IOC code only.

**OS mode:** This is the mode where the OS generator is invoked with a configuration parameter to generate the OS code only.

**Default mode:** This is the current behavior where the IOC code is generated along with OS code.

## [SWS\_Os\_00831] DRAFT

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔The OS Generator shall provide configuration parameters allowing IOC communication code ("IOC mode") to be generated separately from OS code ("OS mode").〕

[SWS\_Os\_00831] means that the OS Generator shall be able to produce only OS code or only IOC code in a single invocation.

## [SWS\_Os\_00832] DRAFT

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔The Operating System in the Host Software Cluster shall be able to handle multiple IOC code Instances related to different Software Clusters.〕

## [SWS\_Os\_00833] DRAFT

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔When the OS generator is invoked in "OS mode" it shall only generate the OS code. Thereby the OS code shall not include any code that depends on a specific IOC configuration, because different Clusters will use different IOC configurations with the same OS code.〕

Please note that it is mandatory to use the same OS configuration for the generation of the different IOC instances to ensure compatibility between the IOC and OS code.

## [SWS\_Os\_00834] DRAFT

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔When the OS generator is invoked in "IOC mode" it shall only generate the IOC code. Thereby the name of the C module containing the generated IOC code shall be loc.c and the name of the header file containing the generated IOC APIs shall be loc.h.〕

Requirements [SWS\_Os\_00833] and [SWS\_Os\_00834] ensure that OS and IOC can be generated independently from each other but linked together while building the ECU instance /Machine. ()

## [SWS\_Os\_00835] DRAFT

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔If the IOC is configured, there shall be a function `IocInit` responsible for the initialization of the data structures of the IOC.〕

Memory protection boundaries are a characteristic of OS-Applications and special communication mechanisms are needed to cross them. Multi-Core systems may also need additional measures to make communication between cores safe.

All AUTOSAR software, both BSW and software components, must belong to an OS-Application (see [7.9.3](#)), but not necessarily to the same one. It is expected that the BSW will be trusted code, but it shall be defined as one or more OS-Applications.

The IOC provides communication services between OS-Applications and in particular over core boundaries in Multi-Core systems. Because the cross-core communication is always an inter-OS-Application communication, the two mechanisms are combined. An inter OS-Application communication may not necessarily require a cross core communication, however.

Communication between OS-Applications is expected to be more frequent than inter ECU communication. This would be the case when existing; closely related Software Components and their runnable entities are distributed to two or more cores to increase system performance. Meeting timing constraints is expected to become more difficult, when runnables which have been designed to run on a single core are distributed over several cores.

In systems with only one core, the IOC can be omitted completely, if just one OS-Application is available, or if no OS-Application uses memory protection mechanisms.

The IOC does not provide standardized support for measurement of IOC channels.

### 7.10.2 IOC - General purpose

The IOC provides communication services which can be accessed by clients which need to communicate across OS-Application boundaries on the same ECU or Software Cluster.

The RTE uses IOC services to communicate across such boundaries. All communication must be routed through the RTE on sender (or client) and on receiver (or server) side.

Direct access to IOC services by clients other than the RTE is not supported. A use of IOC from CDDs is discouraged. Only sender/receiver communication is supported however by the IOC.

To keep the RTE as hardware independent as possible, all inter OS-Application and inter core communication mechanisms and implementation variants are encapsulated in the IOC. The IOC internal functionality is dependent on hardware architecture properties, in particular on the memory architecture.

The IOC has to guarantee data consistency in inter OS-Application and inter core (Multi-Core systems) communication, this means in particular:

- In queued communication the sequential order of communication operations shall remain unchanged. In the N:1 communication case, the order of the messages from the different sources is a property of the implementation.
- The content of all data sent in one communication operation shall remain unchanged, i.e. each communication operation shall be treated as atomic operation.
- The lock mechanism (interrupt locks; spinlocks; lock free implementation; ...) which is used by the IOC to guarantee the data consistency is not standardized.

### 7.10.3 IOC functionality

#### 7.10.3.1 Communication

The IOC provides sender-receiver (signal passing) communication only. The RTE translates Client-Server invocations and response transmissions into Sender-Receiver communication.

1:1, N:1 and N:M (unqueued only) communication are supported by the IOC.

The IOC allows the transfer of one data item per atomic communication operation. A data item can either be a value for atomic basic data types or a reference for complex data structures. The data structure must be implemented as a single memory block, however. This way the data item can be transmitted in one piece. The IOC does not need to know the internal data structure. The basic memory address and length (which can be calculated from the type of the data item) is sufficient. The IOC does, e.g., not support a conversion of endianness between cores.

Transferring more than one data item in one operation is also supported for 1:1 communication only. In this case several types and memory addresses have to be used by the IOC function. The advantage compared to sequential IOC calls is that mechanisms to open memory protection boundaries and to notify the receiver have to be executed just once. Additionally, all data items are guaranteed to be consistent, because they are transferred in one atomic operation.

The IOC provides both, unqueued (Last-is-Best, data semantics) or queued (First-In-First-Out, event semantics) communication operations. If present, the IOC internal queue has a configurable length.

Each atomic communication operation gets specified individually by its own description block in a Configuration Description with regard to sender, receiver, data type(s), notification, and queuing.

#### 7.10.3.2 Notification

The IOC optionally notifies the receiver as soon as the transferred data is available for access on the receiver side, by calling a configured callback function which gets provided by the user of the communication.

A possible implementation is to trigger an interrupt (Category 2 ISR) mechanism to invoke the callback function from the ISR on receiver side, or to use a microcontroller supplied trap. The callback function shall be efficient and compact, because it is called from within the ISR.

In certain cases, it might not be necessary to trigger an ISR to notify the receiver. The IOC generator can then select the appropriate IOC internal notification method based on the hardware architecture and other constraints. This might be more efficient than an ISR for communication between OS-Applications on the same core.

The notification might be handled completely by the client of the IOC, e.g. when the RTE calls the IOC send function, and then notifies the receiver side RTE that new data are available from the IOC. In this case, the IOC is not affected at all by the details of the notification mechanism.

In case such alternative solutions prove to be more efficient, the IOC internal notification might get removed in future AUTOSAR releases.

#### 7.10.4 IOC interface

The interface between RTE and IOC shall be similar to the interface between Software Components and the RTE, i.e. by generating specific interfaces for each communication operation instead of providing a generic API.

This supports optimization methods (like function inlining or replacing function calls by macros) much better than standardized interfaces. Most of the optimization can be performed offline at code generation time instead of consuming valuable real-time resources.

There is a unique set of IOC service APIs (at least to send and receive data) for each data communication specified in the IOC Configuration Description. Each service API gets generated and can be identified by a unique Id for each data communication. In case of N:1 communication, each sender must use its own API.

The same IOC service API and hence the same 1:1 communication can get used by more than one runnable inside the same SWC both on sender and on receiver side. However, the IOC functions are not reentrant, because otherwise e.g. spinlock errors could occur in case the IOC uses spinlocks in Multi-Core systems. The same IOC API must therefore only be called sequentially. This is no problem, if all runnable entities are scheduled within the same Task, otherwise the caller is responsible to guarantee that the same IOC API is not called again before it returns from a different invocation.

Software Components may access the IOC only via RTE. Only the RTE decides which communication services to use to support the communication needs of Software Components.

#### 7.10.5 IOC internal structure

This section gives some hints on possible IOC implementation options.

The IOC may enter the privileged mode to cross the protection boundaries between OS-Applications. The IOC therefore has to be part of the OS. Note that functionality that is placed in the kernel context might be non-interruptible by Tasks or Category 2 ISRs. The functionality can be interrupted by Cat1 ISRs, however.

The IOC send service writes data into a buffer located in a memory area which is shared with the receiving communication partners (This is one possible implementation

example using shared memory). Depending on the hardware architecture and other constraints, different implementation options might be available within the IOC. These options shall be transparent to the client (RTE), however.

The IOC ensures data consistency, i.e. there is a protection against concurrent access to the same data from all senders and the receiver for protection against inconsistent behavior and data corruption. The implementation can be hardware dependent.

In systems with shared memory, there can be a specific communication buffer for each data item in a memory section which is shared between the sending and receiving OS-Applications.

If an IOC communication with event semantics (queued) is configured the length of the queue shall be defined.

#### 7.10.6 IOC configuration and generation

Data element specific interfaces between RTE and IOC require extensive code generation. Instead of generating the IOC together with the RTE, a sequential code generation process is used, to separate generic RTE code generation and hardware dependent IOC code generation as much as possible. The following steps shall be performed:

- Step 1: Specify all information about the allocation of Software Components to OS-Applications and cores in the ECU Configuration Description file.
- Step 2: Generate the RTE. The RTE generator creates data element specific IOC services calls and the corresponding IOC Configuration Description blocks (XML format) to specify the communication relations for each data element.
- Step 3: Generate the IOC code, according to the IOC Configuration Description (Step 2) while considering the hardware description files. Additionally, generate a header file (loc.h) for inclusion in RTE.c to provide definitions, function prototypes and macros.

Each atomic communication has to be specified in the IOC Configuration Description in a standardized XML format. There is one description block per communication operation specifying:

- Unique identifier
- Data type(s)
- Sender properties
- Receiver properties
- Name of callback function on receiver side in case of notification.
- Whether communication is queued or unqueued (last is best)
- In case of queued communication: Length of the queue

For details see chapter [10.3](#)

For each inter-OS-Application communication, the RTE generator creates one or more calls to an IOC function to send or receive data, and adds a corresponding description block to the IOC Configuration Description.

In ECUs or Software Clusters with only one OS-Application, the IOC Configuration Description can be omitted.

### **[SWS\_Os\_00824]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

「All the data allocated by the OS for the IOC communication shall be wrapped with the memory allocation keywords mechanism

```
1 #define OS_<IE>_START_SEC_<sadm>
2 #include "Os_MemMap.h"
3
4 <IOC buffers>
5
6 #define OS_<IE>_STOP_SEC_<sadm>
7 #include "Os_MemMap.h"
```

where <IE> is the shortName of the sending [OsApplication](#) configured in [OsIocSendingOsApplicationRef](#) of the respective [OsIocCommunication](#) channel, and <sadm> is the shortName of the referred swAddrMethod, if configured in [OsMemoryMappingCodeLocationRef](#) of the respective [OsIocDataProperties](#) within the [OsIocCommunication](#) channel. If the [OsMemoryMappingCodeLocationRef](#) is not defined the OS is permitted to select an appropriate swAddrMethod.]

## **7.10.7 IOC integration examples**

This section describes two typical use cases that show how the IOC can support communication between OS-Applications. In both examples the OS-Applications are located on different cores of a Multi-Core system.

### **7.10.7.1 Example 1 - 1:1 sender/receiver communication without notification**

One Software Component sends data items in *event* semantics (queued) to another Software Component located on a different core. A runnable entity on the receiver side is invoked periodically (e.g. by an [Alarm](#)) and receives the data via RTE (see figure [7.25](#)).

Because the communication crosses core boundaries, the RTE invokes the IOC to transfer the data from core 0 to core 1.


On the sending side, the

```
Rte_Send_<port>_<item> (..., <data>)
```

call is mapped to an

`IocSend_<Id> (<data>)`

call.



**Figure 7.25: IOC without notification**

In this example, the `IocSend` service writes the data into a buffer, located in a shared memory area which can get read by the receiver via the IOC.

On the receiving side, the receiving runnable gets invoked periodically. The

`Rte_Receive_<port>_<item> (..., <data>)`

call is mapped to an

`IocReceive_<Id> (<data>)`

call to read data from the IOC internal queue. An additional queue within the RTE is not necessary for 1:1 communication.

The IOC generator generates all the send and receive functions. The functions might be defined as macros for optimization purposes.

This kind of port to port communication without notification is suitable for:

- Sender/receiver communication
- Queued or unqueued communication
- 1:1 communication.

### 7.10.7.2 Example 2 - N:1 client/server communication with receiver notification by RTE

One Software Component invokes a service operation that is provided by another Software Component located on a different core. A runnable entity on the receiver side is activated to calculate the result (see figure 7.26).

The RTE realizes the service on client side by mapping the client/server call to a sender/receiver communication. Because the communication crosses core boundaries, the RTE uses the IOC to transfer the data from Core 0 to Core 1.

On the sending side, the

`Rte_Call_<port>_<op> (..., <data>)`

call is mapped to a

`IocSend_<Id> (<data>)`

call to transmit the parameters over the IOC to the core hosting the server runnable.




Figure 7.26: IOC with notification by RTE

After writing the data into the IOC internal queue buffer, the `Rte_Call` function uses an OS call to notify the receiver by activating the server Task on the receiving core. This Task is provided by the RTE. This Task body is responsible for reading the data from the IOC buffer by calling `IocReceive` function and for forwarding the data to the server runnable. Depending on the return value of the IOC function, the `IocReceive` and server runnable calls might be repeated several times to empty the IOC internal queued buffer (if specified).

The result of the service on Core 1 is transferred back to the client on Core 0 in a similar way. The communication path of the result is not displayed in figure [7.26](#).

This kind of port to port communication with notification by the RTE is suitable for:

- Sender/receiver communication with notification
- Client/server communication. In this case the RTE has to provide services to map the server call into 1:1 sender/receiver communication for the server call and another sender/receiver communication to return the result to the client
- Queued or unqueued communication
- 1:1 communication, if the receiver does not poll for data periodically (In this case, the solution in example 1 might have been more suitable)
- N:1 communication.

## 7.11 System Scalability

### 7.11.1 Background & Rationale

In order to customize the operating system to the needs of the user and to take full advantage of the processor features the operating system can be scaled accordingly with scalability classes, see [[SWS\\_Os\\_00241](#)].

Feature	Scalability Class 1	Scalability Class 2	Scalability Class 3	Scalability Class 4
Minimum number of Schedule Tables supported	2	8	2	8
Minimum number of OS-Applications supported	0	0	2	2
Minimum number of software Counters supported	8	8	8	8

**Table 7.4: Minimum requirements of scalability classes**

### 7.11.2 Requirements

#### [[SWS\\_Os\\_00240](#)]

*Upstream requirements: [SRS\\_Os\\_11012](#), [SRS\\_Os\\_11016](#)*

[If an implementation of a lower scalability class supports features of higher classes then the interfaces for the features must comply with this Operating System software specification.]

## [SWS\_Os\_00241] Scalability classes

*Upstream requirements:* [SRS\\_Os\\_11012](#), [SRS\\_Os\\_11016](#)

〔

Feature	Described in Section	Scalability Class 1	Scalability Class 2	Scalability Class 3	Scalability Class 4	Hardware requirements
OSEK OS (all conformance classes)	Chapter 7.1	Yes	Yes	Yes	Yes	
Counter Interface	<a href="#">Increment-Counter</a>	Yes	Yes	Yes	Yes	
SWFRT Interface	<a href="#">GetCounter-Value</a> , <a href="#">GetElapsed-Value</a>	Yes	Yes	Yes	Yes	
ScheduleTables	Chapter 7.3	Yes	Yes	Yes	Yes	
Stack Monitoring	Chapter 7.5	Yes	Yes	Yes	Yes	
<a href="#">ProtectionHook</a>	Chapter 7.8		Yes	Yes	Yes	
Timing Protection	Chapter 7.7.2		Yes		Yes	Timer(s) with high priority interrupt
Global Time/Synchronization Support	Chapter 7.4		Yes		Yes	Global time source
Memory Protection	Chapter 7.7.1, Chapter 7.7.4			Yes	Yes	MPU
OS-Applications	Chapter 7.6, Chapter 7.12	* <sup>6</sup>	* <sup>7</sup>	Yes	Yes	
Service Protection	Chapter 7.7.3			Yes	Yes	
<a href="#">CallTrustedFunc- tion</a>	Chapter 7.7.5			Yes	Yes	(Non-)privileged Modes

The Operating System module shall support the features according to this given table.

〕

## [SWS\_Os\_00327]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔The Operating System module shall always use extended status in Scalability Class 3 and 4.〕

## 7.12 Hook Functions

### 7.12.1 Background & Rationale

Hook routines as defined in OSEK OS run at the level of the Operating System module and therefore can only belong to the trusted environment. Furthermore, these hook routines are global to the system (system-specific) and will probably be supplied by the ECU integrator.

<sup>6</sup>see [\[SWS\\_Os\\_00764\]](#)

<sup>7</sup>see [\[SWS\\_Os\\_00764\]](#)

In AUTOSAR however, each OS-Application may have the need to execute application specific code e.g. initialize some hardware in its own additional (application-specific) startup hook. These are called application specific hook routines. In general the application specific hooks have the same properties as the hook routines described in the OSEK OS specification. Differences are described below.

## 7.12.2 Requirements

### [SWS\_Os\_00439]

*Upstream requirements: SRS\_Os\_00097*

〔The Operating System module shall provide the OSEK error macros (OSEK\_error...()) to all configured error hooks AND there shall be two (like in OIL) global configuration parameters to switch these macros on or off.〕

#### StartupHook

### [SWS\_Os\_00060]

*Upstream requirements: SRS\_Os\_11001*

〔If an application-specific startup hook is configured for an OS-Application <App>, the Operating System module shall call `StartupHook_<App>` on startup of the Operating System module.〕

### [SWS\_Os\_00226]

*Upstream requirements: SRS\_Os\_11001*

〔The Operating System module shall execute an application-specific startup hook with the access rights of the associated OS-Application.〕

### [SWS\_Os\_00236]

*Upstream requirements: SRS\_Os\_11001*

〔If both a system-specific and one (or more) application specific startup hook(s) are configured, the Operating System module shall call the system-specific startup hook before the application-specific startup hook(s).〕

#### ShutdownHook

### [SWS\_Os\_00112]

*Upstream requirements: SRS\_Os\_11001*

〔If an application-specific shutdown hook is configured for an OS-Application <App>, the Operating System module shall call `ShutdownHook_<App>` on shutdown of the OS.〕

**[SWS\_Os\_00225]**

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔The Operating System module shall execute an application-specific shutdown hook with the access rights of the associated OS-Application.〕

**[SWS\_Os\_00237]**

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔If both a system-specific and one (or more) application specific shutdown hook(s) are configured, the Operating System module shall call the system-specific shutdown hook after the application-specific shutdown hook(s).〕

**ErrorHook****[SWS\_Os\_00246]**

*Upstream requirements:* [SRS\\_Os\\_11013](#)

〔When an error occurs AND an application-specific error hook is configured for the faulty OS-Application <App>, the Operating System module shall call that application-specific error hook `ErrorHook_<App>` after the system specific error hook is called (if configured).〕

**[SWS\_Os\_00085]**

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔The Operating System module shall execute an application-specific error hook with the access rights of the associated OS-Application.〕

**[SWS\_Os\_00367]**

*Upstream requirements:* [SRS\\_Os\\_00097](#)

〔Operating System module's services which do not return a `StatusType` - except `ActivateTaskAsyn` and `SetEventAsyn` - shall not raise the error hook(s).〕

## 7.13 Hardware peripheral access

### 7.13.1 Background & Rationale

On some MCU architectures, there are memory mapped hardware registers (peripheral area), which are only accessible in specific modes (e.g. in privileged mode). As long as a `Tasks/ISRs` is running with full hardware access they can directly access these registers. If memory protection is used by the Operating System, Task/ISRs of non-trusted Os-Applications cannot access such registers directly because this would be recognized as a memory violation by the Operating System.

To allow access to such registers even from non-trusted applications the Operating Systems offers the following APIs to read, write and modify registers:

- `ReadPeripheral8`
- `ReadPeripheral16`
- `ReadPeripheral32`
- `WritePeripheral8`
- `WritePeripheral16`
- `WritePeripheral32`
- `ModifyPeripheral8`
- `ModifyPeripheral16`
- `ModifyPeripheral32`

In order to control the access to the registers the access has to be configured for each `OsApplication`. By this the Os can check during run-time if a caller has sufficient rights.

### 7.13.2 Requirements

#### **[SWS\_Os\_00806]**

*Upstream requirements:* [SRS\\_Os\\_11005](#)

「Check access to peripheral registers

The Operating System shall only execute access to peripheral registers via APIs `ReadPeripheralX`, `WritePeripheralX` and `ModifyPeripheralX` if :

- parameter `Address` is in range of `OsPeripheralAreaStartAddress` and `OsPeripheralAreaEndAddress`
- parameter `Area` is valid
- the caller is configured to have sufficient rights (`OsPeripheralAreaAccessingApplication`).

」

#### **[SWS\_Os\_00807]**

*Upstream requirements:* [SRS\\_Os\\_11005](#)

「Error handling of peripheral access API

If the Operating System detects an error (see [\[SWS\\_Os\\_00806\]](#)) while executing a `ReadPeripheralX`, `WritePeripheralX` and `ModifyPeripheralX` the OS shall return the appropriate `StatusType` and call the `ErrorHook`. Otherwise `E_OK` shall be returned.」

## 7.14 Interrupt source API

### 7.14.1 Background & Rationale

The Operating System needs to guarantee the scheduling, wherefore it needs to be the only component which accesses the interrupt controller. Therefore it provides to other BSW/CDD components the interfaces `DisableInterruptSource`, `EnableInterruptSource` and `ClearPendingInterrupt` to give access to the interrupt control registers of category 2 ISRs.

The pair of `DisableInterruptSource`/`EnableInterruptSource` may be used for two different purposes:

1. A specific interrupt should be masked for a short time (potentially to avoid data consistency problems). A masked request shall be served afterwards, once the interrupt source gets enabled again.
2. Interrupt requests of a specific source should be ignored for a specific time (potentially a longer time e.g. while the CAN driver sleeps). After enabling the source, only new requests should be considered.

### 7.14.2 Requirements

#### [SWS\_Os\_00808]

*Upstream requirements:* [SRS\\_Os\\_11011](#)

〔The Operating System shall provide for each category 2 interrupt source (`OsIsrCategory == CATEGORY_2`) the APIs `DisableInterruptSource`, `EnableInterruptSource` and `ClearPendingInterrupt`.〕

`DisableInterruptSource`/`EnableInterruptSource` does not support nested calls.

#### [SWS\_Os\_00809]

*Upstream requirements:* [SRS\\_Os\\_11011](#)

〔Nested calls of interrupt source control API〕

The Operating System shall return `E_OS_NOFUNC` (in EXTENDED status) in case `DisableInterruptSource` is called for an interrupt source which is already disabled or `EnableInterruptSource` is called for an interrupt source which is already enabled.〕

#### [SWS\_Os\_00810]

*Upstream requirements:* [SRS\\_Os\\_11011](#)

〔Error handling of interrupt source control API〕

If the Operating System detects an error while executing a `DisableInterruptSource`, `EnableInterruptSource` and `ClearPendingInterrupt` the OS shall

return the appropriate `StatusType` and call the `ErrorHook`. Otherwise `E_OK` shall be returned.]

**[SWS\_Os\_00811]**

*Upstream requirements: SRS\_Os\_11011*

〔A call of `EnableInterruptSource` shall enable the requested interrupt source by modifying the interrupt controller registers. Additionally it shall clear the interrupt pending flag.〕

**[SWS\_Os\_00812]**

*Upstream requirements: SRS\_Os\_11011*

〔A call of `DisableInterruptSource` shall disable the requested interrupt source by modifying the interrupt controller registers.〕

**[SWS\_Os\_00813]**

*Upstream requirements: SRS\_Os\_11011*

〔A call of `ClearPendingInterrupt` shall clear the interrupt pending flag by modifying the respective interrupt controller registers.〕

**[SWS\_Os\_00814]**

*Upstream requirements: SRS\_Os\_11011*

〔Clearing of pending interrupts shall be restricted to clearing the pending flag in the interrupt controller.〕

Note: This does not necessarily guarantee that the interrupt request is cleared successfully, i.e. the `ISR` may still be serviced afterwards. (This may happen due to racing conditions or as the request needs to be cleared in the requesting hardware unit also.)

## 7.15 Error classification

AUTOSAR BSW modules normally report their errors to Det (development errors) or Dem (production errors). The OS handles errors differently (see also [2]) and does not report its errors to Dem/Det. If a reporting of errors to Dem/Det is needed the user can perform these actions in the `ErrorHook`.

The following table contains all error codes which might be reported from the OS (besides those already defined in [2])

**[SWS\_Os\_91025] Definition of development errors in module Os***Upstream requirements: [SRS\\_BSW\\_00480](#)*

[

Type of error	Related error code	Error value
An invalid address is given as a parameter to a service.	E_OS_ILLEGAL_ADDRESS	Assigned by implementation
A memory access violation occurred	E_OS_PROTECTION_MEMORY	Assigned by implementation
A stack fault detected via stack monitoring by the OS	E_OS_STACKFAULT	Assigned by implementation
Core is not available	E_OS_CORE	Assigned by implementation
Potential deadlock due to wrong nesting	E_OS_NESTING_DEADLOCK	Assigned by implementation
Tasks terminates without a TerminateTask() or ChainTask() call.	E_OS_MISSINGEND	Assigned by implementation
A Task/Category 2 ISR blocks for too long	E_OS_PROTECTION_LOCKED	Assigned by implementation
De-scheduling with occupied spinlock	E_OS_SPINLOCK	Assigned by implementation
Service cannot be called.	E_OS_SERVICEID	Assigned by implementation
A trap occurred	E_OS_PROTECTION_EXCEPTION	Assigned by implementation
Deadlock situation due to interference	E_OS_INTERFERENCE_DEADLOCK	Assigned by implementation
A Task or Category 2 ISR exceeds its execution time budget	E_OS_PROTECTION_TIME	Assigned by implementation
A service of the OS is called inside an interrupt disable/enable pair.	E_OS_DISABLEDINT	Assigned by implementation
A Task/Category 2 ISR arrives before its timeframe has expired	E_OS_PROTECTION_ARRIVAL	Assigned by implementation

]

**7.16 ARTI Debug Information****[SWS\_Os\_00858]***Upstream requirements: [SRS\\_Os\\_12001](#)*

[The OS shall create an ARTI module description file.]

**[SWS\_Os\_00829]***Upstream requirements: [SRS\\_Os\\_12003](#)*

[ARTI module description file shall support all ORTI containers.]

The ARTI Debug Information intends to enable the attached tool to evaluate and display information about the operating system, its state, its performance, the different Task states, the different operating system objects etc.

Additionally the ARTI Debug Information contains dynamic information as a set of attributes that are represented by formulas to access corresponding dynamic values. Formulas for dynamic data access are comprised of constants, operations, and symbolic names within the target file. To obtain internal values of the required OS objects, the debug tool can then evaluate the given formula.

### 7.16.1 OS ARTI Objects

It describes a set of attributes for system objects and a method for interpreting the data obtained. The types defined in the section are specified to allow the debugger to determine the target memory access method as well as the best way of displaying the retrieved data. In most cases the information that the user will require to see is a textual description of an attribute rather than the actual value read from the variable.

An example of this is as follows; when a user requests the current state of a Task he will expect to see something like RUNNING, WAITING, READY or SUSPENDED, instead of the actual numeric value that is used by the OS to represent this information internally. For this reason a mapping is specified, which allows a kernel manufacturer to describe how an internal OS value must be mapped to a descriptive value.

- ArtiOs
- ArtiHwCore
- ArtiOsAlarm
- ArtiOsContext
- ArtiOsIslt
- ArtiOsResource
- ArtiOsMessageContainer
- ArtiOsScheduleTable
- ArtiOsSpinlock
- ArtiOsStack
- ArtiOsTask

These objects are declared in Arti containers with definitions named "\*Class". The instances of these objects are placed in the same Arti container with definitions named "\*Instance".

## 7.17 ARTI Hook Macros

### [SWS\_Os\_00836]

*Upstream requirements: RS\_ARTIFO\_00014, SRS\_Os\_12002*

〔The OS shall incorporate special macros that can be used by an ARTI trace tool to insert tracing functionality of any kind.〕

These macros shall be active only if the Boolean configuration parameter `OsUseArti` is set to true, thereby enabling tracing support globally within the OS.]

### [SWS\_Os\_00837]

*Upstream requirements: RS\_ARTIFO\_00014, SRS\_Os\_12002*

〔The hooks for an AUTOSAR CP OS shall follow the general structure of ARTI macros: `ARTI_TRACE(_contextName, _className, _instanceName, instanceParameter, _eventName, eventParameter);`〕

Some of the parameters are using literal text (Token) rather than a symbolic identifier. This allows a macro definition concatenating these parameters to more specific macros. Passing and evaluating all parameters at run-time would be very costly especially by means of run-time consumption. Here is a possible implementation of the generic `ARTI_TRACE` macro as it could be defined by a ARTI trace tool vendor to match the interface of his trace tool:

```
1 #define ARTI_TRACE(_contextName, _className, _instanceName, \
                  instanceParameter, _eventName, eventParameter) \
2 ARTI_TRACE##_##_className##_##_eventName##_##_instanceName##_##_# \
                  _contextName((instanceParameter), (eventParameter))
```

Such an implementation will generate one hook for all the possible combinations of `_className`, `_eventName` and `_contextName` and pass only parameters `instance_id` and `event_value` at run-time.

The parameters' meanings are described in the following.

- `_contextName` Token, literal text, name of the context. One of the following:
  - NOSUSP indicating that the hook gets called in a context where interrupts are disabled
  - SPRVSR indicating that the called hook may disable interrupts
  - USER indicating the called hook cannot disable interrupts
- `_className` Token, literal text, name of the class of macros. Predefined classes for an AUTOSAR OS are:
  - AR\_CP\_OS\_APPLICATION starts and stops the application
  - AR\_CP\_OS\_TASK schedules Tasks
  - AR\_CP\_OS\_CAT2ISR dispatches Category 2 interrupts

- AR\_CP\_OS\_SERVICECALLS calls service routines
- AR\_CP\_OS\_SPINLOCK calls spinlocks
- AR\_CP\_OS\_HOOK calls OS hooks
- \_instanceName Short name of the OS instance as defined in the ARXML.
- instanceParameter Index [uint32] 0..4294967295 of the CPU core as seen by the OS (<Core Index>). Should always start with 0 and count up consecutively. This might be equal to the index of the physical core, but doesn't have to be.
- \_eventName Token, literal text, name of the event as defined for a particular class.
- eventParameter A [uint32] 0..4294967295 value as an argument to an event.

Therefore all ARTI macros for an AUTOSAR OS do compile the following template:

```
1 ARTI_TRACE(_contextName, <AR OS Class Name>, <OS Short Name>, <Core
Index>, <Event Name>, <Event Parameter>)
```

Example of hook call in OS:

```
1 ARTI_TRACE(NOSUSP, AR_CP_OS_TASK, OS1, (uint32)GetCoreID(),
OsTask_Activation, (uint32)GetTaskID());
```

Example of preprocessed output:

```
1 ARTI_TRACE_NOSUSP_AR_CP_OS_TASK_OS1_OsTask_Activation((uint32)GetCoreID()
(), (uint32)GetTaskID());
```

### 7.17.1 Class AR\_CP\_OS\_APPLICATION

#### [SWS\_Os\_00838]

*Upstream requirements: [RS\\_Arti\\_00029](#)*

〔The OS shall create events of class AR\_CP\_OS\_APPLICATION to allow tracing of OS applications [as defined for the AUTOSAR Classic Platform]〕

The states used by ARTI are based on the states of OS-Applications, see figure 7.10 in chapter Background & Rationale [7.6.1](#) for details.

States used by ARTI:

ARTI	OS
Initial	-
Accessible	APPLICATION_ACCESSIBLE
Terminated	APPLICATION_TERMINATED

**Table 7.5: OS-Application states used by ARTI**

Transitions used by ARTI:

Name	Transition	Event Name
Start	Initial -> Accessible	OsApplication_Start
Terminate	Accessible -> Terminated	OsApplication_Terminate

**Table 7.6: OS-Application transitions used by ARTI**

### [SWS\_Os\_00839]

*Upstream requirements: RS\_ARTIFO\_00015*

ARTI macros of the class AR\_CP\_OS\_APPLICATION shall compile the following template:

```
1 ARTI_TRACE (_contextName, AR_CP_OS_APPLICATION, <OS Short Name>, <Core
ID>, <Event Name>, <Application ID>)
```

]

The <Core ID> for any event shall represent the core id where the corresponding application is running on.

The <Event Name> should follow the transition table above.

The <Application ID> shall be a numeric identifier of the OS Application.

### 7.17.2 Class AR\_CP\_OS\_TASK

ARTI needs to trace all Task states and all state transitions within the OS. For some timing parameters (e.g. the "runtime" of a Task, which goes from started to terminated), the simple "ready" state of the OS is not enough. Tools evaluating the timings need to reconstruct a more complex state diagram by calculating the transitions from history. To be compatible to the pure OS state diagram, AR\_CP\_OS\_TASK refers to this state model, knowing that tools need to postprocess the event flow to get all relevant information. However, if an OS implementation can provide a more detailed state diagram, ARTI allows to define more events that won't need postprocessing and allow earlier synchronization of the trace if it is truncated (limited trace buffers). This state diagram is then handled with the class "AR\_CP\_OSARTI\_TASK". If possible, the second state machine is to be preferred.

### [SWS\_Os\_00840]

*Upstream requirements: RS\_Arti\_00030*

The OS shall create events that follow the state machine defined in the classes AR\_CP\_OSARTI\_TASK or AR\_CP\_OS\_TASK. Both classes may be used for task-level tracing, with AR\_CP\_OSARTI\_TASK being preferred due to its extended tracing capabilities.]

### [SWS\_Os\_00864] Task State Order

*Upstream requirements: RS\_Arti\_00030*

「The OS shall invoke ARTI hooks for tasks following the order specified in ISO 17356-3 "Task state model".」

### [SWS\_Os\_00865] Task Running State

*Upstream requirements: RS\_Arti\_00030*

「Only one task shall be in the "Running" state for each core at a time.」

AR\_CP\_OS\_TASK

The following state diagram shows the states and transitions as defined by the OS:




Figure 7.27: ARTI Task states

Transitions used by ARTI:

Name	Transition	Event Name
Activate	Suspended -> Ready	OsTask_Activate
Start	Ready -> Running	OsTask_Start
Preempt	Running -> Ready	OsTask_Preempt
Wait	Running -> Waiting	OsTask_Wait
Release	Waiting -> Ready	OsTask_Release
Terminate	Running -> Suspended	OsTask_Terminate

Table 7.7: Task transitions used by ARTI

AR\_CP\_OSARTI\_TASK

The class AR\_CP\_OSARTI\_TASK contains events allowing the tracing of OS Tasks with an enhanced state model.

The following states diagram shows the state machine as used by ARTI:




Figure 7.28: ARTI enhanced Task states

States used by ARTI:

ARTI	OS
Suspended	SUSPENDED
Activated	READY
Running	RUNNING
Preempted	READY
Waiting	WAITING
Released	READY

Table 7.8: Task states used by ARTI

Transitions used by ARTI:

Name	Transition	Event Name
Activate	Suspended -> Activated	OsTask_Activate
Start	Activated -> Running	OsTask_Start
Preempt	Running -> Preempted	OsTask_Preempt
Resume	Preempted -> Running	OsTask_Resume
Wait	Running -> Waiting	OsTask_Wait





Name	Transition	Event Name
Release	Waiting -> Released	OsTask_Release
Continue	Released -> Running	OsTask_Continue
Terminate	Running -> Suspended	OsTask_Terminate

**Table 7.9: Enhanced task transitions used by ARTI**

### [SWS\_Os\_00841]

*Upstream requirements: RS\_ARTIFO\_00015*

ARTI macros of the classes AR\_CP\_OS\_TASK and AR\_CP\_OSARTI\_TASK shall compile the following templates:

- 1 ARTI\_TRACE(\_contextName, AR\_CP\_OS\_TASK, <OS Short Name>, <Core ID>, <Event Name>, <Task ID>)
- 2 ARTI\_TRACE(\_contextName, AR\_CP\_OSARTI\_TASK, <OS Short Name>, <Core ID>, <Event Name>, <Task ID>)

]

The <Core ID> for any event shall represent the core id where the corresponding Task is scheduled on.

The <Event Name> should follow the transition table above.

The <Task ID> shall be a numeric identifier of the OS Task.

### [SWS\_Os\_00866] ARTI Hook Sequence Task Termination

*Upstream requirements: RS\_Arti\_00030*

If a task is in the Ready, Activated, Released, or Preempted state when another task terminates, the OS shall invoke the OsTask\_Terminate event for the terminating task, followed by the OsTask\_Start, OsTask\_Resume, or OsTask\_Continue event for the task transitioning to the Running state.]

### [SWS\_Os\_00867] ARTI Hook Sequence Task Preemption

*Upstream requirements: RS\_Arti\_00030*

If a task (B) is transitioning to Running state while another task (A) is in the Running state, the OS shall first invoke the OsTask\_Preempt event for the already running task (A), followed by the OsTask\_Start or OsTask\_Resume event for the task (B).]


### [SWS\_Os\_00868] ARTI Hook Sequence Task Chaining

*Upstream requirements: RS\_Arti\_00030*

In the case of task chaining, the OS shall first invoke the OsTask\_Terminate event for the task that called the ChainTask() service. Followed by an OsTask\_Activate event for the task which got chained to it. The same is true if the task chains to itself.]

**Example 7.1**
**Single Basic Task:**

The following diagram shows the life cycle of a single terminating basic task.




**Figure 7.29: Single Basic Task**

The diagram illustrates the order of events; however, it does not depict the timing. The OS shall call the corresponding ARTI hooks for the events shown in the diagram. Therefore, two events cannot happen at the same point in time. Even if no other task is running, as shown in the diagram, it is expected that the OS calls both ARTI hooks (Activate and Start). It will take the CPU some time to call the two ARTI hooks and therefore the two events will be spaced apart in time.

**Example 7.2**
**Two Basic Tasks Without Preemption:**

The following diagram shows the life cycle of two terminating basic tasks. Task A starts first, Task B which has a lower priority than Task A gets activated and will therefore run after Task A.



**Figure 7.30: Two Basic Tasks Without Preemption**

### Example 7.3

Two Basic Tasks With Preemption:

The following diagram shows the life cycle of a two terminating basic task. Task A starts first, Task B which has a higher priority than Task A gets activated and will therefore preempt it.




Figure 7.31: Two Basic Tasks With Preemption

### Example 7.4

Two Basic Tasks Chained:

The following diagram shows the life cycle of task A chaining to task B.




Figure 7.32: Two Basic Tasks Chained

### Example 7.5

Single Basic Task Chains to Itself:

The following diagram shows the life cycle of a single terminating basic task which uses task chaining to activate itself one more time, therefore runs a second time before it finally terminates.




Figure 7.33: Task Chained to Itself

There will be a rescheduling between step (3) and (4), if a task with a higher or same priority is in ready state during the ChainTask call.

### 7.17.3 Class AR\_CP\_OS\_CAT2ISR

#### [SWS\_Os\_00849]

*Upstream requirements: RS\_Arti\_00031*


[The OS shall create events to trace all states of Cat2Isrs and all state transitions within the OS ("Cat2Isr" refers to a category 2 interrupt service routine).]

For some timing parameters (e.g. the interrupt pending time), the simple Category 2 interrupt start/stop of the OS is not enough. Tools evaluating the timings need to reconstruct a more complex state diagram by calculating the transitions from history. To be compatible to the OS, AR\_CP\_OS\_CAT2ISR refers to this state model, knowing that tools need to postprocess the event flow to get all relevant information. However, if an OS implementation can provide a more detailed state diagram, ARTI allows to define more events that won't need postprocessing and allow earlier synchronization of the trace if it is truncated (limited trace buffers). This state diagram is then handled with the class "AR\_CP\_OSARTI\_CAT2ISR". If possible, the second state machine is to be preferred.

AR\_CP\_OS\_CAT2ISR

The class AR\_CP\_OS\_CAT2ISR contains events allowing the tracing of Category 2 interrupts as defined for the AUTOSAR Classic Platform.

The following state diagram shows the states and transitions as defined by the OS:



**Figure 7.34: ARTI category 2 ISR states**

Transitions used by ARTI:

Name	Transition	Event Name
Start	Inactive -> Running	OsCat2Isr_Start
Stop	Running -> Inactive	OsCat2Isr_Stop

**Table 7.10: ISR transitions used by ARTI**

### AR\_CP\_OSARTI\_CAT2ISR

The class AR\_CP\_OSARTI\_CAT2ISR contains events allowing the tracing of Category 2 interrupts with an enhanced state model.

The following state diagram shows the state machine as used by ARTI:




Figure 7.35: ARTI enhanced category 2 ISR states

States used by ARTI:

ARTI	OS
Inactive	Inactive
Activated	Inactive
Running	Running
Preempted	Running

Table 7.11: ISR states used by ARTI

Transitions used by ARTI:

Name	Transition	Event Name
Activate	Inactive-> Activated	OsCat2Isr_Activate
Start	Activated -> Running	OsCat2Isr_Start
Preempt	Running -> Preempted	OsCat2Isr_Preempt
Resume	Preempted -> Running	OsCat2Isr_Resume
Stop	Running -> Inactive	OsCat2Isr_Stop

Table 7.12: Enhanced ISR transitions used by ARTI

### [SWS\_Os\_00842]

Upstream requirements: [RS\\_ARTIFO\\_00015](#)

[ARTI macros of the classes AR\_CP\_OS\_CAT2ISR and AR\_CP\_OSARTI\_CAT2ISR shall compile the following template:

- 1 ARTI\_TRACE(\_contextName, AR\_CP\_OS\_CAT2ISR, <OS Short Name>, <Core Index>, <Event Name>, <Cat2Isr Index>)
- 2 ARTI\_TRACE(\_contextName, AR\_CP\_OSARTI\_CAT2ISR, <OS Short Name>, <Core Index>, <Event Name>, <Cat2Isr Index>)

]

The <Core Index> for any event shall represent the core index where the corresponding Category 2 interrupt is scheduled on.

The <Event Name> should follow the transition table above.

The <Cat2Isr Index> shall be a numeric identifier of the Category 2 interrupt.

### Example 7.6

Category 2 ISR interrupting a task without rescheduling:

The following diagram shows a category 2 ISR interrupting a task. Depending on the implementation of the OS, a category 2 ISR may cause a preemption of a task. The state transition to the Preempted state is optional, as there is no state model in the OS that refers to ISRs and tasks. If the task state does not change to Preempted, the task stays in the Running state during the whole ISR run.





Figure 7.36: ISR2 Interrupting Task

### Example 7.7

Category 2 ISR causing a rescheduling of tasks:

The following diagram shows a category 2 ISR interrupting Task A and activating the higher priority task B. Task B gets scheduled and preempts Task A. Depending on the implementation of the OS, the preemption of Task A may already happen at the activation of the ISR (between 3 and 4), or after the activation of Task B (between 5 and 8).



#### 7.17.4 Class AR\_CP\_OS\_SERVICECALLS

##### [SWS\_Os\_00843]

*Upstream requirements:* [RS\\_Arti\\_00032](#)

「The OS shall create events of class AR\_CP\_OS\_SERVICECALLS when entering and exiting the service call from an application context.」

These hooks shall only be called, if the service call is called from an application context. It shall not be called, if the service call is used within the OS context.

The events apply only to the entries and exits of the service calls, not to the objects (and their states) handled by the service call.

##### [SWS\_Os\_00844]

*Upstream requirements:* [RS\\_ARTIFO\\_00015](#)

「ARTI macros of the class AR\_CP\_OS\_SERVICECALLS shall compile the following template:」

```
1 ARTI_TRACE (_contextName, AR_CP_OS_SERVICECALLS, <OS Short Name>, <Core
Index>, <eventName>, <eventParameter>)
```

]

The <Core Index> for any event in the following table shall represent the core id where the corresponding service call is called.

The <eventName> is a string literal composed of a prefix "OsServiceCall", the service call name and "\_Start" or "\_Return" for the entry or exit of the service call. E.g. when [ActivateTask](#) is called, the event names on entry and exit are OsServiceCall\_ActivateTask\_Start rsp. OsServiceCall\_ActivateTask\_Return.

The <eventParamter> is an uint32 representation of either one of the function parameters or the return value. It depends on the service call and is listed in the following table:

OS Service Call	From	eventParameter on Start	on Return
<a href="#">ActivateTask</a>	OSEK	TaskID	( <a href="#">StatusType</a> ) returnValue
<a href="#">TerminateTask</a>	OSEK	TaskID	( <a href="#">StatusType</a> ) returnValue
<a href="#">ChainTask</a>	OSEK	TaskID	( <a href="#">StatusType</a> ) returnValue
<a href="#">Schedule</a>	OSEK	0	( <a href="#">StatusType</a> ) returnValue
<a href="#">GetTaskID</a>	OSEK	0	( <a href="#">TaskType</a> ) *TaskID
<a href="#">GetTaskState</a>	OSEK	TaskID	( <a href="#">TaskStateType</a> ) *State
<a href="#">EnableAllInterrupts</a>	OSEK	0	0
<a href="#">DisableAllInterrupts</a>	OSEK	0	0
<a href="#">ResumeAllInterrupts</a>	OSEK	0	0
<a href="#">SuspendAllInterrupts</a>	OSEK	0	0
<a href="#">ResumeOSInterrupts</a>	OSEK	0	0
<a href="#">SuspendOSInterrupts</a>	OSEK	0	0
<a href="#">GetResource</a>	OSEK	ResID	( <a href="#">StatusType</a> ) returnValue
<a href="#">ReleaseResource</a>	OSEK	ResID	( <a href="#">StatusType</a> ) returnValue
<a href="#">SetEvent</a>	OSEK	TaskID	( <a href="#">StatusType</a> ) returnValue
<a href="#">ClearEvent</a>	OSEK	Mask	( <a href="#">StatusType</a> ) returnValue
<a href="#">GetEvent</a>	OSEK	TaskID	( <a href="#">EventMaskType</a> ) * Event
<a href="#">WaitEvent</a>	OSEK	Mask	( <a href="#">StatusType</a> ) returnValue
<a href="#">GetAlarmBase</a>	OSEK	AlarmID	( <a href="#">AlarmBaseRefType</a> ) Info
<a href="#">GetAlarm</a>	OSEK	AlarmID	( <a href="#">TickType</a> ) *Tick
<a href="#">SetRelAlarm</a>	OSEK	AlarmID	( <a href="#">StatusType</a> ) returnValue
<a href="#">SetAbsAlarm</a>	OSEK	AlarmID	( <a href="#">StatusType</a> ) returnValue
<a href="#">CancelAlarm</a>	OSEK	AlarmID	( <a href="#">StatusType</a> ) returnValue
<a href="#">GetActiveApplication-Mode</a>	OSEK	0	( <a href="#">AppModeType</a> ) returnValue
<a href="#">StartOS</a>	OSEK	Mode	not applicable
<a href="#">ShutdownOS</a>	OSEK	Error	not applicable
<a href="#">GetApplicationID</a>	AUTOSAR	0	( <a href="#">ApplicationType</a> ) return Value
<a href="#">GetCurrentApplicationID</a>	AUTOSAR	0	( <a href="#">ApplicationType</a> ) return Value
<a href="#">GetISRID</a>	AUTOSAR	0	( <a href="#">ISRTYPE</a> ) return Value
<a href="#">CallTrustedFunction</a>	AUTOSAR	FunctionIndex	( <a href="#">StatusType</a> ) returnValue





OS Service Call	From	eventParameter on Start	on Return
CheckISRMemoryAccess	AUTOSAR	ISRID	(AccessType) returnValue
CheckTaskMemoryAccess	AUTOSAR	TaskID	(AccessType) returnValue
CheckObjectAccess	AUTOSAR	AppID	(ObjectAccessType) returnValue
CheckObjectOwnership	AUTOSAR	ObjectTypeType	(ApplicationType) returnValue
StartScheduleTableRel	AUTOSAR	ScheduleTableID	(StatusType) returnValue
StartScheduleTableAbs	AUTOSAR	ScheduleTableID	(StatusType) returnValue
StopScheduleTable	AUTOSAR	ScheduleTableID	(StatusType) returnValue
NextScheduleTable	AUTOSAR	ScheduleTableID_To	(StatusType) returnValue
StartScheduleTableSynchron	AUTOSAR	ScheduleTableID	(StatusType) returnValue
SyncScheduleTable	AUTOSAR	ScheduleTableID	(StatusType) returnValue
SetScheduleTableAsync	AUTOSAR	ScheduleTableID	(StatusType) returnValue
GetScheduleTableStatus	AUTOSAR	ScheduleTableID	(ScheduleTableStatusType) *ScheduleStatus
IncrementCounter	AUTOSAR	CounterID	(StatusType) returnValue
GetCounterValue	AUTOSAR	CounterID	(TickType) *Value
GetElapsedValue	AUTOSAR	CounterID	(TickType) *ElapsedValue
TerminateApplication	AUTOSAR	Application	(StatusType) returnValue
GetApplicationState	AUTOSAR	Application	(ApplicationStateType) *Value
GetNumberOfActivatedCores	AUTOSAR	0	(uint32) returnValue
GetCoreID	AUTOSAR	0	(CoreIdType) returnValue
StartCore	AUTOSAR	CoreID	(StatusType) *Status
GetSpinlock	AUTOSAR	SpinlockId	(StatusType) returnValue
ReleaseSpinlock	AUTOSAR	SpinlockId	(StatusType) returnValue
TryToGetSpinlock	AUTOSAR	SpinlockId	(TryToGetSpinlockType) *Success
ShutdownAllCores	AUTOSAR	Error	0
ReadPeripheral8	AUTOSAR	Address	(uint8) *ReadValue
ReadPeripheral16	AUTOSAR	Address	(uint16) *ReadValue
ReadPeripheral32	AUTOSAR	Address	(uint32) *ReadValue
WritePeripheral8	AUTOSAR	Address	(StatusType) returnValue
WritePeripheral16	AUTOSAR	Address	(StatusType) returnValue
WritePeripheral32	AUTOSAR	Address	(StatusType) returnValue
ModifyPeripheral8	AUTOSAR	Address	(StatusType) returnValue
ModifyPeripheral16	AUTOSAR	Address	(StatusType) returnValue
ModifyPeripheral32	AUTOSAR	Address	(StatusType) returnValue
EnableInterruptSource	AUTOSAR	ISRID	(StatusType) returnValue
DisableInterruptSource	AUTOSAR	ISRID	(StatusType) returnValue
ClearPendingInterrupt	AUTOSAR	ISRID	(StatusType) returnValue
ActivateTaskAsyn	AUTOSAR	id	0



OS Service Call	From	eventParameter on Start	on Return
<code>SetEventAsyn</code>	AUTOSAR	<code>id</code>	0
<code>isOsStarted</code>	AUTOSAR	0	(boolean) <code>returnValue</code>

**Table 7.13: Parameter details for AR\_CP\_OS\_SERVICECALLS**

If the eventParameter of a returning service call is not of type StatusType, and if the service call does not return E\_OK, the hook shall be called with a non-valid value as eventParameter, to give the hook consuming tool the possibility to detect the failure of the call.


### 7.17.5 Class AR\_CP\_OS\_SPINLOCK

#### [SWS\_Os\_00845]

*Upstream requirements: RS\_Arti\_00033*

[The OS shall create events of class AR\_CP\_OS\_SPINLOCK to allow tracing of OS spinlocks and all state transitions within the OS.]

These macros mark an event of an actual state change, not the OS service call. (E.g. getting a spinlock may happen later than requesting it; a request to release may not cause a release if it is already released.)



**Figure 7.38: ARTI spin lock states**

#### [SWS\_Os\_00846]

*Upstream requirements: RS\_ARTIFO\_00015*

[ARTI macros of the class AR\_CP\_OS\_SPINLOCK shall compile the following template:

```

1 ARTI_TRACE (_contextName, AR_CP_OS_SPINLOCK, <OS Short Name>, <Core
Index>, <_eventName>, <eventParameter>)
  
```

]

The <Core Index> for any event in the following table shall represent the core id where the corresponding service call is called.

The following events are part of the class AR\_CP\_OS\_SPINLOCK:

Event description	State transition	_eventName	eventParameter
Locking Spinlock	Released -> Locked	OsSpinlock_Locked	SpinlockId
Releasing Spinlock	Locked -> Released	OsSpinlock_Released	SpinlockId

**Table 7.14: Events for spinlocks**

## 7.17.6 Class AR\_CP\_OS\_HOOK

### [SWS\_Os\_00856]

*Upstream requirements: RS\_Arti\_00034*

〔The OS shall create events of class AR\_CP\_OS\_HOOK when entering and exiting the hook function.〕

### [SWS\_Os\_00857]

*Upstream requirements: RS\_Arti\_00034, RS\_ARTIFO\_00015*

〔ARTI macros of the class AR\_CP\_OS\_HOOK shall compile the following template:

1 ARTI\_TRACE (\_contextName, AR\_CP\_OS\_HOOK, <OS Short Name>, <Core Index>, <eventName>, <eventParameter>)

〕

The <Core Index> for any event in the following table shall represent the core id on which the corresponding hook function is executed.

The <eventName> is a string literal composed of the prefix OsHook, the hook function name and \_Start or \_Return for the entry or exit of the hook function. E.g. when the [ErrorHook](#) is called, the event names on entry and exit are OsHook\_ErrorHook\_Start respectively OsHook\_ErrorHook\_Return.

The <eventParamter> is an uint32 representation of either the function parameter or the return value. It depends on the hook function and is listed in the following table:

OS hook function	Origin	eventParameter on Start	eventParameter on Return
ErrorHook	OSEK	Error	0
ErrorHook_<App>	AUTOSAR	Error	0
PostTaskHook	OSEK	0	0
PreTaskHook	OSEK	0	0
ProtectionHook	AUTOSAR	Fatalerror	ReturnValue
StartupHook	OSEK	0	0
StartupHook_<App>	AUTOSAR	0	0



△

OS hook function	Origin	eventParameter on Start	eventParameter on Return
ShutdownHook	OSEK	Error	0
ShutdownHook_<App>	AUTOSAR	Fatalerror	0

**Table 7.15: Parameters for hook functions**

The ARTI hook which indicates the exit of the [ProtectionHook](#) (e.g. `eventName` is `OsHook_ProtectionHook_Return`) shall be invoked after the OS has checked the `ReturnValue` of the [ProtectionHook](#) (based on the requirements described in chapter 7.8.2., for example [[SWS\\_Os\\_00506](#)] or [[SWS\\_Os\\_00475](#)]). The `eventParameter` of this ARTI hook shall reflect the action which is taken by the OS as a result of the return value of the [ProtectionHook](#).

## 8 API specification

This chapter contains the APIs offered by the operating system. Note that not all services are available in all scalability classes, and that the behavior of some services is extended for specific scalability classes. For example, API to relatively start a ScheduleTable has an additional check if the ScheduleTable allows implicit synchronization. This check is only performed in SC2 and SC4 where synchronization of ScheduleTables is supported.

### 8.1 Constants

#### 8.1.1 Error codes of type [StatusType](#)

The following constants are available in a multi-core environment.

#### [SWS\_Os\_91007] Definition of datatype [AppModeType](#)

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔

<b>Name</b>	AppModeType		
<b>Kind</b>	Enumeration		
<b>Range</b>	DONOTCARE	–	–
<b>Description</b>	AppMode of the core shall be inherited from another core.		
<b>Available via</b>	Os.h		

〕

#### [SWS\_Os\_91002] Definition of datatype [TotalNumberOfCores](#)

*Upstream requirements:* [SRS\\_Os\\_80011](#)

〔

<b>Name</b>	TotalNumberOfCores		
<b>Kind</b>	Type		
<b>Derived from</b>	scalar		
<b>Range</b>	1..65535	–	–
<b>Description</b>	The total number of cores		
<b>Available via</b>	Os.h		

〕

#### [SWS\_Os\_00873] Additional task state

*Upstream requirements:* [SRS\\_Os\\_13000](#)

〔The AUTOSAR OS shall provide the symbol [BUDGET\\_EXHAUSTED](#) as additional task state if there is at least one Task configured with [OsTaskTimingProtectionDeferrableServer=TRUE](#).〕

Additional constants are in section [7.15](#) and [\[2\]](#).

## 8.2 Macros

```
OSMEMORY_IS_READABLE (<AccessType>)
OSMEMORY_IS_WRITEABLE (<AccessType>)
OSMEMORY_IS_EXECUTABLE (<AccessType>)
OSMEMORY_IS_STACKSPACE (<AccessType>)
```

These macros return a value not equal to zero if the memory is readable / writable / executable or stack space. The argument of the macros must be of type `AccessType`. Typically the return value of the service `CheckTaskMemoryAccess` (or `CheckISRMemoryAccess`) is used as argument for these macros.

## 8.3 Type definitions

### 8.3.1 `ApplicationType` (for OS-Applications)

#### [SWS\_Os\_00772] Definition of datatype `ApplicationType`

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔

<b>Name</b>	ApplicationType		
<b>Kind</b>	Type		
<b>Derived from</b>	uint32		
<b>Range</b>	INVALID_OSAPPLICATION	–	–
<b>Description</b>	This data type identifies the OS-Application.		
<b>Available via</b>	Os.h		

〕

#### [SWS\_Os\_00826]

*Upstream requirements:* [SRS\\_Os\\_80005](#)

〔The range of valid OS-Applications described by `ApplicationType` shall be zero-based and consecutive. The value shall be defined by the `EcucPartitionId` of the `EcucPartition` referenced by the OS-Application. The Value of `INVALID_OSAPPLICATION` shall lie outside the range of valid OS-Application IDs.〕

Note: The OS may use other representations internally for a performance optimal implementation.

#### [SWS\_Os\_CONSTR\_00001]

*Upstream requirements:* [SRS\\_Os\\_80005](#)

〔The relationship between `OsApplication` and `EcucPartition` is supposed to be unique. This means that an `EcucPartition` must not be referenced by multiple `OsAppEcucPartitionRefs`.〕

**[SWS\_Os\_CONSTR\_00002]***Upstream requirements: SRS\_Os\_80005*

「EcucPartitionIds shall be unique, zero based and consecutive.」

**8.3.2 ApplicationStateType****[SWS\_Os\_00773] Definition of datatype ApplicationStateType***Upstream requirements: SRS\_Os\_11001*

[

<b>Name</b>	ApplicationStateType		
<b>Kind</b>	Type		
<b>Derived from</b>	scalar		
<b>Range</b>	APPLICATION_ACCESSIBLE	–	–
	APPLICATION_TERMINATED	–	–
<b>Description</b>	This data type identifies the state of an OS-Application.		
<b>Available via</b>	Os.h		

]

**8.3.3 ApplicationStateRefType****[SWS\_Os\_00774] Definition of datatype ApplicationStateRefType***Upstream requirements: SRS\_Os\_11001*

[

<b>Name</b>	ApplicationStateRefType		
<b>Kind</b>	Type		
<b>Derived from</b>	pointer		
<b>Description</b>	This data type points to location where a ApplicationStateType can be stored.		
<b>Available via</b>	Os.h		

]

### 8.3.4 TrustedFunctionIndexType

#### [SWS\_Os\_00775] Definition of datatype TrustedFunctionIndexType

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔

<b>Name</b>	TrustedFunctionIndexType
<b>Kind</b>	Type
<b>Derived from</b>	scalar
<b>Description</b>	This data type identifies a trusted function.
<b>Available via</b>	Os.h

〕

### 8.3.5 TrustedFunctionParameterRefType

#### [SWS\_Os\_00776] Definition of datatype TrustedFunctionParameterRefType

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔

<b>Name</b>	TrustedFunctionParameterRefType
<b>Kind</b>	Type
<b>Derived from</b>	pointer
<b>Description</b>	This data type points to a structure which holds the arguments for a call to a trusted function.
<b>Available via</b>	Os.h

〕

### 8.3.6 AccessType

#### [SWS\_Os\_00777] Definition of datatype AccessType

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔

<b>Name</b>	AccessType
<b>Kind</b>	Type
<b>Derived from</b>	integral
<b>Description</b>	This type holds information how a specific memory region can be accessed.
<b>Available via</b>	Os.h

〕

### 8.3.7 [ObjectType](#)

#### [SWS\_Os\_00778] Definition of datatype [ObjectType](#)

*Upstream requirements:* [SRS\\_Os\\_11001](#)

]

<b>Name</b>	ObjectType		
<b>Kind</b>	Type		
<b>Derived from</b>	implementation_specific		
<b>Range</b>	ACCESS	—	—
	NO_ACCESS	—	—
<b>Description</b>	This data type identifies if an OS-Application has access to an object.		
<b>Available via</b>	Os.h		

]

### 8.3.8 [ObjectAccessType](#)

#### [SWS\_Os\_00779] Definition of datatype [ObjectAccessType](#)

*Upstream requirements:* [SRS\\_Os\\_11001](#)

]

<b>Name</b>	ObjectAccessType		
<b>Kind</b>	Type		
<b>Derived from</b>	implementation_specific		
<b>Range</b>	OBJECT_TASK	—	—
	OBJECT_ISR	—	—
	OBJECT_ALARM	—	—
	OBJECT_RESOURCE	—	—
	OBJECT_COUNTER	—	—
	OBJECT_SCHEDULETABLE	—	—
<b>Description</b>	This data type identifies an object.		
<b>Available via</b>	Os.h		

]

### 8.3.9 [MemoryStartAddressType](#)

#### [SWS\_Os\_00780] Definition of datatype [MemoryStartAddressType](#)

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔

<b>Name</b>	MemoryStartAddressType
<b>Kind</b>	Pointer
<b>Type</b>	void*
<b>Description</b>	This data type is a pointer which is able to point to any location in the MCU address space.
<b>Available via</b>	Os.h

〕

### 8.3.10 [MemorySizeType](#)

#### [SWS\_Os\_00781] Definition of datatype [MemorySizeType](#)

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔

<b>Name</b>	MemorySizeType
<b>Kind</b>	Type
<b>Derived from</b>	implementation_specific
<b>Description</b>	This data type holds the size (in bytes) of a memory region.
<b>Available via</b>	Os.h

〕

### 8.3.11 [ISRTYPE](#)

#### [SWS\_Os\_00782] Definition of datatype [ISRTYPE](#) 〔

<b>Name</b>	ISRTYPE
<b>Kind</b>	Type
<b>Derived from</b>	implementation_specific
<b>Range</b>	INVALID_ISR
<b>Description</b>	This data type identifies an interrupt service routine (ISR).
<b>Available via</b>	Os.h

〕

### 8.3.12 ScheduleTableType

#### [SWS\_Os\_00783] Definition of datatype ScheduleTableType

*Upstream requirements:* [SRS\\_Os\\_00098](#)

]

<b>Name</b>	ScheduleTableType
<b>Kind</b>	Type
<b>Derived from</b>	implementation_specific
<b>Description</b>	This data type identifies a schedule table.
<b>Available via</b>	Os.h

]

### 8.3.13 ScheduleTableStatusType

#### [SWS\_Os\_00784] Definition of datatype ScheduleTableStatusType

*Upstream requirements:* [SRS\\_Os\\_00098](#)

]

<b>Name</b>	ScheduleTableStatusType		
<b>Kind</b>	Type		
<b>Derived from</b>	implementation_specific		
<b>Range</b>	SCHEDULETABLE_STOPPED	–	–
	SCHEDULETABLE_NEXT	–	–
	SCHEDULETABLE_WAITING	–	–
	SCHEDULETABLE_RUNNING	–	–
	SCHEDULETABLE_RUNNING_AND_SYNCHRONOUS	–	–
<b>Description</b>	This type describes the status of a schedule. The status can be one of the following: <ul style="list-style-type: none"> <li>The schedule table is not started (SCHEDULETABLE_STOPPED)</li> <li>The schedule table will be started after the end of currently running schedule table (schedule table was used in NextScheduleTable() service) (SCHEDULETABLE_NEXT)</li> <li>The schedule table uses explicit synchronization, has been started and is waiting for the global time. (SCHEDULETABLE_WAITING)</li> <li>The schedule table is running, but is currently not synchronous to a global time source (SCHEDULETABLE_RUNNING)</li> <li>The schedule table is running and is synchronous to a global time source (SCHEDULETABLE_RUNNING_AND_SYNCHRONOUS)</li> </ul>		
<b>Available via</b>	Os.h		

]

### 8.3.14 ScheduleTableStatusRefType

#### [SWS\_Os\_00785] Definition of datatype ScheduleTableStatusRefType

*Upstream requirements:* [SRS\\_Os\\_00098](#)

]

<b>Name</b>	ScheduleTableStatusRefType
<b>Kind</b>	Pointer
<b>Type</b>	<a href="#">ScheduleTableStatusType</a> *
<b>Description</b>	This data type points to a variable of the data type ScheduleTableStatusType.
<b>Available via</b>	Os.h

]

### 8.3.15 ProtectionReturnType

#### [SWS\_Os\_00787] Definition of datatype ProtectionReturnType

*Upstream requirements:* [SRS\\_Os\\_11001](#)

]

<b>Name</b>	ProtectionReturnType		
<b>Kind</b>	Type		
<b>Derived from</b>	implementation_specific		
<b>Range</b>	PRO_IGNORE	–	–
	PRO_TERMINATETASKISR	–	–
	PRO_TERMINATEAPPL	–	–
	PRO_SHUTDOWN	–	–
	PRO_PREVENT_ARRIVAL_RATE	–	–
<b>Description</b>	This data type identifies a value which controls further actions of the OS on return from the protection hook.		
<b>Available via</b>	Os.h		

]

### 8.3.16 RestartType

#### [SWS\_Os\_00788] Definition of datatype RestartType

*Upstream requirements:* [SRS\\_Os\\_11001](#)

]

<b>Name</b>	RestartType
<b>Kind</b>	Type
<b>Derived from</b>	implementation_specific



△

<b>Range</b>	OS_OSAPPLICATION_RESTART	–	–
	OS_OSAPPLICATION_NO_RESTART	–	–
<b>Description</b>	This data type defines the use of a Restart Task after terminating an OS-Application.		
<b>Available via</b>	Os.h		

]

### 8.3.17 PhysicalTimeType

#### [SWS\_Os\_00789] Definition of datatype PhysicalTimeType [

<b>Name</b>	PhysicalTimeType
<b>Kind</b>	Type
<b>Derived from</b>	implementation_specific
<b>Description</b>	This data type is used for values returned by the conversion macro (see [SWS_Os_00393]) OS_TICKS2<Unit>_<Counter>().
<b>Available via</b>	Os.h

]

### 8.3.18 CoreIdType

#### [SWS\_Os\_00790] Definition of datatype CoreIdType

*Upstream requirements: SRS\_Os\_80011*

[

<b>Name</b>	CoreIdType		
<b>Kind</b>	Type		
<b>Derived from</b>	scalar		
<b>Range</b>	OS_CORE_ID_MASTER	–	refers to the master core, may be an alias for OS_CORE_ID_<x>
	OS_CORE_ID_0..OS_CORE_ID_65533	–	refers to logical core 0, core 1 etc.
<b>Description</b>	CoreIdType is a scalar that allows identifying a single core. The CoreIdType shall represent the logical CoreID		
<b>Available via</b>	Os.h		

]

#### [SWS\_Os\_00825]

*Upstream requirements: SRS\_Os\_80011*

[The range of valid Core-IDs described by **CoreIdType** shall be zero-based and consecutive.]

### 8.3.19 SpinlockIdType

#### [SWS\_Os\_00791] Definition of datatype SpinlockIdType

Upstream requirements: [SRS\\_Os\\_80021](#)

]

<b>Name</b>	SpinlockIdType		
<b>Kind</b>	Type		
<b>Derived from</b>	scalar		
<b>Range</b>	1..65535	–	0x01, 0x02, ...: identifies a spinlock instance
	INVALID_SPINLOCK	0	represents an invalid spinlock instance
<b>Description</b>	SpinlockIdType identifies a spinlock instance and is used by the API functions: GetSpinlock, ReleaseSpinlock and TryToGetSpinlock.		
<b>Available via</b>	Os.h		

]

### 8.3.20 TryToGetSpinlockType

#### [SWS\_Os\_00792] Definition of datatype TryToGetSpinlockType

Upstream requirements: [SRS\\_Os\\_80021](#)

]

<b>Name</b>	TryToGetSpinlockType		
<b>Kind</b>	Enumeration		
<b>Range</b>	TRYTOGETSPINLOCK_SUCCESS	–	Spinlock successfully occupied
	TRYTOGETSPINLOCK_NOSUCCESS	–	Unable to occupy the spinlock
<b>Description</b>	The TryToGetSpinlockType indicates if the spinlock has been occupied or not.		
<b>Available via</b>	Os.h		

]

### 8.3.21 AreaidType

#### [SWS\_Os\_91000] Definition of datatype AreaidType

Upstream requirements: [SRS\\_Os\\_11001](#)

]

<b>Name</b>	AreaidType		
<b>Kind</b>	Type		
<b>Derived from</b>	scalar		





<b>Range</b>	0..65534	–	identifies a peripheral area
<b>Description</b>	AreaIdType identifies a peripheral area and is used by the API functions: ReadPeripheralX, WritePeripheralX and ModifyPeripheralX		
<b>Available via</b>	Os.h		



### 8.3.22 CounterType

#### [SWS\_Os\_00786] Definition of datatype CounterType

<b>Name</b>	CounterType
<b>Kind</b>	Type
<b>Derived from</b>	uint32
<b>Description</b>	This data type identifies a counter.
<b>Available via</b>	Os.h



## 8.4 Function definitions

The availability of the following services is defined in table [SWS\_Os\_00241]. The use of these services may be restricted depending on the context they are called from. See table 7.1 for details.

### 8.4.1 GetApplicationID

#### [SWS\_Os\_00016] Definition of API function GetApplicationID

*Upstream requirements: SRS\_Os\_11001*



<b>Service Name</b>	GetApplicationID	
<b>Syntax</b>	<code>ApplicationType GetApplicationID (</code> <code>    void</code> <code>)</code>	
<b>Service ID [hex]</b>	0x00	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	None	
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	<code>ApplicationType</code>	<identifier of running OS-Application> or <code>INVALID_OSAPPLICATION</code>





<b>Description</b>	This service determines the OS-Application (a unique identifier has to be allocated to each application) where the caller originally belongs to (was configured to).
<b>Available via</b>	Os.h

]

### [SWS\_Os\_00261]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

「`GetApplicationID` shall return the application identifier to which the executing Task/Cat2 ISR/hook was configured.」

This means that the return value of `GetApplicationID`, when called from a category 1 ISR, is undefined.

### [SWS\_Os\_00262]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

「If no OS-Application is running, `GetApplicationID` shall return `INVALID_OSAPPLICATION`.」

### [SWS\_Os\_00514]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

「Availability of `GetApplicationID`: Available in Scalability Classes 3 and 4 and in multi-core systems.」

## 8.4.2 `GetCurrentApplicationID`

### [SWS\_Os\_00797] Definition of API function `GetCurrentApplicationID`

*Upstream requirements:* [SRS\\_Os\\_11001](#)

[

<b>Service Name</b>	GetCurrentApplicationID	
<b>Syntax</b>	<code>ApplicationType GetCurrentApplicationID (</code> <code>                  void</code> <code>                  )</code>	
<b>Service ID [hex]</b>	0x27	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	None	
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	<code>ApplicationType</code>	<identifier of the OS-Application> or <code>INVALID_OSAPPLICATION</code>





<b>Description</b>	This service determines the OS-Application where the caller of the service is currently executing. Note that if the caller is not within a CallTrustedFunction() call the value is equal to the result of GetApplicationID().
<b>Available via</b>	Os.h

]

### [SWS\_Os\_00798]

*Upstream requirements: SRS\_Os\_11001*

「GetCurrentApplicationID shall return the application identifier in which the current Task/Cat2 ISR/hook is executed.」

This means that the return value of GetCurrentApplicationID, when called from a category 1 ISR, is undefined.

### [SWS\_Os\_00799]

*Upstream requirements: SRS\_Os\_11001*

「If no OS-Application is running, GetCurrentApplicationID shall return INVALID\_OSAPPLICATION.」

### [SWS\_Os\_00800]

*Upstream requirements: SRS\_Os\_11016*

「Availability of GetCurrentApplicationID: Available in Scalability Classes 3 and 4.」

#### 8.4.3 [GetISRID](#)

### [SWS\_Os\_00511] Definition of API function GetISRID 「

<b>Service Name</b>	GetISRID	
<b>Syntax</b>	<code>ISRTypE GetISRID (</code> <code>          void</code> <code>)</code>	
<b>Service ID [hex]</b>	0x01	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	None	
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	ISRTypE	<Identifier of running ISR> or INVALID_ISR
<b>Description</b>	This service returns the identifier of the currently executing ISR.	
<b>Available via</b>	Os.h	

]

**[SWS\_Os\_00263]** [If called from category 2 ISR (or Hook routines called inside a category 2 ISR), [GetISRID](#) shall return the identifier of the currently executing ISR.]

**[SWS\_Os\_00264]** [If its caller is not a category 2 ISR (or Hook routines called inside a category 2 ISR), [GetISRID](#) shall return INVALID\_ISR.]

**[SWS\_Os\_00515]**

*Upstream requirements:* [SRS\\_Os\\_11016](#)

[Availability of [GetISRID](#): Available in all Scalability Classes.]

#### 8.4.4 [CallTrustedFunction](#)

**[SWS\_Os\_00097] Definition of API function CallTrustedFunction**

*Upstream requirements:* [SRS\\_Os\\_11001](#)

[

<b>Service Name</b>	CallTrustedFunction	
<b>Syntax</b>	<code>StatusType CallTrustedFunction (</code> <code>    TrustedFunctionIndexType FunctionIndex,</code> <code>    TrustedFunctionParameterRefType FunctionParams</code> <code>)</code>	
<b>Service ID [hex]</b>	0x02	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	FunctionIndex	Index of the function to be called.
	FunctionParams	Pointer to the parameters for the function - specified by the FunctionIndex - to be called. If no parameters are provided, a NULL_PTR has to be passed.
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	StatusType	E_OK: No Error E_OS_SERVICEID: No function defined for this index
<b>Description</b>	A (trusted or non-trusted) OS-Application uses this service to call a trusted function	
<b>Available via</b>	Os.h	

]

**[SWS\_Os\_00265]**

*Upstream requirements:* [SRS\\_Os\\_11001](#)

[If <FunctionIndex> is a defined function index, [CallTrustedFunction](#) shall call the function <FunctionIndex> out of a list of implementation specific trusted functions with the protection settings of the OS-Application which provides the trusted function AND shall return E\_OK after completion.]

**[SWS\_Os\_00312]**

*Upstream requirements:* [SRS\\_Os\\_11001](#)

[Caveats of [CallTrustedFunction](#):

- The called trusted function must conform to the following C prototype: `void TRUSTED_<name_of_the_trusted_service> ( TrustedFunctionIndex Type, TrustedFunctionParameterRefType );` (The arguments are the same as the arguments of `CallTrustedFunction`).
- Normally, a user will not directly call this service, but it will be part of some standard interface, e.g. a standard I/O interface.
- It is the duty of the called trusted function to check rights of passed parameters, especially if parameters are interpreted as out parameters.
- It should be noted that the `CallTrustedFunction` does not disable timing protection for the Task which called the service. This may lead to timing faults (calls of the `ProtectionHook`) even inside of a trusted OS-Application. It is therefore recommended to use `CallTrustedFunction` only for stateless functions (e.g. functions which do not write or do not have internal states)

]

**[SWS\_Os\_00266]***Upstream requirements: SRS\_Os\_11001*

〔When `CallTrustedFunction` calls the function `<FunctionIndex>`, that function shall be executed with the same processor mode, memory protection boundaries and the service protection limitations of the OS-Application to which it belongs. The notion of "current application" shall remain that of the calling Task or Category 2 ISR.〕

Reaction to timing protection can be defined to terminate the OS-Application. If a Task is inside `CallTrustedFunction` and Task rescheduling takes place within the same OS-Application, the newly running higher priority Task may cause timing protection and terminate the OS-Application, thus indirectly aborting the trusted function. To avoid this, the scheduling of other Tasks which belong to the same OS-Application as the caller can be restricted, as well as the availability of interrupts of the same OS-Application.

**[SWS\_Os\_00565]** 〔When `CallTrustedFunction` is called and the caller of `CallTrustedFunction` is supervised with timing protection, the Operating System shall delay any timing protection errors until the `CallTrustedFunction` returns to a `OsApplication` with `OsTrustedApplicationDelayTimingViolationCall == FALSE`.〕

**[SWS\_Os\_00563]** 〔

If `OsLockTrustedFunctionCall == TRUE` the OperatingSystem shall not schedule any other Tasks which belong to the same OS-Application as the non-trusted caller of the service. Also interrupts of Category 2 which belong to the same OS-Application shall be disabled during the execution of the service.〕

The lock/disabling in [SWS\_Os\_00563] is required to support timing supervision. Since the caller of a trusted function can be any Task or Category 2 ISR the Operating System has to make sure that no other calls can preempt/interrupt the ongoing trusted function.

### [SWS\_Os\_00364]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔If `CallTrustedFunction` calls the trusted function, that function shall continue to run on the same interrupt/task priority and be allowed to call system services defined for inside trusted functions.〕

See also table in chapter [7.7.3.3](#).

### [SWS\_Os\_00292]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the function index <FunctionIndex> in a call of `CallTrustedFunction` is undefined, `CallTrustedFunction` shall return `E_OS_SERVICEID`.〕

### [SWS\_Os\_00516]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔Availability of `CallTrustedFunction`: Available in Scalability Classes 3 and 4.〕

## 8.4.5 [CheckISRMemoryAccess](#)

### [SWS\_Os\_00512] Definition of API function [CheckISRMemoryAccess](#)

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔

<b>Service Name</b>	CheckISRMemoryAccess	
<b>Syntax</b>	<code>AccessType CheckISRMemoryAccess (</code> <code>    ISRTyp ISRID,</code> <code>    MemoryStartAddressType Address,</code> <code>    MemorySizeType Size</code> <code>)</code>	
<b>Service ID [hex]</b>	0x03	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	ISRID	ISR reference
	Address	Start of memory area
	Size	Size of memory area
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	<code>AccessType</code>	Value which contains the access rights to the memory area.
<b>Description</b>	This service checks if a memory region is write/read/execute accessible and also returns information if the memory region is part of the stack space.	





Available via	Os.h
---------------	------



### [SWS\_Os\_00267]

*Upstream requirements:* [SRS\\_Os\\_11005](#)

〔If the `ISR` reference `<ISRID>` in a call of `CheckISRMemoryAccess` is valid, `CheckISRMemoryAccess` shall return the access rights of the `ISR` on the specified memory area.〕

### [SWS\_Os\_00313]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔If an access right (e.g. "read") is not valid for the whole memory area specified in a call of `CheckISRMemoryAccess`, `CheckISRMemoryAccess` shall yield no access regarding this right.〕

### [SWS\_Os\_00268]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the `ISR` reference `<ISRID>` is not valid, `CheckISRMemoryAccess` shall yield no access rights.〕

### [SWS\_Os\_00517]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔Availability of `CheckISRMemoryAccess`: Available in Scalability Classes 3 and 4.〕

## 8.4.6 `CheckTaskMemoryAccess`

### [SWS\_Os\_00513] Definition of API function `CheckTaskMemoryAccess`

*Upstream requirements:* [SRS\\_Os\\_11001](#)



<b>Service Name</b>	CheckTaskMemoryAccess	
<b>Syntax</b>	<code>AccessType CheckTaskMemoryAccess (</code> <code>    TaskType TaskID,</code> <code>    MemoryStartAddressType Address,</code> <code>    MemorySizeType Size</code> <code>)</code>	
<b>Service ID [hex]</b>	0x04	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	TaskID	Task reference
	Address	Start of memory area



△

	Size	Size of memory area
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	AccessType	Value which contains the access rights to the memory area.
<b>Description</b>	This service checks if a memory region is write/read/execute accessible and also returns information if the memory region is part of the stack space.	
<b>Available via</b>	Os.h	

]

**[SWS\_Os\_00269]***Upstream requirements: SRS\_Os\_11005*

〔If the Task reference <TaskID> in a call of [CheckTaskMemoryAccess](#) is valid, [CheckTaskMemoryAccess](#) shall return the access rights of the Task on the specified memory area.〕

**[SWS\_Os\_00314]***Upstream requirements: SRS\_Os\_11001*

〔If an access right (e.g. "read") is not valid for the whole memory area specified in a call of [CheckTaskMemoryAccess](#), [CheckTaskMemoryAccess](#) shall yield no access regarding this right.〕

**[SWS\_Os\_00270]***Upstream requirements: SRS\_BSW\_00323*

〔If the Task reference <TaskID> in a call of [CheckTaskMemoryAccess](#) is not valid, [CheckTaskMemoryAccess](#) shall yield no access rights.〕

**[SWS\_Os\_00518]***Upstream requirements: SRS\_Os\_11016*

〔Availability of [CheckTaskMemoryAccess](#): Available in Scalability Classes 3 and 4〕

#### 8.4.7 [CheckObjectAccess](#)

##### [SWS\_Os\_00256] Definition of API function [CheckObjectAccess](#)

*Upstream requirements:* [SRS\\_Os\\_11010](#)

〔

<b>Service Name</b>	CheckObjectAccess	
<b>Syntax</b>	<code>ObjectAccessType CheckObjectAccess (</code> <code>    ApplicationType ApplID,</code> <code>    ObjectTypeType ObjectType,</code> <code>    void ...</code> <code>)</code>	
<b>Service ID [hex]</b>	0x05	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	ApplID	OS-Application identifier
	ObjectType	Type of the following parameter
	...	The object to be examined
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	<a href="#">ObjectAccessType</a>	ACCESS if the ApplID has access to the object NO_ACCESS otherwise
<b>Description</b>	This service determines if the OS-Applications, given by ApplID, is allowed to use the IDs of a Task, Resource, Counter, Alarm or Schedule Table in API calls.	
<b>Available via</b>	Os.h	

〕

##### [SWS\_Os\_00271]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔If the OS-Application <ApplID> in a call of [CheckObjectAccess](#) has access to the queried object, [CheckObjectAccess](#) shall return ACCESS.〕

##### [SWS\_Os\_00272]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔If the OS-Application <ApplID> in a call of [CheckObjectAccess](#) has no access to the queried object, [CheckObjectAccess](#) shall return NO\_ACCESS.〕

##### [SWS\_Os\_00423]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔If in a call of [CheckObjectAccess](#) the object to be examined is not a valid object OR <ApplID> is invalid OR <ObjectType> is invalid THEN [CheckObjectAccess](#) shall return NO\_ACCESS.〕

##### [SWS\_Os\_00519]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔Availability of [CheckObjectAccess](#): Available in Scalability Classes 3 and 4.〕

#### 8.4.8 [CheckObjectOwnership](#)

##### [SWS\_Os\_00017] Definition of API function [CheckObjectOwnership](#)

*Upstream requirements:* [SRS\\_Os\\_11010](#)

]

<b>Service Name</b>	CheckObjectOwnership	
<b>Syntax</b>	<code>ApplicationType CheckObjectOwnership (</code> <code>    ObjectTypeType ObjectType,</code> <code>    void ...</code> <code>)</code>	
<b>Service ID [hex]</b>	0x06	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	ObjectType	Type of the following parameter
	...	The object to be examined
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	ApplicationType	<OS-Application>: the OS-Application to which the object Object Type belongs or <a href="#">INVALID_OSAPPLICATION</a> if the object does not exists
<b>Description</b>	This service determines to which OS-Application a given Task, ISR, Counter, Alarm or Schedule Table belongs	
<b>Available via</b>	Os.h	

]

##### [SWS\_Os\_00273]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔If the object <ObjectType> specified in a call of [CheckObjectOwnership](#) exists, [CheckObjectOwnership](#) shall return the identifier of the OS-Application to which the object belongs.〕

##### [SWS\_Os\_00274]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If in a call of [CheckObjectOwnership](#) the specified object <ObjectType> is invalid OR the argument of the type (the "...") is invalid OR the object does not belong to any OS-Application, [CheckObjectOwnership](#) shall return [INVALID\\_OSAPPLICATION](#).〕

##### [SWS\_Os\_00520]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔Availability of [CheckObjectOwnership](#): Available in Scalability Classes 3 and 4 and in multi-core systems.〕

#### 8.4.9 [StartScheduleTableRel](#)

##### [SWS\_Os\_00347] Definition of API function [StartScheduleTableRel](#)

*Upstream requirements:* [SRS\\_Os\\_00098](#)

⌈

<b>Service Name</b>	StartScheduleTableRel	
<b>Syntax</b>	<code>StatusType StartScheduleTableRel (</code> <code>    ScheduleTableType ScheduleTableID,</code> <code>    TickType Offset</code> <code>)</code>	
<b>Service ID [hex]</b>	0x07	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	ScheduleTableID	Schedule table to be started
	Offset	Number of ticks on the counter before the the schedule table processing is started
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	StatusType	<code>E_OK</code> : No Error <code>E_OS_ID</code> (only in EXTENDED status): ScheduleTableID not valid. <code>E_OS_VALUE</code> (only in EXTENDED status): Offset is greater than ( <code>OsCounterMaxAllowedValue - InitialOffset</code> ) or is equal to 0. <code>E_OS_STATE</code> : Schedule table was already started.
<b>Description</b>	This service starts the processing of a schedule table at "Offset" relative to the "Now" value on the underlying counter.	
<b>Available via</b>	Os.h	

⌋

##### [SWS\_Os\_00275]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

⌈ If the ScheduleTable <ScheduleTableID> in a call of [StartScheduleTableRel](#) is not valid, [StartScheduleTableRel](#) shall return `E_OS_ID`. ⌋

##### [SWS\_Os\_00452]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

⌈ If the ScheduleTable <ScheduleTableID> in a call of [StartScheduleTableRel](#) is implicitly synchronized (`OsScheduleTblSyncStrategy = IMPLICIT`), [StartScheduleTableRel](#) shall return `E_OS_ID`. ⌋

##### [SWS\_Os\_00332]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

⌈ If <Offset> in a call of [StartScheduleTableRel](#) is zero [StartScheduleTableRel](#) shall return `E_OS_VALUE`. ⌋

### [SWS\_Os\_00276]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the offset <Offset>) is greater than `OsCounterMaxAllowedValue` of the underlying Counter minus the Initial Offset, `StartScheduleTableRel` shall return `E_OS_VALUE`.〕

### [SWS\_Os\_00277]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the ScheduleTable <ScheduleTableID> in a call of `StartScheduleTableRel` is not in the state `SCHEDULETABLE_STOPPED`, `StartScheduleTableRel` shall return `E_OS_STATE`.〕

### [SWS\_Os\_00278]

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔If the input parameters of `StartScheduleTableRel` are valid and the state of ScheduleTable <ScheduleTableID> is `SCHEDULETABLE_STOPPED`, then `StartScheduleTableRel` shall start the processing of a ScheduleTable <ScheduleTableID>. The Initial Expiry Point shall be processed after <Offset> + Initial Offset ticks have elapsed on the underlying Counter. The state of <ScheduleTableID> is set to `SCHEDULETABLE_RUNNING` before the service returns to the caller.〕

### [SWS\_Os\_00521]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔Availability of `StartScheduleTableRel`: Available in all Scalability Classes.〕

#### 8.4.10 `StartScheduleTableAbs`

### [SWS\_Os\_00358] Definition of API function `StartScheduleTableAbs`

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔

<b>Service Name</b>	<code>StartScheduleTableAbs</code>	
<b>Syntax</b>	<code>StatusType StartScheduleTableAbs (</code> <code>    ScheduleTableType ScheduleTableID,</code> <code>    TickType Start</code> <code>)</code>	
<b>Service ID [hex]</b>	0x08	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	<code>ScheduleTableID</code>	Schedule table to be started
	<code>Start</code>	Absolute counter tick value at which the schedule table is started
<b>Parameters (inout)</b>	None	





<b>Parameters (out)</b>	None	
<b>Return value</b>	StatusType	E_OK: No Error E_OS_ID (only in EXTENDED status): ScheduleTableID not valid E_OS_VALUE (only in EXTENDED status): "Start" is greater than OsCounterMaxAllowedValue E_OS_STATE: Schedule table was already started
<b>Description</b>	This service starts the processing of a schedule table at an absolute value "Start" on the underlying counter.	
<b>Available via</b>	Os.h	

]

### [SWS\_Os\_00348]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

「If the ScheduleTable <ScheduleTableID> in a call of [StartScheduleTableAbs](#) is not valid, [StartScheduleTableAbs](#) shall return E\_OS\_ID.」

### [SWS\_Os\_00349]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

「If the <Start> in a call of [StartScheduleTableAbs](#) is greater than the OsCounter-MaxAllowedValue of the underlying Counter, [StartScheduleTableAbs](#) shall return E\_OS\_VALUE.」

### [SWS\_Os\_00350]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

「If the ScheduleTable <ScheduleTableID> in a call of [StartScheduleTableAbs](#) is not in the state SCHEDULETABLE\_STOPPED, [StartScheduleTableAbs](#) shall return E\_OS\_STATE.」

### [SWS\_Os\_00351]

*Upstream requirements:* [SRS\\_Os\\_00098](#)

「If the input parameters of [StartScheduleTableAbs](#) are valid and <ScheduleTable ID> is in the state SCHEDULETABLE\_STOPPED, [StartScheduleTableAbs](#) shall start the processing of ScheduleTable <ScheduleTableID> when the underlying Counter next equals <Start> and shall set the state of <ScheduleTableID> to

- SCHEDULETABLE\_RUNNING (for a non-synchronized / Explicitly synchronized ScheduleTable) OR
- SCHEDULETABLE\_RUNNING\_AND\_SYNCHRONOUS (for implicitly synchronized ScheduleTable)

before returning to the user. (The Initial Expiry Point will be processed when the underlying Counter next equals <Start>+Initial Offset).」

### [SWS\_Os\_00522]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

「Availability of [StartScheduleTableAbs](#): Available in all Scalability Classes.」

#### 8.4.11 [StopScheduleTable](#)

##### [SWS\_Os\_00006] Definition of API function StopScheduleTable

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔

<b>Service Name</b>	StopScheduleTable	
<b>Syntax</b>	<code>StatusType StopScheduleTable (</code> <code>    ScheduleTableType ScheduleTableID</code> <code>)</code>	
<b>Service ID [hex]</b>	0x09	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	ScheduleTableID	Schedule table to be stopped
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	StatusType	E_OK: No Error E_OS_ID (only in EXTENDED status): ScheduleTableID not valid. E_OS_NOFUNC: Schedule table was already stopped
<b>Description</b>	This service cancels the processing of a schedule table immediately at any point while the schedule table is running.	
<b>Available via</b>	Os.h	

〕

##### [SWS\_Os\_00279]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the ScheduleTable identifier <ScheduleTableID> in a call of [StopScheduleTable](#) is not valid, [StopScheduleTable](#) shall return E\_OS\_ID.〕

##### [SWS\_Os\_00280]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the ScheduleTable with identifier <ScheduleTableID> is in state SCHEDULETABLE\_STOPPED when calling [StopScheduleTable](#), [StopScheduleTable](#) shall return E\_OS\_NOFUNC.〕

##### [SWS\_Os\_00281]

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔If the input parameters of [StopScheduleTable](#) are valid, [StopScheduleTable](#) shall set the state of <ScheduleTableID> to SCHEDULETABLE\_STOPPED and (stop the ScheduleTable <ScheduleTableID> from processing any further expiry points and) shall return E\_OK.〕

##### [SWS\_Os\_00523]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔Availability of [StopScheduleTable](#): Available in all Scalability Classes.〕

#### 8.4.12 [NextScheduleTable](#)

##### [SWS\_Os\_00191] Definition of API function [NextScheduleTable](#)

*Upstream requirements:* [SRS\\_Os\\_00099](#)

]

<b>Service Name</b>	NextScheduleTable	
<b>Syntax</b>	<code>StatusType NextScheduleTable (</code> <code>    ScheduleTableType ScheduleTableID_From,</code> <code>    ScheduleTableType ScheduleTableID_To</code> <code>)</code>	
<b>Service ID [hex]</b>	0x0a	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	ScheduleTableID_From	Currently processed schedule table
	ScheduleTableID_To	Schedule table that provides its series of expiry points
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	<code>StatusType</code>	<code>E_OK</code> : No error <code>E_OS_ID</code> (only in EXTENDED status): ScheduleTableID_From or ScheduleTableID_To not valid <code>E_OS_NOFUNC</code> : ScheduleTableID_From not started <code>E_OS_STATE</code> : ScheduleTableID_To is started or next
<b>Description</b>	This service switches the processing from one schedule table to another schedule table.	
<b>Available via</b>	Os.h	

]

##### [SWS\_Os\_00282]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the input parameter `<ScheduleTableID_From>` or `<ScheduleTableID_To>` in a call of [NextScheduleTable](#) is not valid, [NextScheduleTable](#) shall return `E_OS_ID`.〕

##### [SWS\_Os\_00330]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If in a call of [NextScheduleTable](#) ScheduleTable `<ScheduleTableID_To>` is driven by different Counter than ScheduleTable `<ScheduleTableID_From>` then [NextScheduleTable](#) shall return an error `E_OS_ID`.〕

##### [SWS\_Os\_00283]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the ScheduleTable `<ScheduleTableID_From>` in a call of [NextScheduleTable](#) is in state `SCHEDULETABLE_STOPPED` OR in state `SCHEDULETABLE_NEXT`, [NextScheduleTable](#) shall leave the state of `<ScheduleTable_From>` and `<ScheduleTable_To>` unchanged and return `E_OS_NOFUNC`.〕

**[SWS\_Os\_00309]**

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the `ScheduleTable <ScheduleTableID_To>` in a call of `NextScheduleTable` is not in state `SCHEDULETABLE_STOPPED`, `NextScheduleTable` shall leave the state of `<ScheduleTable_From>` and `<ScheduleTable_To>` unchanged and return `E_OS_STATE`.〕

**[SWS\_Os\_00484]**

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If `OsScheduleTblSyncStrategy` of `<ScheduleTableID_To>` in a call of `NextScheduleTable` is not equal to the `OsScheduleTblSyncStrategy` of `<ScheduleTableID_From>` then `NextScheduleTable` shall return `E_OS_ID`.〕

**[SWS\_Os\_00284]**

*Upstream requirements:* [SRS\\_Os\\_00099](#)

〔If the input parameters of `NextScheduleTable` are valid then `NextScheduleTable` shall start the processing of `ScheduleTable <ScheduleTableID_To>` `<ScheduleTableID_From>.FinalDelay` ticks after the Final Expiry Point on `<ScheduleTableID_From>` is processed and shall return `E_OK`. `NextScheduleTable` shall process the Initial Expiry Point on `<ScheduleTableID_To>` at `<ScheduleTableID_From>.Final Delay + <ScheduleTable_To>.Initial Offset` ticks after the Final Expiry Point on `<ScheduleTableID_From>` is processed .〕

**[SWS\_Os\_00324]**

*Upstream requirements:* [SRS\\_Os\\_00099](#)

〔If the input parameters of `NextScheduleTable` are valid AND the `<ScheduleTableID_From>` already has a "next" `ScheduleTable` then `NextScheduleTable` shall replace the previous "next" `ScheduleTable` with `<ScheduleTableID_To>` and shall change the old "next" `ScheduleTable` state to `SCHEDULETABLE_STOPPED`.〕

**[SWS\_Os\_00505]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔If `OsScheduleTblSyncStrategy` of the `ScheduleTables <ScheduleTableID_From>` and `<ScheduleTableID_To>` in a call of `NextScheduleTable` is `EXPLICIT` and the Operating System module already synchronizes `<ScheduleTableID_From>`, `NextScheduleTable` shall continue synchronization after the start of processing `<ScheduleTableID_To>`.〕

**[SWS\_Os\_00453]**

*Upstream requirements:* [SRS\\_Os\\_00099](#)

〔If the `<ScheduleTableID_From>` in a call of `NextScheduleTable` is stopped, `NextScheduleTable` shall not start the "next" `ScheduleTable` and change its state to `SCHEDULETABLE_STOPPED`.〕

**[SWS\_Os\_00524]**

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔Availability of [NextScheduleTable](#): Available in all Scalability Classes.〕

#### 8.4.13 [StartScheduleTableSynchron](#)

**[SWS\_Os\_00201] Definition of API function StartScheduleTableSynchron**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔

<b>Service Name</b>	StartScheduleTableSynchron	
<b>Syntax</b>	<code>StatusType StartScheduleTableSynchron (</code> <code>    ScheduleTableType ScheduleTableID</code> <code>)</code>	
<b>Service ID [hex]</b>	0x0b	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	ScheduleTableID	Schedule table to be started
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	StatusType	<code>E_OK</code> : No Error <code>E_OS_ID</code> (only in EXTENDED status): ScheduleTableID not valid <code>E_OS_STATE</code> : Schedule table was already started
<b>Description</b>	This service starts an explicitly synchronized schedule table synchronously.	
<b>Available via</b>	Os.h	

〕

**[SWS\_Os\_00387]**

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If in a call of [StartScheduleTableSynchron](#) the ScheduleTable <ScheduleTableID> is not valid OR the ScheduleTable <ScheduleTableID> is not explicitly synchronized ([OsScheduleTblSyncStrategy != EXPLICIT](#)) [StartScheduleTableSynchron](#) shall return `E_OS_ID`.〕

**[SWS\_Os\_00388]**

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the ScheduleTable <ScheduleTableID> in a call of [StartScheduleTableSynchron](#) is not in the state `SCHEDULETABLE_STOPPED`, [StartScheduleTableSynchron](#) shall return `E_OS_STATE`.〕

**[SWS\_Os\_00389]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔If <ScheduleTableID> in a call of [StartScheduleTableSynchron](#) is valid, [StartScheduleTableSynchron](#) shall set the state of <ScheduleTableID> to `SCHEDULETABLE_WAITING` and start the processing of ScheduleTable <ScheduleTableID>.〕

TableID> after the synchronization count of the ScheduleTable is set via [SyncScheduleTable](#). The Initial Expiry Point shall be processed when (Duration-Sync Value)+InitialOffset ticks have elapsed on the synchronization Counter where:

- Duration is <ScheduleTableID>.OsScheduleTableDuration
- SyncValue is the <Value> parameter passed to the [SyncScheduleTable](#)
- InitialOffset is the shortest expiry point offset in <ScheduleTableID>

]

### [SWS\_Os\_00525]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔 Availability of [StartScheduleTableSynchron](#): Available in Scalability Classes 2 and 4. 〕

#### 8.4.14 [SyncScheduleTable](#)

### [SWS\_Os\_00199] Definition of API function SyncScheduleTable

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔

<b>Service Name</b>	SyncScheduleTable	
<b>Syntax</b>	<code>StatusType SyncScheduleTable (</code> <code>    ScheduleTableType ScheduleTableID,</code> <code>    TickType Value</code> <code>)</code>	
<b>Service ID [hex]</b>	0x0c	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	ScheduleTableID	Schedule table to be synchronized
	Value	The current value of the synchronization counter
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	StatusType	<code>E_OK</code> : No errors <code>E_OS_ID</code> (only in EXTENDED status): The ScheduleTableID was not valid or schedule table can not be synchronized (OsScheduleTblSyncStrategy not set or <code>OsScheduleTblSyncStrategy = IMPLICIT</code> ) <code>E_OS_VALUE</code> (only in EXETENDED status): The <Value> is out of range <code>E_OS_STATE</code> : The state of schedule table <ScheduleTableID> is equal to <code>SCHEDULETABLE_STOPPED</code>
<b>Description</b>	This service provides the schedule table with a synchronization count and start synchronization.	
<b>Available via</b>	Os.h	

〕

**[SWS\_Os\_00454]**

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the <ScheduleTableID> in a call of [SyncScheduleTable](#) is not valid OR [ScheduleTable](#) can not be explicitly synchronized ([OsScheduleTblSyncStrategy](#) is not equal to [EXPLICIT](#)) [SyncScheduleTable](#) shall return [E\\_OS\\_ID](#).〕

**[SWS\_Os\_00455]**

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the <Value> in a call of [SyncScheduleTable](#) is greater or equal than the [OsScheduleTableDuration](#), [SyncScheduleTable](#) shall return [E\\_OS\\_VALUE](#).〕

**[SWS\_Os\_00456]**

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the state of the [ScheduleTable](#) <ScheduleTableID> in a call of [SyncScheduleTable](#) is equal to [SCHEDULETABLE\\_STOPPED](#) or [SCHEDULETABLE\\_NEXT](#) [SyncScheduleTable](#) shall return [E\\_OS\\_STATE](#).〕

**[SWS\_Os\_00457]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔If the parameters in a call of [SyncScheduleTable](#) are valid, [SyncScheduleTable](#) shall provide the Operating System module with the current synchronization count for the given [ScheduleTable](#). (It is used to synchronize the processing of the [ScheduleTable](#) to the synchronization Counter.)〕

**[SWS\_Os\_00526]**

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔Availability of [SyncScheduleTable](#): Available in Scalability Classes 2 and 4.〕

#### 8.4.15 [SetScheduleTableAsync](#)

**[SWS\_Os\_00422] Definition of API function [SetScheduleTableAsync](#)**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔

<b>Service Name</b>	<a href="#">SetScheduleTableAsync</a>
<b>Syntax</b>	<a href="#">StatusType</a> <a href="#">SetScheduleTableAsync</a> ( <a href="#">ScheduleTableType</a> <a href="#">ScheduleTableID</a> )
<b>Service ID [hex]</b>	0x0d
<b>Sync/Async</b>	Synchronous
<b>Reentrancy</b>	Reentrant





<b>Parameters (in)</b>	ScheduleTableID	Schedule table for which status is requested
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	StatusType	E_OK: No Error E_OS_ID (only in EXTENDED status): Invalid ScheduleTableID
<b>Description</b>	This service stops synchronization of a schedule table.	
<b>Available via</b>	Os.h	

]

### [SWS\_Os\_00362]

*Upstream requirements: [SRS\\_Os\\_11002](#)*

〔If `SetScheduleTableAsync` is called for a running ScheduleTable, the Operating System module shall stop further synchronization until a `SyncScheduleTable` call is made.〕

### [SWS\_Os\_00323]

*Upstream requirements: [SRS\\_Os\\_11002](#)*

〔If `SetScheduleTableAsync` is called for a running ScheduleTable the Operating System module shall continue to process expiry points on the ScheduleTable.〕

### [SWS\_Os\_00458]

*Upstream requirements: [SRS\\_BSW\\_00323](#)*

〔If `OsScheduleTblSyncStrategy` of <ScheduleTableID> in a call of `SetScheduleTableAsync` is not equal to EXPLICIT OR if <ScheduleTableID> is invalid then `SetScheduleTableAsync` shall return E\_OS\_ID.〕

### [SWS\_Os\_00483]

*Upstream requirements: [SRS\\_BSW\\_00323](#)*

〔If the current state of the <ScheduleTableID> in a call of `SetScheduleTableAsync` equals to SCHEDULETABLE\_STOPPED, SCHEDULETABLE\_NEXT or SCHEDULETABLE\_WAITING then `SetScheduleTableAsync` shall return E\_OS\_STATE.〕

### [SWS\_Os\_00300]

*Upstream requirements: [SRS\\_Os\\_11002](#)*

〔If the current state of <ScheduleTableID> in a call of `SetScheduleTableAsync` equals SCHEDULETABLE\_RUNNING\_AND\_SYNCHRONOUS (or SCHEDULETABLE\_RUNNING) then `SetScheduleTableAsync` shall set (or keep in case of SCHEDULETABLE\_RUNNING) the status of <ScheduleTableID> to SCHEDULETABLE\_RUNNING.〕

### [SWS\_Os\_00527]

*Upstream requirements: [SRS\\_Os\\_11016](#)*

〔Availability of `SetScheduleTableAsync`: Available in Scalability Classes 2 and 4.〕

#### 8.4.16 [GetScheduleTableStatus](#)

##### [SWS\_Os\_00227] Definition of API function GetScheduleTableStatus

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔

<b>Service Name</b>	GetScheduleTableStatus	
<b>Syntax</b>	<code>StatusType GetScheduleTableStatus (</code> <code>    ScheduleTableType ScheduleTableID,</code> <code>    ScheduleTableStatusRefType ScheduleStatus</code> <code>)</code>	
<b>Service ID [hex]</b>	0x0e	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	ScheduleTableID	Schedule table for which status is requested
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	ScheduleStatus	Reference to ScheduleTableStatusType
<b>Return value</b>	StatusType	E_OK: No Error E_OS_ID (only in EXTENDED status): Invalid ScheduleTableID
<b>Description</b>	This service queries the state of a schedule table (also with respect to synchronization).	
<b>Available via</b>	Os.h	

〕

##### [SWS\_Os\_00289]

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔If the ScheduleTable <ScheduleTableID> in a call of [GetScheduleTableStatus](#) is NOT started, [GetScheduleTableStatus](#) shall pass back SCHEDULETABLE\_STOPPED via the reference parameter <ScheduleStatus> AND shall return E\_OK.〕

##### [SWS\_Os\_00353]

*Upstream requirements:* [SRS\\_Os\\_00098](#)

〔If the ScheduleTable <ScheduleTableID> in a call of [GetScheduleTableStatus](#) was used in a [NextScheduleTable](#) call AND waits for the end of the current ScheduleTable, [GetScheduleTableStatus](#) shall return SCHEDULETABLE\_NEXT via the reference parameter <ScheduleStatus> AND shall return E\_OK.〕

##### [SWS\_Os\_00354]

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔If the ScheduleTable <ScheduleTableID> in a call of [GetScheduleTableStatus](#) is configured with explicit synchronization AND <ScheduleTableID> was started with [StartScheduleTableSynchron](#) AND no synchronization count was provided to the Operating System, [GetScheduleTableStatus](#) shall return SCHEDULETABLE\_WAITING via the reference parameter <ScheduleStatus> AND shall return E\_OK.〕

### [SWS\_Os\_00290]

*Upstream requirements:* [SRS\\_Os\\_11002](#)

「If the ScheduleTable <ScheduleTableID> in a call of [GetScheduleTableStatus](#) is started AND synchronous, [GetScheduleTableStatus](#) shall pass back SCHEDULETABLE\_RUNNING\_AND\_SYNCHRONOUS via the reference parameter <Schedule Status> AND shall return E\_OK.」

### [SWS\_Os\_00291]

*Upstream requirements:* [SRS\\_Os\\_00098](#)

「If the ScheduleTable <ScheduleTableID> in a call of [GetScheduleTableStatus](#) is started AND NOT synchronous (deviation is not within the precision interval OR the ScheduleTable has been set asynchronous), [GetScheduleTableStatus](#) shall pass back SCHEDULETABLE\_RUNNING via the reference parameter Schedule Status AND shall return E\_OK.」

### [SWS\_Os\_00293]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

「If the identifier <ScheduleTableID> in a call of [GetScheduleTableStatus](#) is NOT valid, [GetScheduleTableStatus](#) shall return E\_OS\_ID.」

### [SWS\_Os\_00528]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

「Availability of [GetScheduleTableStatus](#): Available in all Scalability Classes.」

## 8.4.17 [IncrementCounter](#)

### [SWS\_Os\_00399] Definition of API function [IncrementCounter](#) 「

<b>Service Name</b>	IncrementCounter	
<b>Syntax</b>	<code>StatusType IncrementCounter (</code> <code>    CounterType CounterID</code> <code>)</code>	
<b>Service ID [hex]</b>	0x0f	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	CounterID	The Counter to be incremented
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	StatusType	E_OK: No errors E_OS_ID (only in EXTENDED status): The CounterID was not valid or counter is implemented in hardware and can not be incremented by software
<b>Description</b>	This service increments a software counter.	
<b>Available via</b>	Os.h	

」

### [SWS\_Os\_00285]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the input parameter <CounterID> in a call of [IncrementCounter](#) is not valid OR the Counter is a hardware Counter, [IncrementCounter](#) shall return [E\\_OS\\_ID](#).〕

### [SWS\_Os\_00286]

*Upstream requirements:* [SRS\\_Os\\_11020](#)

〔If the input parameter of [IncrementCounter](#) is valid, [IncrementCounter](#) shall increment the Counter <CounterID> by one (if any alarm connected to this Counter expires, the given action, e.g. Task activation, is done) and shall return [E\\_OK](#).〕

### [SWS\_Os\_00321]

*Upstream requirements:* [SRS\\_Os\\_11020](#)

〔If in a call of [IncrementCounter](#) an error happens during the execution of an alarm action, e.g. [E\\_OS\\_LIMIT](#) caused by a Task activation, [IncrementCounter](#) shall call the error hook(s), but the [IncrementCounter](#) service itself shall return [E\\_OK](#).〕

### [SWS\_Os\_00529]

*Upstream requirements:* [SRS\\_Os\\_11020](#)

〔Caveats of [IncrementCounter](#): If called from a Task, rescheduling may take place.〕

### [SWS\_Os\_00530]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔Availability of [IncrementCounter](#): Available in all Scalability Classes.〕

## 8.4.18 [GetCounterValue](#)

### [SWS\_Os\_00383] Definition of API function [GetCounterValue](#) 〔

<b>Service Name</b>	GetCounterValue	
<b>Syntax</b>	<code>StatusType GetCounterValue (</code> <code>    CounterType CounterID,</code> <code>    TickRefType Value</code> <code>)</code>	
<b>Service ID [hex]</b>	0x10	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	CounterID	The Counter which tick value should be read
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	Value	Contains the current tick value of the counter





<b>Return value</b>	StatusType	E_OK: No errors E_OS_ID (only in EXTENDED status): The <CounterID> was not valid
<b>Description</b>	This service reads the current count value of a counter (returning either the hardware timer ticks if counter is driven by hardware or the software ticks when user drives counter).	
<b>Available via</b>	Os.h	

]

### [SWS\_Os\_00376]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the input parameter <CounterID> in a call of [GetCounterValue](#) is not valid, [GetCounterValue](#) shall return E\_OS\_ID.〕

**[SWS\_Os\_00377]** 〔If the input parameter <CounterID> in a call of [GetCounterValue](#) is valid, [GetCounterValue](#) shall return the current tick value of the Counter via <Value> and return E\_OK.〕

### [SWS\_Os\_00531]

*Upstream requirements:* [SRS\\_Os\\_11020](#)

〔Caveats of [GetCounterValue](#): Note that for counters of OsCounterType = HARDWARE the real timer value (the - possibly adjusted - hardware value, see [\[SWS\\_Os\\_00384\]](#)) is returned, whereas for counters of OsCounterType = SOFTWARE the current "software" tick value is returned.〕

### [SWS\_Os\_00532]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔Availability of [GetCounterValue](#): Available in all Scalability Classes.〕

#### 8.4.19 [GetElapsedValue](#)

### [SWS\_Os\_00392] Definition of API function [GetElapsedValue](#) 〔

<b>Service Name</b>	GetElapsedValue	
<b>Syntax</b>	<pre>StatusType GetElapsedValue (   CounterType CounterID,   TickRefType Value,   TickRefType ElapsedValue )</pre>	
<b>Service ID [hex]</b>	0x11	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	CounterID	The Counter to be read
<b>Parameters (inout)</b>	Value	in: the previously read tick value of the counter out: the current tick value of the counter





<b>Parameters (out)</b>	ElapsedValue	The difference to the previous read value
<b>Return value</b>	StatusType	E_OK: No errors E_OS_ID (only in EXTENDED status): The CounterID was not valid E_OS_VALUE (only in EXTENDED status): The given Value was not valid
<b>Description</b>	This service gets the number of ticks between the current tick value and a previously read tick value.	
<b>Available via</b>	Os.h	

]

### [SWS\_Os\_00381]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

「If the input parameter <CounterID> in a call of [GetElapsedValue](#) is not valid [GetElapsedValue](#) shall return E\_OS\_ID.」

### [SWS\_Os\_00391]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

「If the <Value> in a call of [GetElapsedValue](#) is larger than the max allowed value of the <CounterID>, [GetElapsedValue](#) shall return E\_OS\_VALUE.」

**[SWS\_Os\_00382]** 「If the input parameters in a call of [GetElapsedValue](#) are valid, [GetElapsedValue](#) shall return the number of elapsed ticks since the given <Value> value via <ElapsedValue> and shall return E\_OK.」

**[SWS\_Os\_00460]** 「[GetElapsedValue](#) shall return the current tick value of the Counter in the <Value> parameter.」

**[SWS\_Os\_00533]** 「Caveats of [GetElapsedValue](#): If the timer already passed the <Value> value a second (or multiple) time, the result returned is wrong. The reason is that the service can not detect such a relative overflow.」

### [SWS\_Os\_00534]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

「Availability of [GetElapsedValue](#): Available in all Scalability Classes.」

#### 8.4.20 [TerminateApplication](#)

##### [SWS\_Os\_00258] Definition of API function [TerminateApplication](#)

*Upstream requirements:* [SRS\\_Os\\_11022](#)

]

<b>Service Name</b>	TerminateApplication	
<b>Syntax</b>	<code>StatusType TerminateApplication (</code> <code>    ApplicationType Application,</code> <code>    RestartType RestartOption</code> <code>)</code>	
<b>Service ID [hex]</b>	0x12	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	Application	The identifier of the OS-Application to be terminated. If the caller belongs to <Application> the call results in a self termination.
	RestartOption	Parameter is no longer used and ignored.
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	StatusType	<code>E_OK</code> : No errors <code>E_OS_ID</code> : <Application> was not valid (only in EXTENDED status) <code>E_OS_ACCESS</code> : The caller does not have the right to terminate <Application> (only in EXTENDED status) <code>E_OS_STATE</code> : The state of <Application> does not allow terminating <Application>
<b>Description</b>	This service terminates the OS-Application to which the calling Task/Category 2 ISR/application specific error hook belongs.	
<b>Available via</b>	Os.h	

]

##### [SWS\_Os\_00493]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the input parameter <Application> in a call of [TerminateApplication](#) is not valid [TerminateApplication](#) shall return `E_OS_ID`.〕

##### [SWS\_Os\_00494]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the input parameter <Application> in a call of [TerminateApplication](#) is valid AND the caller belongs to a non-trusted OS-Application AND the caller does not belong to <Application> [TerminateApplication](#) shall return `E_OS_ACCESS`.〕

##### [SWS\_Os\_00507]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

〔If the state of <Application> in a call of [TerminateApplication](#) is APPLICATION\_TERMINATED [TerminateApplication](#) shall return `E_OS_STATE`.〕

**[SWS\_Os\_00287]**

*Upstream requirements:* [SRS\\_Os\\_11022](#)

〔If the parameters in a call of [TerminateApplication](#) are valid and the above criteria are met [TerminateApplication](#) shall terminate <Application> (i.e. to kill all Tasks, disable the interrupt sources of those ISRs which belong to the OS-Application and free all other OS resources associated with the application). The <Application> state is set to [APPLICATION\\_TERMINATED](#). If the caller belongs to <Application> [TerminateApplication](#) shall not return, otherwise it shall return [E\\_OK](#).〕

**[SWS\_Os\_00535]**

*Upstream requirements:* [SRS\\_Os\\_11022](#)

〔Caveats of [TerminateApplication](#):

- If no applications are configured the implementation shall make sure that this service is not available.
- Tasks and interrupts that are owned by a trusted application can terminate any OS-Application. Tasks and interrupts that are owned by a non-trusted application can only terminate their owning OS-Application.

〕

Note: Although trusted OS-Application can be forcibly terminated by Tasks/Interrupts of other trusted OS-Applications it is not recommended. This may have further impacts, e.g. to users who are currently part of such an OS-Application via a [CallTrusted-Function](#) call.

**[SWS\_Os\_00536]**

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔Availability of [TerminateApplication](#): Available in Scalability Classes 3 and 4.〕

#### 8.4.21 [GetApplicationState](#)

**[SWS\_Os\_00499] Definition of API function [GetApplicationState](#)**

*Upstream requirements:* [SRS\\_Os\\_11001](#)

〔

<b>Service Name</b>	GetApplicationState
<b>Syntax</b>	<pre>StatusType GetApplicationState (     ApplicationType Application,     ApplicationStateRefType Value )</pre>
<b>Service ID [hex]</b>	0x14
<b>Sync/Async</b>	Synchronous





<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	Application	The OS-Application from which the state is requested
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	Value	The current state of the application
<b>Return value</b>	StatusType	E_OK: No errors E_OS_ID: <Application> is not valid (only in EXTENDED status)
<b>Description</b>	This service returns the current state of an OS-Application.	
<b>Available via</b>	Os.h	



### [SWS\_Os\_00495]

*Upstream requirements:* [SRS\\_BSW\\_00323](#)

「If the <Application> in a call of `GetApplicationState` is not valid `GetApplicationState` shall return `E_OS_ID`.」

### [SWS\_Os\_00496]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

「If the parameters in a call of `GetApplicationState` are valid, `GetApplicationState` shall return the state of OS-Application <Application> in <Value>.」

### [SWS\_Os\_00537]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

「Availability of `GetApplicationState`: Available in Scalability Classes 3 and 4.」

## 8.4.22 `GetNumberOfActivatedCores`

### [SWS\_Os\_00672] Definition of API function `GetNumberOfActivatedCores`

*Upstream requirements:* [SRS\\_Os\\_80001](#)



<b>Service Name</b>	GetNumberOfActivatedCores	
<b>Syntax</b>	<pre>uint32 GetNumberOfActivatedCores (     void )</pre>	
<b>Service ID [hex]</b>	0x15	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	None	
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	uint32	Number of cores running the AUTOSAR OS (see below)





<b>Description</b>	The function returns the number of cores running the AUTOSAR OS. This function might be a macro.
<b>Available via</b>	Os.h

]

The function `GetNumberOfActivatedCores` shall be callable from within a Task and an Category 2 ISR. Otherwise the behavior is unspecified.

### [SWS\_Os\_00673]

*Upstream requirements:* [SRS\\_Os\\_80001](#)

[The return value of `GetNumberOfActivatedCores` shall be less or equal to the configured value of `OsNumberOfCores`.]

#### 8.4.23 [GetCoreID](#)

### [SWS\_Os\_00674] Definition of API function GetCoreID

*Upstream requirements:* [SRS\\_Os\\_80001](#)

[

<b>Service Name</b>	GetCoreID	
<b>Syntax</b>	<code>CoreIdType GetCoreID (</code> <code>    void</code> <code>)</code>	
<b>Service ID [hex]</b>	0x16	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	None	
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	<code>CoreIdType</code>	The return value is the unique ID of the core.
<b>Description</b>	The function returns a unique core identifier.	
<b>Available via</b>	Os.h	

]

### [SWS\_Os\_00675]

*Upstream requirements:* [SRS\\_Os\\_80001](#)

[The function `GetCoreID` shall return the unique logical CoreID of the core on which the function is called. The value is defined in the configuration parameter EcucCoreId.]

#### 8.4.24 [StartCore](#)

##### [SWS\_Os\_00676] Definition of API function StartCore

*Upstream requirements:* [SRS\\_Os\\_80006](#)

]

<b>Service Name</b>	StartCore	
<b>Syntax</b>	<pre>void StartCore (   CoreIdType CoreID,   StatusType* Status )</pre>	
<b>Service ID [hex]</b>	0x17	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Non Reentrant	
<b>Parameters (in)</b>	CoreID	Core identifier
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	Status	Return value of the function in extended status: E_OK: No Error E_OS_ID: Core ID is invalid. E_OS_ACCESS: The function was called after starting the OS. E_OS_STATE: The Core is already activated. Return value of the function in standard status E_OK: No Error
<b>Return value</b>	None	
<b>Description</b>	It is not supported to call this function after StartOS(). The function starts the core specified by the parameter CoreID. The OUT parameter allows the caller to check whether the operation was successful or not. If a core is started by means of this function StartOS shall be called on the core.	
<b>Available via</b>	Os.h	

]

##### [SWS\_Os\_00677]

*Upstream requirements:* [SRS\\_Os\\_80006](#)

[The function [StartCore](#) shall start one core that shall run under the control of the AUTOSAR OS.]

##### [SWS\_Os\_00678]

*Upstream requirements:* [SRS\\_Os\\_80006](#)

[Calls to the [StartCore](#) function after [StartOS](#) shall return with E\_OS\_ACCESS and the core shall not be started.]

##### [SWS\_Os\_00679]

*Upstream requirements:* [SRS\\_Os\\_80006](#)

[If the parameter CoreIDs refers to a core that was already started by the function [StartCore](#) the related core is ignored and E\_OS\_STATE shall be returned.]

##### [SWS\_Os\_00681]

*Upstream requirements:* [SRS\\_Os\\_80006](#)

[There is no call to the [ErrorHook](#) if an error occurs during [StartCore](#).]

#### 8.4.25 [GetSpinlock](#)

##### [SWS\_Os\_00686] Definition of API function GetSpinlock

*Upstream requirements: [SRS\\_Os\\_80021](#)*

]

<b>Service Name</b>	GetSpinlock	
<b>Syntax</b>	<code>StatusType GetSpinlock (</code> <code>    SpinlockIdType SpinlockId</code> <code>)</code>	
<b>Service ID [hex]</b>	0x19	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	SpinlockId	The value refers to the spinlock instance that shall be locked.
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	StatusType	<code>E_OK</code> - In standard and extended status : No Error <code>E_OS_ID</code> - In extended status: The SpinlockId is invalid <code>E_OS_INTERFERENCE_DEADLOCK</code> - In extended status: A TASK tries to occupy the spinlock while the lock is already occupied by a TASK on the same core. This would cause a deadlock. <code>E_OS_NESTING_DEADLOCK</code> - In extended status: A TASK tries to occupy the spinlock while a TASK on the same core is holding a different spinlock in a way that may cause a deadlock. <code>E_OS_ACCESS</code> - In extended status: The spinlock cannot be accessed.
<b>Description</b>	GetSpinlock tries to occupy a spin-lock variable. If the function returns, either the lock is successfully taken or an error has occurred. The spinlock mechanism is an active polling mechanism. The function does not cause a de-scheduling.	
<b>Available via</b>	Os.h	

]

##### [SWS\_Os\_00687]

*Upstream requirements: [SRS\\_Os\\_80021](#)*

[The function [GetSpinlock](#) shall occupy a spinlock. If the spinlock is already occupied the function shall busy wait until the spinlock becomes available.]

##### [SWS\_Os\_00688]

*Upstream requirements: [SRS\\_Os\\_80021](#)*

[The function [GetSpinlock](#) shall return `E_OK` if no error was detected. The spinlock is now occupied by the calling Task/Category 2 ISR on the calling core.]

##### [SWS\_Os\_00689]

*Upstream requirements: [SRS\\_Os\\_80021](#)*

[The function [GetSpinlock](#) shall return `E_OS_ID` if the parameter SpinlockID refers to a spinlock that does not exist.]

**[SWS\_Os\_00690]**

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔The function `GetSpinlock` shall return `E_OS_INTERFERENCE_DEADLOCK` if the spinlock referred by the parameter `SpinlockID` is already occupied by a Task/Category 2 ISR on the same core.〕

**[SWS\_Os\_00691]**

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔The function `GetSpinlock` shall return `E_OS_NESTING_DEADLOCK` if the sequence by which multiple spinlocks are occupied at the same time on one core do not comply with the configured order.〕

**[SWS\_Os\_00692]**

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔The function `GetSpinlock` shall return `E_OS_ACCESS` if the accessing OS-Application was not listed in the configuration (`OsSpinlock`).〕

**[SWS\_Os\_00693]**

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔It shall be allowed to call the function `GetSpinlock` while interrupts are disabled.〕

**[SWS\_Os\_00694]**

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔It shall be allowed to call the function `GetSpinlock` while a Resource is occupied.〕

#### 8.4.26 `ReleaseSpinlock`

**[SWS\_Os\_00695] Definition of API function `ReleaseSpinlock`**

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔

<b>Service Name</b>	ReleaseSpinlock	
<b>Syntax</b>	<code>StatusType ReleaseSpinlock (</code> <code>    SpinlockIdType SpinlockId</code> <code>)</code>	
<b>Service ID [hex]</b>	0x1a	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	SpinlockId	The value refers to the spinlock instance that shall be locked.
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	





<b>Return value</b>	StatusType	E_OK - In standard and extended status: No Error E_OS_ID - In extended status: The SpinlockId is invalid. E_OS_STATE - In extended status: The Spinlock is not occupied by the TASK E_OS_ACCESS - In extended status: The Spinlock cannot be accessed. E_OS_NOFUNC - In extended status: Attempt to release a spinlock while another spinlock (or resource) has to be released before.
<b>Description</b>	ReleaseSpinlock releases a spinlock variable that was occupied before. Before terminating a TASK all spinlock variables that have been occupied with GetSpinlock() shall be released. Before calling WaitEVENT all Spinlocks shall be released.	
<b>Available via</b>	Os.h	

]

### [SWS\_Os\_00696]

*Upstream requirements: SRS\_Os\_80021*

〔The function `ReleaseSpinlock` shall release a spinlock that has been occupied by the same (calling) Task. If the related `GetSpinlock` call used configured locks (`OsSpinlockLockMethod`) the function shall also perform the undo of the used lock.〕

### [SWS\_Os\_00697]

*Upstream requirements: SRS\_Os\_80021*

〔The function `ReleaseSpinlock` shall return `E_OK` if no error was detected. The spinlock is now free and can be occupied by the same or other Tasks.〕

### [SWS\_Os\_00698]

*Upstream requirements: SRS\_Os\_80021*

〔The function `ReleaseSpinlock` shall return `E_OS_ID` if the parameter `SpinlockID` refers to a spinlock that does not exist.〕

### [SWS\_Os\_00699]

*Upstream requirements: SRS\_Os\_80021*

〔The function `ReleaseSpinlock` shall return `E_OS_STATE` if the parameter `SpinlockID` refers to a spinlock that is not occupied by the calling Task.〕

### [SWS\_Os\_00700]

*Upstream requirements: SRS\_Os\_80021*

〔The function `ReleaseSpinlock` shall return `E_OS_ACCESS` if the Task has no access to the spinlock referred by the parameter `SpinlockID`〕

### [SWS\_Os\_00701]

*Upstream requirements: SRS\_Os\_80021*

〔The function `ReleaseSpinlock` shall return `E_OS_NOFUNC` if the Task tries to release a spinlock while another spinlock (or Resource) has to be released before. No functionality shall be performed.〕

#### 8.4.27 [TryToGetSpinlock](#)

##### [SWS\_Os\_00703] Definition of API function TryToGetSpinlock

*Upstream requirements: [SRS\\_Os\\_80021](#)*

]

<b>Service Name</b>	TryToGetSpinlock	
<b>Syntax</b>	<pre>StatusType TryToGetSpinlock (   SpinlockIdType SpinlockId,   TryToGetSpinlockType* Success )</pre>	
<b>Service ID [hex]</b>	0x1b	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	SpinlockId	The value refers to the spinlock instance that shall be locked.
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	Success	Returns if the lock has been occupied or not
<b>Return value</b>	StatusType	<p><code>E_OK</code> - In standard and extended status: No Error  <code>E_OS_ID</code> - In extended status: The SpinlockId is invalid.  <code>E_OS_INTERFERENCE_DEADLOCK</code> - In extended status: A TASK tries to occupy the spinlock while the lock is already occupied by a TASK on the same core. This would cause a deadlock.  <code>E_OS_NESTING_DEADLOCK</code> - In extended status: A TASK tries to occupy a spinlock while holding a different spinlock in a way that may cause a deadlock.  <code>E_OS_ACCESS</code> - In extended status: The spinlock cannot be accessed.</p>
<b>Description</b>	TryToGetSpinlock has the same functionality as GetSpinlock with the difference that if the spinlock is already occupied by a TASK on a different core the function sets the OUT parameter "Success" and returns with <code>E_OK</code> .	
<b>Available via</b>	Os.h	

]

##### [SWS\_Os\_00704]

*Upstream requirements: [SRS\\_Os\\_80021](#)*

[The function [TryToGetSpinlock](#) shall atomically test the availability of the spinlock and if available occupy it. The result of success is returned.]

##### [SWS\_Os\_00705]

*Upstream requirements: [SRS\\_Os\\_80021](#)*

[The function [TryToGetSpinlock](#) shall set the OUT parameter "Success" to `TRYTOGETSPINLOCK_SUCCESS` if the spinlock was successfully occupied, and `TRYTOGETSPINLOCK_NOSUCCESS` if not. In both cases `E_OK` shall be returned.]

##### [SWS\_Os\_00706]

*Upstream requirements: [SRS\\_Os\\_80021](#)*

[If the function [TryToGetSpinlock](#) does not return `E_OK`, the OUT parameter "Success" shall be undefined.]

**[SWS\_Os\_00707]**

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔The function `TryToGetSpinlock` shall return `E_OS_ID` if the parameter `SpinlockID` refers to a spinlock that does not exist.〕

**[SWS\_Os\_00708]**

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔The function `TryToGetSpinlock` shall return `E_OS_INTERFERENCE_DEADLOCK` if the spinlock referred by the parameter `SpinlockID` is already occupied by a Task on the same core.〕

**[SWS\_Os\_00709]**

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔The function `TryToGetSpinlock` shall return `E_OS_NESTING_DEADLOCK` if a Task tries to occupy a spinlock while holding a different spinlock in a way that may cause a deadlock.〕

**[SWS\_Os\_00710]**

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔The function `TryToGetSpinlock` shall return `E_OS_ACCESS` if the Task has no access to the spinlock referred by the parameter `SpinlockID`〕

**[SWS\_Os\_00711]**

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔It shall be allowed to call the function `TryToGetSpinlock` while interrupts are disabled.〕

**[SWS\_Os\_00712]**

*Upstream requirements:* [SRS\\_Os\\_80021](#)

〔It shall be allowed to call the function `TryToGetSpinlock` while a Resource is occupied.〕

#### 8.4.28 [ShutdownAllCores](#)

##### [SWS\_Os\_00713] Definition of API function [ShutdownAllCores](#)

*Upstream requirements:* [SRS\\_Os\\_80007](#), [SRS\\_BSW\\_00336](#)

〔

<b>Service Name</b>	ShutdownAllCores	
<b>Syntax</b>	<pre>void ShutdownAllCores (     StatusType Error )</pre>	
<b>Service ID [hex]</b>	0x1c	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	Error	<Error> needs to be a valid error code supported by the AUTOSAR OS.
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	None	
<b>Description</b>	After this service the OS on all AUTOSAR cores is shut down. Allowed at TASK level and ISR level and also internally by the OS. The function will never return. The function will force other cores into a shutdown.	
<b>Available via</b>	Os.h	

〕

##### [SWS\_Os\_00714]

*Upstream requirements:* [SRS\\_Os\\_80007](#)

〔A synchronized shutdown shall be triggered by the API function [ShutdownAllCores](#).〕

##### [SWS\_Os\_00715]

*Upstream requirements:* [SRS\\_Os\\_80007](#)

〔[ShutdownAllCores](#) shall not return.〕

##### [SWS\_Os\_00716]

*Upstream requirements:* [SRS\\_Os\\_80007](#)

〔If [ShutdownAllCores](#) is called from non trusted code the call shall be ignored.〕

#### 8.4.29 `ReadPeripheral8`, `ReadPeripheral16`, `ReadPeripheral32`

##### [SWS\_Os\_91013] Definition of API function `ReadPeripheral8`

*Upstream requirements:* [SRS\\_Os\\_11005](#)

]

<b>Service Name</b>	ReadPeripheral8	
<b>Syntax</b>	<code>StatusType ReadPeripheral8 (</code> <code>    AreaIdType Area,</code> <code>    const uint8* Address,</code> <code>    uint8* ReadValue</code> <code>)</code>	
<b>Service ID [hex]</b>	0x28	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	Area	hardware peripheral area reference
	Address	memory address
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	ReadValue	content of the given memory location (<Address>)
<b>Return value</b>	StatusType	<code>E_OK</code> No error <code>E_OS_ID</code> Area id is out of range (EXTENDED status) <code>E_OS_VALUE</code> Address does not belong to given Area (EXTENDED status) <code>E_OS_CALLEVEL</code> Wrong call context of the API function (EXTENDED status) <code>E_OS_ACCESS</code> The calling task or ISR is not allowed to access the given
<b>Description</b>	This service returns the content of a given memory location (<Address>).	
<b>Available via</b>	Os.h	

]

##### [SWS\_Os\_91015] Definition of API function `ReadPeripheral16`

*Upstream requirements:* [SRS\\_Os\\_11005](#)

]

<b>Service Name</b>	ReadPeripheral16	
<b>Syntax</b>	<code>StatusType ReadPeripheral16 (</code> <code>    AreaIdType Area,</code> <code>    const uint16* Address,</code> <code>    uint16* ReadValue</code> <code>)</code>	
<b>Service ID [hex]</b>	0x29	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	Area	hardware peripheral area reference
	Address	memory address
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	ReadValue	content of the given memory location (<Address>)





<b>Return value</b>	StatusType	E_OK No error E_OS_ID Area id is out of range (EXTENDED status) E_OS_VALUE Address does not belong to given Area (EXTENDED status) E_OS_CALLEVEL Wrong call context of the API function (EXTENDED status) E_OS_ACCESS The calling task or ISR is not allowed to access the given
<b>Description</b>	This service returns the content of a given memory location (<Address>).	
<b>Available via</b>	Os.h	



## [SWS\_Os\_91014] Definition of API function ReadPeripheral32

*Upstream requirements: [SRS\\_Os\\_11005](#)*



<b>Service Name</b>	ReadPeripheral32	
<b>Syntax</b>	<pre>StatusType ReadPeripheral32 (   AreaIdType Area,   const uint32* Address,   uint32* ReadValue )</pre>	
<b>Service ID [hex]</b>	0x2a	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	Area	hardware peripheral area reference
	Address	memory address
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	ReadValue	content of the given memory location (<Address>)
<b>Return value</b>	StatusType	E_OK No error E_OS_ID Area id is out of range (EXTENDED status) E_OS_VALUE Address does not belong to given Area (EXTENDED status) E_OS_CALLEVEL Wrong call context of the API function (EXTENDED status) E_OS_ACCESS The calling task or ISR is not allowed to access the given
<b>Description</b>	This service returns the content of a given memory location (<Address>).	
<b>Available via</b>	Os.h	



### 8.4.30 `WritePeripheral8`, `WritePeripheral16`, `WritePeripheral32`

#### [SWS\_Os\_91010] Definition of API function `WritePeripheral8`

*Upstream requirements:* [SRS\\_Os\\_11005](#)

]

<b>Service Name</b>	WritePeripheral8	
<b>Syntax</b>	<code>StatusType WritePeripheral8 (</code> <code>    AreaIdType Area,</code> <code>    uint8* Address,</code> <code>    uint8 WriteValue</code> <code>)</code>	
<b>Service ID [hex]</b>	0x2b	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	Area	hardware peripheral area reference
	Address	memory address
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	WriteValue	value to be written at the memory address
<b>Return value</b>	StatusType	<code>E_OK</code> No error <code>E_OS_ID</code> Area id is out of range (EXTENDED status) <code>E_OS_VALUE</code> Address does not belong to given Area (EXTENDED status) <code>E_OS_CALLEVEL</code> Wrong call context of the API function (EXTENDED status) <code>E_OS_ACCESS</code> The calling task or ISR is not allowed to access the given
<b>Description</b>	This service writes the <value> to a given memory location (<memory address>).	
<b>Available via</b>	Os.h	

]

#### [SWS\_Os\_91012] Definition of API function `WritePeripheral16`

*Upstream requirements:* [SRS\\_Os\\_11005](#)

]

<b>Service Name</b>	WritePeripheral16	
<b>Syntax</b>	<code>StatusType WritePeripheral16 (</code> <code>    AreaIdType Area,</code> <code>    uint16* Address,</code> <code>    uint16 WriteValue</code> <code>)</code>	
<b>Service ID [hex]</b>	0x2c	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	Area	hardware peripheral area reference
	Address	memory address
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	WriteValue	value to be written at the memory address

▽



<b>Return value</b>	StatusType	E_OK No error E_OS_ID Area id is out of range (EXTENDED status) E_OS_VALUE Address does not belong to given Area (EXTENDED status) E_OS_CALLEVEL Wrong call context of the API function (EXTENDED status) E_OS_ACCESS The calling task or ISR is not allowed to access the given
<b>Description</b>	This service writes the <value> to a given memory location (<memory address>).	
<b>Available via</b>	Os.h	



## [SWS\_Os\_91011] Definition of API function WritePeripheral32

*Upstream requirements: [SRS\\_Os\\_11005](#)*



<b>Service Name</b>	WritePeripheral32	
<b>Syntax</b>	<pre>StatusType WritePeripheral32 (   AreaIdType Area,   uint32* Address,   uint32 WriteValue )</pre>	
<b>Service ID [hex]</b>	0x2d	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	Area	hardware peripheral area reference
	Address	memory address
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	WriteValue	content of the given memory location (<Address>)
<b>Return value</b>	StatusType	E_OK No error E_OS_ID Area id is out of range (EXTENDED status) E_OS_VALUE Address does not belong to given Area (EXTENDED status) E_OS_CALLEVEL Wrong call context of the API function (EXTENDED status) E_OS_ACCESS The calling task or ISR is not allowed to access the given
<b>Description</b>	This service writes the <value> to a given memory location (<memory address>).	
<b>Available via</b>	Os.h	



### 8.4.31 `ModifyPeripheral8`, `ModifyPeripheral16`, `ModifyPeripheral32`

#### [SWS\_Os\_91016] Definition of API function `ModifyPeripheral8`

Upstream requirements: [SRS\\_Os\\_11005](#)

<b>Service Name</b>	ModifyPeripheral8	
<b>Syntax</b>	<code>StatusType ModifyPeripheral8 (</code> <code>    AreaIdType Area,</code> <code>    uint8* Address,</code> <code>    uint8 Clearmask,</code> <code>    uint8 Setmask</code> <code>)</code>	
<b>Service ID [hex]</b>	0x2e	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	Area	hardware peripheral area reference
	Address	memory address
	Clearmask	memory address will be modified by an bit-AND
	Setmask	memory address will be modified by an bit-OR
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	<code>StatusType</code>	<code>E_OK</code> No error <code>E_OS_ID</code> Area id is out of range (EXTENDED status) <code>E_OS_VALUE</code> Address does not belong to given Area (EXTENDED status) <code>E_OS_CALLEVEL</code> Wrong call context of the API function (EXTENDED status) <code>E_OS_ACCESS</code> The calling task or ISR is not allowed to access the given
<b>Description</b>	This service modifies a given memory location (<memory address>) with the formula: $*\text{Address} = ((*\text{Address} \& \text{Clearmask})   \text{Setmask})$	
<b>Available via</b>	Os.h	

#### [SWS\_Os\_91018] Definition of API function `ModifyPeripheral16`

Upstream requirements: [SRS\\_Os\\_11005](#)

<b>Service Name</b>	ModifyPeripheral16	
<b>Syntax</b>	<code>StatusType ModifyPeripheral16 (</code> <code>    AreaIdType Area,</code> <code>    uint16* Address,</code> <code>    uint16 Clearmask,</code> <code>    uint16 Setmask</code> <code>)</code>	
<b>Service ID [hex]</b>	0x35	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	Area	hardware peripheral area reference
	Address	memory address





	Clearmask	memory address will be modified by an bit-AND
	Setmask	memory address will be modified by an bit-OR
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	<a href="#">StatusType</a> E_OK No error E_OS_ID Area id is out of range (EXTENDED status) E_OS_VALUE Address does not belong to given Area (EXTENDED status) E_OS_CALLEVEL Wrong call context of the API function (EXTENDED status) E_OS_ACCESS The calling task or ISR is not allowed to access the given	
<b>Description</b>	This service modifies a given memory location (<memory address>) with the formula: $*<\text{Address}> = (*<\text{Address}> \& <\text{clearmask}>)   <\text{setmask}>$	
<b>Available via</b>	Os.h	

]

## [SWS\_Os\_91017] Definition of API function ModifyPeripheral32

Upstream requirements: [SRS\\_Os\\_11005](#)

[

<b>Service Name</b>	ModifyPeripheral32	
<b>Syntax</b>	<code>StatusType ModifyPeripheral32 (</code> <code>  AreaIdType Area,</code> <code>  uint32* Address,</code> <code>  uint32 Clearmask,</code> <code>  uint32 Setmask</code> <code>)</code>	
<b>Service ID [hex]</b>	0x2f	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	Area Address Clearmask Setmask	hardware peripheral area reference
		memory address
		memory address will be modified by an bit-AND
		memory address will be modified by an bit-OR
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	<a href="#">StatusType</a> E_OK No error E_OS_ID Area id is out of range (EXTENDED status) E_OS_VALUE Address does not belong to given Area (EXTENDED status) E_OS_CALLEVEL Wrong call context of the API function (EXTENDED status) E_OS_ACCESS The calling task or ISR is not allowed to access the given	
<b>Description</b>	This service modifies a given memory location (<memory address>) with the formula: $*<\text{Address}> = (*<\text{Address}> \& <\text{clearmask}>)   <\text{setmask}>$	
<b>Available via</b>	Os.h	

]

#### 8.4.32 [EnableInterruptSource](#)

##### [SWS\_Os\_91020] Definition of API function [EnableInterruptSource](#)

*Upstream requirements:* [SRS\\_Os\\_11011](#)

]

<b>Service Name</b>	EnableInterruptSource	
<b>Syntax</b>	<code>StatusType EnableInterruptSource (</code> <code>    ISRTYPE ISRID,</code> <code>    boolean ClearPending</code> <code>)</code>	
<b>Service ID [hex]</b>	0x31	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	ISRID	The ID of a category 2 ISR.
	ClearPending	Defines whether the pending flag shall be cleared (TRUE) or not (FALSE).
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	StatusType	<code>E_OK</code> No error. <code>E_OS_ID</code> ISRID is not a valid category 2 ISR identifier (EXTENDED status) <code>E_OS_CALLEVEL</code> Wrong call context of the API function (EXTENDED status) <code>E_OS_ACCESS</code> The calling application is not the owner of the ISR passed in ISRID (Service Protection)
<b>Description</b>	Enables the interrupt source by modifying the interrupt controller registers. Additionally it may clear the interrupt pending flag	
<b>Available via</b>	Os.h	

]

#### 8.4.33 [DisableInterruptSource](#)

##### [SWS\_Os\_91019] Definition of API function [DisableInterruptSource](#)

*Upstream requirements:* [SRS\\_Os\\_11011](#)

]

<b>Service Name</b>	DisableInterruptSource	
<b>Syntax</b>	<code>StatusType DisableInterruptSource (</code> <code>    ISRTYPE ISRID</code> <code>)</code>	
<b>Service ID [hex]</b>	0x30	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	ISRID	The ID of a category 2 ISR.
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	

▽



<b>Return value</b>	<code>StatusType</code>	<code>E_OK</code> No error. <code>E_OS_ID</code> ISRID is not a valid category 2 ISR identifier (EXTENDED status) <code>E_OS_CALLEVEL</code> Wrong call context of the API function (EXTENDED status) <code>E_OS_ACCESS</code> The calling application is not the owner of the ISR passed in ISRID (Service Protection)
<b>Description</b>	Disables the interrupt source by modifying the interrupt controller registers.	
<b>Available via</b>	Os.h	

]

#### 8.4.34 `ClearPendingInterrupt`

##### [SWS\_Os\_91021] Definition of API function `ClearPendingInterrupt`

Upstream requirements: [SRS\\_Os\\_11011](#)

[

<b>Service Name</b>	ClearPendingInterrupt	
<b>Syntax</b>	<code>StatusType ClearPendingInterrupt (</code> <code>    ISRTYPE ISRID</code> <code>)</code>	
<b>Service ID [hex]</b>	0x32	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	ISRID	The ID of a category 2 ISR.
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	<code>StatusType</code>	<code>E_OK</code> No error. <code>E_OS_ID</code> ISRID is not a valid category 2 ISR identifier (EXTENDED status) <code>E_OS_CALLEVEL</code> Wrong call context of the API function (EXTENDED status) <code>E_OS_ACCESS</code> The calling application is not the owner of the ISR passed in ISRID (Service Protection)
<b>Description</b>	Clears the interrupt pending flag by modifying the interrupt controller registers.	
<b>Available via</b>	Os.h	

]

#### 8.4.35 [ActivateTaskAsyn](#)

##### [SWS\_Os\_91022] Definition of API function ActivateTaskAsyn

*Upstream requirements:* [SRS\\_Os\\_80015](#)

〔

<b>Service Name</b>	ActivateTaskAsyn	
<b>Syntax</b>	<pre>void ActivateTaskAsyn (     TaskType id )</pre>	
<b>Service ID [hex]</b>	0x33	
<b>Sync/Async</b>	Asynchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	id	The id of the task to be activated
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	None	
<b>Description</b>	Asynchronous version of the ActivateTask() function. Intended to be used for cross core task activation. Possible errors are not returned to the caller, but may be reported via error hooks.	
<b>Available via</b>	Os.h	

〕

##### [SWS\_Os\_00818]

*Upstream requirements:* [SRS\\_Os\\_80015](#)

〔Availability of [ActivateTaskAsyn](#): Available in systems which support OS-Applications.〕

Note: If during the Task activation an error occurs, and the caller is already gone (e.g. callers OS-Application is already terminated, OR callers core is shutting down OR ...) calls to error hooks are dropped and no reporting is done.

#### 8.4.36 [SetEventAsyn](#)

##### [SWS\_Os\_91023] Definition of API function SetEventAsyn

*Upstream requirements:* [SRS\\_Os\\_80015](#)

〔

<b>Service Name</b>	SetEventAsyn	
<b>Syntax</b>	<pre>void SetEventAsyn (     TaskType id,     EventMaskType m )</pre>	
<b>Service ID [hex]</b>	0x34	
<b>Sync/Async</b>	Asynchronous	
<b>Reentrancy</b>	Reentrant	



△

<b>Parameters (in)</b>	id	The id of the task to be activated
	m	Mask of the events to be set
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	None	
<b>Description</b>	Asynchronous version of the SetEvent() function. Intended to be used for cross core event setting. Possible errors are not returned to the caller, but may be reported via error hooks.	
<b>Available via</b>	Os.h	

↴

### [SWS\_Os\_00819]

*Upstream requirements:* [SRS\\_Os\\_80015](#)

〔Availability of [SetEventAsyn](#): Available in systems which support OS-Applications.〕

Note: If during the event setting an error occurs and the caller is already gone (e.g. callers OS-Application is already terminated, OR callers core is shutting down OR ...) calls to error hooks are dropped and no reporting is done.

#### 8.4.37 [isOsStarted](#)

### [SWS\_Os\_91034] Definition of API function [isOsStarted](#)

*Status:* DRAFT

*Upstream requirements:* [SRS\\_Os\\_00097](#)

↴

<b>Service Name</b>	isOsStarted (draft)	
<b>Syntax</b>	boolean isOsStarted ( void )	
<b>Service ID [hex]</b>	0x36	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	None	
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	boolean	returns true if StartOS() was called otherwise false.
<b>Description</b>	This API returns a boolean value which indicates if the Os was already started. In case of multi-core it shall check if StartOs was already called on the core where isOsStarted was called. If the Os was (locally) started it returns true otherwise false. The function is intended to be implemented as macro. The function is by nature also callable before StartOs, but assumes a valid and initialized C environment (e.g. main() was called before the use of isOsStarted) <b>Tags:</b> atp.Status=draft	
<b>Available via</b>	Os.h	

↴

The [isOsStarted](#) API can be useful for drivers to detect if the Os was already started or not. Note that if called from within category 1 [ISRs](#) during startup it may happen that

this interrupt just happened while the call to `StartOS` is processed. In such cases the correct return value of true is not guaranteed.

#### 8.4.38 `BudgetReplenish`

##### [SWS\_Os\_91035] Definition of API function `BudgetReplenish` [

<b>Service Name</b>	BudgetReplenish	
<b>Syntax</b>	<code>StatusType BudgetReplenish (</code> <code>    TaskType id</code> <code>)</code>	
<b>Service ID [hex]</b>	0x38	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	id	The id of the Task whose budget is replenished
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	StatusType	<code>E_OK</code> : No error <code>E_OS_ID</code> : If id is no Task Id OR if Task is no Deferrable Server. <code>E_OS_ACCESS</code> : Calling application is not owner/has no access to Task OR id is Task Id of caller Task.
<b>Description</b>	This API replenishes the execution budget of the given Task.	
<b>Available via</b>	Os.h	

]

[SWS\_Os\_00874] Details of `BudgetReplenish` [The function `BudgetReplenish` will add the configured execution budget (`OsTaskExecutionBudget`) to the current budget of the Task. If this would result in a bigger current budget than configured (in `OsTaskExecutionBudget`), the budget is saturated to `OsTaskExecutionBudget`. If the new budget is bigger than 0 and the task was previously in `BUDGET_EXHAUSTED` it will change state to `READY` and a rescheduling may happen.]

Note: As per [SWS\_Os\_91035] it is not allowed to do a "self" replenish by calling the API with the own Task Id. In such cases the API returns `E_OS_ACCESS`.

[SWS\_Os\_00875] Availability of `BudgetReplenish` [The function `BudgetReplenish` is only available in Scalability Classes 2 and 4.]

## 8.5 IOC

### 8.5.1 Imported types

In this chapter all types included from the following modules are listed:

## [SWS\_Os\_91028] Definition of imported datatypes of module Os

Module	Header File	Imported Type
Gpt	Gpt.h	Gpt_ChannelType
	Gpt.h	Gpt_ValueType
Std	Std_Types.h	Std_ReturnType

]

## [SWS\_Os\_00827]

*Upstream requirements: [SRS\\_Os\\_80020](#)*

〔If an `ImplementationDataType` is defined with the `typeEmitter` empty or set to `RTE` and is used for IOC communication, the IOC shall include `Rte_Type.h`〕

## [SWS\_Os\_00828]

*Upstream requirements: [SRS\\_Os\\_80020](#)*

〔If an `ImplementationDataType` is defined with the `typeEmitter` != `RTE` and does end with ".h" and is used for IOC communication, the IOC shall include specified header file.〕

### 8.5.2 Type definitions

None

### 8.5.3 Constants

Name	Communication	Type	Errorname / Value	Annotation
<code>IOC_E_OK</code>	All, SND/RCV	<code>Std_ReturnType</code>	<code>RTE_E_OK / 0</code>	No error occurred
<code>IOC_E_LENGTH</code>	Queued SND	<code>Std_ReturnType</code>	<code>RTE_E_LIMIT / 130</code>	In case of "event" (queued) semantic, the internal buffer within the IOC communication service is too small for the requested transmission size.
<code>IOC_E_LIMIT</code>	Queued SND	<code>Std_ReturnType</code>	<code>RTE_E_LIMIT / 130</code>	In case of "event" (queued) semantic, the internal buffer within the IOC communication service is full (Case: Receiver slower than sender). This error produces additionally an Overlayed Error on the receiver side at the next data reception.





IOC_E_LOST_DATA	Queued RCV	Std_ReturnType	Overlaid Error RTE_E_LOST_DATA / 64	In case of "event" (queued) semantic, this Overlaid Error indicates that the IOC service refuses an <a href="#">IocSend</a> request due to internal buffer overflow.
IOC_E_NO_DATA	Queued RCV	Std_ReturnType	RTE_E_NO_DATA / 131	In case of "event" (queued) semantic, no data is available for reception.

**Table 8.1: IOC constants**

## 8.5.4 Function definitions

### [SWS\_Os\_00805] :

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔The optional length parameter of the API shall be generated if the VariableDataPrototype is of type dynamic and no size indicator is used in the according Application-ArrayDataType.〕

#### 8.5.4.1 [IocInit](#) (DRAFT)

### [SWS\_Os\_91026] Definition of API function [IocInit](#)

*Status:* DRAFT

*Upstream requirements:* [SRS\\_Os\\_80020](#)



<b>Service Name</b>	<a href="#">IocInit</a> (draft)
<b>Syntax</b>	void IocInit ( void )
<b>Service ID [hex]</b>	0x37
<b>Sync/Async</b>	Synchronous
<b>Reentrancy</b>	Non Reentrant
<b>Parameters (in)</b>	None
<b>Parameters (inout)</b>	None
<b>Parameters (out)</b>	None
<b>Return value</b>	None
<b>Description</b>	This service initializes the data structures of the IOC. <b>Tags:</b> atp.Status=draft
<b>Available via</b>	loc.h



#### 8.5.4.2 [IocSend/IocWrite](#)

The [IocWrite](#) API call is generated for "data" (unqueued) semantics and the [IocSend](#) API call is generated for "event" (queued) semantics.

#### [SWS\_Os\_00718] Definition of API function `locSend_<locId>[_<SenderId>]`

*Upstream requirements:* [SRS\\_Os\\_80020](#)

]

<b>Service Name</b>	locSend_<locId>[_<SenderId>]	
<b>Syntax</b>	<pre>Std_ReturnType IocSend_&lt;locId&gt;[_&lt;SenderId&gt;] (     &lt;Data&gt; IN,     [uint16 numberOfBytesIN] )</pre>	
<b>Service ID [hex]</b>	0x1e	
<b>Sync/Async</b>	Asynchronous	
<b>Reentrancy</b>	This function is generated individually for each sender. The individual function is not reentrant (if called from different runnable entities that belong to the same sender), but different functions can be called in parallel.	
<b>Parameters (in)</b>	IN	Data value to be sent over a communication identified by the <locId>. The parameter will be passed by value for primitive data elements and by reference for all other types. Example: Std_ReturnType locSend_RTE_25 (const uint32 UI_Value); Std_ReturnType locSend_RTE_42 (const TASKParams3 *pStr_Value);
	numberOfBytesIN	(optional) number of bytes to be send
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	Std_ReturnType	IOC_E_OK: The data has been passed successfully to the communication service. IOC_E_LIMIT: IOC internal communication buffer is full (Case: Receiver is slower than sender). This error produces an IOC_E_LOST_DATA Overlayed Error on the receiver side at the next data reception. IOC_E_LENGTH: The <numberOfBytesIN> exceeds either the internal buffer or is equal zero, so no data is send.
<b>Description</b>	Performs an "explicit" sender-receiver transmission of data elements with "event" semantic for a unidirectional 1:1 or N:1 communication between OS-Applications located on the same or on different cores. <locId> is a unique identifier that references a unidirectional 1:1 or N:1 communication. <SenderId> is used only in N:1 communication. Together with <locId>, it uniquely identifies the sender. It is separated from <locId> with an underscore. In case of 1:1 communication, it shall be omitted.	
<b>Available via</b>	loc.h	

]

## [SWS\_Os\_91003] Definition of API function locWrite\_<locId>[\_<SenderId>]

Upstream requirements: [SRS\\_Os\\_80020](#)

]

<b>Service Name</b>	locWrite_<locId>[_<SenderId>]	
<b>Syntax</b>	<pre>Std_ReturnType IocWrite_&lt;locId&gt;[_&lt;SenderId&gt;] (   &lt;Data&gt; IN,   [uint16 numberOfBytesIN] )</pre>	
<b>Service ID [hex]</b>	0x1f	
<b>Sync/Async</b>	Asynchronous	
<b>Reentrancy</b>	This function is generated individually for each sender. The individual function is not reentrant (if called from different runnable entities that belong to the same sender), but different functions can be called in parallel.	
<b>Parameters (in)</b>	IN	Data value to be sent over a communication identified by the <locId>. The parameter will be passed by value for primitive data elements and by reference for all other types. Example: Std_ReturnType locWrite_RTE_25 (const uint32 UI_Value); Std_ReturnType locWrite_RTE_42 (const TASKParams3 *pStr_Value);
	numberOfBytesIN	(optional) number of bytes to be send
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	Std_ReturnType	IOC_E_OK: The data has been passed successfully to the communication service. IOC_E_LENGTH: The <numberOfBytesIN> exceeds either the internal buffer or is equal zero, so no data is send.
<b>Description</b>	<p>Performs an "explicit" sender-receiver transmission of data elements with "data" semantic for a unidirectional 1:1 or N:1 communication between OS-Applications located on the same or on different cores.</p> <p>&lt;locId&gt; is a unique identifier that references a unidirectional 1:1 or N:1 communication.</p> <p>&lt;SenderId&gt; is used only in N:1 communication. Together with &lt;locId&gt;, it uniquely identifies the sender. It is separated from &lt;locId&gt; with an underscore. In case of 1:1 communication, it shall be omitted.</p> <p>&lt;numberOfBytesIN&gt; specifies the size of the data to be transmitted (in bytes).</p>	
<b>Available via</b>	loc.h	

]

## General:

### [SWS\_Os\_00719]

Upstream requirements: [SRS\\_Os\\_80020](#)

[[IocSend/IocWrite](#) is asynchronous in that way it shall not have to wait for the reception of the data on the receiving side to return from execution.]

### [SWS\_Os\_00720]

Upstream requirements: [SRS\\_Os\\_80020](#)

[The [IocSend/IocWrite](#) function shall not return until the data given in parameter have been completely physically sent over the communication medium.

For example in case of communication over shared RAM, an [IocSend/IocWrite](#) shall return when all data have been copied in the target shared RAM.]

**[SWS\_Os\_00721]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

「In case of "event" (queued) semantic, the [IocSend](#) function shall guarantee the order of delivery. In case of senders from different cores, the order in which messages are received will be determined by the implementation.」

**[SWS\_Os\_00722]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

「The [IocSend/IocWrite](#) function shall support mechanism to guarantee data-Integrity during transmission.

The [IocSend/IocWrite](#) function shall solve the crossing of the protection boundaries of OS-Applications. It has to be generated in case of intra-core and inter-core communication.」

**[SWS\_Os\_00820]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

「The [IocSend/IocWrite](#) resp. [IocSendGroup/IocWriteGroup](#) function shall be wrapped with the memory allocation keywords mechanism

```
1  #define OS_START_SEC_<sadm>
2  #include "Os_MemMap.h"
3
4
5  <IocSend, IocSendGroup, IocWrite, IocWriteGroup >
6
7  #define OS_STOP_SEC_<sadm>
8  #include "Os_MemMap.h"
```

where [<sadm>](#) is the [shortName](#) of the [SwAddrMethod](#) referenced by the [OsMemoryMappingCodeLocationRef](#) of the sending [OsApplication](#) configured in [OsIoc-SendingOsApplicationRef](#) of the respective [OsIocCommunication](#) channel.

」

**Parameters:****[SWS\_Os\_00723]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

「The IN <Data> parameter of the [IocSend/IocWrite](#) function shall be passed by value for primitive data types, as an pointer to the array base type for arrays and by reference for all other types.」

**[SWS\_Os\_00724]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

「For data passed as an pointer to the array base type or by reference, the [IocSend/IocWrite](#) function shall guarantee upon return that the parameter is safe for re-use.」

**Returned values:****[SWS\_Os\_00725]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔The `IocSend/IocWrite` function shall return `IOC_E_OK` if the data was passed successfully to the communication service.〕

**[SWS\_Os\_00726]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔In case of "event" semantic the `IocSend` function shall return `IOC_E_LIMIT` if an IOC internal transmission buffer became full (Case: Receiver is slower than sender or/ and configured internal IOC buffer size is too small).〕

If this error occurs the IOC internal buffer could not be filled with the parameter. In that case this error shall produce an `IOC_E_LOST_DATA` Overlayed Error on the receiver side at the next data reception (s. [SWS\\_Os\\_00745](#)).〕

**Internal structures:****[SWS\_Os\_00727]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔In case of "event" semantic the IOC shall configure its internal transmission buffer size with the value of the attribute `OsIocBufferLength`.〕

### 8.5.4.3 `IocSendGroup/IocWriteGroup`

The `IocWriteGroup` API call is generated for "data" (unqueued) semantics and the `IocSendGroup` API call is generated for "event" (queued) semantics.

**[SWS\_Os\_00728] Definition of API function `IocSendGroup_<locId>`**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔

<b>Service Name</b>	<code>IocSendGroup_&lt;locId&gt;</code>
<b>Syntax</b>	<pre>Std_ReturnType IocSendGroup_&lt;locId&gt; (   &lt;Data1&gt; IN1,   [uint16 numberOfBytesIN1],   &lt;Data2&gt; IN2,   [uint16 numberOfBytesIN2],   ... )</pre>
<b>Service ID [hex]</b>	0x20
<b>Sync/Async</b>	Asynchronous





<b>Reentrancy</b>	This function is generated individually for each sender. The individual function is not reentrant (if called from different runnable entities that belong to the same sender), but different functions can be called in parallel.	
<b>Parameters (in)</b>	IN1	List of parameters with data values to be sent over a communication identified by the <locl>. The parameters will be passed by value for simple data elements and by reference for all other types. Example: Std_ReturnType locSendGroup_RTE_G1 (const uint32 UI_Value1, const uint16 Value2, const uint8 Value3, const uint16 Value4);
	numberOfBytesIN1	(optional) number of bytes for parameter IN1 to be send.
	IN2	—
	numberOfBytesIN2	—
		—
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	Std_ReturnType	IOC_E_OK: The data has been passed successfully to the communication service. IOC_E_LIMIT: IOC internal communication buffer is full (Case: Receiver is slower than sender). This error produces an IOC_E_LOST_DATA Overlayed Error on the receiver side at the next data reception. IOC_E_LENGTH: At least one of the <numberOfBytesIN<x>> exceeds either the internal buffer or is equal zero, so no data is send.
<b>Description</b>	Performs an "explicit" sender-receiver transmission of data elements with "event" semantic for a unidirectional 1:1 communication between OS-Applications located on the same or on different cores. This API involves a group of data elements which values are specified in parameter. <locl> is a unique identifier that references a unidirectional 1:1 communication involving many data elements. The optional parameter <numberOfBytesIN<x>> specifies the size of the data to be transmitted (in bytes) for parameter <IN<x>>.	
<b>Available via</b>	loc.h	



## [SWS\_Os\_91004] Definition of API function locWriteGroup\_<locl>

Upstream requirements: [SRS\\_Os\\_80020](#)

<b>Service Name</b>	locWriteGroup_<locl>
<b>Syntax</b>	Std_ReturnType locWriteGroup_<locl> ( <Data1> IN1, [uint16 numberOfBytesIN1], <Data2> IN2, [uint16 numberOfBytesIN2], ... )
<b>Service ID [hex]</b>	0x21
<b>Sync/Async</b>	Asynchronous





<b>Reentrancy</b>	This function is generated individually for each sender. The individual function is not reentrant (if called from different runnable entities that belong to the same sender), but different functions can be called in parallel.	
<b>Parameters (in)</b>	IN1	List of parameters with data values to be sent over a communication identified by the <locId>. The parameters will be passed by value for simple data elements and by reference for all other types. Example: Std_ReturnType locWriteGroup_RTE_G1 (const uint32 UI_Value1, const uint16 Value2, const uint8 Value3, const uint16 Value4);
	numberOfBytesIN1	(optional) number of bytes for parameter IN1 to be send.
	IN2	—
	numberOfBytesIN2	—
		—
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	Std_ReturnType	IOC_E_OK: The data has been passed successfully to the communication service. IOC_E_LENGTH: At least one of the <numberOfBytesIN<x>> exceeds either the internal buffer or is equal zero, so no data is sent.
<b>Description</b>	Performs an "explicit" sender-receiver transmission of data elements with "data" semantic for a unidirectional 1:1 communication between OS-Applications located on the same or on different cores. This API involves a group of data elements which values are specified in parameter. <locId> is a unique identifier that references a unidirectional 1:1 communication involving many data elements. The optional parameter <numberOfBytesIN<x>> specifies the size of the data to be transmitted (in bytes) for parameter <IN<x>>.	
<b>Available via</b>	loc.h	

]

## General:

### [SWS\_Os\_00729]

*Upstream requirements: SRS\_Os\_80020*

〔The [IocSendGroup/IocWriteGroup](#) is asynchronous in that way it shall not have to wait for the reception of the data on the receiving side to return from execution.〕

### [SWS\_Os\_00730]

*Upstream requirements: SRS\_Os\_80020*

〔The [IocSendGroup/IocWriteGroup](#) function shall not return until the data given in parameter have been completely physically sent over the communication medium. For example in case of communication over shared RAM, an [IocSendGroup/IocWriteGroup](#) shall return when all data have been copied in the target shared RAM.〕

**[SWS\_Os\_00731]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔In case of "event" semantic, the [IocSendGroup](#) function shall guarantee the order of delivery.〕

**[SWS\_Os\_00732]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔The [IocSendGroup/IocWriteGroup](#) function shall support mechanisms to guarantee data-Integrity during transmission.〕

The [IocSendGroup/IocWriteGroup](#) function shall solve the crossing of the protection boundaries of OS-Applications. It has to be generated in case of intra-core and inter-core communication.〕

**Parameters:****[SWS\_Os\_00733]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔The IN <DataN> parameters of the [IocSendGroup/IocWriteGroup](#) function shall be passed by values for primitive data types, as pointer to the array base type for arrays and by references for all other types.〕

**[SWS\_Os\_00734]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔For data passed as an pointer to the array base type or by reference, the [IocSendGroup/IocWriteGroup](#) function shall guarantee upon return that the parameter is safe for re-use.〕

**Returned values:****[SWS\_Os\_00735]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔The [IocSendGroup/IocWriteGroup](#) function shall return [IOC\\_E\\_OK](#) if the data was passed successfully to the communication service.〕

**[SWS\_Os\_00736]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔In case of "event" semantic the [IocSendGroup](#) function shall return [IOC\\_E\\_LIMIT](#) if an IOC internal transmission buffer got full (Case: Receiver is slower than sender or/ and configured internal IOC buffer size is too small).〕

If this error occurs the IOC Internal buffer could not be filled with the parameter. In that case this error produces an [IOC\\_E\\_LOST\\_DATA](#) Overlayed Error on the receiver side at the next data reception.〕

## Internal structures:

### [SWS\_Os\_00737]

*Upstream requirements:* [SRS\\_Os\\_80020](#)

「In case of "event" semantic the IOC shall configure its internal transmission buffer size with the value of the attribute [OsIocBufferLength](#).」

#### 8.5.4.4 [IocReceive/IocRead](#)

The [IocRead](#) API call is generated for "data" and the [IocReceive](#) API call is generated for "events".

### [SWS\_Os\_00738] Definition of API function [IocReceive\\_<locId>](#)

*Upstream requirements:* [SRS\\_Os\\_80020](#)

「

<b>Service Name</b>	IocReceive_<locId>	
<b>Syntax</b>	<pre>Std_ReturnType IocReceive_&lt;locId&gt; (   &lt;Data&gt; OUT,   [uint16* numberOfBytesOUT] )</pre>	
<b>Service ID [hex]</b>	0x22	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	This function is generated individually for each receiver. The individual function is not reentrant (if called from different runnable entities that belong to the same receiver), but different functions can be called in parallel.	
<b>Parameters (in)</b>	None	
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	OUT	Data reference to be filled with the received data element.
	numberOfBytesOUT	(optional) data reference to be filled with the length of the received data element in bytes.
<b>Return value</b>	Std_ReturnType	<p><a href="#">IOC_E_OK</a>: Data was received successfully</p> <p><a href="#">IOC_E_NO_DATA</a>: No data is available for reception.</p> <p><a href="#">IOC_E_LOST_DATA</a>: This Overlayed Error indicates that the IOC communication service refused an IOCSend request from sender due to an internal buffer overflow. There is no error in the data returned in parameter.</p>
<b>Description</b>	Performs an "explicit" sender-receiver reception of data elements with "event" semantic for a unidirectional communication between OS-Applications located on the same or on different cores.. <locId> is a unique identifier that references a unidirectional 1:1 or N:1 communication.	
<b>Available via</b>	loc.h	

」

## [SWS\_Os\_91005] Definition of API function `locRead_<locId>[_<ReceiverId>]`

*Upstream requirements:* [SRS\\_Os\\_80020](#)

]

<b>Service Name</b>	locRead_<locId>[_<ReceiverId>]	
<b>Syntax</b>	<pre>Std_ReturnType IocRead_&lt;locId&gt;[_&lt;ReceiverId&gt;] (   &lt;Data&gt; OUT,   [uint16* numberOfBytesOUT] )</pre>	
<b>Service ID [hex]</b>	0x23	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Non Reentrant This function is generated individually for each receiver. The individual function is not reentrant (if called from different runnable entities that belong to the same receiver), but different functions can be called in parallel.	
<b>Parameters (in)</b>	None	
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	OUT	Data reference to be filled with the received data element.
	numberOfBytesOUT	(optional) data reference to be filled with the length of the received data element in bytes.
<b>Return value</b>	Std_ReturnType	<code>IOC_E_OK</code> : Data was received successfully
<b>Description</b>	<p>Performs an "explicit" sender-receiver reception of data elements with "data" semantic for a unidirectional communication between OS-Applications located on the same or on different cores.</p> <p><code>&lt;locId&gt;</code> is a unique identifier that references a unidirectional 1:1 or N:1 communication.</p> <p><code>&lt;ReceiverId&gt;</code> is used only in N:M communication. Together with <code>&lt;locId&gt;</code>, it uniquely identifies the receiver. It is separated from <code>&lt;locId&gt;</code> with an underscore. If communication is different from N:M it shall be omitted.</p>	
<b>Available via</b>	loc.h	

]

## General:

### [SWS\_Os\_00739]

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔A successful call to the `IocReceive/IocRead` function indicates that data has been received successfully in the OUT `<Data>` given in parameter.

The `IocReceive/IocRead` function has to be generated in case of intra-core and inter-core communication.〕

### [SWS\_Os\_00822]

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔The `IocReceive/IocRead` resp. `IocReceiveGroup/IocReadGroup` function shall be wrapped with the memory allocation keywords mechanism

```

1  #define OS_START_SEC_<sadm>
2  #include "Os_MemMap.h"
3
4  <IocReceive, IocReceiveGroup , IocRead, IocReadGroup>
5
6  #define OS_STOP_SEC_<sadm>

```

```
7 #include "Os_MemMap.h"
```

where <sadm> is the shortName of the SwAddrMethod referenced by the [OsMemoryMappingCodeLocationRef](#) of the reading OsApplication configured in [OsIocReceivingOsApplicationRef](#) of the respective [OsIocCommunication](#) channel.c()

]

### [SWS\_Os\_00740]

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔If the [OsIocReceiverPullCB](#) attribute is defined with a callback function name, the IOC shall call this function on the receiving core for each data transmission.〕

#### Parameters:

### [SWS\_Os\_00741]

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔In case of "data" semantic the [IocRead](#) function shall always be able to deliver the last available datum. In case of senders from different cores, the precision of the order might be limited by the hardware and implementation.〕

### [SWS\_Os\_00742]

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔The [IocReceive/IocRead](#) function shall guarantee upon returning from execution that the reference given in parameter is safe for use.〕

### [SWS\_Os\_00803]

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔The OUT <Data> parameter of the [IocReceive/IocRead](#) function shall be passed as an pointer to the array base type for arrays and by reference for all other types.〕

#### Returned values:

### [SWS\_Os\_00743]

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔The [IocReceive/IocRead](#) function shall return [IOC\\_E\\_OK](#) if the data was received successfully in the OUT <Data> parameter.〕

### [SWS\_Os\_00744]

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔In case of "event" semantic and if no data is available the function [IocReceive](#) shall return [IOC\\_E\\_NO\\_DATA](#).〕

**[SWS\_Os\_00745]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

「In case of "event" semantic an `IOC_E_LOST_DATA` Overlaid Error shall be returned by the `IocReceive` function if the IOC communication service refused an `IocSend` request from sender due to an internal buffer overflow. There is no error in the data returned in parameter.」

#### 8.5.4.5 `IocReceiveGroup/IocReadGroup`

The `IocReadGroup` API call is generated for "data" and the `IocReceiveGroup` API call is generated for "events".

**[SWS\_Os\_00746] Definition of API function `IocReceiveGroup_<locId>`**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

「

<b>Service Name</b>	locReceiveGroup_<locId>	
<b>Syntax</b>	<pre>Std_ReturnType IocReceiveGroup_&lt;locId&gt; (     &lt;Data1&gt; OUT1,     [uint16* numberOfBytesOUT1],     &lt;Data2&gt; OUT2,     [uint16* numberOfBytesOUT2],     ... )</pre>	
<b>Service ID [hex]</b>	0x24	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	This function is generated individually for each receiver. The individual function is not reentrant (if called from different runnable entities that belong to the same receiver), but different functions can be called in parallel.	
<b>Parameters (in)</b>	None	
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	OUT1 ... OUT2 ... ...	List of data references to be filled with the received data elements. The specified order of the parameter shall match to the specified order in the corresponding send function. (optional) data reference to be filled with the length of the received data element (OUT1) in bytes. – – –
<b>Return value</b>	Std_ReturnType	<code>IOC_E_OK</code> : Data was received successfully. <code>IOC_E_NO_DATA</code> : No data is available for reception. <code>IOC_E_LOST_DATA</code> : This Overlaid Error indicates that the IOC communication service refused an IOCSend request from sender due to an internal buffer overflow. There is no error in the data returned in parameter.





<b>Description</b>	Performs an "explicit" sender-receiver transmission of data elements with "event" semantic for a unidirectional 1:1 communication between OS-Applications located on the same or on different cores. This API involves a group of data elements which values are specified in parameter. <locId> is a unique identifier that references a unidirectional 1:1 communication involving many data elements.
<b>Available via</b>	loc.h

]

## [SWS\_Os\_91006] Definition of API function locReadGroup\_<locId>

*Upstream requirements:* [SRS\\_Os\\_80020](#)

[

<b>Service Name</b>	locReadGroup_<locId>	
<b>Syntax</b>	<pre>Std_ReturnType IocReadGroup_&lt;locId&gt; (     &lt;Data1&gt; OUT1,     [uint16* numberOfBytesOUT1],     &lt;Data2&gt; OUT2,     [uint16* numberOfBytesOUT2],     ... )</pre>	
<b>Service ID [hex]</b>	0x25	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	This function is generated individually for each receiver. The individual function is not reentrant (if called from different runnable entities that belong to the same receiver), but different functions can be called in parallel.	
<b>Parameters (in)</b>	None	
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	OUT1	List of data references to be filled with the received data elements. The specified order of the parameter shall match to the specified order in the corresponding send function.
	numberOfBytesOUT1	(optional) data reference to be filled with the length of the received data element (OUT1) in bytes.
	OUT2	—
	numberOfBytesOUT2	—
		—
<b>Return value</b>	Std_ReturnType	IOC_E_OK: Data was received successfully
<b>Description</b>	Performs an "explicit" sender-receiver transmission of data elements with a "data" semantic for a unidirectional 1:1 communication between OS-Applications located on the same or on different cores. This API involves a group of data elements which values are specified in parameter. <locId> is a unique identifier that references a unidirectional 1:1 communication involving many data elements.	
<b>Available via</b>	loc.h	

]

## General:

**[SWS\_Os\_00747]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔A successful call to the `IocReceiveGroup/IocReadGroup` function indicates that data has been received successfully in the given parameters.〕

The `IocReceiveGroup/IocReadGroup` function has to be generated in case of intra-core and inter-core communication.]

**[SWS\_Os\_00748]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔If the `OsIocReceiverPullCB` attribute is defined with a callback function name, the IOC shall call this function on the receiving core for each data transmission.〕

**Parameters:****[SWS\_Os\_00749]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔In case of "data" semantic the `IocReadGroup` function shall always be able to deliver the last available datum.〕

**[SWS\_Os\_00750]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔The `IocReceiveGroup/IocReadGroup` function shall guarantee upon returning from execution that the references given in parameters are safe for use.〕

**[SWS\_Os\_00804]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔The OUT <DataN> parameters of the `IocReceiveGroup/ IocReadGroup` function shall be passed as pointer to the array base type for arrays and by references for all other types.〕

**Returned values:****[SWS\_Os\_00751]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔The `IocReceiveGroup/IocReadGroup` function shall return `IOC_E_OK` if the data was received successfully in the list of references given in parameter.〕

**[SWS\_Os\_00752]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

〔In case of "event" semantic and if no data is available the function `IocReceiveGroup` shall return `IOC_E_NO_DATA`.〕

**[SWS\_Os\_00753]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

「In case of "event" semantic an `IOC_E_LOST_DATA` Overlayed Error shall be returned by the `IocReceiveGroup` function if the IOC communication service refused an `IocSendGroup` request from sender due to an internal buffer overflow. There is no error in the data returned in parameter.」

#### 8.5.4.6 `IocEmptyQueue`

**[SWS\_Os\_00754] Definition of API function `IocEmptyQueue_<loclId>`**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

」

<b>Service Name</b>	IocEmptyQueue_<loclId>	
<b>Syntax</b>	Std_ReturnType IocEmptyQueue_<IocId> ( void )	
<b>Service ID [hex]</b>	0x26	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Non reentrant	
<b>Parameters (in)</b>	None	
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	Std_ReturnType	<code>IOC_E_OK</code> : Content of the queue was successfully deleted
<b>Description</b>	In case of queued communication identified by the <loclId> in the function name, the content of the IOC internal communication queue shall be deleted.	
<b>Available via</b>	loc.h	

」

**General:****[SWS\_Os\_00755]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

「The function `IocEmptyQueue_<loclId>` shall be present for all IOC elements with queued semantics.」

**[SWS\_Os\_00756]**

*Upstream requirements:* [SRS\\_Os\\_80020](#)

「The function `IocEmptyQueue_<loclId>` shall delete all contents from the associated data queue.」

「The `IocEmptyQueue` should be generated in a more efficient way than an iterative call to an `IocReceive` function.」

## 8.6 Expected Interfaces

In this chapter all interfaces required from other modules are listed.

### 8.6.1 Mandatory Interfaces

There are no mandatory interfaces for the IOC.

### 8.6.2 Optional Interfaces

The following table contains the optional interfaces which might be used by the Os and which are provided by other BSW modules.

#### [SWS\_Os\_91036] Definition of optional interfaces requested by module Os

API Function	Header File	Description
Gpt_DisableNotification	Gpt.h	Disables the interrupt notification for a channel (relevant in normal mode).
Gpt_EnableNotification	Gpt.h	Enables the interrupt notification for a channel (relevant in normal mode).
Gpt_GetTimeElapsed	Gpt.h	Returns the time already elapsed.
Gpt_StartTimer	Gpt.h	Starts a timer channel.
Gpt_StopTimer	Gpt.h	Stops a timer channel.

]

#### 8.6.2.1 ReceiverPullCB

#### [SWS\_Os\_00757] Definition of configurable interface <ReceiverPullCB>

*Upstream requirements: SRS\_Os\_80020*

[

Service Name	<ReceiverPullCB>
Syntax	void <ReceiverPullCB> ( void )
Sync/Async	Synchronous
Reentrancy	Reentrant
Parameters (in)	None
Parameters (inout)	None
Parameters (out)	None
Return value	None

▽



<b>Description</b>	This callback function can be configured for the receiver of a communication. If configured, IOC calls this callback on the receiving core for each data reception. <ReceiverPullCB> is the callback function name configured by the receiver in the OslocReceiverPullCB attribute to be called on data reception."
<b>Available via</b>	Os.h

]

**[SWS\_Os\_00758]***Upstream requirements: [SRS\\_Os\\_80020](#)*

〔The <ReceiverPullCB> function name shall be defined within a configuration file for each IOC communication in the [OsIocReceiverPullCB](#) attribute.〕

**[SWS\_Os\_00759]***Upstream requirements: [SRS\\_Os\\_80020](#)*

〔The name of the callback shall be unique over the micro controller. For this purpose the following example can be considered as orientation for the IOC user:

Example: Rte\_IocReceiveCB\_<IocId>〕

**[SWS\_Os\_00760]***Upstream requirements: [SRS\\_Os\\_80020](#)*

〔The <ReceiverPullCB> function on the receiver side is using the access rights of the receiving [OsApplication](#).〕

Note: This means that such a callback cannot be reused by another [OsApplication](#).

**[SWS\_Os\_00761]***Upstream requirements: [SRS\\_Os\\_80020](#)*

〔This notification mechanism shall be supported for both queued and unqueued communication semantic.〕

The owner of the <ReceiverPullCB> function shall pay attention that the execution time of the function shall not last too long. It shall be possible to call this function from an IOC-ISR.

## 8.7 Hook functions

Hook functions are called by the operating system if specific conditions are met. They are provided by the user. Besides the ProtectionHook below, the hooks from [\[10\]](#) and/ or extensions from [7.12](#) may be called by the OS.

### 8.7.1 ProtectionHook

#### [SWS\_Os\_00538] Definition of configurable interface ProtectionHook

*Upstream requirements: SRS\_Os\_11013*

]

<b>Service Name</b>	ProtectionHook	
<b>Syntax</b>	<code>ProtectionReturnType ProtectionHook (</code> <code>    StatusType Fatalerror</code> <code>)</code>	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	Fatalerror	The error which caused the call to the protection hook
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	ProtectionReturnType	<code>PRO_IGNORE</code> <code>PRO_TERMINATETASKISR</code> <code>PRO_TERMINATEAPPL</code> <code>PRO_SHUTDOWN</code> The return value defines the action the OS shall take after the protection hook.
<b>Description</b>	The protection hook is always called if a serious error occurs. E.g. exceeding the worst case execution time or violating against the memory protection.	
<b>Available via</b>	Os_Externals.h	

]

Depending on the return value the Operating System module will either:

- forcibly terminate the Task/Category 2 ISR which causes the problem OR
- forcibly terminate the OS-Application the Task/Category 2 ISR belong OR
- shutdown the system OR
- do nothing

(see 7.8.2)

#### [SWS\_Os\_00308]

*Upstream requirements: SRS\_Os\_11001*

]  
 If `ProtectionHook` returns an invalid value, the Operating System module shall take the same action as if no protection hook is configured.]

#### [SWS\_Os\_00542]

*Upstream requirements: SRS\_Os\_11016*

]  
 Availability of `ProtectionHook`: Available in Scalability Classes 2, 3 and 4.]

## 8.7.2 Application specific `StartupHook`

### [SWS\_Os\_00539] Definition of configurable interface `StartupHook_<App>`

*Upstream requirements:* [SRS\\_Os\\_00097](#)

]

<b>Service Name</b>	StartupHook_<App>
<b>Syntax</b>	<code>void StartupHook_&lt;App&gt; (</code> <code>void</code> <code>)</code>
<b>Sync/Async</b>	Synchronous
<b>Reentrancy</b>	Reentrant
<b>Parameters (in)</b>	None
<b>Parameters (inout)</b>	None
<b>Parameters (out)</b>	None
<b>Return value</b>	None
<b>Description</b>	The application specific startup hook is called during the start of the OS (after the user has started the OS via StartOS()).
<b>Available via</b>	Os_Externals.h

]

The application specific `StartupHook` is always called after the standard `StartupHook` (see [SWS\_Os\_00236]). If more than one OS-Application is configured which use startup hooks, the order of calls to the startup hooks of the different OS-Applications is not defined.

### [SWS\_Os\_00543]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔Availability of `StartupHook_<App>`: Available in Scalability Classes 3 and 4.]

## 8.7.3 Application specific `ErrorHook`

### [SWS\_Os\_00540] Definition of configurable interface `ErrorHook_<App>`

*Upstream requirements:* [SRS\\_Os\\_11001](#)

]

<b>Service Name</b>	ErrorHook_<App>	
<b>Syntax</b>	<code>void ErrorHook_&lt;App&gt; (</code> <code>StatusType Error</code> <code>)</code>	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	Error	The error which caused the call to the error hook
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	



△

<b>Return value</b>	None
<b>Description</b>	The application specific error hook is called whenever a Task or Category 2 ISR which belongs to the OS-Application causes an error.
<b>Available via</b>	Os_Externals.h

↴

If the general [ErrorHook](#) is configured, the general [ErrorHook](#) is called before the application specific error hook is called (see [[SWS\\_Os\\_00246](#)]).

#### [SWS\_Os\_00544]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔 Availability of [ErrorHook\\_<App>](#): Available in Scalability Classes 3 and 4. 〕

#### 8.7.4 Application specific [ShutdownHook](#)

##### [SWS\_Os\_00541] Definition of configurable interface [ShutdownHook\\_<App>](#)

*Upstream requirements:* [SRS\\_Os\\_00097](#)

〔

<b>Service Name</b>	ShutdownHook_<App>	
<b>Syntax</b>	<pre>void ShutdownHook_&lt;App&gt; (     StatusType Fatalerror )</pre>	
<b>Sync/Async</b>	Synchronous	
<b>Reentrancy</b>	Reentrant	
<b>Parameters (in)</b>	Fatalerror	The error which caused the action to shut down the operating system.
<b>Parameters (inout)</b>	None	
<b>Parameters (out)</b>	None	
<b>Return value</b>	None	
<b>Description</b>	The application specific shutdown hook is called whenever the system starts the shut down of itself.	
<b>Available via</b>	Os_Externals.h	

〕

If the general [ShutdownHook](#) is configured, the general [ShutdownHook](#) is called after all application specific shutdown hook(s) are called (see [[SWS\\_Os\\_00237](#)]). If more OS-Applications with an application specific shutdown hook exist the order of calls to these application specific shutdown hooks is not defined.

#### [SWS\_Os\_00545]

*Upstream requirements:* [SRS\\_Os\\_11016](#)

〔 Availability of [ShutdownHook\\_<App>](#): Available in Scalability Classes 3 and 4. 〕

## 8.8 Service Interfaces

The Os does not provide any service interfaces.

## 9 Sequence diagrams

### 9.1 Sequence chart for calling trusted functions




Figure 9.1: System Call sequence chart

The above sequence describes a call to the `CallITrustedFunction` service. It starts with a user who calls a service which requires itself a call to a trusted function. The service then packs the argument for the trusted function into a structure and calls `CallITrustedFunction` with the ID and the pointer as arguments. Afterwards the OS checks if the access to the requested service is valid. If no access is granted `E_OS_SERVICEID` is returned. Otherwise the trusted service itself is called and the function checks the arguments for access right, etc.

## 9.2 Sequence chart for usage of `ErrorHook`




Figure 9.2: Error Hook sequence chart

The above sequence chart shows the sequence of error hook calls in case a service does not return with `E_OK`. Note that in this case the general error hook and the OS-Application specific error hook are called.

### 9.3 Sequence chart for ProtectionHook




Figure 9.3: ProtectionHook sequence chart

The sequence shows the flow of control if a protection error occurs. Depending on the return values of the ProtectionHook, either the faulty Task/ISR is forcibly terminated or the OS-Application is forcibly terminated or the system is shut down.

## 9.4 Sequence chart for `StartupHook`




Figure 9.4: `StartupHook` sequence chart

The above sequence shows the flow of control during the startup of the OS. Like in OSEK OS the user calls the `StartOS` service to start the OS. During the startup the startup hooks are called in the above order. The rest of the startup sequence is identical to the defined behaviour of OSEK OS.

## 9.5 Sequence chart for `ShutdownHook`

The next sequence shows the behaviour in case of a shut down. The flow is the same as in OSEK OS with the exception that the shut down hooks of the OS-Applications are called before the general `ShutdownHook` is called. Note that the specific shutdown hooks of the application are not allowed to block, they must return to the caller.




Figure 9.5: **ShutdownHook** sequence chart

## 9.6 Sequence diagrams of Sender Receiver communication over the IOC

### 9.6.1 Last-is-best communication

The 9.6 shows a sequence of successful and failure cases in the interaction between the IOC and the RTE in case of last-is-best communication ("data" semantic).





Figure 9.6: IOC - Last-is-best communication

### 9.6.2 Queued communication without pull callback

The figure 9.7 shows the interaction between IOC and RTE with a focus on the congestion control for a queued communication.

The defined communication has no callback functionality for data reception, has an internal buffer size of 2 data elements, no waitpoints are defined and the implicated OS-Applications are located on different cores.



**Figure 9.7: IOC - Queued communication without callback**

### 9.6.3 Queued communication with pull callback

The figure 9.8 shows the interaction between IOC and RTE in case of a queued communication with an activated callback functionality. The RTE might handle notification internally and might therefore not provide any callback functions, but a similar scenario will occur in case of communication between CDDs on different cores. The receiving CDD will provide the callback function in this case.

The defined communication has no waitpoints and describes a communication implicating two OS-Applications located on different cores.




Figure 9.8: IOC Queued Communication with callback

## 10 Configuration specification

In general, this chapter defines configuration parameters and their clustering into containers. In order to support the specification Chapter 10.1 describes fundamentals. It also specifies a template (table) you shall use for the parameter specification. We intend to leave Chapter 10.1 in the specification to guarantee comprehension.

Chapter 10.2 specifies the structure (containers) and the parameters of the module Os.

Chapter 10.3 specifies the structure (containers) and the parameters of the loc.

Chapter 10.4 specifies the structure (containers) and the ARTI parameters for the Os and loc.

Chapter 10.5 specifies published information of the module Os.

### 10.1 How to read this chapter

For details refer to [4] Chapter 10.1 “*Introduction to configuration specification*”.

#### 10.1.1 Rules for parameters

Some configuration parameters are configured as floating point values and sometimes these values must be rounded in order to be used. The following rules define the rounding of specific parameters:

- Execution times (for the timing protection) are "round down"
- Timeframes are "round down"

### 10.2 Containers and configuration parameters

The following chapters summarize all configuration parameters and their containers. Background information about the detailed meaning of the parameters can be found in chapters 7 and 8.

For better readability OIL names of the 2.1 OS specification are given in curly braces in the namefield of configuration parameters.

#### [SWS\_Os\_00861]

*Upstream requirements:* [SRS\\_Os\\_11001](#)

[The used EcucPartitionId(s) which are assigned to an OS-Application shall be zero-based and consecutive. If this is not the case the consistency check shall issue an error.]

**[SWS\_Os\_00862]**

*Upstream requirements: SRS\_Os\_80011*

「The used EcucCoreId(s) which are assigned to an OS-Application shall be zero-based and consecutive. If this is not the case the consistency check shall issue an error.」

### 10.2.1 Os

**[ECUC\_Os\_00396] Definition of EcucModuleDef Os 「**

<b>Module Name</b>	Os
<b>Description</b>	Configuration of the Os (Operating System) module.
<b>Post-Build Variant Support</b>	false
<b>Supported Config Variants</b>	VARIANT-PRE-COMPIL

Included Containers		
Container Name	Multiplicity	Dependency
OsAlarm	0..*	An OsAlarm may be used to asynchronously inform or activate a specific task. It is possible to start alarms automatically at system start-up depending on the application mode.
OsAppMode	1..*	OsAppMode is the object used to define ISO 17356-3 properties for an ISO 17356-3 application mode. No standard attributes are defined for AppMode. In a CPU, at least one AppMode object has to be defined. [source: ISO 17356-6] An OsAppMode called OSDEFAULTAPPMODE must always be there for ISO 17356 compatibility.
OsApplication	0..*	An AUTOSAR OS must be capable of supporting a collection of OS objects (tasks, interrupts, alarms, hooks etc.) that form a cohesive functional unit. This collection of objects is termed an OS-Application. All objects which belong to the same OS-Application have access to each other. Access means to allow to use these objects within API services. Access by other applications can be granted separately.
OsCounter	0..*	Configuration information for the counters that belong to the Os Application.
OsEvent	0..*	Representation of OS events in the configuration context. Adopted from the ISO 17356-6 specification.
Osloc	0..1	Configuration of the IOC (Inter OS Application Communicator).
Oslsr	0..*	The Oslsr container represents an ISO 17356 interrupt service routine.
OsOS	1	OS is the object used to define ISO 17356-3 properties for an ISO 17356 application. Per CPU exactly one OS object has to be defined.
OsPeripheralArea	0..65534	Container to structure the configuration parameters of one peripheral area. The container short name can be used to access this area.
OsResource	0..*	An OsResource object is used to co-ordinate the concurrent access by tasks and ISRs to a shared resource, e.g. the scheduler, any program sequence, memory or any hardware area.



△

<b>Included Containers</b>		
<b>Container Name</b>	<b>Multiplicity</b>	<b>Dependency</b>
OsScheduleTable	0..*	An OsScheduleTable addresses the synchronization issue by providing an encapsulation of a statically defined set of alarms that cannot be modified at runtime.
OsSpinlock	0..*	An OsSpinlock object is used to co-ordinate concurrent access by TASKs/ISR2s on different cores to a shared resource.
OsTask	0..*	This container represents an ISO 17356 task.

J




Figure 10.1: Os configuration overview

### 10.2.2 OsAlarmSetEvent

#### [ECUC\_Os\_00016] Definition of EcucParamConfContainerDef OsAlarmSetEvent

<b>Container Name</b>	OsAlarmSetEvent		
<b>Parent Container</b>	<a href="#">OsAlarmAction</a>		
<b>Description</b>	This container specifies the parameters to set an event		
<b>Multiplicity</b>	0..1		
<b>Configuration Parameters</b>			

<b>Included Parameters</b>			
<b>Parameter Name</b>			
<a href="#">OsAlarmSetEventRef</a>	<b>Multiplicity</b>	<b>ECUC ID</b>	
<a href="#">OsAlarmSetEventTaskRef</a>	1	[ECUC_Os_00017]	
	1	[ECUC_Os_00018]	

<b>No Included Containers</b>
-------------------------------

]

### [ECUC\_Os\_00017] Definition of EcucReferenceDef OsAlarmSetEventRef [

<b>Parameter Name</b>	OsAlarmSetEventRef		
<b>Parent Container</b>	<a href="#">OsAlarmSetEvent</a>		
<b>Description</b>	Reference to the event that will be set by that alarm action		
<b>Multiplicity</b>	1		
<b>Type</b>	Reference to <a href="#">OsEvent</a>		
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
<b>Dependency</b>			

]

### [ECUC\_Os\_00018] Definition of EcucReferenceDef OsAlarmSetEventTaskRef [

<b>Parameter Name</b>	OsAlarmSetEventTaskRef		
<b>Parent Container</b>	<a href="#">OsAlarmSetEvent</a>		
<b>Description</b>	Reference to the task that will be activated by that event		
<b>Multiplicity</b>	1		
<b>Type</b>	Reference to <a href="#">OsTask</a>		
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
<b>Dependency</b>			

]

### 10.2.3 OsAlarm

### [ECUC\_Os\_00003] Definition of EcucParamConfContainerDef OsAlarm [

<b>Container Name</b>	OsAlarm		
<b>Parent Container</b>	<a href="#">Os</a>		
<b>Description</b>	An OsAlarm may be used to asynchronously inform or activate a specific task. It is possible to start alarms automatically at system start-up depending on the application mode.		
<b>Multiplicity</b>	0..*		
<b>Configuration Parameters</b>			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
<a href="#">OsAlarmAccessingApplication</a>	0..*	[ECUC_Os_00004]	
<a href="#">OsAlarmCounterRef</a>	1	[ECUC_Os_00005]	

Included Containers		
Container Name	Multiplicity	Dependency
<a href="#">OsAlarmAction</a>	1	This container defines which type of notification is used when the alarm expires.
<a href="#">OsAlarmAutostart</a>	0..1	If present this container defines if an alarm is started automatically at system start-up depending on the application mode.

]

### [ECUC\_Os\_00004] Definition of EcucReferenceDef OsAlarmAccessingApplication [

<b>Parameter Name</b>	OsAlarmAccessingApplication		
<b>Parent Container</b>	<a href="#">OsAlarm</a>		
<b>Description</b>	Reference to applications which have an access to this object.		
<b>Multiplicity</b>	0..*		
<b>Type</b>	Reference to <a href="#">OsApplication</a>		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

### [ECUC\_Os\_00005] Definition of EcucReferenceDef OsAlarmCounterRef [

<b>Parameter Name</b>	OsAlarmCounterRef		
<b>Parent Container</b>	<a href="#">OsAlarm</a>		
<b>Description</b>	Reference to the assigned counter for that alarm		
<b>Multiplicity</b>	1		
<b>Type</b>	Reference to <a href="#">OsCounter</a>		



<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			




Figure 10.2: OsAlarm configuration overview

### 10.2.4 OsAlarmAction

#### [ECUC\_Os\_00006] Definition of EcucChoiceContainerDef OsAlarmAction [

Choice Container Name	OsAlarmAction
Parent Container	<a href="#">OsAlarm</a>
Description	This container defines which type of notification is used when the alarm expires.
Multiplicity	1

#### No Included Parameters

Container Choices		
Container Name	Multiplicity	Dependency
<a href="#">OsAlarmActivateTask</a>	0..1	This container specifies the parameters to activate a task.
<a href="#">OsAlarmBudgetReplenish</a>	0..1	This container specifies the parameters to activate a task.
<a href="#">OsAlarmCallback</a>	0..1	This container specifies the parameters to call a callback OS alarm action.
<a href="#">OsAlarmIncrementCounter</a>	0..1	This container specifies the parameters to increment a counter.
<a href="#">OsAlarmSetEvent</a>	0..1	This container specifies the parameters to set an event

]

### 10.2.5 OsAlarmActivateTask

#### [ECUC\_Os\_00007] Definition of EcucParamConfContainerDef OsAlarmActivateTask [

Container Name	OsAlarmActivateTask
Parent Container	<a href="#">OsAlarmAction</a>
Description	This container specifies the parameters to activate a task.
Multiplicity	0..1
Configuration Parameters	

#### Included Parameters

Parameter Name	Multiplicity	ECUC ID
<a href="#">OsAlarmActivateTaskRef</a>	1	[ECUC_Os_00008]

#### No Included Containers

]

#### [ECUC\_Os\_00008] Definition of EcucReferenceDef OsAlarmActivateTaskRef [

Parameter Name	OsAlarmActivateTaskRef
Parent Container	<a href="#">OsAlarmActivateTask</a>
Description	Reference to the task that will be activated by that alarm action
Multiplicity	1



△

Type	Reference to <a href="#">OsTask</a>		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### [ECUC\_Os\_00412] Definition of EcucParamConfContainerDef OsAlarmBudgetReplenish

Container Name	OsAlarmBudgetReplenish		
Parent Container	<a href="#">OsAlarmAction</a>		
Description	This container specifies the parameters to activate a task.		
Multiplicity	0..1		
Post-Build Variant Multiplicity	false		
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
<a href="#">OsAlarmBudgetReplenishRef</a>	1	[ECUC_Os_00413]	

No Included Containers
------------------------

]

### [ECUC\_Os\_00413] Definition of EcucReferenceDef OsAlarmBudgetReplenishRef

Parameter Name	OsAlarmBudgetReplenishRef		
Parent Container	<a href="#">OsAlarmBudgetReplenish</a>		
Description	Reference to the task whose execution budget will be replenished by that alarm action. Note that the task must have OsTaskTimingProtectionDeferrableServer enabled.		
Multiplicity	1		
Type	Reference to <a href="#">OsTask</a>		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

## 10.2.6 OsAlarmAutostart

### [ECUC\_Os\_00009] Definition of EcucParamConfContainerDef OsAlarmAutostart

<b>Container Name</b>	OsAlarmAutostart	
<b>Parent Container</b>	<a href="#">OsAlarm</a>	
<b>Description</b>	If present this container defines if an alarm is started automatically at system start-up depending on the application mode.	
<b>Multiplicity</b>	0..1	
<b>Configuration Parameters</b>		

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
<a href="#">OsAlarmAlarmTime</a>	1	[ECUC_Os_00010]
<a href="#">OsAlarmAutostartType</a>	1	[ECUC_Os_00011]
<a href="#">OsAlarmCycleTime</a>	1	[ECUC_Os_00012]
<a href="#">OsAlarmAppModeRef</a>	1..*	[ECUC_Os_00013]

No Included Containers
------------------------

]

### [ECUC\_Os\_00010] Definition of EcucIntegerParamDef OsAlarmAlarmTime [

<b>Parameter Name</b>	OsAlarmAlarmTime		
<b>Parent Container</b>	<a href="#">OsAlarmAutostart</a>		
<b>Description</b>	The relative or absolute tick value when the alarm expires for the first time. Note that for an alarm which is RELATIVE the value must be at bigger than 0.		
<b>Multiplicity</b>	1		
<b>Type</b>	EcucIntegerParamDef		
<b>Range</b>	0 .. 18446744073709551615		
<b>Default value</b>	–		
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	–	
	<b>Post-build time</b>	–	
<b>Dependency</b>			

]

### [ECUC\_Os\_00011] Definition of EcucEnumerationParamDef OsAlarmAutostartType [

<b>Parameter Name</b>	OsAlarmAutostartType		
<b>Parent Container</b>	<a href="#">OsAlarmAutostart</a>		
<b>Description</b>	This specifies the type of autostart for the alarm..		
<b>Multiplicity</b>	1		
<b>Type</b>	EcucEnumerationParamDef		
<b>Range</b>	ABSOLUTE	The alarm is started on startup via SetAbsAlarm().	
	RELATIVE	The alarm is started on startup via SetRelAlarm().	
<b>Post-Build Variant Value</b>	false		



△

Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### [ECUC\_Os\_00012] Definition of EcucIntegerParamDef OsAlarmCycleTime [

Parameter Name	OsAlarmCycleTime		
Parent Container	OsAlarmAutostart		
Description	Cycle time of a cyclic alarm in ticks. If the value is 0 than the alarm is not cyclic.		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	0 .. 18446744073709551615		
Default value	—		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### [ECUC\_Os\_00013] Definition of EcucReferenceDef OsAlarmAppModeRef [

Parameter Name	OsAlarmAppModeRef		
Parent Container	OsAlarmAutostart		
Description	Reference to the application modes for which the AUTOSTART shall be performed		
Multiplicity	1..*		
Type	Reference to <a href="#">OsAppMode</a>		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### 10.2.7 OsAlarmCallback

#### [ECUC\_Os\_00014] Definition of EcucParamConfContainerDef OsAlarmCallback

[

<b>Container Name</b>	OsAlarmCallback		
<b>Parent Container</b>	<a href="#">OsAlarmAction</a>		
<b>Description</b>	This container specifies the parameters to call a callback OS alarm action.		
<b>Multiplicity</b>	0..1		
<b>Configuration Parameters</b>			

<b>Included Parameters</b>			
<b>Parameter Name</b>	<b>Multiplicity</b>	<b>ECUC ID</b>	
<a href="#">OsAlarmCallbackName</a>	1	<a href="#">[ECUC_Os_00087]</a>	
<a href="#">OsMemoryMappingCodeLocationRef</a>	0..1	<a href="#">[ECUC_Os_00409]</a>	

<b>No Included Containers</b>
-------------------------------

]

### [\[ECUC\\_Os\\_00087\]](#) Definition of EcucFunctionNameDef OsAlarmCallbackName

<b>Parameter Name</b>	OsAlarmCallbackName		
<b>Parent Container</b>	<a href="#">OsAlarmCallback</a>		
<b>Description</b>	Name of the function that is called when this alarm callback is triggered.		
<b>Multiplicity</b>	1		
<b>Type</b>	EcucFunctionNameDef		
<b>Default value</b>	—		
<b>Regular Expression</b>	—		
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

### [\[ECUC\\_Os\\_00409\]](#) Definition of EcucForeignReferenceDef OsMemoryMappingCodeLocationRef

<b>Parameter Name</b>	OsMemoryMappingCodeLocationRef		
<b>Parent Container</b>	<a href="#">OsAlarmCallback</a>		
<b>Description</b>	Reference to the memory mapping containing details about the section where the code is placed.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Foreign reference to SW-ADDR-METHOD		
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

### 10.2.8 OsAlarmIncrementCounter

#### [ECUC\_Os\_00302] Definition of EcucParamConfContainerDef OsAlarmIncrementCounter [

Container Name	OsAlarmIncrementCounter	
Parent Container	<a href="#">OsAlarmAction</a>	
Description	This container specifies the parameters to increment a counter.	
Multiplicity	0..1	
Configuration Parameters		

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
<a href="#">OsAlarmIncrementCounterRef</a>	1	[ECUC_Os_00015]

No Included Containers
------------------------

]

#### [ECUC\_Os\_00015] Definition of EcucReferenceDef OsAlarmIncrementCounter Ref [

Parameter Name	OsAlarmIncrementCounterRef	
Parent Container	<a href="#">OsAlarmIncrementCounter</a>	
Description	Reference to the counter that will be incremented by that alarm action	
Multiplicity	1	
Type	Reference to <a href="#">OsCounter</a>	
Post-Build Variant Value	false	
Value Configuration Class	Pre-compile time	X
	Link time	-
	Post-build time	-
Dependency		

]

### 10.2.9 OsApplication

#### [ECUC\_Os\_00114] Definition of EcucParamConfContainerDef OsApplication [

Container Name	OsApplication	
Parent Container	<a href="#">Os</a>	
Description	An AUTOSAR OS must be capable of supporting a collection of OS objects (tasks, interrupts, alarms, hooks etc.) that form a cohesive functional unit. This collection of objects is termed an OS-Application. All objects which belong to the same OS-Application have access to each other. Access means to allow to use these objects within API services. Access by other applications can be granted separately.	
Multiplicity	0..*	
Configuration Parameters		

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
OsTrusted	1	[ECUC_Os_00115]
OsTrustedApplicationDelayTimingViolationCall	1	[ECUC_Os_00395]
OsTrustedApplicationWithProtection	1	[ECUC_Os_00394]
OsAppAlarmRef	0..*	[ECUC_Os_00231]
OsAppCounterRef	0..*	[ECUC_Os_00234]
OsAppEcucPartitionRef	1	[ECUC_Os_00392]
OsAppIsrRef	0..*	[ECUC_Os_00221]
OsAppScheduleTableRef	0..*	[ECUC_Os_00230]
OsAppTaskRef	0..*	[ECUC_Os_00116]
OsMemoryMappingCodeLocationRef	0..1	[ECUC_Os_00402]

Included Containers		
Container Name	Multiplicity	Dependency
OsApplicationHooks	1	Container to structure the OS-Application-specific hooks
OsApplicationTrustedFunction	0..*	Container to structure the configuration parameters of trusted functions

## [ECUC\_Os\_00115] Definition of EcucBooleanParamDef OsTrusted

Parameter Name	OsTrusted		
Parent Container	OsApplication		
Description	Parameter to specify if an OS-Application is trusted or not. true: OS-Application is trusted false: OS-Application is not trusted (default)		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	false		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency	Required for scalability class 3 and 4.		

## [ECUC\_Os\_00395] Definition of EcucBooleanParamDef OsTrustedApplicationDelayTimingViolationCall

Parameter Name	OsTrustedApplicationDelayTimingViolationCall		
Parent Container	OsApplication		
Description	Parameter to specify if a timing violation which occurs within an trusted OS-Application is raised immediately or if it is delayed until the current task returns to the calling OS-Application (return of CallTrustedFunction) true: violation / call to ProtectionHook() is delayed false: timing violation cause an immediate call to the ProtectionHook().		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	true		





<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

### [ECUC\_Os\_00394] Definition of EcucBooleanParamDef OsTrustedApplication WithProtection [

<b>Parameter Name</b>	OsTrustedApplicationWithProtection		
<b>Parent Container</b>	<a href="#">OsApplication</a>		
<b>Description</b>	Parameter to specify if a trusted OS-Application is executed with memory protection or not. true: OS-Application runs within a protected environment. This means that write access is limited. false: OS-Application has full write access (default)		
<b>Multiplicity</b>	1		
<b>Type</b>	<a href="#">EcucBooleanParamDef</a>		
<b>Default value</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

### [ECUC\_Os\_00231] Definition of EcucReferenceDef OsAppAlarmRef [

<b>Parameter Name</b>	OsAppAlarmRef		
<b>Parent Container</b>	<a href="#">OsApplication</a>		
<b>Description</b>	Specifies the OsAlarms that belong to the OsApplication.		
<b>Multiplicity</b>	0..*		
<b>Type</b>	Reference to <a href="#">OsAlarm</a>		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

**[ECUC\_Os\_00234] Definition of EcucReferenceDef OsAppCounterRef**

Parameter Name	OsAppCounterRef		
Parent Container	OsApplication		
Description	References the OsCounters that belong to the OsApplication.		
Multiplicity	0..*		
Type	Reference to OsCounter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

**[ECUC\_Os\_00392] Definition of EcucReferenceDef OsAppEcucPartitionRef**

Parameter Name	OsAppEcucPartitionRef		
Parent Container	OsApplication		
Description	Denotes which "EcucPartition" is implemented by this "OSApplication".		
Multiplicity	1		
Type	Reference to EcucPartition		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

**[ECUC\_Os\_00221] Definition of EcucReferenceDef OsApplsRef**

Parameter Name	OsApplsRef		
Parent Container	OsApplication		
Description	references which OsLsrs belong to the OsApplication		
Multiplicity	0..*		
Type	Reference to OsLsr		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	



△

	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### [ECUC\_Os\_00230] Definition of EcucReferenceDef OsAppScheduleTableRef [

Parameter Name	OsAppScheduleTableRef		
Parent Container	<a href="#">OsApplication</a>		
Description	References the OsScheduleTables that belong to the OsApplication.		
Multiplicity	0..*		
Type	Reference to <a href="#">OsScheduleTable</a>		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### [ECUC\_Os\_00116] Definition of EcucReferenceDef OsAppTaskRef [

Parameter Name	OsAppTaskRef		
Parent Container	<a href="#">OsApplication</a>		
Description	references which OsTasks belong to the OsApplication		
Multiplicity	0..*		
Type	Reference to <a href="#">OsTask</a>		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

**[ECUC\_Os\_00402] Definition of EcucForeignReferenceDef OsMemoryMappingCodeLocationRef**

<b>Parameter Name</b>	OsMemoryMappingCodeLocationRef		
<b>Parent Container</b>	<a href="#">OsApplication</a> , <a href="#">OsApplicationHooks</a> , <a href="#">OsHooks</a> , <a href="#">OsIsr</a> , <a href="#">OsTask</a>		
<b>Description</b>	Reference to the memory mapping containing details about the section where the code is placed.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Foreign reference to SW-ADDR-METHOD		
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]




Figure 10.3: OsApplication configuration overview

### 10.2.10 OsApplicationHooks

#### [ECUC\_Os\_00020] Definition of EcucParamConfContainerDef OsApplicationHooks [

Container Name	OsApplicationHooks		
Parent Container	<a href="#">OsApplication</a>		
Description	Container to structure the OS-Application-specific hooks		
Multiplicity	1		
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
<a href="#">OsAppErrorHook</a>	1	<a href="#">[ECUC_Os_00213]</a>	
<a href="#">OsAppShutdownHook</a>	1	<a href="#">[ECUC_Os_00125]</a>	
<a href="#">OsAppStartupHook</a>	1	<a href="#">[ECUC_Os_00124]</a>	
<a href="#">OsMemoryMappingCodeLocationRef</a>	0..1	<a href="#">[ECUC_Os_00402]</a>	

No Included Containers
------------------------

]

#### [ECUC\_Os\_00213] Definition of EcucBooleanParamDef OsAppErrorHook [

Parameter Name	OsAppErrorHook		
Parent Container	<a href="#">OsApplicationHooks</a>		
Description	Select the OS-Application error hook. true: Hook is called false: Hook is not called		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	—		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency	Required for scalability class 3 and 4.		

]

#### [ECUC\_Os\_00125] Definition of EcucBooleanParamDef OsAppShutdownHook [

Parameter Name	OsAppShutdownHook		
Parent Container	<a href="#">OsApplicationHooks</a>		
Description	Select the OS-Application specific shutdown hook for the OS-Application. true: Hook is called false: Hook is not called		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	—		
Post-Build Variant Value	false		



<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>	Required for scalability class 3 and 4.		

]

### [ECUC\_Os\_00124] Definition of EcucBooleanParamDef OsAppStartupHook

<b>Parameter Name</b>	OsAppStartupHook		
<b>Parent Container</b>	OsApplicationHooks		
<b>Description</b>	Select the OS-Application specific startup hook for the OS-Application. true: Hook is called false: Hook is not called		
<b>Multiplicity</b>	1		
<b>Type</b>	EcucBooleanParamDef		
<b>Default value</b>	—		
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>	Required for scalability class 3 and 4.		

]

For parameter table [ECUC\_Os\_00402] OsMemoryMappingCodeLocationRef, see definition below container OsApplication.




Figure 10.4: OsApplicationHooks configuration overview

### 10.2.11 OsApplicationTrustedFunction

#### [ECUC\_Os\_00021] Definition of EcucParamConfContainerDef OsApplication TrustedFunction

Container Name	OsApplicationTrustedFunction		
Parent Container	<a href="#">OsApplication</a>		
Description	Container to structure the configuration parameters of trusted functions		
Multiplicity	0..*		
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
<a href="#">OsTrustedFunctionName</a>	1	<a href="#">[ECUC_Os_00254]</a>	
<a href="#">OsMemoryMappingCodeLocationRef</a>	0..1	<a href="#">[ECUC_Os_00408]</a>	

No Included Containers
------------------------

]

#### [ECUC\_Os\_00254] Definition of EcucFunctionNameDef OsTrustedFunctionName

Parameter Name	OsTrustedFunctionName		
Parent Container	<a href="#">OsApplicationTrustedFunction</a>		
Description	Trusted function (as part of a trusted OS-Application) available to other OS-Applications. This also supersedes the ISO 17356-6 attribute TRUSTED in APPLICATION because the optionality of this parameter is describing that already.		
Multiplicity	1		
Type	EcucFunctionNameDef		
Default value	-		
Regular Expression	-		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	-	
	Post-build time	-	
Dependency	Required for scalability class 3 and 4 and in trusted OS-Applications.		

]

#### [ECUC\_Os\_00408] Definition of EcucForeignReferenceDef OsMemoryMapping CodeLocationRef

Parameter Name	OsMemoryMappingCodeLocationRef		
Parent Container	<a href="#">OsApplicationTrustedFunction</a>		
Description	Reference to the memory mapping containing details about the section where the code is placed.		
Multiplicity	0..1		
Type	Foreign reference to SW-ADDR-METHOD		



△			
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]




Figure 10.5: OsApplicationTrustedFunction configuration overview

## 10.2.12 OsAppMode

### [ECUC\_Os\_00022] Definition of EcucParamConfContainerDef OsAppMode [

<b>Container Name</b>	OsAppMode
<b>Parent Container</b>	Os
<b>Description</b>	OsAppMode is the object used to define ISO 17356-3 properties for an ISO 17356-3 application mode. No standard attributes are defined for AppMode. In a CPU, at least one AppMode object has to be defined. [source: ISO 17356-6] An OsAppMode called OSDEFAULTAPPMODE must always be there for ISO 17356 compatibility.
<b>Multiplicity</b>	1..*
<b>Configuration Parameters</b>	

No Included Parameters

No Included Containers

]

## 10.2.13 OsCounter

### [ECUC\_Os\_00026] Definition of EcucParamConfContainerDef OsCounter [

<b>Container Name</b>	OsCounter	
<b>Parent Container</b>	Os	
<b>Description</b>	Configuration information for the counters that belong to the OsApplication.	
<b>Multiplicity</b>	0..*	
<b>Configuration Parameters</b>		

<b>Included Parameters</b>		
<b>Parameter Name</b>	<b>Multiplicity</b>	<b>ECUC ID</b>
OsCounterMaxAllowedValue	1	[ECUC_Os_00027]
OsCounterMinCycle	1	[ECUC_Os_00028]
OsCounterTicksPerBase	1	[ECUC_Os_00029]
OsCounterType	1	[ECUC_Os_00255]
OsSecondsPerTick	0..1	[ECUC_Os_00030]
OsCounterAccessingApplication	0..*	[ECUC_Os_00031]

<b>Included Containers</b>		
<b>Container Name</b>	<b>Multiplicity</b>	<b>Dependency</b>
OsDriver	0..1	<p>This Container contains the information who will drive the counter. This configuration is only valid if the counter has Os CounterType set to HARDWARE.</p> <p>If the container does not exist (multiplicity=0) the timer is managed by the OS internally (OSINTERNAL).</p> <p>If the container exists the OS can use the GPT interface to manage the timer. The user have to supply the GPT channel.</p> <p>If the counter is driven by some other (external to the OS) source (like a TPU for example) this must be described as a vendor specific extension.</p>
OsTimeConstant	0..*	<p>Allows the user to define constants which can be e.g. used to compare time values with timer tick values.</p> <p>A time value will be converted to a timer tick value during generation and can later be accessed via the OsConstName.</p> <p>The conversion is done by rounding time values to the nearest fitting tick value.</p>

]

## [ECUC\_Os\_00027] Definition of EcucIntegerParamDef OsCounterMaxAllowedValue

<b>Parameter Name</b>	OsCounterMaxAllowedValue		
<b>Parent Container</b>	OsCounter		
<b>Description</b>	Maximum possible allowed value of the system counter in ticks.		
<b>Multiplicity</b>	1		
<b>Type</b>	EcucIntegerParamDef		
<b>Range</b>	1 .. 18446744073709551615		
<b>Default value</b>	–		
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	–	
	<b>Post-build time</b>	–	
<b>Dependency</b>			

### [ECUC\_Os\_00028] Definition of EcucIntegerParamDef OsCounterMinCycle [

Parameter Name	OsCounterMinCycle		
Parent Container	OsCounter		
Description	The MINCYCLE attribute specifies the minimum allowed number of counter ticks for a cyclic alarm linked to the counter.		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	1 .. 18446744073709551615		
Default value	–		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

]

### [ECUC\_Os\_00029] Definition of EcucIntegerParamDef OsCounterTicksPerBase [

Parameter Name	OsCounterTicksPerBase		
Parent Container	OsCounter		
Description	The TICKSPERBASE attribute specifies the number of ticks required to reach a counterspecific unit. The interpretation is implementation-specific.		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	1 .. 4294967295		
Default value	–		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

]

### [ECUC\_Os\_00255] Definition of EcucEnumerationParamDef OsCounterType [

Parameter Name	OsCounterType		
Parent Container	OsCounter		
Description	This parameter contains the natural type or unit of the counter.		
Multiplicity	1		
Type	EcucEnumerationParamDef		
Range	HARDWARE	This counter is driven by some hardware e.g. a hardware timer unit.	
	SOFTWARE	The counter is driven by some software which calls the IncrementCounter service.	
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	

▽

△

	Post-build time	—	
Dependency			

]

### [ECUC\_Os\_00030] Definition of EcucFloatParamDef OsSecondsPerTick [

Parameter Name	OsSecondsPerTick				
Parent Container	<a href="#">OsCounter</a>				
Description	Time of one counter tick in seconds.				
Multiplicity	0..1				
Type	EcucFloatParamDef				
Range	[0 .. INF]				
Default value	—				
Post-Build Variant Multiplicity	false				
Post-Build Variant Value	false				
Multiplicity Configuration Class	Pre-compile time	X	All Variants		
	Link time	—			
	Post-build time	—			
Value Configuration Class	Pre-compile time	X	All Variants		
	Link time	—			
	Post-build time	—			
Dependency					

]

### [ECUC\_Os\_00031] Definition of EcucReferenceDef OsCounterAccessingApplication [

Parameter Name	OsCounterAccessingApplication		
Parent Container	<a href="#">OsCounter</a>		
Description	Reference to applications which have an access to this object.		
Multiplicity	0..*		
Type	Reference to <a href="#">OsApplication</a>		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]




Figure 10.6: OsCounter configuration overview

### 10.2.14 OsEvent

#### [ECUC\_Os\_00033] Definition of EcucParamConfContainerDef OsEvent

Container Name	OsEvent		
Parent Container	Os		
Description	Representation of OS events in the configuration context. Adopted from the ISO 17356-6 specification.		
Multiplicity	0..*		
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
OsEventMask	0..1	[ECUC_Os_00034]	

No Included Containers
------------------------

### [ECUC\_Os\_00034] Definition of EcucIntegerParamDef OsEventMask [

Parameter Name	OsEventMask		
Parent Container	<a href="#">OsEvent</a>		
Description	If event mask would be set to AUTO in OIL, this parameter should be omitted here.		
Multiplicity	0..1		
Type	EcucIntegerParamDef		
Range	0 .. 18446744073709551615		
Default value	—		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### 10.2.15 OsDriver

### [ECUC\_Os\_00371] Definition of EcucParamConfContainerDef OsDriver [

Container Name	OsDriver		
Parent Container	<a href="#">OsCounter</a>		
Description	<p>This Container contains the information who will drive the counter. This configuration is only valid if the counter has OsCounterType set to HARDWARE.</p> <p>If the container does not exist (multiplicity=0) the timer is managed by the OS internally (OSINTERNAL).</p> <p>If the container exists the OS can use the GPT interface to manage the timer. The user have to supply the GPT channel.</p> <p>If the counter is driven by some other (external to the OS) source (like a TPU for example) this must be described as a vendor specific extension.</p>		
Multiplicity	0..1		
Configuration Parameters			

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
<a href="#">OsGptChannelRef</a>	0..1	[ECUC_Os_00032]

No Included Containers
------------------------

]

### [ECUC\_Os\_00032] Definition of EcucReferenceDef OsGptChannelRef [

Parameter Name	OsGptChannelRef		
Parent Container	<a href="#">OsDriver</a>		
Description	Reference to the GPT channel.		
Multiplicity	0..1		
Type	Symbolic name reference to GptChannelConfiguration		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### 10.2.16 OsHooks

### [ECUC\_Os\_00035] Definition of EcucParamConfContainerDef OsHooks [

Container Name	OsHooks		
Parent Container	<a href="#">OsOS</a>		
Description	Container to structure all hooks belonging to the OS		
Multiplicity	1		
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
<a href="#">OsErrorHook</a>	1	[ECUC_Os_00036]	
<a href="#">OsPostTaskHook</a>	1	[ECUC_Os_00037]	
<a href="#">OsPreTaskHook</a>	1	[ECUC_Os_00038]	
<a href="#">OsProtectionHook</a>	0..1	[ECUC_Os_00214]	
<a href="#">OsShutdownHook</a>	1	[ECUC_Os_00039]	
<a href="#">OsStartupHook</a>	1	[ECUC_Os_00040]	
<a href="#">OsMemoryMappingCodeLocationRef</a>	0..1	[ECUC_Os_00402]	

### No Included Containers

]

**[ECUC\_Os\_00036] Definition of EcucBooleanParamDef OsErrorHook [**

Parameter Name	OsErrorHook		
Parent Container	<a href="#">OsHooks</a>		
Description	Error hook as defined by ISO 17356 true: Hook is called false: Hook is not called		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	–		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

]

**[ECUC\_Os\_00037] Definition of EcucBooleanParamDef OsPostTaskHook [**

Parameter Name	OsPostTaskHook		
Parent Container	<a href="#">OsHooks</a>		
Description	Post-task hook as defined by ISO 17356 true: Hook is called false: Hook is not called		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	–		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

]

**[ECUC\_Os\_00038] Definition of EcucBooleanParamDef OsPreTaskHook [**

Parameter Name	OsPreTaskHook		
Parent Container	<a href="#">OsHooks</a>		
Description	Pre-task hook as defined by ISO 17356 true: Hook is called false: Hook is not called		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	–		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

]

**[ECUC\_Os\_00214] Definition of EcucBooleanParamDef OsProtectionHook** [ ]

Parameter Name	OsProtectionHook		
Parent Container	<a href="#">OsHooks</a>		
Description	Switch to enable/disable the call to the (user supplied) protection hook. true: Protection hook is called on protection error false: Protection hook is not called		
Multiplicity	0..1		
Type	EcucBooleanParamDef		
Default value	–		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency	Required for scalability class 2,3 and 4		


**[ECUC\_Os\_00039] Definition of EcucBooleanParamDef OsShutdownHook** [ ]

Parameter Name	OsShutdownHook		
Parent Container	<a href="#">OsHooks</a>		
Description	Shutdown hook as defined by ISO 17356 true: Hook is called false: Hook is not called		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	–		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

**[ECUC\_Os\_00040] Definition of EcucBooleanParamDef OsStartupHook** [ ]

Parameter Name	OsStartupHook		
Parent Container	<a href="#">OsHooks</a>		
Description	Startup hook as defined by ISO 17356 true: Hook is called false: Hook is not called		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	–		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	





For parameter table [ECUC\_Os\_00402] OsMemoryMappingCodeLocationRef, see definition below container OsApplication.




Figure 10.7: OsHooks configuration overview

### 10.2.17 OsIsr

#### [ECUC\_Os\_00041] Definition of EcucParamConfContainerDef OsIsr [

Container Name	OsIsr
Parent Container	Os
Description	The OsIsr container represents an ISO 17356 interrupt service routine.
Multiplicity	0..*
Configuration Parameters	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
OslsCategory	1	[ECUC_Os_00042]
OslsPeriod	0..1	[ECUC_Os_00403]
OslsResourceRef	0..*	[ECUC_Os_00043]
OsMemoryMappingCodeLocationRef	0..1	[ECUC_Os_00402]

Included Containers		
Container Name	Multiplicity	Dependency
OslsTimingProtection	0..1	This container contains all parameters which are related to timing protection If the container exists, the timing protection is used for this interrupt. If the container does not exist, the interrupt is not supervised regarding timing violations.

]

### [ECUC\_Os\_00042] Definition of EcucEnumerationParamDef OslsCategory [

Parameter Name	OslsCategory		
Parent Container	Osls		
Description	This attribute specifies the category of this ISR.		
Multiplicity	1		
Type	EcucEnumerationParamDef		
Range	CATEGORY_1	Interrupt is of category 1	
	CATEGORY_2	Interrupt is of category 2	
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### [ECUC\_Os\_00403] Definition of EcucFloatParamDef OslsPeriod [

Parameter Name	OslsPeriod				
Parent Container	Osls				
Description	This parameter specifies the period in seconds of this ISR in case of a cyclically triggered interrupt. If this parameter is not given the interrupt can be activated sporadically or cyclically with an unknown period value. This value is information, e.g. for time base calculations in the RTE in case Timing Events are mapped onto this Osls. Be aware, that this parameter is not supposed to be relevant for the OS! It's the responsibility of the integrator to ensure the activation of the ISR according the configured period. This information is given as part of the OS configuration to support configuration work flows using a fixed set of Osls.				
Multiplicity	0..1				
Type	EcucFloatParamDef				
Range	[-INF .. INF]				
Default value	—				
Post-Build Variant Multiplicity	false				





<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

### [ECUC\_Os\_00043] Definition of EcucReferenceDef OsIsrResourceRef [

<b>Parameter Name</b>	OsIsrResourceRef		
<b>Parent Container</b>	<a href="#">OsIsr</a>		
<b>Description</b>	This reference defines the resources accessed by this ISR.		
<b>Multiplicity</b>	0..*		
<b>Type</b>	Reference to <a href="#">OsResource</a>		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

For parameter table [ECUC\_Os\_00402] [OsMemoryMappingCodeLocationRef](#), see definition below container [OsApplication](#).




Figure 10.8: Oslr configuration overview

### 10.2.18 OslrResourceLock

**[ECUC\_Os\_00388] Definition of EcucParamConfContainerDef OslrResourceLock**

<b>Container Name</b>	OsIsrResourceLock	
<b>Parent Container</b>	<a href="#">OsIsrTimingProtection</a>	
<b>Description</b>	This container contains a list of times the interrupt uses resources.	
<b>Multiplicity</b>	0..*	
<b>Configuration Parameters</b>		

<b>Included Parameters</b>		
<b>Parameter Name</b>	<b>Multiplicity</b>	<b>ECUC ID</b>
<a href="#">OsIsrResourceLockBudget</a>	1	[ECUC_Os_00389]
<a href="#">OsIsrResourceLockResourceRef</a>	1	[ECUC_Os_00390]

<b>No Included Containers</b>
-------------------------------

]

### [ECUC\_Os\_00389] Definition of EcucFloatParamDef OsIsrResourceLockBudget

]

<b>Parameter Name</b>	OsIsrResourceLockBudget		
<b>Parent Container</b>	<a href="#">OsIsrResourceLock</a>		
<b>Description</b>	This parameter contains the maximum time the interrupt is allowed to hold the given resource (in seconds).		
<b>Multiplicity</b>	1		
<b>Type</b>	EcucFloatParamDef		
<b>Range</b>	[0 .. INF]		
<b>Default value</b>	–		
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	–	
	<b>Post-build time</b>	–	
<b>Dependency</b>	Required for scalability class 2 and 4		

]

### [ECUC\_Os\_00390] Definition of EcucReferenceDef OsIsrResourceLockResourceRef

]

<b>Parameter Name</b>	OsIsrResourceLockResourceRef		
<b>Parent Container</b>	<a href="#">OsIsrResourceLock</a>		
<b>Description</b>	Reference to the resource the locking time is depending on		
<b>Multiplicity</b>	1		
<b>Type</b>	Reference to <a href="#">OsResource</a>		
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	–	
	<b>Post-build time</b>	–	
<b>Dependency</b>	Required for scalability class 2 and 4		

### 10.2.19 OsIsrTimingProtection

#### [ECUC\_Os\_00326] Definition of EcucParamConfContainerDef OsIsrTimingProtection [

Container Name	OsIsrTimingProtection
Parent Container	<a href="#">OsIsr</a>
Description	This container contains all parameters which are related to timing protection If the container exists, the timing protection is used for this interrupt. If the container does not exist, the interrupt is not supervised regarding timing violations.
Multiplicity	0..1
Configuration Parameters	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
<a href="#">OsIsrAllInterruptLockBudget</a>	0..1	[ECUC_Os_00229]
<a href="#">OsIsrExecutionBudget</a>	0..1	[ECUC_Os_00222]
<a href="#">OsIsrOsInterruptLockBudget</a>	0..1	[ECUC_Os_00387]
<a href="#">OsIsrTimeFrame</a>	0..1	[ECUC_Os_00223]

Included Containers		
Container Name	Multiplicity	Dependency
<a href="#">OsIsrResourceLock</a>	0..*	This container contains a list of times the interrupt uses resources.

]

#### [ECUC\_Os\_00229] Definition of EcucFloatParamDef OsIsrAllInterruptLockBudget [

Parameter Name	OsIsrAllInterruptLockBudget		
Parent Container	<a href="#">OsIsrTimingProtection</a>		
Description	This parameter contains the maximum time for which the ISR is allowed to lock all interrupts (via SuspendAllInterrupts() or DisableAllInterrupts()) (in seconds).		
Multiplicity	0..1		
Type	EcucFloatParamDef		
Range	[0 .. INF]		
Default value	–		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency	Required for scalability class 2 and 4		

]

## [ECUC\_Os\_00222] Definition of EcucFloatParamDef OsIsrExecutionBudget

Parameter Name	OsIsrExecutionBudget		
Parent Container	<a href="#">OsIsrTimingProtection</a>		
Description	The parameter contains the maximum allowed execution time of the interrupt (in seconds).		
Multiplicity	0..1		
Type	EcucFloatParamDef		
Range	[0 .. INF]		
Default value	–		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency	Required for scalability class 2 and 4		

]

## [ECUC\_Os\_00387] Definition of EcucFloatParamDef OsIsrOsInterruptLockBudget

Parameter Name	OsIsrOsInterruptLockBudget		
Parent Container	<a href="#">OsIsrTimingProtection</a>		
Description	This parameter contains the maximum time for which the ISR is allowed to lock all Category 2 interrupts (via SuspendOSInterrupts()) (in seconds).		
Multiplicity	0..1		
Type	EcucFloatParamDef		
Range	[0 .. INF]		
Default value	–		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency	Required for scalability class 2 and 4		

]

### [ECUC\_Os\_00223] Definition of EcucFloatParamDef OsIsrTimeFrame [

Parameter Name	OsIsrTimeFrame				
Parent Container	<a href="#">OsIsrTimingProtection</a>				
Description	This parameter contains the minimum inter-arrival time between successive interrupts (in seconds).				
Multiplicity	0..1				
Type	EcucFloatParamDef				
Range	[0 .. INF]				
Default value	–				
Post-Build Variant Multiplicity	false				
Post-Build Variant Value	false				
Multiplicity Configuration Class	Pre-compile time	X	All Variants		
	Link time	–			
	Post-build time	–			
Value Configuration Class	Pre-compile time	X	All Variants		
	Link time	–			
	Post-build time	–			
Dependency	Required for scalability class 2 and 4				

]

### 10.2.20 OsOS

### [ECUC\_Os\_00044] Definition of EcucParamConfContainerDef OsOS [

Container Name	OsOS		
Parent Container	<a href="#">Os</a>		
Description	OS is the object used to define ISO 17356-3 properties for an ISO 17356 application. Per CPU exactly one OS object has to be defined.		
Multiplicity	1		
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
<a href="#">OsLockTrustedFunctionCall</a>	1	[ECUC_Os_00410]	
<a href="#">OsNumberOfCores</a>	0..1	[ECUC_Os_01019]	
<a href="#">OsScalabilityClass</a>	0..1	[ECUC_Os_00259]	
<a href="#">OsStackMonitoring</a>	1	[ECUC_Os_00307]	
<a href="#">OsStatus</a>	1	[ECUC_Os_00046]	
<a href="#">OsUseArti</a>	1	[ECUC_Os_00406]	
<a href="#">OsUseGetServiceId</a>	1	[ECUC_Os_00047]	
<a href="#">OsUseParameterAccess</a>	1	[ECUC_Os_00048]	
<a href="#">OsUseResScheduler</a>	1	[ECUC_Os_00049]	

Included Containers		
Container Name	Multiplicity	Dependency
<a href="#">OsHooks</a>	1	Container to structure all hooks belonging to the OS

]

## [ECUC\_Os\_00410] Definition of EcucBooleanParamDef OsLockTrustedFunctionCall [

Parameter Name	OsLockTrustedFunctionCall		
Parent Container	OsOS		
Description	The OsLockTrustedFunctionCall attribute defines whether the OS locks preemption while a trusted function call is ongoing.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	true		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

## [ECUC\_Os\_01019] Definition of EcucIntegerParamDef OsNumberOfCores [

Parameter Name	OsNumberOfCores				
Parent Container	OsOS				
Description	Maximum number of cores that are controlled by the OS. The OS uses the value internally. It depends on the ECU HW.				
Multiplicity	0..1				
Type	EcucIntegerParamDef				
Range	1 .. 65535				
Default value	—				
Post-Build Variant Multiplicity	false				
Post-Build Variant Value	false				
Multiplicity Configuration Class	Pre-compile time	X	All Variants		
	Link time	—			
	Post-build time	—			
Value Configuration Class	Pre-compile time	X	All Variants		
	Link time	—			
	Post-build time	—			
Dependency					

]

### [ECUC\_Os\_00259] Definition of EcucEnumerationParamDef OsScalabilityClass

Parameter Name	OsScalabilityClass		
Parent Container	OsOS		
Description	A scalability class for each System Object "OS" has to be selected. In order to customize the operating system to the needs of the user and to take full advantage of the processor features the operating system can be scaled according to the scalability classes. If the scalability class is omitted this translates to the OIL AUTO mechanism.		
Multiplicity	0..1		
Type	EcucEnumerationParamDef		
Range	SC1	–	
	SC2	–	
	SC3	–	
	SC4	–	
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

### [ECUC\_Os\_00307] Definition of EcucBooleanParamDef OsStackMonitoring

Parameter Name	OsStackMonitoring		
Parent Container	OsOS		
Description	Select stack monitoring of Tasks/Category 2 ISRs true: Stacks are monitored false: Stacks are not monitored		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	–		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

### [ECUC\_Os\_00046] Definition of EcucEnumerationParamDef OsStatus

Parameter Name	OsStatus		
Parent Container	OsOS		
Description	The Status attribute specifies whether a system with standard or extended status has to be used. Automatic assignment is not supported for this attribute.		
Multiplicity	1		
Type	EcucEnumerationParamDef		
Range	EXTENDED	–	
	STANDARD	–	
Post-Build Variant Value	false		





Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### [ECUC\_Os\_00406] Definition of EcucBooleanParamDef OsUseArti

Parameter Name	OsUseArti		
Parent Container	OsOS		
Description	The OsUseArti attribute defines whether the OS uses and calls ARTI hooks. This includes also the generation of related ARTI artifacts by the generator.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	—		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### [ECUC\_Os\_00047] Definition of EcucBooleanParamDef OsUseGetServiceId

Parameter Name	OsUseGetServiceId		
Parent Container	OsOS		
Description	As defined by ISO 17356		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	—		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### [ECUC\_Os\_00048] Definition of EcucBooleanParamDef OsUseParameterAccess

Parameter Name	OsUseParameterAccess		
Parent Container	OsOS		
Description	As defined by ISO 17356		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	—		



△

<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

### [ECUC\_Os\_00049] Definition of EcucBooleanParamDef OsUseResScheduler [

<b>Parameter Name</b>	OsUseResScheduler		
<b>Parent Container</b>	OsOS		
<b>Description</b>	The OsUseResScheduler attribute defines whether the resource RES_SCHEDULER is used within the application.		
<b>Multiplicity</b>	1		
<b>Type</b>	EcucBooleanParamDef		
<b>Default value</b>	true		
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]




Figure 10.9: OsOS configuration overview

### 10.2.21 OsPeripheralArea

[ECUC\_Os\_00397] Definition of EcucParamConfContainerDef OsPeripheralArea

<b>Container Name</b>	OsPeripheralArea		
<b>Parent Container</b>	<a href="#">Os</a>		
<b>Description</b>	Container to structure the configuration parameters of one peripheral area. The container short name can be used to access this area.		
<b>Multiplicity</b>	0..65534		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Configuration Parameters</b>			

<b>Included Parameters</b>
<b>Parameter Name</b>
<a href="#">OsPeripheralAreaEndAddress</a>
1
<a href="#">OsPeripheralAreaId</a>
1
<a href="#">OsPeripheralAreaStartAddress</a>
1
<a href="#">OsPeripheralAreaAccessingApplication</a>
0..*
<b>ECUC ID</b>
<a href="#">[ECUC_Os_00400]</a>
<a href="#">[ECUC_Os_00398]</a>
<a href="#">[ECUC_Os_00399]</a>
<a href="#">[ECUC_Os_00401]</a>

<b>No Included Containers</b>
-------------------------------

]

### [ECUC\_Os\_00400] Definition of EcucIntegerParamDef OsPeripheralAreaEndAddress [

<b>Parameter Name</b>	OsPeripheralAreaEndAddress		
<b>Parent Container</b>	<a href="#">OsPeripheralArea</a>		
<b>Description</b>	Last valid address of a peripheral area.		
<b>Multiplicity</b>	1		
<b>Type</b>	EcucIntegerParamDef		
<b>Range</b>	0 .. 18446744073709551615		
<b>Default value</b>	—		
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

### [ECUC\_Os\_00398] Definition of EcucIntegerParamDef OsPeripheralAreaId [

<b>Parameter Name</b>	OsPeripheralAreaId		
<b>Parent Container</b>	<a href="#">OsPeripheralArea</a>		
<b>Description</b>	Id of peripheral area.		
<b>Multiplicity</b>	1		
<b>Type</b>	EcucIntegerParamDef (Symbolic Name generated for this parameter)		
<b>Range</b>	0 .. 18446744073709551615		



△

Default value	—		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### [ECUC\_Os\_00399] Definition of EcucIntegerParamDef OsPeripheralAreaStartAddress

Parameter Name	OsPeripheralAreaStartAddress		
Parent Container	<a href="#">OsPeripheralArea</a>		
Description	First valid address of a peripheral area.		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	0 .. 1844674407309551615		
Default value	—		
Post-Build Variant Multiplicity	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### [ECUC\_Os\_00401] Definition of EcucReferenceDef OsPeripheralAreaAccessingApplication

Parameter Name	OsPeripheralAreaAccessingApplication		
Parent Container	<a href="#">OsPeripheralArea</a>		
Description	Reference to application which have access to this object.		
Multiplicity	0..*		
Type	Reference to <a href="#">OsApplication</a>		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Dependency			

]

## 10.2.22 OsResource

### [ECUC\_Os\_00252] Definition of EcucParamConfContainerDef OsResource

<b>Container Name</b>	OsResource
<b>Parent Container</b>	Os
<b>Description</b>	An OsResource object is used to co-ordinate the concurrent access by tasks and ISRs to a shared resource, e.g. the scheduler, any program sequence, memory or any hardware area.
<b>Multiplicity</b>	0..*
<b>Configuration Parameters</b>	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
OsResourceProperty	1	[ECUC_Os_00050]
OsResourceAccessingApplication	0..*	[ECUC_Os_00051]
OsResourceLinkedResourceRef	0..1	[ECUC_Os_00052]

No Included Containers
------------------------

]

### [ECUC\_Os\_00050] Definition of EcucEnumerationParamDef OsResourceProperty

<b>Parameter Name</b>	OsResourceProperty		
<b>Parent Container</b>	OsResource		
<b>Description</b>	This specifies the type of the resource.		
<b>Multiplicity</b>	1		
<b>Type</b>	EcucEnumerationParamDef		
<b>Range</b>	INTERNAL	The resource is an internal resource.	
	LINKED	The resource is a linked resource (a second name for an existing resource).	
	STANDARD	The resource is a standard resource.	
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
<b>Dependency</b>			

]

### [ECUC\_Os\_00051] Definition of EcucReferenceDef OsResourceAccessingApplication

<b>Parameter Name</b>	OsResourceAccessingApplication		
<b>Parent Container</b>	OsResource		
<b>Description</b>	Reference to applications which have an access to this object.		
<b>Multiplicity</b>	0..*		
<b>Type</b>	Reference to OsApplication		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	Pre-compile time	X	All Variants



△

	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

↴

### [ECUC\_Os\_00052] Definition of EcucReferenceDef OsResourceLinkedResourceRef

Parameter Name	OsResourceLinkedResourceRef		
Parent Container	OsResource		
Description	The link to the resource. Must be valid if OsResourceProperty is LINKED. If OsResourceProperty is not LINKED the value is ignored.		
Multiplicity	0..1		
Type	Reference to OsResource		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

↴




Figure 10.10: OsResource configuration overview

### 10.2.23 OsScheduleTable

#### [ECUC\_Os\_00141] Definition of EcucParamConfContainerDef OsScheduleTable

↴

Container Name	OsScheduleTable
Parent Container	Os
Description	An OsScheduleTable addresses the synchronization issue by providing an encapsulation of a statically defined set of alarms that cannot be modified at runtime.
Multiplicity	0..*
Configuration Parameters	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
OsScheduleTableDuration	1	[ECUC_Os_00053]
OsScheduleTableRepeating	1	[ECUC_Os_00144]
OsScheduleTableCounterRef	1	[ECUC_Os_00145]
OsSchTblAccessingApplication	0..*	[ECUC_Os_00054]

Included Containers		
Container Name	Multiplicity	Dependency
OsScheduleTableAutostart	0..1	This container specifies if and how the schedule table is started on startup of the Operating System. The options to start a schedule table correspond to the API calls to start schedule tables during runtime.
OsScheduleTableExpiryPoint	1..*	The point on a Schedule Table at which the OS activates tasks and/or sets events
OsScheduleTableSync	0..1	This container specifies the synchronization parameters of the schedule table.

↴

#### [ECUC\_Os\_00053] Definition of EcucIntegerParamDef OsScheduleTableDuration

↴

Parameter Name	OsScheduleTableDuration		
Parent Container	OsScheduleTable		
Description	This parameter defines the modulus of the schedule table (in ticks).		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	0 .. 18446744073709551615		
Default value	–		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

↴

**[ECUC\_Os\_00144] Definition of EcucBooleanParamDef OsScheduleTableRepeating**

Parameter Name	OsScheduleTableRepeating		
Parent Container	OsScheduleTable		
Description	true: first expiry point on the schedule table shall be processed at final expiry point delay ticks after the final expiry point is processed. false: the schedule table processing stops when the final expiry point is processed.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	–		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

]

**[ECUC\_Os\_00145] Definition of EcucReferenceDef OsScheduleTableCounterRef**

Parameter Name	OsScheduleTableCounterRef		
Parent Container	OsScheduleTable		
Description	This parameter contains a reference to the counter which drives the schedule table.		
Multiplicity	1		
Type	Reference to OsCounter		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

]

**[ECUC\_Os\_00054] Definition of EcucReferenceDef OsSchTblAccessingApplication**

Parameter Name	OsSchTblAccessingApplication		
Parent Container	OsScheduleTable		
Description	Reference to applications which have an access to this object.		
Multiplicity	0..*		
Type	Reference to OsApplication		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	



	Post-build time	-
Dependency		

]





Figure 10.11: OsScheduleTable configuration overview (part 1)



**Figure 10.12: OsScheduleTable configuration overview (part 2)**

### 10.2.24 OsScheduleTableAutostart

#### [ECUC\_Os\_00335] Definition of EcucParamConfContainerDef OsScheduleTableAutostart

Container Name	OsScheduleTableAutostart
Parent Container	<a href="#">OsScheduleTable</a>
Description	This container specifies if and how the schedule table is started on startup of the Operating System. The options to start a schedule table correspond to the API calls to start schedule tables during runtime.
Multiplicity	0..1
Configuration Parameters	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
<a href="#">OsScheduleTableAutostartType</a>	1	[ECUC_Os_00056]
<a href="#">OsScheduleTableStartValue</a>	0..1	[ECUC_Os_00057]
<a href="#">OsScheduleTableAppModeRef</a>	1..*	[ECUC_Os_00058]

No Included Containers

#### [ECUC\_Os\_00056] Definition of EcucEnumerationParamDef OsScheduleTableAutostartType

Parameter Name	OsScheduleTableAutostartType		
Parent Container	<a href="#">OsScheduleTableAutostart</a>		
Description	This specifies the type of the autostart for the schedule table.		
Multiplicity	1		
Type	EcucEnumerationParamDef		
Range	ABSOLUTE	The schedule table is started during startup with the StartScheduleTableAbs() service.	
	RELATIVE	The schedule table is started during startup with the StartScheduleTableRel() service.	
	SYNCHRON	The schedule table is started during startup with the StartScheduleTableSynchron() service.	
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

**[ECUC\_Os\_00057] Definition of EcucIntegerParamDef OsScheduleTableStartValue** [

Parameter Name	OsScheduleTableStartValue		
Parent Container	<a href="#">OsScheduleTableAutostart</a>		
Description	Absolute autostart tick value when the schedule table starts. Only used if the OsScheduleTableAutostartType is ABSOLUTE. Relative offset in ticks when the schedule table starts. Only used if the OsScheduleTableAutostartType is RELATIVE.		
Multiplicity	0..1		
Type	EcucIntegerParamDef		
Range	0 .. 18446744073709551615		
Default value	–		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

]

**[ECUC\_Os\_00058] Definition of EcucReferenceDef OsScheduleTableAppModeRef** [

Parameter Name	OsScheduleTableAppModeRef		
Parent Container	<a href="#">OsScheduleTableAutostart</a>		
Description	Reference in which application modes the schedule table should be started during startup		
Multiplicity	1..*		
Type	Reference to <a href="#">OsAppMode</a>		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

]

### 10.2.25 OsScheduleTableEventSetting

**[ECUC\_Os\_00059] Definition of EcucParamConfContainerDef OsScheduleTableEventSetting** [

<b>Container Name</b>	OsScheduleTableEventSetting	
<b>Parent Container</b>	<a href="#">OsScheduleTableExpiryPoint</a>	
<b>Description</b>	Event that is triggered by that schedule table.	
<b>Multiplicity</b>	0..*	
<b>Configuration Parameters</b>		

<b>Included Parameters</b>		
<b>Parameter Name</b>	<b>Multiplicity</b>	<b>ECUC ID</b>
<a href="#">OsScheduleTableSetEventRef</a>	1	[ECUC_Os_00060]
<a href="#">OsScheduleTableSetEventTaskRef</a>	1	[ECUC_Os_00061]

<b>No Included Containers</b>
-------------------------------

]

**[ECUC\_Os\_00060] Definition of EcucReferenceDef OsScheduleTableSetEventRef** [

<b>Parameter Name</b>	OsScheduleTableSetEventRef		
<b>Parent Container</b>	<a href="#">OsScheduleTableEventSetting</a>		
<b>Description</b>	Reference to event that will be set by action		
<b>Multiplicity</b>	1		
<b>Type</b>	Reference to <a href="#">OsEvent</a>		
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

**[ECUC\_Os\_00061] Definition of EcucReferenceDef OsScheduleTableSetEventTaskRef** [

<b>Parameter Name</b>	OsScheduleTableSetEventTaskRef		
<b>Parent Container</b>	<a href="#">OsScheduleTableEventSetting</a>		
<b>Description</b>	—		
<b>Multiplicity</b>	1		
<b>Type</b>	Reference to <a href="#">OsTask</a>		
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

## 10.2.26 OsScheduleTableExpiryPoint

### [ECUC\_Os\_00143] Definition of EcucParamConfContainerDef OsScheduleTableExpiryPoint [

Container Name	OsScheduleTableExpiryPoint	
Parent Container	OsScheduleTable	
Description	The point on a Schedule Table at which the OS activates tasks and/or sets events	
Multiplicity	1..*	
Configuration Parameters		

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
OsScheduleTblExpPointOffset	1	[ECUC_Os_00062]

Included Containers		
Container Name	Multiplicity	Dependency
OsScheduleTableEventSetting	0..*	Event that is triggered by that schedule table.
OsScheduleTableTaskActivation	0..*	Task that is triggered by that schedule table.
OsScheduleTableTaskReplenish	0..*	Task that is replenished by that expiry point
OsScheduleTblAdjustableExpPoint	0..1	Adjustable expiry point

### [ECUC\_Os\_00062] Definition of EcucIntegerParamDef OsScheduleTblExpPointOffset [

Parameter Name	OsScheduleTblExpPointOffset		
Parent Container	OsScheduleTableExpiryPoint		
Description	The offset from zero (in ticks) at which the expiry point is to be processed.		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	0 .. 18446744073709551615		
Default value	-		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	-	
	Post-build time	-	
Dependency			

## 10.2.27 OsScheduleTableTaskActivation

### [ECUC\_Os\_00066] Definition of EcucParamConfContainerDef OsScheduleTableTaskActivation [

Container Name	OsScheduleTableTaskActivation	
Parent Container	<a href="#">OsScheduleTableExpiryPoint</a>	
Description	Task that is triggered by that schedule table.	
Multiplicity	0..*	
Configuration Parameters		

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
<a href="#">OsScheduleTableActivateTaskRef</a>	1	[ECUC_Os_00067]

No Included Containers
------------------------

]

**[ECUC\_Os\_00067] Definition of EcucReferenceDef OsScheduleTableActivateTaskRef** [

Parameter Name	OsScheduleTableActivateTaskRef		
Parent Container	<a href="#">OsScheduleTableTaskActivation</a>		
Description	Reference to task that will be activated by action		
Multiplicity	1		
Type	Reference to <a href="#">OsTask</a>		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### 10.2.28 OsScheduleTblAdjustableExpPoint

**[ECUC\_Os\_00068] Definition of EcucParamConfContainerDef OsScheduleTblAdjustableExpPoint** [

Container Name	OsScheduleTblAdjustableExpPoint	
Parent Container	<a href="#">OsScheduleTableExpiryPoint</a>	
Description	Adjustable expiry point	
Multiplicity	0..1	
Configuration Parameters		

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
<a href="#">OsScheduleTableMaxLengthen</a>	1	[ECUC_Os_00069]
<a href="#">OsScheduleTableMaxShorten</a>	1	[ECUC_Os_00070]

No Included Containers
------------------------

]

**[ECUC\_Os\_00069] Definition of EcucIntegerParamDef OsScheduleTableMaxLengthen** [

Parameter Name	OsScheduleTableMaxLengthen		
Parent Container	<a href="#">OsScheduleTblAdjustableExpPoint</a>		
Description	The maximum positive adjustment that can be made to the expiry point offset (in ticks).		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	0 .. 18446744073709551615		
Default value	–		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

]

**[ECUC\_Os\_00070] Definition of EcucIntegerParamDef OsScheduleTableMaxShorten** [

Parameter Name	OsScheduleTableMaxShorten		
Parent Container	<a href="#">OsScheduleTblAdjustableExpPoint</a>		
Description	The maximum negative adjustment that can be made to the expiry point offset (in ticks).		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	0 .. 18446744073709551615		
Default value	–		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

]

### 10.2.29 OsScheduleTableTaskReplenish

**[ECUC\_Os\_00414] Definition of EcucParamConfContainerDef OsScheduleTableTaskReplenish** [

Container Name	OsScheduleTableTaskReplenish		
Parent Container	<a href="#">OsScheduleTableExpiryPoint</a>		
Description	Task that is replenished by that expiry point		
Multiplicity	0..*		



△

Post-Build Variant Multiplicity	false
Configuration Parameters	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
OsScheduleTableReplenishTaskRef	1	[ECUC_Os_00415]

No Included Containers
------------------------

]

### [ECUC\_Os\_00415] Definition of EcucReferenceDef OsScheduleTableReplenishTaskRef

Parameter Name	OsScheduleTableReplenishTaskRef		
Parent Container	OsScheduleTableTaskReplenish		
Description	Reference to Task that will be replenished.		
Multiplicity	1		
Type	Reference to <a href="#">OsTask</a>		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

#### 10.2.30 OsScheduleTableSync

### [ECUC\_Os\_00063] Definition of EcucParamConfContainerDef OsScheduleTableSync

Container Name	OsScheduleTableSync		
Parent Container	OsScheduleTable		
Description	This container specifies the synchronization parameters of the schedule table.		
Multiplicity	0..1		
Configuration Parameters			

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
OsScheduleTblExplicitPrecision	0..1	[ECUC_Os_00064]
OsScheduleTblSyncStrategy	1	[ECUC_Os_00065]

No Included Containers
------------------------

]

**[ECUC\_Os\_00064] Definition of EcucIntegerParamDef OsScheduleTblExplicitPrecision** [

Parameter Name	OsScheduleTblExplicitPrecision		
Parent Container	<a href="#">OsScheduleTableSync</a>		
Description	This configuration is only valid if the explicit synchronization is used.		
Multiplicity	0..1		
Type	EcucIntegerParamDef		
Range	0 .. 18446744073709551615		
Default value	–		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

]

**[ECUC\_Os\_00065] Definition of EcucEnumerationParamDef OsScheduleTblSyncStrategy** [

Parameter Name	OsScheduleTblSyncStrategy				
Parent Container	<a href="#">OsScheduleTableSync</a>				
Description	AUTOSAR OS provides support for synchronization in two ways: explicit and implicit.				
Multiplicity	1				
Type	EcucEnumerationParamDef				
Range	EXPLICIT	The schedule table is driven by an OS counter but processing needs to be synchronized with a different counter which is not an OS counter object.			
	IMPLICIT	The counter driving the schedule table is the counter with which synchronisation is required.			
	NONE	No support for synchronisation.			
Default value	<a href="#">NONE</a>				
Post-Build Variant Value	false				
Value Configuration Class	Pre-compile time	X	All Variants		
	Link time	–			
	Post-build time	–			
Dependency					

]

### 10.2.31 OsSpinlock

**[ECUC\_Os\_00258] Definition of EcucParamConfContainerDef OsSpinlock** [

<b>Container Name</b>	OsSpinlock		
<b>Parent Container</b>	<a href="#">Os</a>		
<b>Description</b>	An OsSpinlock object is used to co-ordinate concurrent access by TASKs/ISR2s on different cores to a shared resource.		
<b>Multiplicity</b>	0..*		
<b>Configuration Parameters</b>			

<b>Included Parameters</b>
<b>Parameter Name</b>
<a href="#">OsSpinlockLockMethod</a>
<a href="#">OsSpinlockAccessingApplication</a>
<a href="#">OsSpinlockSuccessor</a>

**No Included Containers**

]

### [ECUC\_Os\_01038] Definition of EcucEnumerationParamDef OsSpinlockLock Method

<b>Parameter Name</b>	OsSpinlockLockMethod				
<b>Parent Container</b>	<a href="#">OsSpinlock</a>				
<b>Description</b>	Lock method which is used when a spinlock is taken. Note that it is possible that a user (e.g. a Task) might hold more than one spinlock. In this case the last lock taken is forced to use at least a lock method which locks as strong as the current one.				
<b>Multiplicity</b>	1				
<b>Type</b>	EcucEnumerationParamDef				
<b>Range</b>	LOCK_ALL_INTERRUPTS	–			
	LOCK_CAT2_INTERRUPTS	–			
	LOCK_NOTHING	–			
	LOCK_WITH_RES_SCHEDULER	–			
<b>Default value</b>	<a href="#">LOCK_NOTHING</a>				
<b>Post-Build Variant Value</b>	false				
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants		
	<b>Link time</b>	–			
	<b>Post-build time</b>	–			
<b>Dependency</b>					

]

### [ECUC\_Os\_01021] Definition of EcucReferenceDef OsSpinlockAccessingApplication

<b>Parameter Name</b>	OsSpinlockAccessingApplication		
<b>Parent Container</b>	<a href="#">OsSpinlock</a>		
<b>Description</b>	Reference to OsApplications that have an access to this object.		
<b>Multiplicity</b>	1..*		
<b>Type</b>	Reference to <a href="#">OsApplication</a>		



△

<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

### [ECUC\_Os\_01022] Definition of EcucReferenceDef OsSpinlockSuccessor

<b>Parameter Name</b>	OsSpinlockSuccessor		
<b>Parent Container</b>	<a href="#">OsSpinlock</a>		
<b>Description</b>	To check whether a spinlock can be occupied (in a nested way) without any danger of deadlock, a linked list of spinlocks can be defined. A spinlock can only be occupied in the order of the linked list. It is allowed to skip a spinlock. If no linked list is specified, spinlocks cannot be nested.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to <a href="#">OsSpinlock</a>		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			




Figure 10.13: OsSpinlock configuration overview

### 10.2.32 OsTask

#### [ECUC\_Os\_00073] Definition of EcucParamConfContainerDef OsTask [

Container Name	OsTask
Parent Container	Os
Description	This container represents an ISO 17356 task.
Multiplicity	0..*
Configuration Parameters	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
OsTaskActivation	1	[ECUC_Os_00074]
OsTaskPeriod	0..1	[ECUC_Os_00404]
OsTaskPriority	1	[ECUC_Os_00075]
OsTaskSchedule	1	[ECUC_Os_00076]
OsMemoryMappingCodeLocationRef	0..1	[ECUC_Os_00402]
OsTaskAccessingApplication	0..*	[ECUC_Os_00077]
OsTaskEventRef	0..*	[ECUC_Os_00078]
OsTaskResourceRef	0..*	[ECUC_Os_00079]

Included Containers		
Container Name	Multiplicity	Dependency
OsTaskAutostart	0..1	<p>This container determines whether the task is activated during the system start-up procedure or not for some specific application modes.</p> <p>If the task shall be activated during the system start-up, this container is present and holds the references to the application modes in which the task is auto-started.</p>
OsTaskTimingProtection	0..1	This container contains all parameters regarding timing protection of the task.

#### [ECUC\_Os\_00074] Definition of EcucIntegerParamDef OsTaskActivation [

Parameter Name	OsTaskActivation				
Parent Container	OsTask				
Description	This attribute defines the maximum number of queued activation requests for the task. A value equal to "1" means that at any time only a single activation is permitted for this task. Note that the value must be a natural number starting at 1.				
Multiplicity	1				
Type	EcucIntegerParamDef				
Range	1 .. 4294967295				
Default value	-				
Post-Build Variant Value	false				
Value Configuration Class	Pre-compile time	X	All Variants		
	Link time	-			
	Post-build time	-			
Dependency					

### [ECUC\_Os\_00404] Definition of EcucFloatParamDef OsTaskPeriod [

Parameter Name	OsTaskPeriod		
Parent Container	OsTask		
Description	<p>This parameter specifies the period in seconds of this task in case of a cyclically activated task.</p> <p>If this parameter is not given the task can be activated sporadicly or cyclically with a unknown period value.</p> <p>This value is information, e.g. for time base calculations in the RTE in case Timing Events are mapped onto this OsTask. Be aware, that this parameter is not supposed to be relevant for the OS! This information is given as part of the OS configuration to support configuration work flows using a fixed set of OsTasks.</p>		
Multiplicity	0..1		
Type	EcucFloatParamDef		
Range	[-INF .. INF]		
Default value	–		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

### [ECUC\_Os\_00075] Definition of EcucIntegerParamDef OsTaskPriority [

Parameter Name	OsTaskPriority		
Parent Container	OsTask		
Description	<p>The priority of a task is defined by the value of this attribute. This value has to be understood as a relative value, i.e. the values show only the relative ordering of the tasks.</p> <p>ISO 17356-3 defines the lowest priority as zero (0); larger values correspond to higher priorities.</p>		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	0 .. 4294967295		
Default value	–		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

### [ECUC\_Os\_00076] Definition of EcucEnumerationParamDef OsTaskSchedule

Parameter Name	OsTaskSchedule		
Parent Container	<a href="#">OsTask</a>		
Description	The OsTaskSchedule attribute defines the preemptability of the task. If this attribute is set to NON, no internal resources may be assigned to this task.		
Multiplicity	1		
Type	EcucEnumerationParamDef		
Range	FULL	Task is preemptable.	
	NON	Task is not preemptable.	
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

For parameter table [\[ECUC\\_Os\\_00402\] OsMemoryMappingCodeLocationRef](#), see definition below container OsApplication.

### [ECUC\_Os\_00077] Definition of EcucReferenceDef OsTaskAccessingApplication

Parameter Name	OsTaskAccessingApplication		
Parent Container	<a href="#">OsTask</a>		
Description	Reference to applications which have an access to this object.		
Multiplicity	0..*		
Type	Reference to <a href="#">OsApplication</a>		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### [ECUC\_Os\_00078] Definition of EcucReferenceDef OsTaskEventRef

Parameter Name	OsTaskEventRef		
Parent Container	<a href="#">OsTask</a>		
Description	This reference defines the list of events the extended task may react on.		
Multiplicity	0..*		
Type	Reference to <a href="#">OsEvent</a>		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		



△

<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

### [ECUC\_Os\_00079] Definition of EcucReferenceDef OsTaskResourceRef [

<b>Parameter Name</b>	OsTaskResourceRef		
<b>Parent Container</b>	<a href="#">OsTask</a>		
<b>Description</b>	This reference defines a list of resources accessed by this task.		
<b>Multiplicity</b>	0..*		
<b>Type</b>	Reference to <a href="#">OsResource</a>		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]




Figure 10.14: OsTask configuration overview

### 10.2.33 OsTaskAutostart

#### [ECUC\_Os\_00080] Definition of EcucParamConfContainerDef OsTaskAutostart

Container Name	OsTaskAutostart
Parent Container	OsTask
Description	This container determines whether the task is activated during the system start-up procedure or not for some specific application modes. If the task shall be activated during the system start-up, this container is present and holds the references to the application modes in which the task is auto-started.
Multiplicity	0..1
Configuration Parameters	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
OsTaskAppModeRef	1..*	[ECUC_Os_00081]

No Included Containers
------------------------

]

### [ECUC\_Os\_00081] Definition of EcucReferenceDef OsTaskAppModeRef [

Parameter Name	OsTaskAppModeRef		
Parent Container	<a href="#">OsTaskAutostart</a>		
Description	Reference to application modes in which that task is activated on startup of the OS		
Multiplicity	1..*		
Type	Reference to <a href="#">OsAppMode</a>		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### 10.2.34 OsTaskResourceLock

#### [ECUC\_Os\_00082] Definition of EcucParamConfContainerDef OsTaskResourceLock [

Container Name	OsTaskResourceLock		
Parent Container	<a href="#">OsTaskTimingProtection</a>		
Description	This container contains the worst case time between getting and releasing a given resource (in seconds).		
Multiplicity	0..*		
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
<a href="#">OsTaskResourceLockBudget</a>	1	[ECUC_Os_00083]	
<a href="#">OsTaskResourceLockResourceRef</a>	1	[ECUC_Os_00084]	

No Included Containers
------------------------

]

**[ECUC\_Os\_00083] Definition of EcucFloatParamDef OsTaskResourceLockBudget**

Parameter Name	OsTaskResourceLockBudget				
Parent Container	<a href="#">OsTaskResourceLock</a>				
Description	This parameter contains the maximum time the task is allowed to lock the resource (in seconds)				
Multiplicity	1				
Type	<a href="#">EcucFloatParamDef</a>				
Range	[0 .. INF]				
Default value	–				
Post-Build Variant Value	false				
Value Configuration Class	Pre-compile time	X	All Variants		
	Link time	–			
	Post-build time	–			
Dependency	Required for scalability class 2 and 4				

]

**[ECUC\_Os\_00084] Definition of EcucReferenceDef OsTaskResourceLockResourceRef**

Parameter Name	OsTaskResourceLockResourceRef		
Parent Container	<a href="#">OsTaskResourceLock</a>		
Description	Reference to the resource used by the task		
Multiplicity	1		
Type	Reference to <a href="#">OsResource</a>		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency	Required for scalability class 2 and 4		

]

### 10.2.35 OsTaskTimingProtection

**[ECUC\_Os\_00325] Definition of EcucParamConfContainerDef OsTaskTimingProtection**

Container Name	OsTaskTimingProtection		
Parent Container	<a href="#">OsTask</a>		
Description	This container contains all parameters regarding timing protection of the task.		
Multiplicity	0..1		
Configuration Parameters			

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
OsTaskAllInterruptLockBudget	0..1	[ECUC_Os_00085]
OsTaskExecutionBudget	0..1	[ECUC_Os_00185]
OsTaskOsInterruptLockBudget	0..1	[ECUC_Os_00086]
OsTaskTimeFrame	0..1	[ECUC_Os_00391]
OsTaskTimingProtectionDeferrableServer	0..1	[ECUC_Os_00416]

Included Containers		
Container Name	Multiplicity	Dependency
OsTaskResourceLock	0..*	This container contains the worst case time between getting and releasing a given resource (in seconds).

]

### [ECUC\_Os\_00085] Definition of EcucFloatParamDef OsTaskAllInterruptLock Budget

Parameter Name	OsTaskAllInterruptLockBudget				
Parent Container	OsTaskTimingProtection				
Description	This parameter contains the maximum time for which the task is allowed to lock all interrupts (via SuspendAllInterrupts() or DisableAllInterrupts()) (in seconds).				
Multiplicity	0..1				
Type	EcucFloatParamDef				
Range	[0 .. INF]				
Default value	–				
Post-Build Variant Multiplicity	false				
Post-Build Variant Value	false				
Multiplicity Configuration Class	Pre-compile time	X	All Variants		
	Link time	–			
	Post-build time	–			
Value Configuration Class	Pre-compile time	X	All Variants		
	Link time	–			
	Post-build time	–			
Dependency	Required for scalability class 2 and 4				

]

### [ECUC\_Os\_00185] Definition of EcucFloatParamDef OsTaskExecutionBudget

Parameter Name	OsTaskExecutionBudget				
Parent Container	OsTaskTimingProtection				
Description	This parameter contains the maximum allowed execution time of the task (in seconds).				
Multiplicity	0..1				
Type	EcucFloatParamDef				
Range	[0 .. INF]				
Default value	–				
Post-Build Variant Multiplicity	false				
Post-Build Variant Value	false				





<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>	Required for scalability class 2 and 4		

]

### [ECUC\_Os\_00086] Definition of EcucFloatParamDef OsTaskOsInterruptLockBudget

<b>Parameter Name</b>	OsTaskOsInterruptLockBudget		
<b>Parent Container</b>	<a href="#">OsTaskTimingProtection</a>		
<b>Description</b>	This parameter contains the maximum time for which the task is allowed to lock all Category 2 interrupts (via SuspendOSInterrupts()) (in seconds).		
<b>Multiplicity</b>	0..1		
<b>Type</b>	EcucFloatParamDef		
<b>Range</b>	[0 .. INF]		
<b>Default value</b>	—		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>	Required for scalability class 2 and 4		

]

### [ECUC\_Os\_00391] Definition of EcucFloatParamDef OsTaskTimeFrame

<b>Parameter Name</b>	OsTaskTimeFrame		
<b>Parent Container</b>	<a href="#">OsTaskTimingProtection</a>		
<b>Description</b>	The minimum inter-arrival time between activations and/or releases of a task (in seconds).		
<b>Multiplicity</b>	0..1		
<b>Type</b>	EcucFloatParamDef		
<b>Range</b>	[0 .. INF]		
<b>Default value</b>	—		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	





Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency	Only available in scalability class 2 and 4		

]

### [ECUC\_Os\_00416] Definition of EcucBooleanParamDef OsTaskTimingProtection DeferrableServer

Parameter Name	OsTaskTimingProtectionDeferrableServer		
Parent Container	<a href="#">OsTaskTimingProtection</a>		
Description	This parameter defines if the timing protection for this task is done as "Deferrable Server" or not. True means that the Task is a deferrable server		
Multiplicity	0..1		
Type	EcucBooleanParamDef		
Default value	false		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency	Required for scalability class 2 and 4		

]

### 10.2.36 OsTimeConstant

#### [ECUC\_Os\_00386] Definition of EcucParamConfContainerDef OsTimeConstant

Container Name	OsTimeConstant		
Parent Container	<a href="#">OsCounter</a>		
Description	Allows the user to define constants which can be e.g. used to compare time values with timer tick values. A time value will be converted to a timer tick value during generation and can later on accessed via the OsConstName. The conversion is done by rounding time values to the nearest fitting tick value.		
Multiplicity	0..*		
Configuration Parameters			
Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
<a href="#">OsTimeValue</a>	1	<a href="#">[ECUC_Os_00002]</a>	
No Included Containers			

]

**[ECUC\_Os\_00002] Definition of EcucFloatParamDef OsTimeValue [**

<b>Parameter Name</b>	OsTimeValue		
<b>Parent Container</b>	<a href="#">OsTimeConstant</a>		
<b>Description</b>	This parameter contains the value of the constant in seconds.		
<b>Multiplicity</b>	1		
<b>Type</b>	EcucFloatParamDef		
<b>Range</b>	[0 .. INF]		
<b>Default value</b>	–		
<b>Post-Build Variant Value</b>	false		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	–	
	<b>Post-build time</b>	–	
<b>Dependency</b>			

]

## 10.3 Containers and configuration parameter extensions of the IOC

This section describes the content of the IOC Configuration Description that is needed for the generation of the IOC API.




Figure 10.15: Osloc configuration overview

### 10.3.1 Osloc

#### [ECUC\_Os\_01000] Definition of EcucParamConfContainerDef Osloc

Container Name	Osloc
Parent Container	Os
Description	Configuration of the IOC (Inter OS Application Communicator).
Multiplicity	0..1
Configuration Parameters	

#### No Included Parameters

Included Containers		
Container Name	Multiplicity	Dependency
OslocCommunication	0..*	<p>Representation of a 1:1 or N:1 or N:M (unqueued only) communication between software parts located in different OS-Applications that are bound to the same or to different cores. The name shall begin with the name of the sending software service and be followed by a unique identifier delivered by the sending software service. In the case of RTE as user attention shall be paid on the fact that uniqueness for identifier names has to be reached over ports, data elements, object instances and maybe additional identification properties (E.g. Case 1:N mapping to 1:1). Example:</p> <ul style="list-style-type: none"> <li>• &lt;NameSpace&gt;_UniqueId</li> </ul>

]

### 10.3.2 OslocCommunication

#### [ECUC\_Os\_01003] Definition of EcucParamConfContainerDef OslocCommunication

Container Name	OslocCommunication
Parent Container	Osloc
Description	<p>Representation of a 1:1 or N:1 or N:M (unqueued only) communication between software parts located in different OS-Applications that are bound to the same or to different cores. The name shall begin with the name of the sending software service and be followed by a unique identifier delivered by the sending software service. In the case of RTE as user attention shall be paid on the fact that uniqueness for identifier names has to be reached over ports, data elements, object instances and maybe additional identification properties (E.g. Case 1:N mapping to 1:1). Example:</p> <ul style="list-style-type: none"> <li>• &lt;NameSpace&gt;_UniqueId</li> </ul>
Multiplicity	0..*
Configuration Parameters	

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
OslocBufferLength	0..1	[ECUC_Os_01001]	

Included Containers		
Container Name	Multiplicity	Dependency
OslocDataProperties	1..*	Data properties of the data to be transferred on the IOC communication channel.
OslocReceiverProperties	1..*	Representation of receiver properties for one communication. For each OslocCommunication one (1:1) or many receivers (N:M) have to be defined. This container should be instantiated within an OslocCommunication.
OslocSenderProperties	1..*	Representation of sender properties for one communication. For each OslocCommunication one (1:1) or many senders (N:1 or N:M) have to be defined. Multiplicity > 1 (N:1 or N:M communication) is only allowed for Multiplicity of OslocDataType Ref = 1. This container should be instantiated within an Osloc Communication.

]

## [ECUC\_Os\_01001] Definition of EcucIntegerParamDef OslocBufferLength [

Parameter Name	OslocBufferLength		
Parent Container	<a href="#">OslocCommunication</a>		
Description	This attribute defines the size of the IOC internal queue to be allocated for a queued communication. This configuration information shall allow the optimization of the needed memory for communications requiring buffers within the RTE and within the IOC.		
Multiplicity	0..1		
Type	<a href="#">EcucIntegerParamDef</a>		
Range	1 .. 4294967295		
Default value	–		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

]

### 10.3.3 OslocSenderProperties

## [ECUC\_Os\_01015] Definition of EcucParamConfContainerDef OslocSenderProperties [

Container Name	OslocSenderProperties		
Parent Container	<a href="#">OslocCommunication</a>		
Description	Representation of sender properties for one communication. For each Osloc Communication one (1:1) or many senders (N:1 or N:M) have to be defined. Multiplicity > 1 (N:1 or N:M communication) is only allowed for Multiplicity of OslocDataTypeRef = 1. This container should be instantiated within an OslocCommunication.		
Multiplicity	1..*		
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
<a href="#">OslocFunctionImplementationKind</a>	0..1	[ECUC_Os_01036]	
<a href="#">OslocSenderId</a>	0..1	[ECUC_Os_01016]	
<a href="#">OslocSendingOsApplicationRef</a>	1	[ECUC_Os_01014]	

No Included Containers
------------------------

]

For parameter table [\[ECUC\\_Os\\_01036\] OslocFunctionImplementationKind](#), see definition below container [OslocReceiverProperties](#).

### [ECUC\_Os\_01016] Definition of EcucIntegerParamDef OslocSenderId [

Parameter Name	OslocSenderId				
Parent Container	<a href="#">OslocSenderProperties</a>				
Description	Representation of a sender in a N:1 or N:M communication to distinguish between senders. This parameter does not exist in 1:1 communication.				
Multiplicity	0..1				
Type	<a href="#">EcucIntegerParamDef</a>				
Range	0 .. 255				
Default value	–				
Post-Build Variant Multiplicity	false				
Post-Build Variant Value	false				
Multiplicity Configuration Class	Pre-compile time	X	All Variants		
	Link time	–			
	Post-build time	–			
Value Configuration Class	Pre-compile time	X	All Variants		
	Link time	–			
	Post-build time	–			
Dependency					

]

### [ECUC\_Os\_01014] Definition of EcucReferenceDef OslocSendingOsApplicationRef [

Parameter Name	OslocSendingOsApplicationRef		
Parent Container	<a href="#">OslocSenderProperties</a>		
Description	This attribute is a reference to the sending OS-Application instance defined in the configuration file of the OS. This information shall allows the generator to get additional information necessary for the code generation like: <ul style="list-style-type: none"><li>• The protection properties of the communicating OS-Applications to find out which protection boundaries have to be crossed.</li><li>• The core identifiers to find out if an intra or an inter core communication has to be realized</li><li>• Interrupt details in case of cross core notification to realize over IRQs</li></ul>		
Multiplicity	1		
Type	Reference to <a href="#">OsApplication</a>		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

]

#### 10.3.4 OslocReceiverProperties

### [ECUC\_Os\_01017] Definition of EcucParamConfContainerDef OslocReceiverProperties [

<b>Container Name</b>	OslocReceiverProperties	
<b>Parent Container</b>	OslocCommunication	
<b>Description</b>	Representation of receiver properties for one communication. For each Osloc Communication one (1:1) or many receivers (N:M) have to be defined. This container should be instantiated within an OslocCommunication.	
<b>Multiplicity</b>	1..*	
<b>Configuration Parameters</b>		

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
OslocFunctionImplementationKind	0..1	[ECUC_Os_01036]
OslocReceiverId	0..1	[ECUC_Os_00407]
OslocReceiverPullCB	0..1	[ECUC_Os_01010]
OslocReceivingOsApplicationRef	1	[ECUC_Os_01012]
OsMemoryMappingCodeLocationRef	0..1	[ECUC_Os_00411]

## No Included Containers

]

**[ECUC\_Os\_01036] Definition of EcucEnumerationParamDef OslocFunctionImplementationKind**

<b>Parameter Name</b>	OslocFunctionImplementationKind				
<b>Parent Container</b>	OslocReceiverProperties, OslocSenderProperties				
<b>Description</b>	This parameter is used to select whether this communication is implemented as a macro or as a function.				
<b>Multiplicity</b>	0..1				
<b>Type</b>	EcucEnumerationParamDef				
<b>Range</b>	DO_NOT_CARE	It is not defined whether a macro or a function is used.			
	FUNCTION	Communication is implemented as a function			
	MACRO	Communication is implemented as a macro			
<b>Default value</b>	DO_NOT_CARE				
<b>Post-Build Variant Multiplicity</b>	false				
<b>Post-Build Variant Value</b>	false				
<b>Multiplicity Configuration Class</b>	Pre-compile time	X	All Variants		
	Link time	—			
	Post-build time	—			
<b>Value Configuration Class</b>	Pre-compile time	X	All Variants		
	Link time	—			
	Post-build time	—			
<b>Dependency</b>					

]

### [ECUC\_Os\_00407] Definition of EcucIntegerParamDef OslocReceiverId [

Parameter Name	OslocReceiverId				
Parent Container	OslocReceiverProperties				
Description	Representation of a receiver in a N:M communication to distinguish between receivers. This parameter does not exist in 1:1 or N:1 communication.				
Multiplicity	0..1				
Type	EcucIntegerParamDef				
Range	0 .. 255				
Default value	–				
Post-Build Variant Multiplicity	false				
Post-Build Variant Value	false				
Multiplicity Configuration Class	Pre-compile time	X	All Variants		
	Link time	–			
	Post-build time	–			
Value Configuration Class	Pre-compile time	X	All Variants		
	Link time	–			
	Post-build time	–			
Dependency					

### [ECUC\_Os\_01010] Definition of EcucFunctionNameDef OslocReceiverPullCB [

Parameter Name	OslocReceiverPullCB		
Parent Container	OslocReceiverProperties		
Description	This attribute defines the name of a callback function that the IOC shall call on the receiving core for each data reception. In case of non existence of this attribute no ReceiverPullCB notification shall be applied by the IOC. The name of the function shall begin with the name of the receiving module, followed with a callback name and followed by the loId. Example: void RTE_ReceiverPullCB_RTE25 (void). If this attribute does not exist, it means that no ReceiverPullCB shall be called (No notification from IOC is required). If this attribute exists the IOC shall call the callback function on the receiving core.		
Multiplicity	0..1		
Type	EcucFunctionNameDef		
Default value	–		
Regular Expression	–		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			

**[ECUC\_Os\_01012] Definition of EcucReferenceDef OslocReceivingOsApplicationRef** [

Parameter Name	OslocReceivingOsApplicationRef		
Parent Container	<a href="#">OslocReceiverProperties</a>		
Description	<p>This attribute is a reference to the receiving OsApplication instance defined in the configuration file of the OS.</p> <p>This information allows for the generator to get additional information necessary for the code generation like:</p> <ul style="list-style-type: none"> <li>• The protection properties of the communicating OsApplications to find out which protections have to be crossed</li> <li>• The core identifiers to find out if an intra or an inter core communication has to be realized</li> <li>• Interrupt details in case of cross core notification to realize over IRQs</li> </ul>		
Multiplicity	1		
Type	Reference to <a href="#">OsApplication</a>		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

**[ECUC\_Os\_00411] Definition of EcucForeignReferenceDef OsMemoryMappingCodeLocationRef** [

Parameter Name	OsMemoryMappingCodeLocationRef		
Parent Container	<a href="#">OslocReceiverProperties</a>		
Description	Reference to the memory mapping containing details about the section where the code of OslocReceiverPullCB is placed.		
Multiplicity	0..1		
Type	Foreign reference to SW-ADDR-METHOD		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### 10.3.5 OslocDataProperties

**[ECUC\_Os\_01023] Definition of EcucParamConfContainerDef OslocDataProperties** [

<b>Container Name</b>	OslocDataProperties		
<b>Parent Container</b>	<a href="#">OslocCommunication</a>		
<b>Description</b>	Data properties of the data to be transferred on the IOC communication channel.		
<b>Multiplicity</b>	1..*		
<b>Configuration Parameters</b>			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
<a href="#">OslocDataPropertyIndex</a>	0..1	<a href="#">[ECUC_Os_01035]</a>	
<a href="#">OslocInitValue</a>	0..1	<a href="#">[ECUC_Os_01024]</a>	
<a href="#">OslocDataTypeRef</a>	1	<a href="#">[ECUC_Os_01005]</a>	
<a href="#">OsMemoryMappingCodeLocationRef</a>	0..1	<a href="#">[ECUC_Os_00405]</a>	

No Included Containers
------------------------

]

## [ECUC\_Os\_01035] Definition of EcucIntegerParamDef OslocDataPropertyIndex

]

<b>Parameter Name</b>	OslocDataPropertyIndex				
<b>Parent Container</b>	<a href="#">OslocDataProperties</a>				
<b>Description</b>	This parameter is used to define in which order the data is send, e.g. whether locSend Group(A,B) or locSendGroup(B,A) shall be used.				
<b>Multiplicity</b>	0..1				
<b>Type</b>	EcucIntegerParamDef				
<b>Range</b>	0 .. 255				
<b>Default value</b>	–				
<b>Post-Build Variant Multiplicity</b>	false				
<b>Post-Build Variant Value</b>	false				
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants		
	<b>Link time</b>	–			
	<b>Post-build time</b>	–			
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants		
	<b>Link time</b>	–			
	<b>Post-build time</b>	–			
<b>Dependency</b>					

]

## [ECUC\_Os\_01024] Definition of EcucStringParamDef OslocInitValue

]

<b>Parameter Name</b>	OslocInitValue		
<b>Parent Container</b>	<a href="#">OslocDataProperties</a>		
<b>Description</b>	Initial Value for the data to be transferred on the IOC communication channel.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	EcucStringParamDef		
<b>Default value</b>	–		





Regular Expression	–		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			



### [ECUC\_Os\_01005] Definition of EcucForeignReferenceDef OslocDataTypeRef

Parameter Name	OslocDataTypeRef		
Parent Container	OslocDataProperties		
Description	<p>This is the type of the data to be transferred on the IOC communication channel. This attribute is necessary to generate the parameter type of the loc functions. Additionally this information should be used to compute the data size for necessary data copy operations within the loc module.</p> <p>If more than one attribute is defined, the IOC generator should generate an locXxx Group function (Xxx= CHOICE [Send, Receive, Write, Read]).</p> <p>N:1 or N:M communication (Multiplicity of OslocSenderProperties &gt; 1) is only allowed for multiplicity of OslocDataTypeRef = 1</p>		
Multiplicity	1		
Type	Foreign reference to IMPLEMENTATION-DATA-TYPE		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Dependency			



### [ECUC\_Os\_00405] Definition of EcucForeignReferenceDef OsMemoryMappingCodeLocationRef

Parameter Name	OsMemoryMappingCodeLocationRef		
Parent Container	OslocDataProperties		
Description	Reference to the memory mapping containing details about the section where the IOC buffer is placed.		
Multiplicity	0..1		
Type	Foreign reference to SW-ADDR-METHOD		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	–	
	Post-build time	–	
Value Configuration Class	Pre-compile time	X	All Variants



△

	Link time	–	
	Post-build time	–	
Dependency			

]

## 10.4 Containers and configuration parameters for ARTI

This section describes the structure (containers) and the parameters of ARTI objects related to the OS configuration. ARTI objects are defined by the MOD\_ARTI model.

For a detailed description of the referenced ARTI parameters, please see chapter 10 of [11]. Also refer to application note 12.7 of this document.

### [SWS\_Os\_00859]

*Upstream requirements:* RS\_Arti\_00001, RS\_Arti\_00002, RS\_Arti\_00003, RS\_Arti\_00005, RS\_Arti\_00007, RS\_Arti\_00011, RS\_Arti\_00012, RS\_Arti\_00014, RS\_Arti\_00016, RS\_Arti\_00018, RS\_Arti\_00022, RS\_Arti\_00023, RS\_Arti\_00004, RS\_Arti\_00009

〔The configuration items [ArtiHardware](#) and [ArtiOs](#) and their related subcontainers contain the parameters to configure ARTI objects.〕

#### 10.4.1 ArtiHardware

##### [ECUC\_Arti\_00061] Definition of EcucParamConfContainerDef ArtiHardware 〔

Container Name	ArtiHardware		
Parent Container	Arti		
Description	The ArtiHardware container contains ARTI extensions to the EcucHardware module.		
Multiplicity	0..1		
Post-Build Variant Multiplicity	true		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	–	
	Post-build time	X	VARIANT-POST-BUILD
Configuration Parameters			

##### No Included Parameters

Included Containers		
Container Name	Multiplicity	Dependency
<a href="#">ArtiHardwareCoreClass</a>	0..1	Contains the layout of an ARTI "Core" object, extending the EcucCoreDefinition.
<a href="#">ArtiHardwareCoreInstance</a>	0..*	Description: Represents an instance of an ARTI "Core" object, extending the EcucCoreDefinition. When using ARTI for debugging or hardware based tracing, this is mandatory (i.e. multiplicity 1..*), else optional.

]

```

<ECUC-MODULE-CONFIGURATION-VALUES>
<SHORT-NAME>Vendor1ArtiHardware</SHORT-NAME>
<DEFINITION-REF DEST="ECUC-MODULE-DEF">
/AUTOSAR/Arti/ArtiHardware</DEFINITION-REF>
<CONTAINERS>
<ECUC-CONTAINER-VALUE>
<SHORT-NAME>ArtiCoreClass</SHORT-NAME>
<DEFINITION-REF DEST="ECUC-PARAM-CONF-CONTAINER-DEF">
/AUTOSAR/Arti/ArtiHardware/ArtiHardwareCoreClass</DEFINITION-REF>
<...>
</ECUC-CONTAINER-VALUE>
<ECUC-CONTAINER-VALUE>
<SHORT-NAME>ArtiCore0</SHORT-NAME>
<DEFINITION-REF DEST="ECUC-PARAM-CONF-CONTAINER-DEF">
/AUTOSAR/Arti/ArtiHardware/ArtiHardwareCoreInstance</DEFINITION-REF>
<...>
</ECUC-CONTAINER-VALUE>
<ECUC-CONTAINER-VALUE>
<SHORT-NAME>ArtiCore1</SHORT-NAME>
<DEFINITION-REF DEST="ECUC-PARAM-CONF-CONTAINER-DEF">
/AUTOSAR/Arti/ArtiHardware/ArtiHardwareCoreInstance</DEFINITION-REF>
<...>
</ECUC-CONTAINER-VALUE>
</CONTAINERS>
</ECUC-MODULE-CONFIGURATION-VALUES>

```

#### 10.4.2 ArtiHardwareCoreClass

##### [ECUC\_Arti\_00062] Definition of EcucParamConfContainerDef ArtiHardwareCoreClass [

Container Name	ArtiHardwareCoreClass		
Parent Container	ArtiHardware		
Description	Contains the layout of an ARTI "Core" object, extending the EcucCoreDefinition.		
Multiplicity	0..1		
Post-Build Variant Multiplicity	true		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	-	
	Post-build time	X	VARIANT-POST-BUILD
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
ArtiHardwareCoreClassCurrentApplicationRef	0..1	[ECUC_Arti_00054]	
ArtiHardwareCoreClassCurrentLsrRef	0..1	[ECUC_Arti_00056]	
ArtiHardwareCoreClassCurrentTaskRef	1	[ECUC_Arti_00058]	
ArtiHardwareCoreClassGenericComponentRef	0..1	[ECUC_Arti_00064]	



△

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
ArtiHardwareCoreClassLastErrorRef	0..1	[ECUC_Arti_00066]
ArtiHardwareCoreClassRunningTaskPriorityRef	0..1	[ECUC_Arti_00094]

No Included Containers
------------------------

]

### [ECUC\_Arti\_00054] Definition of EcucReferenceDef ArtiHardwareCoreClassCurrentApplicationRef

Parameter Name	ArtiHardwareCoreClassCurrentApplicationRef		
Parent Container	ArtiHardwareCoreClass		
Description	Refers to the ArtiObjectClassParameter that defines the ArtiCurrentApplicationInstance parameter.		
Multiplicity	0..1		
Type	Reference to ArtiObjectClassParameter		
Post-Build Variant Multiplicity	true		
Post-Build Variant Value	true		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD
Dependency			

]

### [ECUC\_Arti\_00056] Definition of EcucReferenceDef ArtiHardwareCoreClassCurrentLsrRef

Parameter Name	ArtiHardwareCoreClassCurrentLsrRef		
Parent Container	ArtiHardwareCoreClass		
Description	Refers to the ArtiObjectClassParameter that defines the ArtiCurrentLsrInstance parameter.		
Multiplicity	0..1		
Type	Reference to ArtiObjectClassParameter		
Post-Build Variant Value	true		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD
Dependency			

]

**[ECUC\_Arti\_00058] Definition of EcucReferenceDef ArtiHardwareCoreClassCurrentTaskRef**

Parameter Name	ArtiHardwareCoreClassCurrentTaskRef		
Parent Container	ArtiHardwareCoreClass		
Description	Refers to the ArtiObjectClassParameter that defines the ArtiCurrentTaskInstance parameter.		
Multiplicity	1		
Type	Reference to ArtiObjectClassParameter		
Post-Build Variant Value	true		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD
Dependency			

]

**[ECUC\_Arti\_00064] Definition of EcucReferenceDef ArtiHardwareCoreClassGenericComponentRef**

Parameter Name	ArtiHardwareCoreClassGenericComponentRef		
Parent Container	ArtiHardwareCoreClass		
Description	Refers to an ArtiGenericComponentClass that extends the core description.		
Multiplicity	0..1		
Type	Reference to ArtiGenericComponentClass		
Post-Build Variant Multiplicity	true		
Post-Build Variant Value	true		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD
Dependency			

]

**[ECUC\_Arti\_00066] Definition of EcucReferenceDef ArtiHardwareCoreClassLastErrorRef**

Parameter Name	ArtiHardwareCoreClassLastErrorRef		
Parent Container	ArtiHardwareCoreClass		
Description	Refers to the ArtiObjectClassParameter that defines the ArtiLastErrorInstance parameter.		
Multiplicity	0..1		
Type	Reference to ArtiObjectClassParameter		
Post-Build Variant Multiplicity	true		
Post-Build Variant Value	true		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	





	Post-build time	X	VARIANT-POST-BUILD
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD
Dependency			

]

### [ECUC\_Arti\_00094] Definition of EcucReferenceDef ArtiHardwareCoreClassRunningTaskPriorityRef

Parameter Name	ArtiHardwareCoreClassRunningTaskPriorityRef		
Parent Container	ArtiHardwareCoreClass		
Description	Refers to the ArtiObjectClassParameter that defines the ArtiHwCoreInstanceRunningTaskPriority parameter. This attribute specifies how to evaluate the current priority of the task referred by RUNNINGTASK. The current priority can be different from the static task priority as a result of priority ceiling protocol. This attribute differs from ArtiCurrentTask->ArtiOsTaskClassPriority as here is a single variable while in multiple tasks there is a single variable per task.		
Multiplicity	0..1		
Type	Reference to ArtiObjectClassParameter		
Post-Build Variant Multiplicity	true		
Post-Build Variant Value	true		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD
Dependency			

]

```

<ECUC-CONTAINER-VALUE>
<SHORT-NAME>ArtiCoreClass</SHORT-NAME>
<DEFINITION-REF DEST="ECUC-PARAM-CONF-CONTAINER-DEF">/AUTOSAR/Arti/
ArtiHardware/ArtiHardwareCoreClass</DEFINITION-REF>
<REFERENCE-VALUES>
  <ECUC-REFERENCE-VALUE>
    <DEFINITION-REF DEST="ECUC-REFERENCE-DEF">/AUTOSAR/Arti/
    ArtiHardware/ArtiHardwareCoreClass/
    ArtiHardwareCoreClassCurrentApplicationRef</DEFINITION-REF>
    <VALUE-REF DEST="ECUC-CONTAINER-VALUE">/Vendor1/Vendor1Arti/
    ArtiObjectClassParameter_ArtiHwCore_CurrentApplication
  </VALUE-REF>
  </ECUC-REFERENCE-VALUE>
  <ECUC-REFERENCE-VALUE>
    <DEFINITION-REF DEST="ECUC-REFERENCE-DEF">/AUTOSAR/Arti/
    ArtiHardware/ArtiHardwareCoreClass/
    ArtiHardwareCoreClassCurrentTaskRef</DEFINITION-REF>
    <VALUE-REF DEST="ECUC-CONTAINER-VALUE">/Vendor1/Vendor1Arti/
    ArtiObjectClassParameter_ArtiHwCore_CurrentTask</VALUE-REF>
  </ECUC-REFERENCE-VALUE>
</REFERENCE-VALUES>

```

&lt;/ECUC-CONTAINER-VALUE&gt;

### 10.4.3 ArtiHardwareCoreInstance

#### [ECUC\_Arti\_00063] Definition of EcucParamConfContainerDef ArtiHardwareCoreInstance [

Container Name	ArtiHardwareCoreInstance		
Parent Container	ArtiHardware		
Description	Description: Represents an instance of an ARTI "Core" object, extending the EcucCore Definition. When using ARTI for debugging or hardware based tracing, this is mandatory (i.e. multiplicity 1..*), else optional.		
Multiplicity	0..*		
Post-Build Variant Multiplicity	true		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
ArtiHardwareCoreInstanceCoreId	0..1	[ECUC_Arti_00091]	
ArtiHardwareCoreInstanceCurrentApplicationRef	0..1	[ECUC_Arti_00055]	
ArtiHardwareCoreInstanceCurrentLsrRef	0..1	[ECUC_Arti_00057]	
ArtiHardwareCoreInstanceCurrentTaskRef	0..1	[ECUC_Arti_00059]	
ArtiHardwareCoreInstanceEcucCoreRef	1	[ECUC_Arti_00060]	
ArtiHardwareCoreInstanceGenericComponentRef	0..1	[ECUC_Arti_00065]	
ArtiHardwareCoreInstanceLastErrorRef	0..1	[ECUC_Arti_00067]	
ArtiHardwareCoreInstanceRunningTaskPriorityRef	0..1	[ECUC_Arti_00095]	
ArtiHardwareCoreInstanceValidRef	0..1	[ECUC_Arti_00096]	

No Included Containers

]

#### [ECUC\_Arti\_00091] Definition of EcucIntegerParamDef ArtiHardwareCoreInstanceCoreId [

Parameter Name	ArtiHardwareCoreInstanceCoreId		
Parent Container	ArtiHardwareCoreInstance		
Description	This parameter represents the "CoreID" as given by the OS, returned by GetCoreID().		
Multiplicity	0..1		
Type	EcucIntegerParamDef		
Range	0 .. 65533		
Default value	—		
Post-Build Variant Multiplicity	false		





<b>Post-Build Variant Value</b>	true		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	—	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Dependency</b>			

]

### [ECUC\_Arti\_00055] Definition of EcucReferenceDef ArtiHardwareCoreInstance CurrentApplicationRef [

<b>Parameter Name</b>	ArtiHardwareCoreInstanceCurrentApplicationRef		
<b>Parent Container</b>	ArtiHardwareCoreInstance		
<b>Description</b>	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "current application" that is running on this core.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiObjectInstanceParameter		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	true		
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	—	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Dependency</b>			

]

### [ECUC\_Arti\_00057] Definition of EcucReferenceDef ArtiHardwareCoreInstance CurrentIsrRef [

<b>Parameter Name</b>	ArtiHardwareCoreInstanceCurrentIsrRef		
<b>Parent Container</b>	ArtiHardwareCoreInstance		
<b>Description</b>	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "current ISR" that is running on this core.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiObjectInstanceParameter		
<b>Post-Build Variant Multiplicity</b>	true		
<b>Post-Build Variant Value</b>	true		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	—	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	—	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Dependency</b>			

]

**[ECUC\_Arti\_00059] Definition of EcucReferenceDef ArtiHardwareCoreInstance CurrentTaskRef**

Parameter Name	ArtiHardwareCoreInstanceCurrentTaskRef		
Parent Container	ArtiHardwareCoreInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "current task" that is running on this core.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	true		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD
Dependency			

]

**[ECUC\_Arti\_00060] Definition of EcucReferenceDef ArtiHardwareCoreInstance EcucCoreRef**

Parameter Name	ArtiHardwareCoreInstanceEcucCoreRef		
Parent Container	ArtiHardwareCoreInstance		
Description	Refers to the EcucCoreDefinition of this core.		
Multiplicity	1		
Type	Reference to EcucCoreDefinition		
Post-Build Variant Value	true		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD
Dependency			

]

**[ECUC\_Arti\_00065] Definition of EcucReferenceDef ArtiHardwareCoreInstance GenericComponentRef**

Parameter Name	ArtiHardwareCoreInstanceGenericComponentRef		
Parent Container	ArtiHardwareCoreInstance		
Description	Refers to an ArtiGenericComponentInstance that extends a core.		
Multiplicity	0..1		
Type	Reference to ArtiGenericComponentInstance		
Post-Build Variant Multiplicity	true		
Post-Build Variant Value	true		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD





Dependency	
------------	--



**[ECUC\_Arti\_00067] Definition of EcucReferenceDef ArtiHardwareCoreInstanceLastErrorRef**

Parameter Name	ArtiHardwareCoreInstanceLastErrorRef		
Parent Container	ArtiHardwareCoreInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "last error" that happened on this core.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	true		
Post-Build Variant Value	true		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD
Dependency			



**[ECUC\_Arti\_00095] Definition of EcucReferenceDef ArtiHardwareCoreInstanceRunningTaskPriorityRef**

Parameter Name	ArtiHardwareCoreInstanceRunningTaskPriorityRef		
Parent Container	ArtiHardwareCoreInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "running task priority" that is on this core.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	true		
Post-Build Variant Value	true		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	—	
	Post-build time	X	VARIANT-POST-BUILD
Dependency			



## [ECUC\_Arti\_00096] Definition of EcucReferenceDef ArtiHardwareCoreInstance ValidRef

Parameter Name	ArtiHardwareCoreInstanceValidRef		
Parent Container	ArtiHardwareCoreInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "validity" of this ArtiHwCoreInstance. Every object declaration may contain a VALID attribute telling the debugger whether the object's attributes are currently valid. It may have an integer type of any size. Its possible values are 0 (invalid) and non zero (object is valid).		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

```

<ECUC-CONTAINER-VALUE>
<SHORT-NAME>ArtiCore0</SHORT-NAME>
<DEFINITION-REF DEST="ECUC-PARAM-CONF-CONTAINER-DEF">/AUTOSAR/Arti/
ArtiHardware/ArtiHardwareCoreInstance</DEFINITION-REF>
<REFERENCE-VALUES>
<ECUC-REFERENCE-VALUE>
<DEFINITION-REF DEST="ECUC-REFERENCE-DEF">/AUTOSAR/Arti/
ArtiHardware/ArtiHardwareCoreInstance/
ArtiHardwareCoreInstanceCurrentApplicationRef</DEFINITION-REF>
<VALUE-REF DEST="ECUC-CONTAINER-VALUE">/Vendor1/Vendor1Arti/
ArtiObjectInstanceParameter_CurrentApplicationOnCore0
</VALUE-REF>
</ECUC-REFERENCE-VALUE>
<ECUC-REFERENCE-VALUE>
<DEFINITION-REF DEST="ECUC-REFERENCE-DEF">/AUTOSAR/Arti/
ArtiHardware/ArtiHardwareCoreInstance/
ArtiHardwareInstanceCurrentTaskRef</DEFINITION-REF>
<VALUE-REF DEST="ECUC-CONTAINER-VALUE">/Vendor1/Vendor1Arti/
ArtiObjectInstanceParameter_CurrentTaskOnCore0</VALUE-REF>
</ECUC-REFERENCE-VALUE>
<ECUC-REFERENCE-VALUE>
<DEFINITION-REF DEST="ECUC-REFERENCE-DEF">/AUTOSAR/Arti/
ArtiHardware/ArtiHardwareCoreInstance/
ArtiHardwareCoreInstanceEcucCoreRef</DEFINITION-REF>
<VALUE-REF DEST="ECUC-CONTAINER-VALUE">
/Vendor1/Vendor1EcucEcucC/Hardware/Core0</VALUE-REF>
</ECUC-REFERENCE-VALUE>
</REFERENCE-VALUES>
</ECUC-CONTAINER-VALUE>

```

#### 10.4.4 ArtiOs

##### [ECUC\_Arti\_00071] Definition of EcucParamConfContainerDef ArtiOs [

Container Name	ArtiOs		
Parent Container	Arti		
Description	The ArtiOs container contains ARTI extensions to the EcucDefs/Os module.		
Multiplicity	0..1		
Post-Build Variant Multiplicity	true		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Configuration Parameters			

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
ArtiOsGenericComponentRef	0..*	[ECUC_Arti_00178]

Included Containers		
Container Name	Multiplicity	Dependency
ArtiOsAlarmClass	0..1	Contains the layout of an ArtiOsAlarm object.
ArtiOsAlarmInstance	0..*	Represents an instance of an ArtiOsAlarm object, extending the EcuC OsTaskAlarm.
ArtiOsClass	0..1	Contains the layout of an ARTI "Os" object, extending the EcuC OsOS.
ArtiOsContextClass	0..1	Contains the layout of an ARTI "OsContext" object.
ArtiOsContextInstance	0..*	Represents an instance of an "ArtiContext" object.
ArtiOsInstance	0..1	Represents an instance of an ARTI "Os" object, extending the EcuC OsOS.
ArtiOsOslsClass	0..1	Contains the layout of an ARTI "Osls" object, extending the EcuC Osls.
ArtiOsOslsInstance	0..*	Represents an instance of an ARTI "Osls" object, extending the EcuC Osls.
ArtiOsMessageContainerClass	0..1	Contains the layout of an ARTI "OsMessageContainer" object. The "OsMessageContainer" object represents an existing combination of OSEK messages.
ArtiOsMessageContainerInstance	0..*	Represents an instance of an "ArtiMessageContainer" object.
ArtiOsResourceClass	0..1	Contains the layout of an ArtiOsResource object. The ArtiOs Resource object represents an OSEK resource.
ArtiOsResourceInstance	0..*	Represents an instance of an ArtiOsResource object.
ArtiOsScheduleTableClass	0..1	Contains the layout of an ArtiOsScheduleTable object.
ArtiOsScheduleTableInstance	0..*	Represents an instance of an ArtiOsScheduleTable object, extending the EcuC OsScheduleTable.
ArtiOsSpinlockClass	0..1	Contains the layout of an ArtiOsSpinlock object.
ArtiOsSpinlockInstance	0..*	Represents an instance of an ArtiOsSpinlock object, extending the EcuC OsSpinlock.
ArtiOsStackClass	0..1	Contains the layout of an ArtiOsStack object. The ArtiOsStack object defines the memory area of any stack in the system.
ArtiOsStackInstance	0..*	Represents an instance of an ArtiOsStack object.
ArtiOsTaskClass	0..1	Contains the layout of an ARTI "OsTask" object, extending the EcuC OsTask.
ArtiOsTaskInstance	0..*	Represents an instance of an ARTI "OsTask" object, extending the EcuC OsTask.

]

## [ECUC\_Arti\_00178] Definition of EcucReferenceDef ArtiOsGenericComponentRef

Parameter Name	ArtiOsGenericComponentRef		
Parent Container	ArtiOs		
Description	Refers to an ArtiGenericComponentClass that relates to the OS.		
Multiplicity	0..*		
Type	Reference to ArtiGenericComponentClass		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

```

<ECUC-MODULE-CONFIGURATION-VALUES>
<SHORT-NAME>Vendor1ArtiOs</SHORT-NAME>
<DEFINITION-REF DEST="ECUC-MODULE-DEF">
/AUTOSAR/Arti/ArtiOs</DEFINITION-REF>
<CONTAINERS>
<ECUC-CONTAINER-VALUE>
<SHORT-NAME>ArtiOsClass_Conf</SHORT-NAME>
<DEFINITION-REF DEST="ECUC-PARAM-CONF-CONTAINER-DEF">
/AUTOSAR/Arti/ArtiOs/ArtiOsClass</DEFINITION-REF>
<...>
</ECUC-CONTAINER-VALUE>
<ECUC-CONTAINER-VALUE>
<SHORT-NAME>ArtiOsInstance_Conf</SHORT-NAME>
<DEFINITION-REF DEST="ECUC-PARAM-CONF-CONTAINER-DEF">
/AUTOSAR/Arti/ArtiOs/ArtiOsInstance</DEFINITION-REF>
<...>
</ECUC-CONTAINER-VALUE>
<ECUC-CONTAINER-VALUE>
<SHORT-NAME>ArtiOsTaskClass_Conf</SHORT-NAME>
<DEFINITION-REF DEST="ECUC-PARAM-CONF-CONTAINER-DEF">
/AUTOSAR/Arti/ArtiOs/ArtiOsTaskClass</DEFINITION-REF>
</ECUC-CONTAINER-VALUE>
<ECUC-CONTAINER-VALUE>
<SHORT-NAME>ArtiOsTaskInstance_TaskHighPriority</SHORT-NAME>
<DEFINITION-REF DEST="ECUC-PARAM-CONF-CONTAINER-DEF">
/AUTOSAR/Arti/ArtiOs/ArtiOsTaskInstance</DEFINITION-REF>
<...>
</ECUC-CONTAINER-VALUE>
<ECUC-CONTAINER-VALUE>
<SHORT-NAME>ArtiOsTaskInstance_TaskLowPriority</SHORT-NAME>
<DEFINITION-REF DEST="ECUC-PARAM-CONF-CONTAINER-DEF">
/AUTOSAR/Arti/ArtiOs/ArtiOsTaskInstance</DEFINITION-REF>
<...>

```

```

</ECUC-CONTAINER-VALUE>
</CONTAINERS>
</ECUC-MODULE-CONFIGURATION-VALUES>
  
```

#### 10.4.5 ArtiOsAlarmClass

##### [ECUC\_Arti\_00108] Definition of EcucParamConfContainerDef ArtiOsAlarm Class

Container Name	ArtiOsAlarmClass		
Parent Container	ArtiOs		
Description	Contains the layout of an ArtiOsAlarm object.		
Multiplicity	0..1		
Post-Build Variant Multiplicity	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
ArtiOsAlarmClassGenericComponentClassRef	0..1	[ECUC_Arti_00110]	
ArtiOsAlarmClassStateRef	0..1	[ECUC_Arti_00111]	

No Included Containers
------------------------

]

##### [ECUC\_Arti\_00110] Definition of EcucReferenceDef ArtiOsAlarmClassGeneric ComponentClassRef

Parameter Name	ArtiOsAlarmClassGenericComponentClassRef		
Parent Container	ArtiOsAlarmClass		
Description	Refers to an ArtiGenericComponentClass that extends the ArtiOsAlarmClass.		
Multiplicity	0..1		
Type	Reference to ArtiGenericComponentClass		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

## [ECUC\_Arti\_00111] Definition of EcucReferenceDef ArtiOsAlarmClassStateRef [

Parameter Name	ArtiOsAlarmClassStateRef		
Parent Container	ArtiOsAlarmClass		
Description	Refers to the ArtiObjectClassParameter that declares the attribute ArtiOsAlarmState Ref in ArtiOsAlarmInstances. This attribute specifies if an alarm is "RUNNING" or "STOPPED". The referred ArtiObjectClassParameter does include the mapping from integer to human readable "RUNNING" or "STOPPED".		
Multiplicity	0..1		
Type	Reference to ArtiObjectClassParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

## 10.4.6 ArtiOsAlarmInstance

### [ECUC\_Arti\_00109] Definition of EcucParamConfContainerDef ArtiOsAlarmInstance [

Container Name	ArtiOsAlarmInstance		
Parent Container	ArtiOs		
Description	Represents an instance of an ArtiOsAlarm object, extending the EcuC OsTaskAlarm.		
Multiplicity	0..*		
Post-Build Variant Multiplicity	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
ArtiOsAlarmInstanceAction	0..1	[ECUC_Arti_00112]	
ArtiOsAlarmInstanceCounter	0..1	[ECUC_Arti_00113]	
ArtiOsAlarmInstanceAlarmTimeRef	0..1	[ECUC_Arti_00156]	
ArtiOsAlarmInstanceCycleTimeRef	0..1	[ECUC_Arti_00114]	
ArtiOsAlarmInstanceEcuCRef	0..1	[ECUC_Arti_00115]	
ArtiOsAlarmInstanceGenericComponentInstanceRef	0..1	[ECUC_Arti_00116]	
ArtiOsAlarmInstanceStateRef	0..1	[ECUC_Arti_00117]	
ArtiOsAlarmInstanceValidRef	0..1	[ECUC_Arti_00118]	

### No Included Containers

]

**[ECUC\_Arti\_00112] Definition of EcucStringParamDef ArtiOsAlarmInstanceAction** [

Parameter Name	ArtiOsAlarmInstanceAction		
Parent Container	ArtiOsAlarmInstance		
Description	This attribute provides a string with a description of the action when the alarm expires, e.g. "ActivateTask TaskA".		
Multiplicity	0..1		
Type	EcucStringParamDef		
Default value	–		
Regular Expression	–		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	–	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	–	
Dependency			

]

**[ECUC\_Arti\_00113] Definition of EcucStringParamDef ArtiOsAlarmInstanceCounter** [

Parameter Name	ArtiOsAlarmInstanceCounter		
Parent Container	ArtiOsAlarmInstance		
Description	This attribute provides a string containing the name of the counter used by this alarm.		
Multiplicity	0..1		
Type	EcucStringParamDef		
Default value	–		
Regular Expression	–		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	–	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	–	
Dependency			

**[ECUC\_Arti\_00156] Definition of EcucReferenceDef ArtiOsAlarmInstanceAlarmTimeRef**

Parameter Name	ArtiOsAlarmInstanceAlarmTimeRef		
Parent Container	ArtiOsAlarmInstance		
Description	This attribute specifies how to evaluate the time until the alarm expires next. The time should be represented in seconds.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00114] Definition of EcucReferenceDef ArtiOsAlarmInstanceCycleTimeRef**

Parameter Name	ArtiOsAlarmInstanceCycleTimeRef		
Parent Container	ArtiOsAlarmInstance		
Description	This attribute specifies how to evaluate the cycle time for cyclic alarms. The value of "cycle time" is 0 for non-cyclic alarms. The time should be represented in seconds.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00115] Definition of EcucReferenceDef ArtiOsAlarmInstanceEcuCRef**

Parameter Name	ArtiOsAlarmInstanceEcuCRef		
Parent Container	ArtiOsAlarmInstance		
Description	Refers to an EcuC OsAlarm that is being extended.		
Multiplicity	0..1		
Type	Reference to OsAlarm		





<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

**[ECUC\_Arti\_00116] Definition of EcucReferenceDef ArtiOsAlarmInstance GenericComponentInstanceRef [**

<b>Parameter Name</b>	ArtiOsAlarmInstanceGenericComponentInstanceRef		
<b>Parent Container</b>	ArtiOsAlarmInstance		
<b>Description</b>	Refers to an ArtiGenericComponentInstance that extends the ArtiOsAlarmInstance.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiGenericComponentInstance		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

**[ECUC\_Arti\_00117] Definition of EcucReferenceDef ArtiOsAlarmInstanceState Ref [**

<b>Parameter Name</b>	ArtiOsAlarmInstanceStateRef		
<b>Parent Container</b>	ArtiOsAlarmInstance		
<b>Description</b>	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "state" of this alarm. The result then is mapped with the typemap of the ArtiOsAlarmStateRef of the ArtiOsAlarmClass.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiObjectInstanceParameter		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME



△

	Post-build time	–	
Dependency			

]

### [ECUC\_Arti\_00118] Definition of EcucReferenceDef ArtiOsAlarmInstanceValidRef

Parameter Name	ArtiOsAlarmInstanceValidRef		
Parent Container	<a href="#">ArtiOsAlarmInstance</a>		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "validity" of this alarm. Every object declaration may contain a VALID attribute telling the debugger whether the object's attributes are currently valid. It may have an integer type of any size. Its possible values are 0 (invalid) and non zero (object is valid).		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	–	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	–	
Dependency			

]

### 10.4.7 ArtiOsClass

#### [ECUC\_Arti\_00074] Definition of EcucParamConfContainerDef ArtiOsClass

Container Name	ArtiOsClass		
Parent Container	<a href="#">ArtiOs</a>		
Description	Contains the layout of an ARTI "Os" object, extending the EcuC OsOS.		
Multiplicity	0..1		
Post-Build Variant Multiplicity	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	–	
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
<a href="#">ArtiOsClassAppModeRef</a>	1	[ECUC_Arti_00072]	
<a href="#">ArtiOsClassGenericComponentRef</a>	0..1	[ECUC_Arti_00076]	
<a href="#">ArtiOsClassServiceTraceRef</a>	0..1	[ECUC_Arti_00097]	

No Included Containers
------------------------

## [ECUC\_Arti\_00072] Definition of EcucReferenceDef ArtiOsClassAppModeRef

Parameter Name	ArtiOsClassAppModeRef		
Parent Container	ArtiOsClass		
Description	Refers to the ArtiObjectClassParameter that defines the ArtiOsAppModelInstance parameter.		
Multiplicity	1		
Type	Reference to ArtiObjectClassParameter		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

## [ECUC\_Arti\_00076] Definition of EcucReferenceDef ArtiOsClassGenericComponentRef

Parameter Name	ArtiOsClassGenericComponentRef		
Parent Container	ArtiOsClass		
Description	Refers to an ArtiGenericComponentClass that extends the OS description.		
Multiplicity	0..1		
Type	Reference to ArtiGenericComponentClass		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

## [ECUC\_Arti\_00097] Definition of EcucReferenceDef ArtiOsClassServiceTraceRef

Parameter Name	ArtiOsClassServiceTraceRef		
Parent Container	ArtiOsClass		
Description	Refers to the ArtiObjectClassParameter that defines the ArtiOsInstanceServiceTrace parameter. This attribute indicates the entry or exit of a service routine and the ID of this service routine. The value of this attribute must be evaluated from one single memory location.		
Multiplicity	0..1		
Type	Reference to ArtiObjectClassParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		





<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

```

<ECUC-CONTAINER-VALUE>
<SHORT-NAME>ArtiOsClass_Conf</SHORT-NAME>
<DEFINITION-REF DEST="ECUC-PARAM-CONF-CONTAINER-DEF">/AUTOSAR/Arti/
ArtiOs/ArtiOsClass</DEFINITION-REF>
<REFERENCE-VALUES>
<ECUC-REFERENCE-VALUE>
<DEFINITION-REF DEST="ECUC-REFERENCE-DEF">/AUTOSAR/Arti/
ArtiOs/ArtiOsClass/ArtiOsClassAppModeRef</DEFINITION-REF>
<VALUE-REF DEST="ECUC-CONTAINER-VALUE">/Vendor1/Vendor1Arti/
ArtiObjectClassParameter_ArtiOs_OsAppMode</VALUE-REF>
</ECUC-REFERENCE-VALUE>
</REFERENCE-VALUES>
</ECUC-CONTAINER-VALUE>

```

#### 10.4.8 ArtiOsContextClass

##### [ECUC\_Arti\_00119] Definition of EcucParamConfContainerDef ArtiOsContext Class

<b>Container Name</b>	ArtiOsContextClass		
<b>Parent Container</b>	ArtiOs		
<b>Description</b>	Contains the layout of an ARTI "OsContext" object.		
<b>Multiplicity</b>	0..1		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Configuration Parameters</b>			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
ArtiOsContextClassGenericComponentClassRef	0..1	[ECUC_Arti_00121]	

No Included Containers
------------------------

]

## [ECUC\_Arti\_00121] Definition of EcucReferenceDef ArtiOsContextClassGenericComponentClassRef

Parameter Name	ArtiOsContextClassGenericComponentClassRef		
Parent Container	ArtiOsContextClass		
Description	Refers to an ArtiGenericComponentClass that extends the ArtiOsContextClass.		
Multiplicity	0..1		
Type	Reference to ArtiGenericComponentClass		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

### 10.4.9 ArtiOsContextInstance

## [ECUC\_Arti\_00120] Definition of EcucParamConfContainerDef ArtiOsContextInstance

Container Name	ArtiOsContextInstance		
Parent Container	ArtiOs		
Description	Represents an instance of an "ArtiContext" object.		
Multiplicity	0..*		
Post-Build Variant Multiplicity	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
ArtiOsContextInstanceAddressRef	0..1	[ECUC_Arti_00122]	
ArtiOsContextInstanceGenericComponentInstanceRef	0..1	[ECUC_Arti_00123]	
ArtiOsContextInstanceSizeRef	0..1	[ECUC_Arti_00124]	
ArtiOsContextInstanceValidRef	0..1	[ECUC_Arti_00125]	

No Included Containers
------------------------

]

**[ECUC\_Arti\_00122] Definition of EcucReferenceDef ArtiOsContextInstanceAddressRef** [

Parameter Name	ArtiOsContextInstanceAddressRef		
Parent Container	ArtiOsContextInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "address" of this context.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]  
**[ECUC\_Arti\_00123] Definition of EcucReferenceDef ArtiOsContextInstanceGenericComponentInstanceRef** [

Parameter Name	ArtiOsContextInstanceGenericComponentInstanceRef		
Parent Container	ArtiOsContextInstance		
Description	Refers to an ArtiGenericComponentInstance that extends the ArtiOsContext.		
Multiplicity	0..1		
Type	Reference to ArtiGenericComponentInstance		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]  
**[ECUC\_Arti\_00124] Definition of EcucReferenceDef ArtiOsContextInstanceSizeRef** [

Parameter Name	ArtiOsContextInstanceSizeRef		
Parent Container	ArtiOsContextInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "size" of this context.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		





<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

**[ECUC\_Arti\_00125] Definition of EcucReferenceDef ArtiOsContextInstanceValidRef** [

<b>Parameter Name</b>	ArtiOsContextInstanceValidRef		
<b>Parent Container</b>	ArtiOsContextInstance		
<b>Description</b>	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "validity" of this context. Every object declaration may contain a VALID attribute telling the debugger whether the object's attributes are currently valid. It may have an integer type of any size. Its possible values are 0 (invalid) and non zero (object is valid).		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiObjectInstanceParameter		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

#### 10.4.10 ArtiOsInstance

**[ECUC\_Arti\_00080] Definition of EcucParamConfContainerDef ArtiOsInstance** [

<b>Container Name</b>	ArtiOsInstance		
<b>Parent Container</b>	ArtiOs		
<b>Description</b>	Represents an instance of an ARTI "Os" object, extending the EcuC OsOS.		
<b>Multiplicity</b>	0..1		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	




**Configuration Parameters**

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
ArtiOsInstanceAppModeRef	1	[ECUC_Arti_00073]
ArtiOsInstanceEcucRef	1	[ECUC_Arti_00075]
ArtiOsInstanceGenericComponentRef	0..1	[ECUC_Arti_00078]
ArtiOsInstanceHookRef	0..*	[ECUC_Arti_00079]
ArtiOsInstanceServiceTraceRef	0..1	[ECUC_Arti_00098]
ArtiOsInstanceValidRef	0..1	[ECUC_Arti_00099]

**No Included Containers**

**[ECUC\_Arti\_00073] Definition of EcucReferenceDef ArtiOsInstanceAppModeRef**


Parameter Name	ArtiOsInstanceAppModeRef		
Parent Container	ArtiOsInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "application mode" of this OS.		
Multiplicity	1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			


**[ECUC\_Arti\_00075] Definition of EcucReferenceDef ArtiOsInstanceEcucRef**

Parameter Name	ArtiOsInstanceEcucRef		
Parent Container	ArtiOsInstance		
Description	Refers to the EcucDefs/Os/OsOS of this OS.		
Multiplicity	1		
Type	Reference to OsOS		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			



**[ECUC\_Arti\_00078] Definition of EcucReferenceDef ArtiOsInstanceGenericComponentRef**

Parameter Name	ArtiOsInstanceGenericComponentRef		
Parent Container	ArtiOsInstance		
Description	Refers to an ArtiGenericComponentInstance that extends the OS.		
Multiplicity	0..1		
Type	Reference to ArtiGenericComponentInstance		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

**[ECUC\_Arti\_00079] Definition of EcucReferenceDef ArtiOsInstanceHookRef**

Parameter Name	ArtiOsInstanceHookRef		
Parent Container	ArtiOsInstance		
Description	Refers to a hook defined in the OS.		
Multiplicity	0..*		
Type	Reference to ArtiHook		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

**[ECUC\_Arti\_00098] Definition of EcucReferenceDef ArtiOsInstanceServiceTraceRef**

Parameter Name	ArtiOsInstanceServiceTraceRef		
Parent Container	ArtiOsInstance		
Description	Refers to a hook defined in the OS.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL





	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
Dependency			

]

### [ECUC\_Arti\_00099] Definition of EcucReferenceDef ArtiOsInstanceValidRef

Parameter Name	ArtiOsInstanceValidRef		
Parent Container	ArtiOsInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "validity" of this ArtiOsInstance. Every object declaration may contain a VALID attribute telling the debugger whether the object's attributes are currently valid. It may have an integer type of any size. Its possible values are 0 (invalid) and non zero (object is valid).		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

```

<ECUC-CONTAINER-VALUE>
<SHORT-NAME>ArtiOsInstance_Conf</SHORT-NAME>
<DEFINITION-REF DEST="ECUC-PARAM-CONF-CONTAINER-DEF">/AUTOSAR/Arti/
ArtiOs/ArtiOsInstance</DEFINITION-REF>
<REFERENCE-VALUES>
<ECUC-REFERENCE-VALUE>
<DEFINITION-REF DEST="ECUC-REFERENCE-DEF">/AUTOSAR/Arti/
ArtiOs/ArtiOsInstance/ArtiOsInstanceAppModeRef</DEFINITION-REF>
<VALUE-REF DEST="ECUC-CONTAINER-VALUE">/Vendor1/Vendor1Arti/
ArtiObjectInstanceParameter_OsAppMode</VALUE-REF>
</ECUC-REFERENCE-VALUE>
<ECUC-REFERENCE-VALUE>
<DEFINITION-REF DEST="ECUC-REFERENCE-DEF">/AUTOSAR/Arti/
ArtiOs/ArtiOsInstance/ArtiOsInstanceEcucRef</DEFINITION-REF>
<VALUE-REF DEST="ECUC-CONTAINER-VALUE">/Vendor1/Vendor1EcucOs/
Vendor1Os</VALUE-REF>
</ECUC-REFERENCE-VALUE>
<ECUC-REFERENCE-VALUE>
<DEFINITION-REF DEST="ECUC-REFERENCE-DEF">/AUTOSAR/Arti/
ArtiOs/ArtiOsInstance/ArtiOsInstanceHookRef</DEFINITION-REF>
<VALUE-REF DEST="ECUC-CONTAINER-VALUE">/Vendor1/Vendor1Arti/
ArtiHook_ArtiOs_TaskStart</VALUE-REF>
</ECUC-REFERENCE-VALUE>

```

```

<ECUC-REFERENCE-VALUE>
<DEFINITION-REF DEST="ECUC-REFERENCE-DEF">/AUTOSAR/Arti/
ArtiOs/ArtiOsInstance/ArtiOsInstanceHookRef</DEFINITION-REF>
<VALUE-REF DEST="ECUC-CONTAINER-VALUE">/Vendor1/Vendor1Arti/
ArtiHook_ArtiOs_TaskStop</VALUE-REF>
</ECUC-REFERENCE-VALUE>
</REFERENCE-VALUES>
</ECUC-CONTAINER-VALUE>
  
```

#### 10.4.11 ArtiOsIsrClass

##### [ECUC\_Arti\_00081] Definition of EcucParamConfContainerDef ArtiOsIsrClass [

Container Name	ArtiOsIsrClass		
Parent Container	ArtiOs		
Description	Contains the layout of an ARTI "OsIsr" object, extending the EcuC OsIsr.		
Multiplicity	0..1		
Post-Build Variant Multiplicity	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Configuration Parameters			
Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
ArtiOsIsrClassGenericComponentRef	0..1	[ECUC_Arti_00084]	
No Included Containers			

##### [ECUC\_Arti\_00084] Definition of EcucReferenceDef ArtiOsIsrClassGenericComponentRef [

Parameter Name	ArtiOsIsrClassGenericComponentRef		
Parent Container	ArtiOsIsrClass		
Description	Refers to an optional ArtiGenericComponentClass that extends the OsIsr with additional parameters.		
Multiplicity	0..1		
Type	Reference to ArtiGenericComponentClass		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME





Dependency	Post-build time	–	
------------	-----------------	---	--



#### 10.4.12 ArtiOsIsrInstance

##### [ECUC\_Arti\_00086] Definition of EcucParamConfContainerDef ArtiOsIsrInstance



Container Name	ArtiOsIsrInstance		
Parent Container	ArtiOs		
Description	Represents an instance of an ARTI "OsIsr" object, extending the EcuC OsIsr.		
Multiplicity	0..*		
Post-Build Variant Multiplicity	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	–	
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
ArtiOsIsrInstanceCategory	0..1	[ECUC_Arti_00174]	
ArtiOsIsrInstanceFunction	0..1	[ECUC_Arti_00083]	
ArtiOsIsrInstanceld	1	[ECUC_Arti_00093]	
ArtiOsIsrInstanceEcucRef	0..1	[ECUC_Arti_00082]	
ArtiOsIsrInstanceGenericComponentRef	0..1	[ECUC_Arti_00085]	
ArtiOsIsrInstanceTimingProtectionLastTimeFrameRef	0..1	[ECUC_Arti_00211]	
ArtiOsIsrInstanceTimingProtectionUsedBudgetRef	0..1	[ECUC_Arti_00212]	
ArtiOsIsrInstanceValidRef	0..1	[ECUC_Arti_00157]	

No Included Containers
------------------------



##### [ECUC\_Arti\_00174] Definition of EcucEnumerationParamDef ArtiOsIsrInstance Category

Parameter Name	ArtiOsIsrInstanceCategory	
Parent Container	ArtiOsIsrInstance	
Description	Specifies category of this ISR. If omitted the instance is related to a CATEGORY_2.	
Multiplicity	0..1	
Type	EcucEnumerationParamDef	
Range	CATEGORY_1	–
	CATEGORY_2	–



△

Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00083] Definition of EcucFunctionNameDef ArtiOslsrlInstanceFunction** [

Parameter Name	ArtiOslsrlInstanceFunction		
Parent Container	ArtiOslsrlInstance		
Description	This parameter represents the C function name of the ISR routine.		
Multiplicity	0..1		
Type	EcucFunctionNameDef		
Default value	—		
Regular Expression	—		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00093] Definition of EcucIntegerParamDef ArtiOslsrlInstanceld** [

Parameter Name	ArtiOslsrlInstanceld		
Parent Container	ArtiOslsrlInstance		
Description	This parameter represents the "ISRID" as given by the OS, returned by GetISRID().		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	0 .. 18446744073709551615		
Default value	—		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

**[ECUC\_Arti\_00082] Definition of EcucReferenceDef ArtiOsIsrInstanceEcucRef**

Parameter Name	ArtiOsIsrInstanceEcucRef		
Parent Container	<a href="#">ArtiOsIsrInstance</a>		
Description	Refers to the EcucDefs/Os/OsIsr of this ISR.		
Multiplicity	0..1		
Type	Reference to <a href="#">OsIsr</a>		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

**[ECUC\_Arti\_00085] Definition of EcucReferenceDef ArtiOsIsrInstanceGenericComponentRef**

Parameter Name	ArtiOsIsrInstanceGenericComponentRef		
Parent Container	<a href="#">ArtiOsIsrInstance</a>		
Description	Refers to an optional ArtiGenericComponentInstance that extends this OsIsr with additional parameters.		
Multiplicity	0..1		
Type	Reference to <a href="#">ArtiGenericComponentInstance</a>		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

**[ECUC\_Arti\_00211] Definition of EcucReferenceDef ArtiOsIsrInstanceTimingProtectionLastTimeFrameRef**

Parameter Name	ArtiOsIsrInstanceTimingProtectionLastTimeFrameRef		
Parent Container	<a href="#">ArtiOsIsrInstance</a>		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the last time frame related to the OsIsr/OsIsrTimingProtection configuration.		
Multiplicity	0..1		
Type	Reference to <a href="#">ArtiObjectInstanceParameter</a>		
Post-Build Variant Multiplicity	false		





Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			



### [ECUC\_Arti\_00212] Definition of EcucReferenceDef ArtiOsIsrInstanceTimingProtectionUsedBudgetRef

Parameter Name	ArtiOsIsrInstanceTimingProtectionUsedBudgetRef		
Parent Container	ArtiOsIsrInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the used budget related to the OsIsr/OsIsrTimingProtection configuration.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			



### [ECUC\_Arti\_00157] Definition of EcucReferenceDef ArtiOsIsrInstanceValidRef

Parameter Name	ArtiOsIsrInstanceValidRef		
Parent Container	ArtiOsIsrInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "validity" of this ArtiOsIsrInstance. Every object declaration may contain a VALID attribute telling the debugger whether the object's attributes are currently valid. It may have an integer type of any size. Its possible values are 0 (invalid) and non zero (object is valid).		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME





	Post-build time	—	
Dependency			

]

#### 10.4.13 ArtiOsMessageContainerClass

##### [ECUC\_Arti\_00126] Definition of EcucParamConfContainerDef ArtiOsMessageContainerClass [

Container Name	ArtiOsMessageContainerClass		
Parent Container	ArtiOs		
Description	Contains the layout of an ARTI "OsMessageContainer" object. The "OsMessageContainer" object represents an existing combination of OSEK messages.		
Multiplicity	0..1		
Post-Build Variant Multiplicity	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
ArtiOsMessageContainerClassGenericComponentClassRef	0..1	[ECUC_Arti_00128]	

No Included Containers
------------------------

]

##### [ECUC\_Arti\_00128] Definition of EcucReferenceDef ArtiOsMessageContainerClassGenericComponentClassRef [

Parameter Name	ArtiOsMessageContainerClassGenericComponentClassRef		
Parent Container	ArtiOsMessageContainerClass		
Description	Refers to an ArtiGenericComponentClass that extends the ArtiOsMessageContainer Class.		
Multiplicity	0..1		
Type	Reference to ArtiGenericComponentClass		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME





	Post-build time	–	
Dependency			

]

#### 10.4.14 ArtiOsMessageContainerInstance

##### [ECUC\_Arti\_00127] Definition of EcucParamConfContainerDef ArtiOsMessageContainerInstance [

Container Name	ArtiOsMessageContainerInstance		
Parent Container	ArtiOs		
Description	Represents an instance of an "ArtiMessageContainer" object.		
Multiplicity	0..*		
Post-Build Variant Multiplicity	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	–	
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
ArtiOsMessageContainerInstanceMsgName	0..1	[ECUC_Arti_00129]	
ArtiOsMessageContainerInstanceMsgType	0..1	[ECUC_Arti_00130]	
ArtiOsMessageContainerInstanceFirstElementRef	0..1	[ECUC_Arti_00131]	
ArtiOsMessageContainerInstanceGenericComponentInstanceRef	0..1	[ECUC_Arti_00132]	
ArtiOsMessageContainerInstanceQueueCountRef	0..1	[ECUC_Arti_00133]	
ArtiOsMessageContainerInstanceQueueSizeRef	0..1	[ECUC_Arti_00134]	
ArtiOsMessageContainerInstanceValidRef	0..1	[ECUC_Arti_00135]	

No Included Containers
------------------------

]

##### [ECUC\_Arti\_00129] Definition of EcucStringParamDef ArtiOsMessageContainerInstanceMsgName [

Parameter Name	ArtiOsMessageContainerInstanceMsgName
Parent Container	ArtiOsMessageContainerInstance
Description	This attribute provides the name of the message as defined in OIL file.
Multiplicity	0..1
Type	EcucStringParamDef
Default value	–
Regular Expression	–





<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

**[ECUC\_Arti\_00130] Definition of EcucStringParamDef ArtiOsMessageContainerInstanceMsgType** [

<b>Parameter Name</b>	ArtiOsMessageContainerInstanceMsgType		
<b>Parent Container</b>	<a href="#">ArtiOsMessageContainerInstance</a>		
<b>Description</b>	This attribute provides the type of the message.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	EcucStringParamDef		
<b>Default value</b>	—		
<b>Regular Expression</b>	—		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

**[ECUC\_Arti\_00131] Definition of EcucReferenceDef ArtiOsMessageContainerInstanceFirstElementRef** [

<b>Parameter Name</b>	ArtiOsMessageContainerInstanceFirstElementRef		
<b>Parent Container</b>	<a href="#">ArtiOsMessageContainerInstance</a>		
<b>Description</b>	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "firstelement" of this "ArtiOsMessageContainer". This attribute provides the formula for evaluation of address of first valid message. This message will be received next. If no message is in the queue the value is zero.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiObjectInstanceParameter		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME



△

	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

**[ECUC\_Arti\_00132] Definition of EcucReferenceDef ArtiOsMessageContainerInstanceGenericComponentInstanceRef** [

<b>Parameter Name</b>	ArtiOsMessageContainerInstanceGenericComponentInstanceRef		
<b>Parent Container</b>	ArtiOsMessageContainerInstance		
<b>Description</b>	Refers to an ArtiGenericComponentInstance that extends the ArtiOsMessageContainer Instance.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiGenericComponentInstance		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

**[ECUC\_Arti\_00133] Definition of EcucReferenceDef ArtiOsMessageContainerInstanceQueueCountRef** [

<b>Parameter Name</b>	ArtiOsMessageContainerInstanceQueueCountRef		
<b>Parent Container</b>	ArtiOsMessageContainerInstance		
<b>Description</b>	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "queuecount" of this "ArtiOsMessageContainer". This attribute provides the number of valid messages in the queue and "1" for unqueued messages.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiObjectInstanceParameter		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

**[ECUC\_Arti\_00134] Definition of EcucReferenceDef ArtiOsMessageContainerInstanceQueueSizeRef**

Parameter Name	ArtiOsMessageContainerInstanceQueueSizeRef		
Parent Container	ArtiOsMessageContainerInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "queuesize" of this "ArtiOsMessageContainer". This attribute provides the size of the queue for queued messages and "1" for unqueued messages.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00135] Definition of EcucReferenceDef ArtiOsMessageContainerInstanceValidRef**

Parameter Name	ArtiOsMessageContainerInstanceValidRef		
Parent Container	ArtiOsMessageContainerInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "validity" of this ArtiOsMessageContainerInstance. Every object declaration may contain a VALID attribute telling the debugger whether the object's attributes are currently valid. It may have an integer type of any size. Its possible values are 0 (invalid) and non zero (object is valid).		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

#### 10.4.15 ArtiOsResourceClass

**[ECUC\_Arti\_00136] Definition of EcucParamConfContainerDef ArtiOsResource Class**

<b>Container Name</b>	ArtiOsResourceClass		
<b>Parent Container</b>	<a href="#">ArtiOs</a>		
<b>Description</b>	Contains the layout of an ArtiOsResource object. The ArtiOsResource object represents an OSEK resource.		
<b>Multiplicity</b>	0..1		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Configuration Parameters</b>			

<b>Included Parameters</b>
<b>Parameter Name</b>
<a href="#">ArtiOsResourceClassGenericComponentClassRef</a>
0..1
<a href="#">ArtiOsResourceClassLockerRef</a>
0..1
<a href="#">ArtiOsResourceClassStateRef</a>
0..1
<b>ECUC ID</b>
<a href="#">[ECUC_Arti_00138]</a>
<a href="#">[ECUC_Arti_00139]</a>
<a href="#">[ECUC_Arti_00140]</a>

No Included Containers

]

**[ECUC\_Arti\_00138] Definition of EcucReferenceDef ArtiOsResourceClass GenericComponentClassRef** [

<b>Parameter Name</b>	ArtiOsResourceClassGenericComponentClassRef		
<b>Parent Container</b>	<a href="#">ArtiOsResourceClass</a>		
<b>Description</b>	Refers to an ArtiGenericComponentClass that extends the ArtiOsResourceClass.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiGenericComponentClass		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

**[ECUC\_Arti\_00139] Definition of EcucReferenceDef ArtiOsResourceClassLocker Ref** [

<b>Parameter Name</b>	ArtiOsResourceClassLockerRef		
<b>Parent Container</b>	<a href="#">ArtiOsResourceClass</a>		
<b>Description</b>	Refers to the ArtiObjectClassParameter that declares the attribute ArtiOsResource LockerRef in ArtiOsResourceInstances. This attribute indicates the locking ArtiOsTask Instance or ArtiOsIsrInstance.		





<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiObjectClassParameter		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			



### [ECUC\_Arti\_00140] Definition of EcucReferenceDef ArtiOsResourceClassState Ref

<b>Parameter Name</b>	ArtiOsResourceClassStateRef		
<b>Parent Container</b>	ArtiOsResourceClass		
<b>Description</b>	Refers to the ArtiObjectClassParameter that declares the attribute ArtiOsResource StateRef in ArtiOsResourceInstances. This attribute represents the state of a resource ("LOCKED"/"UNLOCKED"). The ArtiObjectClassParameter does include the mapping from integer to human readable "LOCKED" or "UNLOCKED".		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiObjectClassParameter		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			



#### 10.4.16 ArtiOsResourceInstance

### [ECUC\_Arti\_00137] Definition of EcucParamConfContainerDef ArtiOsResource Instance

<b>Container Name</b>	ArtiOsResourceInstance		
<b>Parent Container</b>	ArtiOs		
<b>Description</b>	Represents an instance of an ArtiOsResource object.		
<b>Multiplicity</b>	0..*		



△

<b>Post-Build Variant Multiplicity</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Configuration Parameters</b>			

<b>Included Parameters</b>
<b>Parameter Name</b>
ArtiOsResourceInstancePriority
0..1
[ECUC_Arti_00141]
ArtiOsResourceInstanceEcuCRef
0..1
[ECUC_Arti_00142]
ArtiOsResourceInstanceGenericComponentInstanceRef
0..1
[ECUC_Arti_00143]
ArtiOsResourceInstanceLockerRef
0..1
[ECUC_Arti_00145]
ArtiOsResourceInstanceStateRef
0..1
[ECUC_Arti_00144]
ArtiOsResourceInstanceValidRef
0..1
[ECUC_Arti_00146]

No Included Containers

]

## [ECUC\_Arti\_00141] Definition of EcucStringParamDef ArtiOsResourceInstancePriority

<b>Parameter Name</b>	ArtiOsResourceInstancePriority		
<b>Parent Container</b>	ArtiOsResourceInstance		
<b>Description</b>	This attribute has two components that state: that the RESOURCE is used by TASKs only or by TASKs and ISRs, and the priority that will be used when locking the RESOURCE.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	EcucStringParamDef		
<b>Default value</b>	—		
<b>Regular Expression</b>	—		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

**[ECUC\_Arti\_00142] Definition of EcucReferenceDef ArtiOsResourceInstanceEcuCRef** [

Parameter Name	ArtiOsResourceInstanceEcuCRef		
Parent Container	ArtiOsResourceInstance		
Description	Refers to an EcuC OsResource that is being extended.		
Multiplicity	0..1		
Type	Reference to OsResource		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00143] Definition of EcucReferenceDef ArtiOsResourceInstanceGenericComponentInstanceRef** [

Parameter Name	ArtiOsResourceInstanceGenericComponentInstanceRef		
Parent Container	ArtiOsResourceInstance		
Description	Refers to an ArtiGenericComponentInstance that extends the ArtiOsResourceInstance.		
Multiplicity	0..1		
Type	Reference to ArtiGenericComponentInstance		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00145] Definition of EcucReferenceDef ArtiOsResourceInstanceLockerRef** [

Parameter Name	ArtiOsResourceInstanceLockerRef		
Parent Container	ArtiOsResourceInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "locker" of this ArtiOsResource.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		





<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			



### [ECUC\_Arti\_00144] Definition of EcucReferenceDef ArtiOsResourceInstance StateRef

<b>Parameter Name</b>	ArtiOsResourceInstanceStateRef		
<b>Parent Container</b>	ArtiOsResourceInstance		
<b>Description</b>	Refers to the ArtiObjectInstanceStateParameter that contains the evaluation for the "state" of this ArtiOsResource.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiObjectInstanceStateParameter		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			



### [ECUC\_Arti\_00146] Definition of EcucReferenceDef ArtiOsResourceInstance ValidRef

<b>Parameter Name</b>	ArtiOsResourceInstanceValidRef		
<b>Parent Container</b>	ArtiOsResourceInstance		
<b>Description</b>	Refers to the ArtiObjectInstanceStateParameter that contains the evaluation for the "validity" of this ArtiOsResourceInstance. Every object declaration may contain a VALID attribute telling the debugger whether the object's attributes are currently valid. It may have an integer type of any size. Its possible values are 0 (invalid) and non zero (object is valid).		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiObjectInstanceStateParameter		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL



△

	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

#### 10.4.17 ArtiOsScheduleTableClass

##### [ECUC\_Arti\_00182] Definition of EcucParamConfContainerDef ArtiOsScheduleTableClass

Container Name	ArtiOsScheduleTableClass		
Parent Container	ArtiOs		
Description	Contains the layout of an ArtiOsScheduleTable object.		
Multiplicity	0..1		
Post-Build Variant Multiplicity	false		
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
ArtiOsScheduleTableClassCurrentStateRef	0..1	[ECUC_Arti_00184]	
ArtiOsScheduleTableClassGenericComponentClassRef	0..1	[ECUC_Arti_00183]	

No Included Containers

]

##### [ECUC\_Arti\_00184] Definition of EcucReferenceDef ArtiOsScheduleTableClass CurrentStateRef

Parameter Name	ArtiOsScheduleTableClassCurrentStateRef		
Parent Container	ArtiOsScheduleTableClass		
Description	Refers to the ArtiObjectClassParameter that defines the ArtiCurrentScheduleTable StateInstance parameter including the state mapping.		
Multiplicity	0..1		
Type	Reference to ArtiObjectClassParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00183] Definition of EcucReferenceDef ArtiOsScheduleTableClass GenericComponentClassRef** ↗

Parameter Name	ArtiOsScheduleTableClassGenericComponentClassRef		
Parent Container	ArtiOsScheduleTableClass		
Description	Refers to an ArtiGenericComponentClass that extends the ArtiOsScheduleTableClass.		
Multiplicity	0..1		
Type	Reference to ArtiGenericComponentClass		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

#### 10.4.18 ArtiOsScheduleTableInstance

**[ECUC\_Arti\_00185] Definition of EcucParamConfContainerDef ArtiOsScheduleTableInstance** ↗

Container Name	ArtiOsScheduleTableInstance		
Parent Container	ArtiOs		
Description	Represents an instance of an ArtiOsScheduleTable object, extending the EcuC Os ScheduleTable.		
Multiplicity	0..*		
Post-Build Variant Multiplicity	false		
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
ArtiOsScheduleTableInstanceCoreRef	0..1	[ECUC_Arti_00186]	
ArtiOsScheduleTableInstanceCounterValueRef	0..1	[ECUC_Arti_00187]	
ArtiOsScheduleTableInstanceCurrentStateRef	0..1	[ECUC_Arti_00188]	
ArtiOsScheduleTableInstanceEcucRef	0..1	[ECUC_Arti_00189]	
ArtiOsScheduleTableInstanceExpiryTimeRef	0..1	[ECUC_Arti_00190]	
ArtiOsScheduleTableInstanceGenericComponentInstanceRef	0..1	[ECUC_Arti_00191]	
ArtiOsScheduleTableInstanceNextEventRef	0..1	[ECUC_Arti_00224]	
ArtiOsScheduleTableInstanceNextExpiryPointRef	0..1	[ECUC_Arti_00192]	
ArtiOsScheduleTableInstanceNextScheduleTableRef	0..1	[ECUC_Arti_00193]	

No Included Containers
------------------------

]

**[ECUC\_Arti\_00186] Definition of EcucReferenceDef ArtiOsScheduleTableInstanceCoreRef**

Parameter Name	ArtiOsScheduleTableInstanceCoreRef		
Parent Container	ArtiOsScheduleTableInstance		
Description	Refers to the ArtiHardwareCoreInstance on which this OsScheduleTable runs.		
Multiplicity	0..1		
Type	Reference to ArtiHardwareCoreInstance		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00187] Definition of EcucReferenceDef ArtiOsScheduleTableInstanceCounterValueRef**

Parameter Name	ArtiOsScheduleTableInstanceCounterValueRef		
Parent Container	ArtiOsScheduleTableInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the absolute counter value.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00188] Definition of EcucReferenceDef ArtiOsScheduleTableInstanceStateRef**

Parameter Name	ArtiOsScheduleTableInstanceStateRef		
Parent Container	ArtiOsScheduleTableInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "current state" of this OsScheduleTable.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		





Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00189] Definition of EcucReferenceDef ArtiOsScheduleTableInstanceEcucRef**

Parameter Name	ArtiOsScheduleTableInstanceEcucRef		
Parent Container	ArtiOsScheduleTableInstance		
Description	Refers to an EcuC OsScheduleTable that is being extended.		
Multiplicity	0..1		
Type	Reference to <a href="#">OsScheduleTable</a>		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00190] Definition of EcucReferenceDef ArtiOsScheduleTableInstanceExpiryTimeRef**

Parameter Name	ArtiOsScheduleTableInstanceExpiryTimeRef		
Parent Container	ArtiOsScheduleTableInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the expiry time.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	





Dependency			
------------	--	--	--

]

**[ECUC\_Arti\_00191] Definition of EcucReferenceDef ArtiOsScheduleTableInstanceGenericComponentInstanceRef** [

Parameter Name	ArtiOsScheduleTableInstanceGenericComponentInstanceRef		
Parent Container	ArtiOsScheduleTableInstance		
Description	Refers to an ArtiGenericComponentInstance that extends the ArtiOsScheduleTable Instance.		
Multiplicity	0..1		
Type	Reference to ArtiGenericComponentInstance		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00224] Definition of EcucReferenceDef ArtiOsScheduleTableInstanceNextEventRef** [

Parameter Name	ArtiOsScheduleTableInstanceNextEventRef		
Parent Container	ArtiOsScheduleTableInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "next event".		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00192] Definition of EcucReferenceDef ArtiOsScheduleTableInstanceNextExpiryPointRef**

Parameter Name	ArtiOsScheduleTableInstanceNextExpiryPointRef		
Parent Container	ArtiOsScheduleTableInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "next expiry point".		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00193] Definition of EcucReferenceDef ArtiOsScheduleTableInstanceNextScheduleTableRef**

Parameter Name	ArtiOsScheduleTableInstanceNextScheduleTableRef		
Parent Container	ArtiOsScheduleTableInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "next schedule table".		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

#### 10.4.19 ArtiOsSpinlockClass

**[ECUC\_Arti\_00194] Definition of EcucParamConfContainerDef ArtiOsSpinlockClass**

<b>Container Name</b>	ArtiOsSpinlockClass
<b>Parent Container</b>	ArtiOs
<b>Description</b>	Contains the layout of an ArtiOsSpinlock object.
<b>Multiplicity</b>	0..1
<b>Post-Build Variant Multiplicity</b>	false
<b>Configuration Parameters</b>	

<b>Included Parameters</b>		
<b>Parameter Name</b>	<b>Multiplicity</b>	<b>ECUC ID</b>
ArtiOsScheduleTableClassGenericComponentClassRef	0..1	[ECUC_Arti_00195]
ArtiOsSpinlockClassCurrentOwnerTypeRef	0..1	[ECUC_Arti_00197]
ArtiOsSpinlockClassCurrentStateRef	0..1	[ECUC_Arti_00196]

<b>No Included Containers</b>
-------------------------------

]

### [ECUC\_Arti\_00195] Definition of EcucReferenceDef ArtiOsScheduleTableClass GenericComponentClassRef [

<b>Parameter Name</b>	ArtiOsScheduleTableClassGenericComponentClassRef		
<b>Parent Container</b>	ArtiOsSpinlockClass		
<b>Description</b>	Refers to an ArtiGenericComponentClass that extends the ArtiOsSpinlockClass.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiGenericComponentClass		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
<b>Value Configuration Class</b>	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
<b>Dependency</b>			

]

### [ECUC\_Arti\_00197] Definition of EcucReferenceDef ArtiOsSpinlockClassCurrent OwnerTypeRef [

<b>Parameter Name</b>	ArtiOsSpinlockClassCurrentOwnerTypeRef		
<b>Parent Container</b>	ArtiOsSpinlockClass		
<b>Description</b>	Refers to the ArtiObjectClassParameter that defines the ArtiCurrentSpinlockOwner TypeInstance parameter including the type mapping.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiObjectClassParameter		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		



△

<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

### [ECUC\_Arti\_00196] Definition of EcucReferenceDef ArtiOsSpinlockClassCurrentStateRef

<b>Parameter Name</b>	ArtiOsSpinlockClassCurrentStateRef		
<b>Parent Container</b>	ArtiOsSpinlockClass		
<b>Description</b>	Refers to the ArtiObjectClassParameter that defines the ArtiCurrentSpinlockState Instance parameter including the state mapping.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiObjectClassParameter		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	—	
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

### 10.4.20 ArtiOsSpinlockInstance

### [ECUC\_Arti\_00198] Definition of EcucParamConfContainerDef ArtiOsSpinlockInstance

<b>Container Name</b>	ArtiOsSpinlockInstance		
<b>Parent Container</b>	ArtiOs		
<b>Description</b>	Represents an instance of an ArtiOsSpinlock object, extending the EcuC OsSpinlock.		
<b>Multiplicity</b>	0..*		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Configuration Parameters</b>			

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
ArtiOsSpinlockInstanceCurrentOwnerRef	0..1	[ECUC_Arti_00199]
ArtiOsSpinlockInstanceCurrentOwnerTypeRef	0..1	[ECUC_Arti_00200]
ArtiOsSpinlockInstanceCurrentStateRef	0..1	[ECUC_Arti_00201]
ArtiOsSpinlockInstanceEcuCRef	0..1	[ECUC_Arti_00202]
ArtiOsSpinlockInstanceGenericComponentInstanceRef	0..1	[ECUC_Arti_00203]
ArtiOsSpinlockInstanceLockingCoreRef	0..1	[ECUC_Arti_00204]

## No Included Containers

## [ECUC\_Arti\_00199] Definition of EcucReferenceDef ArtiOsSpinlockInstanceCurrentOwnerRef

Parameter Name	ArtiOsSpinlockInstanceCurrentOwnerRef		
Parent Container	ArtiOsSpinlockInstance		
Description	Refers to the ArtiObjectInstanceStateParameter that contains the evaluation for the owner ID (task or ISR2).		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceStateParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

## [ECUC\_Arti\_00200] Definition of EcucReferenceDef ArtiOsSpinlockInstanceCurrentOwnerTypeRef

Parameter Name	ArtiOsSpinlockInstanceCurrentOwnerTypeRef		
Parent Container	ArtiOsSpinlockInstance		
Description	Refers to the ArtiObjectInstanceStateParameter that contains the evaluation for the "current owner type" of this OsSpinlock.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceStateParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants



△

	Link time	—	
	Post-build time	—	
Dependency			

]

### [ECUC\_Arti\_00201] Definition of EcucReferenceDef ArtiOsSpinlockInstanceCurrentStateRef

Parameter Name	ArtiOsSpinlockInstanceCurrentStateRef		
Parent Container	ArtiOsSpinlockInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "current state" of this OsSpinlock.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

### [ECUC\_Arti\_00202] Definition of EcucReferenceDef ArtiOsSpinlockInstanceEcuCRef

Parameter Name	ArtiOsSpinlockInstanceEcuCRef		
Parent Container	ArtiOsSpinlockInstance		
Description	Refers to an EcuC OsSpinlock that is being extended.		
Multiplicity	0..1		
Type	Reference to OsSpinlock		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00203] Definition of EcucReferenceDef ArtiOsSpinlockInstance GenericComponentInstanceRef** [

Parameter Name	ArtiOsSpinlockInstanceGenericComponentInstanceRef		
Parent Container	ArtiOsSpinlockInstance		
Description	Refers to an ArtiGenericComponentInstance that extends the ArtiOsSpinlockInstance.		
Multiplicity	0..1		
Type	Reference to ArtiGenericComponentInstance		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00204] Definition of EcucReferenceDef ArtiOsSpinlockInstance LockingCoreRef** [

Parameter Name	ArtiOsSpinlockInstanceLockingCoreRef		
Parent Container	ArtiOsSpinlockInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the current locking core.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

#### 10.4.21 ArtiOsStackClass

**[ECUC\_Arti\_00147] Definition of EcucParamConfContainerDef ArtiOsStackClass** [

<b>Container Name</b>	ArtiOsStackClass		
<b>Parent Container</b>	ArtiOs		
<b>Description</b>	Contains the layout of an ArtiOsStack object. The ArtiOsStack object defines the memory area of any stack in the system.		
<b>Multiplicity</b>	0..1		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Configuration Parameters</b>			

<b>Included Parameters</b>		
<b>Parameter Name</b>	<b>Multiplicity</b>	<b>ECUC ID</b>
ArtiOsStackClassGenericComponentClassRef	0..1	[ECUC_Arti_00149]

No Included Containers

]

### [ECUC\_Arti\_00149] Definition of EcucReferenceDef ArtiOsStackClassGenericComponentClassRef [

<b>Parameter Name</b>	ArtiOsStackClassGenericComponentClassRef		
<b>Parent Container</b>	ArtiOsStackClass		
<b>Description</b>	Refers to an ArtiGenericComponentClass that extends the ArtiOsStackClass.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiGenericComponentClass		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

## 10.4.22 ArtiOsStackInstance

[ECUC\_Arti\_00148] Definition of EcucParamConfContainerDef ArtiOsStackInstance [

<b>Container Name</b>	ArtiOsStackInstance		
<b>Parent Container</b>	<a href="#">ArtiOs</a>		
<b>Description</b>	Represents an instance of an ArtiOsStack object.		
<b>Multiplicity</b>	0..*		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Configuration Parameters</b>			

<b>Included Parameters</b>			
<b>Parameter Name</b>	<b>Multiplicity</b>	<b>ECUC ID</b>	
<a href="#">ArtiOsStackInstanceDirection</a>	0..1	[ECUC_Arti_00150]	
<a href="#">ArtiOsStackInstanceBaseAddressRef</a>	0..1	[ECUC_Arti_00151]	
<a href="#">ArtiOsStackInstanceFillPatternRef</a>	0..1	[ECUC_Arti_00152]	
<a href="#">ArtiOsStackInstanceGenericComponentInstanceRef</a>	0..1	[ECUC_Arti_00153]	
<a href="#">ArtiOsStackInstanceSizeRef</a>	0..1	[ECUC_Arti_00154]	
<a href="#">ArtiOsStackInstanceValidRef</a>	0..1	[ECUC_Arti_00155]	

<b>No Included Containers</b>
-------------------------------

]

## [ECUC\_Arti\_00150] Definition of EcucStringParamDef ArtiOsStackInstanceDirection

<b>Parameter Name</b>	ArtiOsStackInstanceDirection		
<b>Parent Container</b>	ArtiOsStackInstance		
<b>Description</b>	This attribute specifies the direction of stack growth and may have either "UP" or "DOWN" as its value. UP means growing from lower to higher addresses. DOWN means growing from higher addresses to lower addresses.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	EcucStringParamDef		
<b>Default value</b>	—		
<b>Regular Expression</b>	—		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

**[ECUC\_Arti\_00151] Definition of EcucReferenceDef ArtiOsStackInstanceBaseAddressRef**

Parameter Name	ArtiOsStackInstanceBaseAddressRef		
Parent Container	ArtiOsStackInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "baseaddress" of this ArtiOsStack. This attribute specifies the lowest address of stack memory area, regardless of the stack direction.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00152] Definition of EcucReferenceDef ArtiOsStackInstanceFillPatternRef**

Parameter Name	ArtiOsStackInstanceFillPatternRef		
Parent Container	ArtiOsStackInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "fillpattern" of this ArtiOsStack. If the operating system fills the stack during initialisation, this attribute specifies with which pattern the stack area is initialised. This allows the debugger to evaluate the maximum stack usage. For "stackdirection" "DOWN" the pattern starts at "baseaddress". For "stackdirection" "UP" the pattern starts at "baseaddress" + "size". If no pattern is used, this attribute must be omitted.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

## [ECUC\_Arti\_00153] Definition of EcucReferenceDef ArtiOsStackInstanceGenericComponentInstanceRef

Parameter Name	ArtiOsStackInstanceGenericComponentInstanceRef		
Parent Container	ArtiOsStackInstance		
Description	Refers to an ArtiGenericComponentInstance that extends the ArtiOsStackInstance.		
Multiplicity	0..1		
Type	Reference to ArtiGenericComponentInstance		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

## [ECUC\_Arti\_00154] Definition of EcucReferenceDef ArtiOsStackInstanceSizeRef

Parameter Name	ArtiOsStackInstanceSizeRef		
Parent Container	ArtiOsStackInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "size" of this ArtiOsStack. This attribute represents the size (in bytes) of the memory area allocated for stack.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

## [ECUC\_Arti\_00155] Definition of EcucReferenceDef ArtiOsStackInstanceValidRef

Parameter Name	ArtiOsStackInstanceValidRef		
Parent Container	ArtiOsStackInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "validity" of this ArtiOsStackInstance. Every object declaration may contain a VALID attribute telling the debugger whether the object's attributes are currently valid. It may have an integer type of any size. Its possible values are 0 (invalid) and non zero (object is valid).		



△

<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiObjectInstanceParameter		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

↴

#### 10.4.23 ArtiOsTaskClass

##### [ECUC\_Arti\_00087] Definition of EcucParamConfContainerDef ArtiOsTaskClass

↴

<b>Container Name</b>	ArtiOsTaskClass		
<b>Parent Container</b>	ArtiOs		
<b>Description</b>	Contains the layout of an ARTI "OsTask" object, extending the EcuC OsTask.		
<b>Multiplicity</b>	0..1		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Configuration Parameters</b>			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
ArtiOsTaskClassClassGenericComponentRef	0..1	[ECUC_Arti_00077]	
ArtiOsTaskClassContextRef	0..1	[ECUC_Arti_00100]	
ArtiOsTaskClassCurrentTaskStateRef	0..1	[ECUC_Arti_00068]	
ArtiOsTaskClassPriorityRef	0..1	[ECUC_Arti_00101]	
ArtiOsTaskClassStackRef	0..1	[ECUC_Arti_00102]	

<b>No Included Containers</b>
-------------------------------

↴

**[ECUC\_Arti\_00077] Definition of EcucReferenceDef ArtiOsTaskClassClass GenericComponentRef**

Parameter Name	ArtiOsTaskClassClassGenericComponentRef		
Parent Container	ArtiOsTaskClass		
Description	Refers to an ArtiGenericComponentClass that extends the OsTask.		
Multiplicity	0..1		
Type	Reference to ArtiGenericComponentClass		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

**[ECUC\_Arti\_00100] Definition of EcucReferenceDef ArtiOsTaskClassContextRef**

Parameter Name	ArtiOsTaskClassContextRef		
Parent Container	ArtiOsTaskClass		
Description	ArtiOsTaskContextRef in ArtiOsTaskInstances. This attribute contains a reference to the context object that the task is currently using.		
Multiplicity	0..1		
Type	Reference to ArtiObjectClassParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

**[ECUC\_Arti\_00068] Definition of EcucReferenceDef ArtiOsTaskClassCurrentTaskStateRef**

Parameter Name	ArtiOsTaskClassCurrentTaskStateRef		
Parent Container	ArtiOsTaskClass		
Description	Refers to the ArtiObjectClassParameter that defines the ArtiCurrentTaskStateInstance parameter including the task state mapping.		
Multiplicity	0..1		
Type	Reference to ArtiObjectClassParameter		





<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

### [ECUC\_Arti\_00101] Definition of EcucReferenceDef ArtiOsTaskClassPriorityRef

[

<b>Parameter Name</b>	ArtiOsTaskClassPriorityRef		
<b>Parent Container</b>	ArtiOsTaskClass		
<b>Description</b>	Refers to the ArtiObjectClassParameter that declares the attribute ArtiOsTaskPriority Ref in ArtiOsTaskInstances. This attribute represents the current priority of the TASK object. The current priority can be different from the static task priority as a result of priority ceiling protocol. The priority displayed is the priority as defined in the OsTask.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiObjectClassParameter		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

### [ECUC\_Arti\_00102] Definition of EcucReferenceDef ArtiOsTaskClassStackRef

[

<b>Parameter Name</b>	ArtiOsTaskClassStackRef		
<b>Parent Container</b>	ArtiOsTaskClass		
<b>Description</b>	Refers to the ArtiObjectClassParameter that declares the attribute ArtiOsTaskStackRef in ArtiOsTaskInstances. This attribute contains a reference to the stack object that the task is currently using.		
<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiObjectClassParameter		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL





	Link time	X	VARIANT-LINK-TIME
	Post-build time	-	
Dependency			



```

<ECUC-CONTAINER-VALUE>
<SHORT-NAME>ArtiOsTaskClass_Conf</SHORT-NAME>
<DEFINITION-REF DEST="ECUC-PARAM-CONF-CONTAINER-DEF">/AUTOSAR/Arti/
ArtiOs/ArtiOsTaskClass</DEFINITION-REF>
<REFERENCE-VALUES>
<ECUC-REFERENCE-VALUE>
<DEFINITION-REF DEST="ECUC-REFERENCE-DEF">/AUTOSAR/Arti/
ArtiOs/ArtiOsTaskClass/
ArtiOsTaskClassGenericComponentRef</DEFINITION-REF>
<VALUE-REF DEST="ECUC-CONTAINER-VALUE">/Vendor1/Vendor1ArtiGeneric/
ArtiGenericComponentClass_Vendor1Task</VALUE-REF>
</ECUC-REFERENCE-VALUE>
</REFERENCE-VALUES>
</ECUC-CONTAINER-VALUE>

```

#### 10.4.24 ArtiOsTaskInstance

##### [ECUC\_Arti\_00090] Definition of EcucParamConfContainerDef ArtiOsTaskInstance

Container Name	ArtiOsTaskInstance		
Parent Container	ArtiOs		
Description	Represents an instance of an ARTI "OsTask" object, extending the EcuC OsTask.		
Multiplicity	0..*		
Post-Build Variant Multiplicity	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	-	
Configuration Parameters			

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
ArtiOsTaskInstanceFunction	0..1	[ECUC_Arti_00089]	
ArtiOsTaskInstanceContextRef	0..1	[ECUC_Arti_00104]	
ArtiOsTaskInstanceCurrentActivationsRef	0..1	[ECUC_Arti_00105]	
ArtiOsTaskInstanceCurrentTaskStateRef	0..1	[ECUC_Arti_00069]	
ArtiOsTaskInstanceEcucRef	1	[ECUC_Arti_00088]	
ArtiOsTaskInstanceGenericComponentRef	0..1	[ECUC_Arti_00070]	
ArtiOsTaskInstanceIdRef	1	[ECUC_Arti_00225]	
ArtiOsTaskInstancePriorityRef	0..1	[ECUC_Arti_00106]	





Included Parameters		
Parameter Name	Multiplicity	ECUC ID
ArtiOsTaskInstanceStackRef	0..1	[ECUC_Arti_00107]
ArtiOsTaskInstanceTimingProtectionLastTimeFrameRef	0..1	[ECUC_Arti_00214]
ArtiOsTaskInstanceTimingProtectionUsedBudgetRef	0..1	[ECUC_Arti_00213]
ArtiOsTaskInstanceValidRef	0..1	[ECUC_Arti_00103]

No Included Containers
------------------------

]

**[ECUC\_Arti\_00089] Definition of EcucFunctionNameDef ArtiOsTaskInstance Function** [

Parameter Name	ArtiOsTaskInstanceFunction		
Parent Container	ArtiOsTaskInstance		
Description	This parameter represents the C function name of the task body.		
Multiplicity	0..1		
Type	EcucFunctionNameDef		
Default value	-		
Regular Expression	-		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	-	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	-	
Dependency			

]

**[ECUC\_Arti\_00104] Definition of EcucReferenceDef ArtiOsTaskInstanceContext Ref** [

Parameter Name	ArtiOsTaskInstanceContextRef		
Parent Container	ArtiOsTaskInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the ArtiOs Context of this ArtiOsTask.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	-	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL



△

	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00105] Definition of EcucReferenceDef ArtiOsTaskInstanceCurrentActivationsRef** [

Parameter Name	ArtiOsTaskInstanceCurrentActivationsRef		
Parent Container	<a href="#">ArtiOsTaskInstance</a>		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "current activations" of this task. This attribute specifies the number of current activations for the task.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00069] Definition of EcucReferenceDef ArtiOsTaskInstanceCurrentTaskStateRef** [

Parameter Name	ArtiOsTaskInstanceCurrentTaskStateRef		
Parent Container	<a href="#">ArtiOsTaskInstance</a>		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "current state" of this task.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

**[ECUC\_Arti\_00088] Definition of EcucReferenceDef ArtiOsTaskInstanceEcucRef**

Parameter Name	ArtiOsTaskInstanceEcucRef		
Parent Container	ArtiOsTaskInstance		
Description	Refers to the EcucDefs/Os/OsTask of this TASK.		
Multiplicity	1		
Type	Reference to OsTask		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

**[ECUC\_Arti\_00070] Definition of EcucReferenceDef ArtiOsTaskInstanceGenericComponentRef**

Parameter Name	ArtiOsTaskInstanceGenericComponentRef		
Parent Container	ArtiOsTaskInstance		
Description	Refers to an ArtiGenericComponentInstance that extends the OsTask.		
Multiplicity	0..1		
Type	Reference to ArtiGenericComponentInstance		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

**[ECUC\_Arti\_00225] Definition of EcucReferenceDef ArtiOsTaskInstanceldRef**

Parameter Name	ArtiOsTaskInstanceldRef		
Parent Container	ArtiOsTaskInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "Task ID"; of type TaskType as given by the OSEK OS, returned by GetTaskID().		
Multiplicity	1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL



△

	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00106] Definition of EcucReferenceDef ArtiOsTaskInstancePriorityRef**

]

Parameter Name	ArtiOsTaskInstancePriorityRef		
Parent Container	ArtiOsTaskInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "task priority" of this task.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00107] Definition of EcucReferenceDef ArtiOsTaskInstanceStackRef**

]

Parameter Name	ArtiOsTaskInstanceStackRef		
Parent Container	ArtiOsTaskInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the ArtiOs Stack of this ArtiOsTask.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	X	VARIANT-LINK-TIME
	Post-build time	—	
Dependency			

**[ECUC\_Arti\_00214] Definition of EcucReferenceDef ArtiOsTaskInstanceTimingProtectionLastTimeFrameRef** [

Parameter Name	ArtiOsTaskInstanceTimingProtectionLastTimeFrameRef		
Parent Container	ArtiOsTaskInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the last time frame related to the OsTask/OsTaskTimingProtection configuration.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00213] Definition of EcucReferenceDef ArtiOsTaskInstanceTimingProtectionUsedBudgetRef** [

Parameter Name	ArtiOsTaskInstanceTimingProtectionUsedBudgetRef		
Parent Container	ArtiOsTaskInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the used budget related to the OsTask/OsTaskTimingProtection configuration.		
Multiplicity	0..1		
Type	Reference to ArtiObjectInstanceParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	—	
	Post-build time	—	
Dependency			

]

**[ECUC\_Arti\_00103] Definition of EcucReferenceDef ArtiOsTaskInstanceValidRef** [

Parameter Name	ArtiOsTaskInstanceValidRef		
Parent Container	ArtiOsTaskInstance		
Description	Refers to the ArtiObjectInstanceParameter that contains the evaluation for the "validity" of this ArtiOsTaskInstance. Every object declaration may contain a VALID attribute telling the debugger whether the object's attributes are currently valid. It may have an integer type of any size. Its possible values are 0 (invalid) and non zero (object is valid).		





<b>Multiplicity</b>	0..1		
<b>Type</b>	Reference to ArtiObjectInstanceParameter		
<b>Post-Build Variant Multiplicity</b>	false		
<b>Post-Build Variant Value</b>	false		
<b>Multiplicity Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Value Configuration Class</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPIL
	<b>Link time</b>	X	VARIANT-LINK-TIME
	<b>Post-build time</b>	—	
<b>Dependency</b>			

]

```

<ECUC-CONTAINER-VALUE>
<SHORT-NAME>ArtiOsTaskInstance_TaskHighPriority</SHORT-NAME>
<DEFINITION-REF DEST="ECUC-PARAM-CONF-CONTAINER-DEF">/AUTOSAR/Arti/
ArtiOs/ArtiOsTaskInstance</DEFINITION-REF>
<REFERENCE-VALUES>
<ECUC-REFERENCE-VALUE>
<DEFINITION-REF DEST="ECUC-REFERENCE-DEF">/AUTOSAR/Arti/
ArtiOs/ArtiOsTaskInstance/
ArtiOsTaskInstanceGenericComponentRef</DEFINITION-REF>
<VALUE-REF DEST="ECUC-CONTAINER-VALUE">/Vendor1/Vendor1ArtiGeneric/
ArtiGenericComponentInstance_TaskHighPriority</VALUE-REF>
</ECUC-REFERENCE-VALUE>
<ECUC-REFERENCE-VALUE>
<DEFINITION-REF DEST="ECUC-REFERENCE-DEF">/AUTOSAR/Arti/
ArtiOs/ArtiOsTaskInstance/
ArtiOsTaskInstanceEcucRef</DEFINITION-REF>
<VALUE-REF DEST="ECUC-CONTAINER-VALUE">/Vendor1/Vendor1EcucOs/
TaskHighPriority</VALUE-REF>
</ECUC-REFERENCE-VALUE>
</REFERENCE-VALUES>
</ECUC-CONTAINER-VALUE>

```

## 10.5 Published Information

For details refer to [4] Chapter 10.3 “Published Information”.

## 11 Generation of the OS




Figure 11.1: Generation activities

### 11.1 Read in configuration

#### [SWS\_Os\_00172]

*Upstream requirements: SRS\_BSW\_00159*

[The generator shall provide the user the ability of reading the information of a selectable configuration file.]

### 11.2 Consistency check

The consistency check can issue warnings or errors. Warnings mean that the generation is completed successfully, only indicating a not advisable configuration. Errors mean that the generation is not performed.

**[SWS\_Os\_00173]**

*Upstream requirements:* [SRS\\_BSW\\_00167](#)

〔The generator shall provide the user the ability of performing a consistency check of the current configuration.〕

**[SWS\_Os\_00050]**

*Upstream requirements:* [SRS\\_BSW\\_00167](#)

〔If service protection is required and `OsStatus` is not equal to EXTENDED (all the associated error handling is provided), the consistency check shall issue an error.〕

**[SWS\_Os\_00045]**

*Upstream requirements:* [SRS\\_BSW\\_00167](#)

〔If timing protection is configured together with OSEK OS Category 1 interrupts, the consistency check shall issue a warning.〕

**[SWS\_Os\_00562]**

*Upstream requirements:* [SRS\\_BSW\\_00167](#)

〔If timing protection is configured together with `OsPreTaskHook` or `OsPostTaskHook` the consistency check shall issue a warning.〕

**[SWS\_Os\_00320]**

*Upstream requirements:* [SRS\\_BSW\\_00167](#)

〔If configured attributes do not match the configured scalability class (e.g. defining an execution time budget in `Tasks` or `Category 2 ISRs` and selected scalability class is 1) the consistency check shall issue a warning.〕

**[SWS\_Os\_00311]**

*Upstream requirements:* [SRS\\_BSW\\_00167](#)

〔If `OsScalabilityClass` is SC3 or SC4, or system is Multi-Core, AND a `Task` OR `Category 2 ISR` OR `Counters` OR `Alarms` OR `ScheduleTables` does not belong to exactly one OS-Application the consistency check shall issue an error.〕

**[SWS\_Os\_00361]**

*Upstream requirements:* [SRS\\_BSW\\_00167](#)

〔If `OsScalabilityClass` is SC3 or SC4, or system is Multi-Core, AND a `Category 1 ISR` does not belong to exactly one trusted OS-Application the consistency check shall issue an error.〕

**[SWS\_Os\_00177]**

*Upstream requirements:* [SRS\\_BSW\\_00167](#)

〔If `OsScalabilityClass` is SC3 or SC4, or system is Multi-Core, AND an interrupt source that is used by the OS is assigned to an OS-Application, the consistency check shall issue an error.〕

**[SWS\_Os\_00303]**

*Upstream requirements:* [SRS\\_BSW\\_00167](#)

〔If `OsAlarmIncrementCounter` is configured as action on alarm expiry AND the alarm is driven directly or indirectly (a cyclic chain of alarm actions with `OsAlarmIncrementCounter`) by that Counter, the consistency check shall issue a warning.〕

**[SWS\_Os\_00328]**

*Upstream requirements:* [SRS\\_BSW\\_00167](#)

〔If `OsStatus` is STANDARD and `OsScalabilityClass` is SC3 or SC4 the consistency check shall issue an error.〕

**[SWS\_Os\_00343]**

*Upstream requirements:* [SRS\\_BSW\\_00167](#)

〔If `OsScalabilityClass` is SC3 or SC4, or system is Multi-Core, AND a Task is referenced within a ScheduleTable object AND the OS-Application of the Schedule Table has no access to the Task, the consistency check shall issue an error.〕

**[SWS\_Os\_00344]**

*Upstream requirements:* [SRS\\_BSW\\_00167](#)

〔If `OsScalabilityClass` is SC3 or SC4, or system is Multi-Core, AND a Task is referenced within an alarm object AND the OS-Application of the alarm has no access to the Task, the consistency check shall issue an error.〕

**[SWS\_Os\_00440]**

*Upstream requirements:* [SRS\\_Os\\_11002](#)

〔If a ScheduleTable has `OsScheduleTblSyncStrategy` = IMPLICIT and the `OsCounterMaxAllowedValue`+1 of the associated Counter is not equal to the duration of the ScheduleTable then the consistency check shall issue an error.〕

**[SWS\_Os\_00461]**

*Upstream requirements:* [SRS\\_BSW\\_00167](#)

〔If `OsScalabilityClass` is SC2, SC3 or SC4 AND Alarm Callbacks are configured the consistency check shall issue an error.〕

**[SWS\_Os\_00850]**

*Upstream requirements:* [SRS\\_BSW\\_00159](#)

〔If `OsUseResScheduler` is TRUE AND the configuration contains a resource called RES\_SCHEDULER, the generation tool shall ignore the configured RES\_SCHEDULER.〕

**[SWS\_Os\_00877] Alarm action and Task property must fit together** 〔If an Alarm uses the action to replenish a budget then the Task referenced by `OsAlarmBudgetReplenishRef` must have have `OsTaskTimingProtectionDeferrableServer` enabled. If this is not the case the consistency check shall issue an error.〕

**[SWS\_Os\_00878] Replenish via expiry point must fit to Task** [If an expiry point of a SchuduleTable uses the action to replenish a budget then the Task referenced by `OsScheduleTableReplenishTaskRef` must have have `OsTaskTimingProtectionDeferrableServer` enabled. If this is not the case the consistency check shall issue an error.]

**[SWS\_Os\_00879] A Deferrable Server needs a execution time budget** [If a Task has `OsTaskTimingProtectionDeferrableServer` enabled (is TRUE), then this Task must also have a valid `OsTaskExecutionBudget`. Otherwise the consistency check shall issue an error.]

**[SWS\_Os\_00880] A Deferrable Server requires its own priority level** [If a Task has `OsTaskTimingProtectionDeferrableServer` enabled (is TRUE), then on the same core there shall be no other Task(s) configured which use the same `OsTaskPriority`. Otherwise the consistency check shall issue an error.]

**[SWS\_Os\_00881] A Deferrable Server cannot use internal OS resources** [If a Task has `OsTaskTimingProtectionDeferrableServer` enabled (is TRUE), then this Task cannot reference a `OsResource` (via `OsTaskResourceRef`) which has a `OsResourceProperty` configured as LINKED. In such cases the consistency check shall issue an error.]

## 11.3 Generating operating system

### [SWS\_Os\_00179]

*Upstream requirements:* [SRS\\_BSW\\_00167](#)

[If the consistency check of the read-in configuration file has not run free of errors, the generator shall not generate/configure the operating system.]

### [SWS\_Os\_00336]

*Upstream requirements:* [SRS\\_Os\\_11019](#)

[The generator shall generate a relocatable memory section containing the interrupt vector table.]

### [SWS\_Os\_00370]

*Upstream requirements:* [SRS\\_BSW\\_00159](#)

[The generator shall print out information about timers used internally by the OS during generation (e.g. on console, list file).]

### [SWS\_Os\_00393]

*Upstream requirements:* [SRS\\_BSW\\_00159](#)

[The generator shall create conversation macros to convert counter ticks (given as argument) into real time. The format of the macro is `OS_TICKS2<Unit>_<Counter>`

(ticks) whereas <Unit> is one of NS (nanoseconds), US (microseconds), MS (milliseconds) or SEC (seconds) and <Counter> is the name of the Counter; E.g. OS\_TICKS2MS\_MyCounter())]

**[SWS\_Os\_00815]**

*Upstream requirements: [SRS\\_BSW\\_00351](#)*

[The OS code shall wrap each declaration of Task, ISR, trusted functions, alarm callbacks and hook functions with the Memory Mapping Allocation Keywords macros.

```
1 #define OS_START_SEC_<sadm>
2 #include "Os_MemMap.h"
3
4 < Task, ISR, trusted functions or hook functions declaration>
5
6 #define OS_STOP_SEC_<sadm>
7 #include "Os_MemMap.h"
```

where <sadm> is the shortName of the SwAddrMethod if configured (e.g. in [OsMemoryMappingCodeLocationRef](#)).]

## 12 Application Notes

### 12.1 Hooks

In OSEK OS, PreTask & PostTask Hooks run at the level of the OS with unrestricted access rights and therefore must be trusted. It is strongly recommended that these hook routines are only used during debugging and are not used in a final product.

When an OS-Application is killed the shutdown and startup hooks of the OS-Application are not called.

All application-specific hook functions (startup, shutdown and error) must return (blocking or endless loops are not acceptable).

### 12.2 Providing Trusted Functions

Address checking shall be done before data is accessed. Special care must be taken if parameters passed by reference point to the stack space of a Task or interrupt, because this address space might no longer belong to the Task or interrupt when the address is used.

The following code fragment shows an example how a trusted function is called and how the checks should be done.

```
1 struct parameter_struct {type1 name1, type2 name2, StatusType
2     return_value};
3
4 /* This service is called by the user and uses a trusted function */
5 StatusType system_service( type1 parameter1, type2 parameter2)
6 {
7     /* store parameters in a structure (parameter1 and parameter2) */
8     struct parameter_struct local_struct;
9     local_struct.name1 = parameter1;
10    local_struct.name2 = parameter2;
11    /* call CallTrustedFunction with appropriate index and
12     * pointer to structure */
13    if(CallTrustedFunction(SYSTEM_SERVICE_INDEX, &local_struct) != E_OK
14        )
15        return(FUNCTION_DOES_NOT_EXIST);
16    return(local_struct.return_value);
17 }
18
19 /* The CallTrustedFunction() service switches to the privileged
20  * mode. Note that the example is only a fragment! */
21 StatusType CallTrustedFunction( TrustedFunctionIndexType ix,
22     TrustedFunctionParameterRefType ref)
23 {
24     /* check for legal service index and return error if necessary */
25     if(ix > MAX_SYSTEM_SERVICE)
26         return(E_OS_SERVICEID);
27     /* some implementation specific magic happens: the processor is
```

```

25      * set to privileged mode */
26
27      /* indirectly call target function based on the index */
28      (*(system-service_list[ix]))(ix, ref);
29      /* some implementation specific magic happens: the processor is
30      * set to non-privileged mode */
31
32      return(E_OK);
33  }
34
35
36  /* This part of the system service is called by
37  * CallTrustedFunction() */
38  void TRUSTED_system_service_part2 (TrustedFunctionIndexType a,
39  parameter_struct *local_struct)
40  {
41      TaskRefType task;
42      type1 parameter1;
43      type2 parameter2;
44      if (GetTaskID(&task) != E_OK)
45          task = INVALID_TASK;
46      /* get parameters out of the structure (parameter1 and
47      * parameter2) */
48      parameter1 = local_struct.name1;
49      parameter2 = local_struct.name2;
50      /* check the parameters if necessary */
51      /* example is for parameter1 being an address and parameter2
52      * being a size */
53      /* example only for system_service called from tasks */
54      if (GetISRID() != INVALID_ISR)
55      {
56          /* error: not callable from ISR */
57          local_struct.return_value = E_OS_ACCESS;
58      }
59      else if (OSMEMORY_IS_WRITEABLE (CheckTaskMemoryAccess (task, parameter1
60          , parameter2)))
61      {
62          /* system_service_part3() is now the function as it
63          * would be if directly called in a non-protected
64          * environment */
65          local_struct.return_value = system_service_part3 (parameter1,
66          parameter2);
67      }
68      else
69      {
70          /* error handling */
71          local_struct.return_value = E_OS_ACCESS;
72      }
73  }

```

Note: Since the service of `CallTrustedFunction` is very generic, it is needed to define a stub-interface which does the packing and unpacking of the arguments (as the example show). Depending on the implementation the stub interface may be (partly) generated by the generation tool.

## 12.3 Software Components and OS-Applications

Trusted OS-Applications can be permitted access to IO space. As software components can not be allowed direct access to the hardware, software components can not be trusted OS-Applications because this would violate this protection feature. The configuration process must ensure that this is the case.

The AUTOSAR Virtual Function Bus (VFB) specification places no restrictions on how runnables from software components are mapped to OS Tasks. However, the protection mechanisms in AUTOSAR OS apply only to OS managed objects. This means that all runnables in a Task:

- Are not protected from each other at runtime
- Share the same protection boundary

If runnables need to be protected they must therefore be allocated to different Tasks and those Tasks protected accordingly.

A simple rule can suffice:

"When allocating runnables to Tasks, only allocate runnables from the same software component into the same Task."

If multiple software components from the same application are to reside on the same processor, then, assuming protection is required between applications (or parts thereof) on the same processor, this rule could be modified to relax the scope of protection to the application:

"When allocating runnables to Tasks, only allocate runnables from the same application into the same Task."

## 12.4 Global Time Synchronization

The OS currently assumes that the global time synchronization is done by the user (unless implicit synchronization is used). This allows maximum flexibility regarding the time source. For synchronization with e.g. FlexRay some glue code may be necessary which transfer the information from the time source to the OS.

## 12.5 Working with FlexRay

ScheduleTables in the AUTOSAR OS may be synchronized with a global (network) time provided by FlexRay in essentially two ways:

- Using the FlexRay interface's services for controlling timer interrupts related to global time to provide a "hardware" counter tick source to drive the processing of a ScheduleTable (implicit synchronization)

- Using the FlexRay interface's service for accessing the current global time and passing this into the OS through the `SyncScheduleTable` OS service call

This section looks at the second option only.

In FlexRay time is presented as a tuple of a Cycle and a MacrotickOffset within the cycle. Cycle is an 8-bit value and MacrotickOffset is a 16-bit value.

In AUTOSAR OS a `ScheduleTable` is associated with an underlying `Counter` that has a notion of ticks. It is therefore possible to synchronize with either the `Cycle` or the tuple of `Cycle/MacrotickOffset` to give the resolution of synchronization required by the application.

If `Cycle` only resolution is required then an OS `Counter` object should be configured to have a `OsCounterMaxAllowedValue` equal to the maximum number of Cycles. If `Cycle/MacrotickOffset` is required then an OS `Counter` object should be configured with a `OsCounterMaxAllowedValue` of the maximum number of Cycles multiplied by the `MacrotickOffset`. This provides the OS with a time base against which a `ScheduleTable` can be synchronized.

Synchronization between the OS and an external global time source is provided by telling the OS the global time through the `SyncScheduleTable` service call. This call takes a scalar parameter of `TickCount` so to interface this to FlexRay's representation of time a small conversion needs to be done. The following example assumes a `Cycle` of 255 with 65535 Macroticks per `Cycle`. `TickCount` is at least 24-bits wide.

```

1 #define OSTIME(x) (TickCount) (x);
2
3 FrIf_GetGlobalTime(Controller, &Cycle, &Macrotick);
4
5 SyncScheduleTable(Tbl, ((OSTIME(Cycle) <<16)+(OSTIME(Macrotick))));
```

Telling the `ScheduleTable` that `GlobalTime` can be done when the application detects that the FlexRay controller has lost synchronization with the network (by polling the controller sync status). The following code indicates how this can be used to force an associated `ScheduleTable` into the `SCHEDULETABLE_RUNNING` state from the `SCHEDULETABLE_RUNNING_AND_SYNCHRONOUS` state.

```

1 Fr_SyncStateType CurrentSyncStatus;
2
3 if (FrIf_GetSyncState(Controller, &CurrentSyncStatus) == E_OK) {
4
5     if (CurrentSyncStatus == FR_ASYNC) {
6         SetScheduleTableAsync(Table);
7     }
8
9 }
```

Of course, other actions are possible here, like stopping the `ScheduleTable`, as best fits user requirements.

## 12.6 Migration from OIL to XML

This version of the AUTOSAR OS specification does not directly support the configuration via OIL. The support for OIL was dropped in favour of XML because XML is the standard configuration language in AUTOSAR and is essential if configuration data has to be imported / exported from / to other AUTOSAR modules or between different tools during development.

Since OIL and XML are both ASCII formats a tool vendor may offer a possibility to import (old) OIL files and to store them as (AUTOSAR OS) XML files. Currently all known vendors support at least the import of existing OIL configurations.

Note that for showing conformance to the OSEK OS specification, each OSEK OS vendor must support OIL. This means that practically each AUTOSAR OS vendor will offer some sort of import of OIL configurations - at least to show the OSEK OS conformance.

## 12.7 Debug support

For the AUTOSAR OS the following information may be useful for users and should be considered for debug support (and may be published, e.g. in the BSWMD):

- General information about how to retrieve the current (active) Task or ISR and their (current) priority and (current) stack.
- For ISRs: Information about the name of interrupts, their mapping to the ISR identifier, the associated hardware and the used stack(s).
- For Tasks: Information about the name of the Task, its identifier, the task state, the possible priorities, the event mask (if its an extended Task), the OS-Application to whom the Task belongs (if existant) and the used stack.
- For Resources: Information about the name of the Resource, its mapping to the identifier, its priority and the current owner (the Task/ISR which currently holds the Resource)
- For Alarms: Information about the name of the Alarm, its mapping to the identifier, the Counter to whom it belong, the action which is executed on expiry and the current state (running or stopped). In running state the next expiry in ticks and the possible cycle time shall be also published.
- For Counters: Information about the name of the Counter, its mapping to the identifier, its associated alarms and the current counter value.
- For ScheduleTables: Information about the name of the ScheduleTable, its mapping to the identifier, its current state and the next expiry point (if the table is running).
- For OS-Applications: Information about the name of the OS-Application, its mapping to the identifier, its current state and the memory sections assigned to it (if memory protection is used).

ARTI implements mechanisms to retrieve the described information (see [11]).

User documentation should contain information about the implemented debug features.

## 12.8 Integration hints for peripheral protection

Peripheral protection requires configuration on the core level usually conditioned by a supervisor access. For this reason the task of the peripheral protection is assigned to the OS module.

Peripheral protection may be implemented in two ways

- using MPU
- using dedicated peripheral protection units of the target MCU.

When using the memory protection unit, it is reasonable if two or more protected region descriptors are available for peripheral protection mechanism. The region descriptors shall be programmed to allow access to those peripherals the current OS-Application shall work with. The defined regions shall cover all memory mapped configuration registers for the peripherals to be protected. The advantage of using the MPU is that the configuration is the same as for memory protection. One of the disadvantages of this method is that it could be impossible to cover all peripheral control registers with available MPU region descriptors. The number of such descriptors is typically low.

Beware that using this method may have implication to the linker file of the project software configuration.

Second method is using a dedicated register protection schema. This method shall allow to precisely select peripherals for every OS Application. However the number of peripherals may make the register protection implementation rather bulky. Therefore it is advisable to reduce the number of protected peripherals to a reasonable value.

For both methods the configuration shall be placed into custom OS Application properties. The configuration shall be active when a Task (or ISR) of a particular OS Application is running.

## 12.9 Termination of OS-Applications

Inconsistencies may occur when an [OsApplication](#) is terminated, depending on its state at the termination.

- A notification from an asynchronous job started before the termination of [OsApplication](#) can occur afterwards.
- An asynchronous memory read or write started before the termination of [OsApplication](#) can occur afterwards and may cause data inconsistency.

- A requested mode or state to another [OsApplication](#) (e.g. from a SW-C to A BSW) can lead to unsynchronized state machines.

Therefore special care needs to be taken by developers to avoid such inconsistencies and guaranty a correct behavior. This is especially true if an OS-Application is forcible terminated.

## 13 Outlook on Memory Protection Configuration

As stated before, memory protection configuration is not standardized yet. Nevertheless it seems helpful to contribute a recommendation in this chapter, how the configuration might work.

### 13.1 Configuration Approach

Both, SW-Components and BSW modules, map code and variables to dedicated, disjoined memory sections (see [12] Chapter 8 “*Implementation*”, and *Specification of Memory Mapping* [13]).

This essential precondition (avoid an inseparable conglomeration of variables in the default section) can be used to support configuration of memory protection domains:

- The generator can save for each OS-Application a (processor-specific) maximum number of output sections for data in a file (to be used in the linker file).
- The generator can uniquely identify the address spaces of the data output sections with symbols using the naming convention (see *memory allocation keywords* `_STOP_SEC_VAR` and `_START_SEC_VAR` for start and stop symbols) in the specification mentioned above.

The input data sections in the object files of an OS-Application can then be assigned to the output sections (with potential tool support). Usually, this is one segment for global data, and one segment for code.

To achieve portability, the user shall group all variables belonging to a private data section (Task/ISR or OS-Application) in separate files.

## A Not applicable requirements

### [SWS\_Os\_NA\_00767]

*Upstream requirements:* SRS\_BSW\_00344, SRS\_BSW\_00404, SRS\_BSW\_00405, SRS\_BSW\_00170, SRS\_BSW\_00419, SRS\_BSW\_00383, SRS\_BSW\_00384, SRS\_BSW\_00375, SRS\_BSW\_00406, SRS\_BSW\_00168, SRS\_BSW\_00407, SRS\_BSW\_00423, SRS\_BSW\_00337, SRS\_BSW\_00369, SRS\_BSW\_00339, SRS\_BSW\_00422, SRS\_BSW\_00417, SRS\_BSW\_00409, SRS\_BSW\_00385, SRS\_BSW\_00386, SRS\_BSW\_00437, SRS\_BSW\_00388, SRS\_BSW\_00389, SRS\_BSW\_00390, SRS\_BSW\_00392, SRS\_BSW\_00393, SRS\_BSW\_00395, SRS\_BSW\_00396, SRS\_BSW\_00399, SRS\_BSW\_00403, SRS\_BSW\_00416, SRS\_BSW\_00425, SRS\_BSW\_00432, SRS\_BSW\_00452, SRS\_BSW\_00458, SRS\_BSW\_00461, SRS\_BSW\_00466, SRS\_BSW\_00469, SRS\_BSW\_00470, SRS\_BSW\_00471, SRS\_BSW\_00472, SRS\_BSW\_00478, SRS\_BSW\_00490, SRS\_BSW\_00491, SRS\_BSW\_00492, RS\_Arti\_00008, RS\_Arti\_00025, RS\_Arti\_00039, RS\_Arti\_00040, RS\_Arti\_00041, RS\_Arti\_00042, RS\_Arti\_04085, RS\_Arti\_04086, RS\_Arti\_04087, RS\_Arti\_04089, RS\_Arti\_04090, RS\_Arti\_04101, RS\_Arti\_04143, RS\_Arti\_04145, RS\_Arti\_00038, RS\_Arti\_00028, RS\_Arti\_00035, RS\_Arti\_00036, RS\_Arti\_00037

[These requirements are not applicable to this specification.]

## B History of Constraints and Specification Items

### B.1 Differences between R24-11 and R25-11

#### B.1.1 Added Specification Items in R25-11

[ECUC\_Arti\_00225] [ECUC\_Os\_00411] [ECUC\_Os\_00412] [ECUC\_Os\_00413]  
[ECUC\_Os\_00414] [ECUC\_Os\_00415] [ECUC\_Os\_00416] [SWS\_Os\_00864]  
[SWS\_Os\_00865] [SWS\_Os\_00866] [SWS\_Os\_00867] [SWS\_Os\_00868] [SWS\_Os\_00869] [SWS\_Os\_00870] [SWS\_Os\_00871] [SWS\_Os\_00872] [SWS\_Os\_00873] [SWS\_Os\_00874] [SWS\_Os\_00875] [SWS\_Os\_00876] [SWS\_Os\_00877] [SWS\_Os\_00878] [SWS\_Os\_00879] [SWS\_Os\_00880] [SWS\_Os\_00881] [SWS\_Os\_91035] [SWS\_Os\_91036]

#### B.1.2 Changed Specification Items in R25-11

[ECUC\_Arti\_00055] [ECUC\_Arti\_00059] [ECUC\_Arti\_00063] [ECUC\_Arti\_00090] [ECUC\_Arti\_00091] [ECUC\_Os\_00006] [ECUC\_Os\_00143] [ECUC\_Os\_00325] [ECUC\_Os\_01017] [SWS\_Os\_00064] [SWS\_Os\_00407] [SWS\_Os\_00440] [SWS\_Os\_00473] [SWS\_Os\_00786] [SWS\_Os\_00788] [SWS\_Os\_00836] [SWS\_Os\_00840] [SWS\_Os\_91028]

#### B.1.3 Deleted Specification Items in R25-11

[ECUC\_Arti\_00092] [SWS\_Os\_00560] [SWS\_Os\_00769] [SWS\_Os\_00770] [SWS\_Os\_00771] [SWS\_Os\_00793] [SWS\_Os\_00794] [SWS\_Os\_00802] [SWS\_Os\_91027]

#### B.1.4 Added Constraints in R25-11

none

#### B.1.5 Changed Constraints in R25-11

none

#### B.1.6 Deleted Constraints in R25-11

none

## B.2 Differences between R23-11 and R24-11

### B.2.1 Added Specification Items in R24-11

[ECUC\_Arti\_00182] [ECUC\_Arti\_00183] [ECUC\_Arti\_00184] [ECUC\_Arti\_00185]  
[ECUC\_Arti\_00186] [ECUC\_Arti\_00187] [ECUC\_Arti\_00188] [ECUC\_Arti\_00189]  
[ECUC\_Arti\_00190] [ECUC\_Arti\_00191] [ECUC\_Arti\_00192] [ECUC\_Arti\_00193]  
[ECUC\_Arti\_00194] [ECUC\_Arti\_00195] [ECUC\_Arti\_00196] [ECUC\_Arti\_00197]  
[ECUC\_Arti\_00198] [ECUC\_Arti\_00199] [ECUC\_Arti\_00200] [ECUC\_Arti\_00201]  
[ECUC\_Arti\_00202] [ECUC\_Arti\_00203] [ECUC\_Arti\_00204] [ECUC\_Arti\_00211]  
[ECUC\_Arti\_00212] [ECUC\_Arti\_00213] [ECUC\_Arti\_00214] [ECUC\_Arti\_00224]  
[ECUC\_Os\_00410] [SWS\_Os\_00863] [SWS\_Os\_91028]

### B.2.2 Changed Specification Items in R24-11

[ECUC\_Arti\_00071] [ECUC\_Arti\_00086] [ECUC\_Arti\_00090] [ECUC\_Os\_00044]  
[ECUC\_Os\_00114] [SWS\_Os\_00106] [SWS\_Os\_00244] [SWS\_Os\_00258] [SWS\_Os\_00287]  
[SWS\_Os\_00364] [SWS\_Os\_00467] [SWS\_Os\_00502] [SWS\_Os\_00506]  
[SWS\_Os\_00538] [SWS\_Os\_00563] [SWS\_Os\_00773] [SWS\_Os\_00784] [SWS\_Os\_00787]  
[SWS\_Os\_00788] [SWS\_Os\_91026]

### B.2.3 Deleted Specification Items in R24-11

[ECUC\_Os\_00120] [SWS\_Os\_00111] [SWS\_Os\_00365] [SWS\_Os\_00459] [SWS\_Os\_00497]  
[SWS\_Os\_00498] [SWS\_Os\_00501] [SWS\_Os\_00503] [SWS\_Os\_00508]  
[SWS\_Os\_00547] [SWS\_Os\_00548] [SWS\_Os\_00555] [SWS\_Os\_00557] [SWS\_Os\_00564]  
[SWS\_Os\_91029]

### B.2.4 Added Constraints in R24-11

none

### B.2.5 Changed Constraints in R24-11

none

### B.2.6 Deleted Constraints in R24-11

none

## B.3 Differences between R22-11 and R23-11

### B.3.1 Added Specification Items in R23-11

[SWS\_Os\_00859] [SWS\_Os\_00860] [SWS\_Os\_00861] [SWS\_Os\_00862] [SWS\_Os\_91034]

### B.3.2 Changed Specification Items in R23-11

[SWS\_Os\_00261] [SWS\_Os\_00287] [SWS\_Os\_00548] [SWS\_Os\_00566] [SWS\_Os\_00573] [SWS\_Os\_00675] [SWS\_Os\_00798] [SWS\_Os\_00820] [SWS\_Os\_00822] [SWS\_Os\_00826] [SWS\_Os\_91025]

### B.3.3 Deleted Specification Items in R23-11

[SWS\_Os\_00821] [SWS\_Os\_00823]

### B.3.4 Added Constraints in R23-11

[SWS\_Os\_CONSTR\_00001] [SWS\_Os\_CONSTR\_00002]

### B.3.5 Changed Constraints in R23-11

none

### B.3.6 Deleted Constraints in R23-11

none