

Document Title	Guide to Modemanagement
Document Owner	AUTOSAR
Document Responsibility	AUTOSAR
Document Identification No	440
Document Classification	Auxiliary

Document Version	2.2.0
Document Status	Final
Part of Release	4.1
Revision	3

Document Change History			
Date	Version	Changed by	Description
31.03.2014	2.2.0	AUTOSAR Release Management	<ul style="list-style-type: none"> • Clarified Wakeup Handling • Extended diagnostic related mode management • Fixed inconsistencies with BswM
14.08.2013	2.1.0	AUTOSAR Release Management	<ul style="list-style-type: none"> • Added section about Pretended Networking
26.02.2013	2.0.0	AUTOSAR Administration	<ul style="list-style-type: none"> • Changes regarding J1939 Network Management • Introduction of J1939 Diagnostic Mode Management
27.10.2011	1.0.0	AUTOSAR Administration	<ul style="list-style-type: none"> • Initial release

Disclaimer

This specification and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the specification.

The material contained in this specification is protected by copyright and other types of Intellectual Property Rights. The commercial exploitation of the material contained in this specification requires a license to such Intellectual Property Rights.

This specification may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only.

For any other purpose, no part of the specification may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The AUTOSAR specifications have been developed for automotive applications only. They have neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.

Advice for users

AUTOSAR specifications may contain exemplary items (exemplary reference models, "use cases", and/or references to exemplary technical solutions, devices, processes or software).

Any such exemplary items are contained in the specifications for illustration purposes only, and they themselves are not part of the AUTOSAR Standard. Neither their presence in such specifications, nor any later documentation of AUTOSAR conformance of products actually implementing such exemplary items, imply that intellectual property rights covering such exemplary items are licensed under the same rules as applicable to the AUTOSAR Standard.

Table of Contents

1	Introduction	7
1.1	Further Work	7
2	Overall mechanisms and concepts	8
2.1	Declaration of modes	8
2.2	Mode managers and mode users	10
2.3	Modes in the RTE	10
2.4	Modes in the Basic Software Scheduler	11
2.5	Communication of modes	11
2.5.1	Mode switch	12
2.5.2	Mode request	13
2.5.3	Conformance of mode switches and mode requests	13
2.5.4	Mode proxies	13
2.5.5	Mode communication on multi core ECUs	14
3	Configuration of the Basic Software Modemanager	16
3.1	Process how to configure and integrate a BswM	16
3.2	Semantics of BswM Configuration: Interfaces and behavioral aspects	17
3.2.1	Interface of the BswM	17
3.2.1.1	Mode Requests	17
3.2.1.2	Available Actions	18
3.2.2	Definition of the interface in pseudo code	19
3.2.2.1	Mode switch and mode request interfaces	19
3.2.2.2	ModeRequestPorts defined by the standardized interface of the BswM	21
3.2.2.3	Configurable ModeRequestPorts	27
3.2.2.4	Configurable ModeSwitchPorts	28
3.2.3	Configuration of the BswM behavior	29
3.3	ECU state management	30
3.3.1	Startup	31
3.3.2	Run	32
3.3.3	Shutdown	33
3.3.4	Sleep	34
3.3.5	Wakeup	34
3.4	Communication Management	34
3.4.1	Startup and Shutdown	35
3.4.2	I-PDU Group Switching	35
3.4.3	J1939 Networkmanagement	39
3.4.4	J1939 diagnostic mode management	41
3.4.5	Pretended Networking	41
3.4.5.1	Activation of Pretended Networking	42
3.4.5.2	Deactivation of Pretended Networking	43
3.5	Diagnostics	43
3.5.1	Diagnostic Session Control	43

3.5.2	ECU Reset	44
3.5.3	Rapid Power Shutdown	46
3.5.4	Communciation Control diagnostic service	47
3.5.5	Control DTC Setting	50
3.5.6	Roe Status	50
4	Backward Compatibility	52
4.1	Startup	54
4.2	Running	55
4.3	Shutdown	57
4.4	Wakeup	59
5	Acronyms and abbreviations	60
5.1	Technical Terms	60

References

- [1] Specification of ECU State Manager with fixed state machine
AUTOSAR_SWS_ECUStateManagerFixed
- [2] Software Component Template
AUTOSAR_TPS_SoftwareComponentTemplate
- [3] Meta Model
AUTOSAR_MMOD_MetaModel
- [4] Basic Software Module Description Template
AUTOSAR_TPS_BSWModuleDescriptionTemplate
- [5] Specification of Basic Software Mode Manager
AUTOSAR_SWS_BSWModeManager
- [6] Specification of Diagnostic Communication Manager
AUTOSAR_SWS_DiagnosticCommunicationManager
- [7] Glossary
AUTOSAR_TR_Glossary

1 Introduction

This document is a general introduction to AUTOSAR mode management for the Release 4.0.3 onwards. Its main purpose is to give users as well as developers of AUTOSAR an detailed overview of the different aspects of AUTOSAR mode management based on examples, which are explained in context. The code listings in this document together form the configuration of a sample ECU.

Chapter 2 explains the basic mode management concepts e.g. modes in general, how mode switches are implemented, roles of mode managers and mode users etc. It secondly gives an introduction to Application Mode management and the dependencies to Basic Software Mode management, which are closely related.

The `Basic Software Modemanager` is the central mode management module in AUTOSAR R4.0. It is configurable to a high degree. How this configuration can be achieved is the topic of chapter 3.

Chapter 4 than deals with migration strategies from fixed ECU Management as it was used in AUTOSAR R3.1¹ to the new approach of ECU management of AUTOSAR 4.0

1.1 Further Work

Due to complexity and broad scope of this topic there are still some uses cases which are not yet described here in full detail. These issues will be enhanced in further releases.

- ECUs as Gateways
- Communication management for FlexRay
- Communication management for Ethernet
- Communication management for Lin (including schedule table switching)
- DCM Routing path groups
- BSWM configuration for multicore ECUs

¹and in R4.0 with the ECU Statemanager with fixed state machine[1]

2 Overall mechanisms and concepts

This chapter gives an overview of the concept of modes and a short definition of states in AUTOSAR. Definitions of the terms mode and state can be found in chapter 5.1 A mode can be seen as the current state of an ECU¹ wide, global variable, which is maintained by the RTE respectively the Schedule Manager. The possible assignments of a mode are defined in `ModeDeclarationGroups`, which are defined in the AUTOSAR Software Component Template [2]. Modes can be used for different purposes. First of all modes are used to synchronize Software Components and Basic Software Modules. Via modes specified triggers can be enabled and disabled, and consequently the activation of `ExecutableEntitys` can be prevented. Also `ExecutableEntitys` can be triggered explicitly during a Mode Switch. On the other hand mode switches can explicitly trigger executable entities during transition from one mode to another. For example the RTE can activate an `OnEntry ExecutableEntity` to initialize a certain resource before entering a specific mode. In this mode the triggers of this `ExecutableEntity` are activated. If the mode is left the `OnExit ExecutableEntity` is called, which could execute some cleanup code and the triggers would be deactivated.

2.1 Declaration of modes

The Software Component Template [2] defines a generic mechanism for describing modes in AUTOSAR. Modes are defined via `ModeDeclarations`. A `ModeDeclaration` represents a possible assignment of the current state of a global variable. E.g in ECU state management there may exist the `ModeDeclarations` `STARTUP`, `RUN`, `POST_RUN`, `SLEEP`.

A `ModeDeclarationGroup` groups several `ModeDeclarations` in a similar way as an enumeration groups literals. In the given example this could be the `ModeDeclarationGroup` `ECUMODE`. For each `ModeDeclarationGroup` an `InitialMode` has to be defined, which is assigned to the variable at startup. Figure 2.1 shows an excerpt of the AUTOSAR Metamodel [3] with the relationships of `ModeDeclarations`, `ModeDeclarationGroups` and `ExecutableEntitys`.

¹In R4.0 this is limited to a single partition




Figure 2.1: Excerpt of Metamodel regarding Modes

2.2 Mode managers and mode users

In mode management there are two parties involved: *Mode managers* and *mode users*. Responsible for switching modes are *Mode managers*, which are the only instances able to change the value of the global variable. A mode manager is either a Software Component, which provides a `ModeRequestPort` or a *Basic Software Module*, which either provides also a `ModeRequestPort` in its Software Component Description or a `ModeDeclarationGroup` in its Basic Software Module Description. Mode users are informed of Mode switches via well-defined mechanisms and have the possibility to read the currently active mode at any time. If a Mode user wants to change into a different mode it can request a Mode switch from the corresponding Mode manager.

2.3 Modes in the RTE

The AUTOSAR Runtime Environment implements the concept of modes. For this purposes it creates for each `ModeDeclarationGroupPrototype` of an Atomic Software Component a so called `ModeMachineInstance`. A `ModeMachineInstance` is a state machine whose states are defined by the `ModeDeclarations` of the respective `ModeDeclarationGroup`.

Figure 2.2 depicts the interaction of `ModeDeclarationGroupPrototypes` Mode managers and Mode users. Note that the mode switch ports of the mode users are not directly connected to the corresponding `PPorts` of the mode managers but instead are connected to the mode machine instances of the RTE. This is important to understand the mechanism of mode switching inside the RTE.




Figure 2.2: The RTE instantiates for each `ModeDeclarationGroupPrototype` a `ModemachinInstance`

Previous versions of the Basic Software Modules especially the ECU state manager module have differentiated between ECU states and ECU modes. ECU modes were longer lasting operational ECU states that were visible to applications i.e. starting up, shutting down, going to sleep and waking up. The ECU Manager states were generally continuous sequences of ECU Manager module operations terminated by waiting until external conditions were fulfilled. Startup1, for example, contained all BSW initialization before the OS was started and terminated when the OS returned control to the ECU Manager module. With flexible ECU management the ECU state machine is implemented as general modes under the control of the BSW Mode Manager module. To overcome this terminology problem states are used only internally and are not visible to the application. For interaction with the application the basic software has to use modes.

2.4 Modes in the Basic Software Scheduler

The Basic Software Scheduler provides for Basic Software Modules a similar mechanism for mode communication as the RTE provides it for Software Components. If a Basic Software Module provides a `ModeDeclarationGroupPrototype` as `providedModeGroup` in its Basic Software Module Description the Basic Software Scheduler instantiates a `ModeMachineInstance`. Consequently for this Basic Software Module a `SchM\protect\T1\textunderscore Switch` API is provided, which enables this module to initiate a Mode switch. Mode users have to reference the `ModeDeclarationGroupPrototype` as `requiredModeGroup` and will get a `SchM\protect\T1\textunderscore Mode` API to read the mode, which is currently active. Mode requests between Basic Software Modules can be communicated directly via function calls, as Basic Software Modules.

Another possibility for a Basic Software Module acting as a Mode user to get informed about mode switches, is to register a BSW Module Entry, which is triggered by a Mode Switch Event (see also [4]).

2.5 Communication of modes

The Software Component Template differs the following distinctive types of mode communication between Mode managers and Mode users.

- **Mode Switch:** A Mode Switch is the communication of a current mode transition from one mode to another. Mode Switches are always initiated by Mode Managers.
- **Mode Request:** A Mode Request is the request of a mode user to the Mode Manager to enter a certain mode. Note that it is not guaranteed that the Mode Manager will enter this mode. Moreover he has to arbitrate all requests from the Mode Users and decide which mode he will enter.

Furthermore, the concept of Mode Proxies and information about communication of modes on multi core ECUs is given.

2.5.1 Mode switch

As every other communication between Software Components or between Software Components and Basic Software Modules, Modes are communicated via `PortPrototypes`. Each `PortPrototype` has to be typed by a `PortInterface`. In case of mode communication there exist so called mode switch interfaces, which are `PortInterfaces`. These are shown in Figure 2.3. Each `ModeSwitchInterface` has exactly one `ModeDeclarationGroupPrototype` which consists of multiple `ModeDeclarations`. Any `ModeDeclaration` represents one mode of the `ModeDeclarationGroup`. One of these is defined as the initial mode.




Figure 2.3: mode switch interface

These `Mode switches` are necessary because Software Components need to be capable of reacting to state changes initiated by a `ModeManager`. Depending on the configuration there are two mechanisms available how a Software Component can react on a mode change.

1. A `ModeSwitchEvent` can trigger a `OnExtry`, `OnTransition` or `OnEntryRunnable`.
2. An `RTEEvent` can be disabled in a certain mode and consequently prevent the execution of accordant `ExecutableEntities`.

2.5.2 Mode request

Mode requests are distributed on the way from the mode requester (Mode Arbitration SWC or a generic SWC) to the `mode manager`. The `mode managers` on each ECU then have to decide and initiate the local mode switch. Thus the arbitration result is communicated only locally on each ECU using RTE mode switch mechanism.

For `mode requests`, the communication of modes works slightly differently as for `mode switches`: without `ModeDeclarationGroups`.

The request of modes is done via standard `SenderReceiverInterfaces`. Contrarily to `ModeSwitchInterfaces` the requested mode is not given by a `ModeDeclarationGroup` but by a `VariableDataPrototype` that has to contain an enumeration. This enumeration consists of a set which contains the modes that can be requested.

Mode requests can be distributed in the whole system. For application and vehicle modes, the requests of the mode requester have to be distributed to all affected ECUs. This implies a 1:n-connection between the mode requester and the mode Managers. In AUTOSAR this is only possible with Sender-Receiver Communication. The mode manager only requires the information about the requested mode and not the mode switch from the mode requester. The `mode manager` has one Sender-Receiver port for each mode requester. To actually transmit the signal, COM shall use a periodic signal with signal timeout notification to RTE. The `mode manager` will use the data element outdated event to release a mode request.

2.5.3 Conformance of mode switches and mode requests

As stated above, the `ModeSwitchInterfaces` work with `ModeDeclarationGroups` whereas `mode request interfaces` takes parameters via `VariableDataPrototypes` containing enumerations.

The configuration utility is in duty to ensure with respect to consistency the equivalence of represented data in both representations. That means that the elements of the enumeration must precisely match the elements of the `ModeDeclarationGroup`. Or formulated another way: All modes available in one of the interfaces must also be available in the other one.

2.5.4 Mode proxies

Currently AUTOSAR has a constraint that only local software components are allowed to communicate with `ServiceComponents`. So it is not possible that a `SoftwareComponent` can request modes from a remote e.g Basic Software Mode Manager. To overcome this limitation so called `ServiceProxyComponentType` were introduced in AUTOSAR Release 4.0. Figure 2.4 depicts this concept.

For the application software and the RTE a `ServiceProxySoftwareComponentType` behaves like a "normal" `AtomicSwComponentType`, but it is actually a proxy for an AUTOSAR Service. This means that on the one side it has to communicate over service ports with the ECU-local `ServiceSwComponentType` it represents. On the other side it has to offer the corresponding `PortPrototypes` to the `ApplicationSwComponentTypes`. In the meta-model, the `ServiceProxySwComponentType` does not differ from an `ApplicationSwComponentType` except by its class. It is up to the implementer to meet the restrictions imposed by the semantics as a proxy. The main difference between a `ServiceProxySwComponentType` and an `ApplicationSwComponentType` is on system level: A prototype of a `ServiceProxySwComponentType` can be mapped to several ECUs even if it appears only once in the VFB system, because such a prototype is required on each ECU, where it has to address a local `ServiceSwComponentType`. As a result of this, a `ServiceProxySwComponentType` can only receive but not send signals over the network. (see also [2]).




Figure 2.4: Communication via ServiceProxySwComponents

2.5.5 Mode communication on multi core ECUs

The RTE does not synchronize `ModeMachineInstances` over the different partitions of an ECU. `rte_sws_2724` states that the RTE shall reject configurations where one `ModeDeclarationGroupPrototype` of a provide port is connected to `ModeDeclarationGroupPrototypes` of require ports from more than one partition. Consequently all `ModeUsers` of a `ModeDeclarationGroupPrototype` have to live inside a single partition. Note that the `ModeManager` of the `ModeDeclarationGroupPrototype` can of course exist in another partition as shown in Fig. 2.6




Figure 2.5: Invalid configuration

Figure 2.6: Corrected version according to [SWS_Rte_02724]

This limitation has a deep impact on mode managers with mode users on different cores. The mode manager has to provide a dedicated `ModePort` for each partition in which one or more of its mode users are located. To trigger a mode change it has to call `Rte_switch` for each mode port separately. If configured it will also get an separate `Mode_Switch_Acknowledgement` from each `ModeMachineInstance`. This means that the possible mapping of mode users and mode managers to different core has to be taken into account to some extent during design time of the Software Components.

3 Configuration of the Basic Software Modemanager

The BSW Mode Manager is the module that implements the part of the Vehicle Mode Management and Application Mode Management concept that resides in the BSW. Its responsibility is to arbitrate mode requests from application layer Software Components or other Basic Software Modules based on rules, and perform actions based on the arbitration result.

From an functional point view the BswM is responsible to put the Basic Software in a state so that the Basic Software can run properly and meet the functional requirements.

The configuration of the BswM is very project- and ECU- specific. Therefore it can not be standardized by AUTOSAR. Nevertheless it is expected that a BswM implementation behaves in specific situations in a certain way . This chapter starts with an introduction on the general concept of the BswM, which is more or less a execution environment for rules described by the user. Afterwards typical scenarios in the lifecycle of an ECU are described and examples are given how the BswM could be configured.

3.1 Process how to configure and integrate a BswM

The configuration and integration of a BswM into an ECU project consists of the same steps as for other Basic Software Modules. Nevertheless it is described for a better understanding of the next steps. In general the following actions have to be taken:

1. Create a ECUC configuration of the module. For the BswM this configuration contains:
 - (a) the necessary `ModeRequestSources`,
 - (b) the provided `ModeSwitchPorts`,
 - (c) a description of the `Rules` and `ActionLists`.
2. The configuration is used as input for the module generator, which creates
 - (a) a `SoftwareComponentDescription` of the AUTOSAR Interface,
 - (b) the implementation of the module¹.
3. The last step is to integrate the Module into the ECU by connecting the ports of the `Software Components` with the corresponding ports of the BswM.

¹This documents assumes that the Implementation of the BswM is generated to a large extend.

3.2 Semantics of BswM Configuration: Interfaces and behavioral aspects

In general the BswM can be seen as a state machine, which is defined by its interface and a behavioral description. The input actions of this state machine are mode requests. Each mode request is described in the ECU configuration of the BswM as a `BswMModeRequestSource`. These mode requests can be of different types (C-API calls, mode requests via RTE, mode notifications via RTE, etc.) but internally they are treated in the same way.

If a mode is requested the internal mirror of this `BswMModeRequestSource` is updated and depending on the configuration a rule evaluation is triggered, which results in the execution of predefined action lists. Action lists group Actions. Typically an action is a triggering of a mode switch in the RTE or Schedule Manager, but there are also predefined actions which change the status of some Basic Software Module.

3.2.1 Interface of the BswM

The interface is defined by the `BswMModeRequestSource` and the `BswMAction-ListItem` containers.

3.2.1.1 Mode Requests

`BswMModeRequestSource` is a `ChoiceContainer`, which can be of the following kinds:

1. C-APIs, which are defined in the specification of the BswM. `BasicSoftware-Modules` can directly call C-APIs from the BswM, who will translate them internally into a `ModeRequest`. For example a call to the API

```
BswM_CanSM_CurrentState(  
    NetworkHandleType Network,  
    CanSM_BswMCurrentStateType CurrentState  
)
```

is to be mapped to different `ModeRequestPorts` depending on the parameter `Network`, which identifies the channel on which the event occurred. The parameter `CurrentState` then contains the mode which is requested. The mode requests, which are defined by the standardized interface of the BswM are described in more detailed in [3.2.2.2](#)

2. `RPorts` typed by a `SenderReceiverInterface`. `BswMSwcModeRequest`: For each container of this type the BswM has to create a corresponding `RPort` in its Service Component Description.
3. `RPorts` typed by a `ModeSwitchInterface`. `BswMSwcModeNotification`: For each container of this type the BswM has to create a corresponding `RPort` in

its Service Component Description. As it is typed by a `ModeSwitchInterface` the BswM acts as a mode user of this `ModeMachineInstance` and is informed if the mode manager performs an `rte_switch`.

4. `RequiredModeDeclarationGroupPrototypeS` `BswMBswModeNotification`: For each container of this type the BswM has to create a corresponding `RequiredModeDeclarationGroupPrototype` in the role `required-ModeDeclarationGroup` in its Basic Software Module Description. In this case the BswM also acts as a mode user, but the `ModeMachineInstance` is maintained by the Schedule Manager. The BswM therefore gets informed if the mode manager e.g. another Basic Software Module performs a `SchM_Switch` call.

3.2.1.2 Available Actions

`BswMActionListItems` can be of the following kinds:

1. C-APIs from other BswM Modules, which are called directly during the execution of an `ActionList`.
 - `BswMComMAAllowCom`
 - `BswMComMModeLimitation`
 - `BswMComMModeSwitch`
 - `BswMDeadlineMonitoringControl`
 - `BswMEcuMGoDown`
 - `BswMEcuMSelectShutdownTarget`
 - `BswMJ1939Rm`
 - `BswMLinScheduleSwitch`
 - `BswMNMControl`
 - `BswMPduGroupSwitch`
 - `BswMPduRouterControl`
 - `BswMRteSwitch`
 - `BswMSchMSwitch`
 - `BswMSwitchIPduMode`
 - `BswMTriggerIPduSend`
 - `BswMTriggerSlaveRTESStop`
 - `BswMTriggerStartUpPhase2`
 - `BswMUserCallout`

2. `PPorts` typed by a `ModeSwitchInterface: SwitchPort` For each container of this type the BswM has to create a corresponding `PPort` in its Service Component Description if it is referenced by a `RteSwitch` action.
3. `ProvidedModeDeclarationGroupPrototypes SwitchPort:` For each container of this type the BswM has to create a corresponding `ProvidedModeDeclarationGroupPrototype` in the role `providedModeGroup` in its Basic Software Module Description if the `SwitchPort` is referenced by a `SchMSwitch` action. In this case the BswM also acts as a mode manager, but the `ModeMachineInstance` is maintained by the Schedule Manager.

3.2.2 Definition of the interface in pseudo code

The following paragraphs define the interface of the BswM in pseudo code.

3.2.2.1 Mode switch and mode request interfaces

An example of the BswM configuration of `ModeSwitchInterfaces` is shown in Listing 3.1. There is a `ModeDeclarationGroup` and a `ModeSwitchInterface` created. The `ModeSwitchInterface` uses the defined `ModeDeclarationGroup` as prototype where `exampleModes` is the short name of the `ModeSwitchInterface`.

Listing 3.1: Mode switch interface for the overall mode of a ECU

```
modeGroup MDG_ApplicationModes {
    APP_ACTIVE,
    APP_STARTING,
    APP_INACTIVE
}

interface modeSwitch MSIF_ApplicationModes {
    mode MDG_ApplicationModes appMode
}
```

A configuration of a `mode request interface` that corresponds to the `ModeSwitchInterface` of Listing 3.1 is shown as example in Listing 3.2. Out of this BswM configuration an `Arxml` description will be created which includes the mode declarations and interfaces. An excerpt of that `arxml` is shown in 3.3.

Listing 3.2: Declaration of a `Mode request interface`

```
enum ENUM_ApplicationModes{
    ModeA,
    ModeB,
    ModeC
}

interface senderReceiver exampleModeRequestPort {
    data ENUM_ApplicationsModes exampleModeRequest
}
```

Listing 3.3: Excerpt of the `mode request interface`'s ARXML description

```
<SENDER-RECEIVER-INTERFACE>
  <SHORT-NAME>exampleModeRequestPort</SHORT-NAME>
  <IS-SERVICE>false</IS-SERVICE>
  <DATA-ELEMENTS>
    <VARIABLE-DATA-PROTOTYPE>
      <SHORT-NAME>exampleModeRequest</SHORT-NAME>
      ...
      <TYPE-TREF DEST="APPLICATION-PRIMITIVE-DATA-TYPE">ENUM_ApplicationModes
        </TYPE-TREF>
    </VARIABLE-DATA-PROTOTYPE>
  </DATA-ELEMENTS>
</SENDER-RECEIVER-INTERFACE>

...

<APPLICATION-PRIMITIVE-DATA-TYPE>
  <SHORT-NAME>ENUM_ApplicationModes</SHORT-NAME>
  <CATEGORY>VALUE</CATEGORY>
  <SW-DATA-DEF-PROPS>
    <SW-DATA-DEF-PROPS-VARIANTS>
      <SW-DATA-DEF-PROPS-CONDITIONAL>
        <COMPU-METHOD-REF DEST="COMPU-METHOD">ENUM_ApplicationModes_def</
          COMPU-METHOD-REF>
        </SW-DATA-DEF-PROPS-CONDITIONAL>
      </SW-DATA-DEF-PROPS-VARIANTS>
    </SW-DATA-DEF-PROPS>
  </APPLICATION-PRIMITIVE-DATA-TYPE>

...

<COMPU-METHOD>
  <SHORT-NAME>ENUM_ApplicationModes_def</SHORT-NAME>
  <CATEGORY>TEXTTABLE</CATEGORY>
  <COMPU-INTERNAL-TO-PHYS>
    <COMPU-SCALES>
      <COMPU-SCALE>
        <LOWER-LIMIT INTERVAL-TYPE="CLOSED">0</LOWER-LIMIT>
        <UPPER-LIMIT INTERVAL-TYPE="CLOSED">0</UPPER-LIMIT>
        <COMPU-CONST>
          <VT>ModeA</VT>
        </COMPU-CONST>
      </COMPU-SCALE>
      <COMPU-SCALE>
        <LOWER-LIMIT INTERVAL-TYPE="CLOSED">1</LOWER-LIMIT>
        <UPPER-LIMIT INTERVAL-TYPE="CLOSED">1</UPPER-LIMIT>
        <COMPU-CONST>
          <VT>ModeB</VT>
        </COMPU-CONST>
      </COMPU-SCALE>
      <COMPU-SCALE>
        <LOWER-LIMIT INTERVAL-TYPE="CLOSED">2</LOWER-LIMIT>
        <UPPER-LIMIT INTERVAL-TYPE="CLOSED">2</UPPER-LIMIT>
        <COMPU-CONST>
          <VT>ModeC</VT>
        </COMPU-CONST>
      </COMPU-SCALE>
    </COMPU-SCALES>
  </COMPU-INTERNAL-TO-PHYS>
</COMPU-METHOD>
```

```

    </COMPU-CONST>
    </COMPU-SCALE>
  </COMPU-SCALES>
  </COMPU-INTERNAL-TO-PHYS>
</COMPU-METHOD>

```

Every mode request to the BswM has to be mapped to an restricted set of values, which allows the integrator the define the arbitration rules.

3.2.2.2 ModeRequestPorts defined by the standardized interface of the BswM

In the BswM configuration, the mode request sources have to be defined. The following ModeRequestPorts are implicitly defined by API of the BswM. This subsection summarizes the port interface.

The following ModeDeclarationGroups are defined in the particular SWS documents of the AUTOSAR specification as C-Enums. Nevertheless they are referenced here in form of BswM configurations which act as a base for the rest of this document. Refer to the definition of C-Enums in the SWS documents for the definition of modes.

3.2.2.2.1 BswMComMIndication

Purpose: Function called by ComM to indicate its current state.

Signature:

```

void BswM_ComM_CurrentMode(
    NetworkHandleType Network,
    ComM_ModeType RequestedMode
)

```

Modes: modeGroup ComM_ModeType

Example:

```

request ComMIndication ComM_Mode_Channell {
  processing IMMEDIATE
  initialValue COMM_NO_COM_NO_PENDING_REQUEST
  source MyComM.ComMChannell
}

```

Note: This ModeRequestSource has to be created once for each ComM-Channel identified by the Network parameter.

3.2.2.2.2 BswMComMPncRequest

Purpose: Function called by ComM to indicate the current state of a partial network.

Signature:

```

void BswM_ComM_CurrentPNCMode(
    PNCHandleType PNC,

```

```
ComM_PncModeType CurrentPncMode
)
```

Modes: modeGroup ComM_PncModeType

Example:

```
request ComMPncRequest PNC1 {
  processing IMMEDIATE
  initialValue PNC_NO_COMMUNICATION
  source MyComM.ComMPnc1
}
request ComMPncRequest PNC2 {
  processing IMMEDIATE
  initialValue PNC_NO_COMMUNICATION
  source MyComM.ComMPnc2
}
request ComMPncRequest PNC3 {
  processing IMMEDIATE
  initialValue PNC_NO_COMMUNICATION
  source MyComM.ComMPnc3
}
```

Note: This ModeRequestSource has to be created once for each partial network.

3.2.2.2.3 BswMDcmComModeRequest

Purpose: Function called by DCM to indicate the current state of CommunicationControl.

Signature:

```
void BswM_Dcm_CommunicationMode_CurrentState(
    NetworkHandleType Network,
    Dcm_CommunicationModeType RequestedMode
)
```

Modes: modeGroup Dcm_CommunicationModeType

Example:

```
request DcmComModeRequest
  BswM_Dcm_CommunicationMode_CurrentState {
  processing IMMEDIATE
  initialValue DCM_ENABLE_RX_TX_NORM
  network "network1"
}
```

3.2.2.2.4 BswMCanSMIndication

Purpose: Function called by CanSM to indicate its current state.

Signature:

```
void BswM_CanSM_CurrentState(
    NetworkHandleType Network,
    CanSM_BswMCurrentStateType CurrentState
)
```

Modes: modeGroup CanSM_BswMCurrentStateType

Example:

```

request CanSMIndication CanSM_Can1 {
  processing IMMEDIATE
  initialValue CANSMBBWMNOCOMMUNICATION
  source MyComM.CanNet1
}

request CanSMIndication CanSM_Can2 {
  processing IMMEDIATE
  initialValue CANSMBBWMNOCOMMUNICATION
  source MyComM.CanNet2
}

```

Note: This ModeRequestSource has to be created once for each CAN channel.

3.2.2.2.5 BswMEthSMIndication

Purpose: Function called by EthSM to indicate its current state.

Signature:

```

void BswM_EthSM_CurrentState(
    NetworkHandleType Network,
    EthSM_NetworkModeStateType CurrentState
)

```

Modes: modeGroup EthSM_NetworkModeStateType

Example:

```

request EthSMIndication EthSM_Network1 {
  processing IMMEDIATE
  initialValue ETHSMNOCOMMUNICATION
  source MyComM.EthSmNetwork
}

```

Note: This ModeRequestSource has to be created once for each ethernet channel.

3.2.2.2.6 BswMFrSMIndication

Purpose: Function called by FrSM to indicate its current state.

Signature:

```

void BswM_FrSM_CurrentState(
    NetworkHandleType Network,
    FrSM_BswM_StateType CurrentState
)

```

Modes: modeGroup FrSM_BswM_StateType

Example:

```

request FrSMIndication FrSM_BswM_StateType {
  processing IMMEDIATE
  initialValue FRSM_BBWM_READY
}

```

```

    source MyComM.EthSmNetwork
}

```

Note: This ModeRequestSource has to be created once for each FlexRay cluster.

3.2.2.2.7 BswMLinSMIndication

Purpose: Function called by LinSM to indicate its current state.

Signature:

```

void BswM_LinSM_CurrentState(
    NetworkHandleType Network,
    LinSM_ModeType CurrentState
)

```

Modes: modeGroup LinSM_ModeType

Example:

```

request LinSMIndication LinSM_CurrentState {
    processing IMMEDIATE
    initialValue LINSM_NO_COM
    source MyComM.LinSMChannel
}

```

Note: This ModeRequestSource has to be created once for each Lin channel.

3.2.2.2.8 BswMEcuMIndication

Purpose: Function called by the ECUM with fixed state machine to indicate its current state.

Signature:

```

void BswM_EcuM_CurrentState(
    EcuM_StateType CurrentState
)

```

Modes: modeGroup EcuM_StateType

Example:

```

request EcuMIndication EcuM_State {
    processing IMMEDIATE
    initialValue ECUM_STATE_STARTUP
}

```

3.2.2.2.9 BswMEcuMWakeupSource

Purpose: Function called by the ECUM to indicate the current state of the wakeup sources.

Signature:

```

void BswM_EcuM_CurrentWakeup(
    EcuM_WakeupSourceType source,

```



```
        EcuM_WakeupStatusType state
    )
```

Modes: modeGroup EcuM_WakeupStatusType

Example:

```
request EcuMWakeupSource EcuM_WakeupSource {
    processing IMMEDIATE
    initialValue ECUM_WKSTATUS_NONE
    source MyEcuM.EcuMWakeupSource1
}
```

Note: This ModeRequestSource has to be created once for each Wakeup source.

3.2.2.2.10 BswMLinScheduleIndication

Purpose: Function called by LinSM to indicate the currently active schedule table for a specific LIN channel.

Signature:

```
void BswM_LinSM_CurrentSchedule(
    NetworkHandleType Network,
    LinIf_SchHandleType CurrentSchedule
)
```

Modes: The reported modes depend on the configured schedules in the Lin Statemanager.

Example:

```
request LinScheduleIndication LinSM1_CurrentSchedule {
    processing IMMEDIATE
    initialValue TBD
    source MyLinSM.LinSMChannel
}
```

3.2.2.2.11 BswMLinTpModeRequest

Purpose: Function called by LinTP to request a mode for the corresponding LIN channel. The LinTp_Mode mainly correlates to the LIN schedule table that should be used.

Signature:

```
void BswM_LinTp_RequestMode(
    NetworkHandleType Network,
    LinTp_Mode LinTpRequestedMode
)
```

Modes: modeGroup LinTp_Mode

Example:

```
request LinTpModeRequest LinTp_Mode {
    processing IMMEDIATE
    initialValue LINTP_APPLICATIVE_SCHEDULE
    source MyLinIF.config0.LinIFChannel
}
```

3.2.2.2.12 BswMNvMJobModeIndication

Purpose: Indicates the current status of the multiblock job. The job is identified via BswMNvmService, e.g. 0x0c for NvmReadAll, 0x0d for NvmWriteAll.

Signature:

```
void BswM_NvM_CurrentJobMode(
    uint8 ServiceId,
    NvM_RequestResultType CurrentJobMode
)
```

Modes: modeGroup NvM_RequestResultType

Example:

```
request NvMJobModeIndication NvMWriteAllJobMode {
    service WriteAll
    initialValue NVM_BLK_NOT_OK
    processing IMMEDIATE
}

request NvMJobModeIndication NvMReadAllJobMode {
    service ReadAll
    initialValue NVM_BLK_NOT_OK
    processing IMMEDIATE
}
```

3.2.2.2.13 BswMNvMRequest

Purpose: Via this Mode Request Source the NvM indicates the current status of the specified block.

Signature:

```
void BswM_NvM_CurrentBlockMode(
    NvM_BlockIdType Block,
    NvM_RequestResultType CurrentBlockMode
)
```

Modes: modeGroup NvM_RequestResultType

3.2.2.2.14 BswMJ1939NmIndication

Signature:

```
void BswM_J1939Nm_StateChangeNotification(
    NetworkHandleType nmNetworkHandle,
    uint8 Node,
    Nm_StateType nmCurrentState
)
```

Modes: modeGroup Nm_StateType

Example:

```
request BswMJ1939NmIndication J1939NmState {
    network "Channel1"
```

```
node "Node1"
  initialValue NM_STATE_UNINIT
  processing IMMEDIATE
}
```

Note: This ModeRequestSource has to be configured for each channel managed by J1939 network management. This type of Mode Request Source is currently not supported by ARText.

3.2.2.2.15 BswMWdgMRequestPartitionReset

Signature: `void BswM_WdgM_RequestPartitionReset (ApplicationType Application)`

Modes: `modeGroup WdgM_PartitionResetType`

Example:

```
request WdgMRequestPartitionReset WdgM_RequestResetPart1 {
  processing IMMEDIATE
  initialValue Wdgm_Partition_Reset_NotRequested
  source MyEcuC.eCucPartition
}
```

Note: This ModeRequestSource has to be created once for each partition for which a reset can be requested by the Watchdog Manager module.

3.2.2.2.16 BswMJ1939DcmBroadcastStatus

Signature: `void BswM_J1939DcmBroadcastStatus (uint16 networkMask)`

Modes: `modeGroup J1939DcmBroadcastStatusType`

Example:

```
request BswMJ1939DcmBroadcastStatus
J1939BroadcastStatusChannel1 {
  processing IMMEDIATE
  initialValue NETWORK_DISABLED
  source MyComM.CanNet1
}
```

Note: This is a notification of the desired broadcast status per network, triggered via DM13.

3.2.2.3 Configurable ModeRequestPorts

Besides the interface, which is defined by the standardized interface of the BswM, additional mode request ports can be defined via the configuration parameters.

E.g. it is necessary for the interaction with applications, that an application software component at least notifies the BswM about its current state. This can be achieved by definition of a `ModeRequestPort` as shown in Listing 3.4. The BswM will then create a corresponding `RPort` typed by a `SenderReceiverInterface`.

Listing 3.4: Application ModeRequestPort

```
request SwcModeRequest ApplModeRequest {
    source MSIF_ApplicationModes.appMode
    processing IMMEDIATE
    initialValue ModeA
}
```

Note that the reference to a `ModeDeclarationGroupPrototype` can be misleading. The meaning is that the BswM creates a `SenderReceiverInterface` containing a `VariableDataPrototype`. The `SwDataDefProps` of this `VariableDataPrototype` refer to a `CompuMethod`, which defines an enumeration corresponding to the referred `ModeDeclarationGroupPrototype`.

Listing 3.5: Application ModeNotification

```
request SwcModeNotification ApplModeNotification {
    source MSIF_ApplicationModes.appMode
    processing IMMEDIATE
    initialValue ModeA
}
```

Listing 3.5 shows the declaration of a mode notification port. Note that in contrast to 3.4 the BswM will generate a `RPort` typed by a `ModeSwitchInterface` in this case. The BswM then gets informed via a `ModeSwitchNotification` if the mode manager initiates a mode switch.

Listing 3.6: BasicSoftwareModeNotification

```
request BswModeNotification EcuMode {
    source MSIF_EcuMode.ecuMode
    processing IMMEDIATE
    initialValue ECU_STARTUP_ONE
}
```

Listing 3.6 shows the declaration of a mode notification port. If such a port is configured, the BswM configuration tool will create a `requiredModeGroup ModeDeclarationGroupPrototype`, so that the BswM gets informed of mode switches via the Schedule Manager, if the corresponding mode manager initiates a mode switch with a call to `SchM_Switch` API.

3.2.2.4 Configurable ModeSwitchPorts

In the configuration of the BswM contains `BswMSwitchPorts`. These containers contain references to mode switch interfaces. If a `BswMSwitchPorts` is referenced by a `BswMSchMSwitch` action the module generator of the BswM shall create

a providedModeGroup ModeDeclarationGroupPrototype. If a BswMSwitchPorts is referenced by a BswMRteSwitch action the module generator of the BswM shall create a PPort typed by the corresponding ModeSwitchInterface. 3.7 show an example for a mode switch port.

Listing 3.7: Example for a configurable mode switch port

```
switchport EcuMode {
  modeSwitchinterface MSIF_EcuMode
}
```

3.2.3 Configuration of the BswM behavior

The behavior of the BswM is specified via rules and action lists. A rule is a logical expression, which combines the current values of ModeRequestPorts. The evaluation of each rule either results in the execution of its true or false action lists.

The ModeControlContainer contains these ActionLists. An ActionList can consist of a set of atomic actions, other “nested” ActionLists or it can reference (nested) rules which are then evaluated in the context of this Actionlist.

The following example shows a simple rule, which activates the IPDU Groups of a dedicated CAN channel. According to this rule, the BswM has to provide a ModeRequestPort of type CanSMIndication named Can1_Indication. This is a ModeRequest from a basic software module in this case from the Can State manager. In code this ModeRequestPorts corresponds to the API BswM_CanSM_CurrentState as described in [SWS_BswM_00049] in [5]. The source parameter identifies the network to which this ModeRequestSourcePort belongs to. It's up to the configuration tool of the BswM to allocate the right parameters for the API corresponding to the referenced ECUC Container.

The value of the ModeRequestSourcePort initially is CAN_SM_BswM_NO_COMMUNICATION.

processing immediate means that every evaluation rule, which refers to this ModeRequestSourcePort shall immediately be processed. If this parameter would be deferred in case of a ModeRequest, the evaluation of rules would be delayed until the next run of the main function of the BswM.

The following example shows an arbitration rule called canIPDUActivation. The overall content is rather self explanatory. The initial parameters specifies that the initial result of the rule evaluation is false.

Listing 3.8: Example for a rule

```
rule checkApplRequest initially false {
  if ( ApplModeRequest == MDG_ApplicationModes.ModeA && EcuMode ==
    MDG_EcuMode.ECU_RUN) {
    actionlist checkApplRequestTrueActions
  }
}
```

```
actions checkApplRequestTrueActions on condition {
  ComMAllowCom MyComM.CanNet1 true
  SchMSwitch EcuMode : ECU_RUN
}
```

At which point in time a rule is executed, after an event has occurred depends on the parameter `BswMActionListExecution`. Either it is executed every time the rule is evaluated with the corresponding result, or only when the evaluation result has changed from the previous evaluation. This is called `triggered` respectively `conditional` execution.

Table 3.1 gives an overview in which situations an `ActionList` is executed or not. Triggered `ActionLists` are executed (triggered) if the result of the rule evaluation changes. Conditional `ActionLists` depend only on the current result (condition) of the evaluation independent if it has changed or not.

Table 3.1: Execution of Action Lists depending on parameter `BswMActionListExecution`

eval. result (old) -> (new)	true -> true	true -> false	false -> false	false -> true
TrueActionList	CONDITION	-	-	TRIGGERED/ CONDITION
FalseActionList	-	TRIGGERED/ CONDITION	CONDITION	-

3.3 ECU state management

During startup and shutdown the task of the BswM is to initialize all basic software modules in a similar way as it is done by the ECUM in older AUTOSAR releases. To achieve this the following `ModeDeclarationGroup` is defined, which indicates the overall state of the ECU to application software components and is used for internal rule arbitration.

The modes of this `ModeDeclarationGroup` are named similar to the states of the ECUM with fixed state machine. Nevertheless they have due to several reasons not exactly the same semantics.

Listing 3.9: ModeDeclarationGroup for overall ECU state management

```
modeGroup MDG_EcuMode {
  ECU_RUN,
  ECU_APP_RUN,
  ECU_APP_POST_RUN,
  ECU_GO_SLEEP,
  ECU_GO_OFF_ONE,
  ECU_SLEEP,
  ECU_GO_OFF_TWO,
  ECU_STARTUP_ONE,
  ECU_STARTUP_TWO,
  ECU_RESET_READY
}
```

```
interface modeSwitch MSIF_EcuMode {
    mode MDG_EcuMode ecuMode
}
```

The initial mode of this ModeDeclarationGroup is ECU_STARTUP_ONE.

3.3.1 Startup

The ECUM starts the operating system and initializes in its *post OS sequence* the Schedule manager and the BswM. The BswM then has to take care, that all necessary init routines of the basic software modules are called and that the RTE is started.

In this scenario it is expected that the BswM has the following `providedModeGroup`. The purpose of this `modeGroup` is to track the current state/mode of the ECU similar to the states of the ECU State manager in previous AUTOSAR releases.

Rule `InitBlockII` specifies the initialization of basic drivers to access the NVRAM and initiates `NvM_ReadAll`. As the `EcuMode` source has the processing attribute set to `DEFERRED` this rule will be evaluated every time the main function of the BswM is called. After the first run it sets the `EcuMode` to `ECU_STARTUP_TWO` so that the action list will never be invoked again.

If the `NvM_ReadAll` job is finished the `NvM_ReadAllFinished` rule is triggered, which initiates the remaining initialization and switches the `EcuMode` to `ECU_RUN`.

Listing 3.10: Rules and ActionLists for Startup

```
rule InitBlockII initially false {
    if ( EcuMode == MDG_EcuMode.ECU_STARTUP_ONE ) {
        actionlist InitBlockIIActions
    }
}

actions InitBlockIIActions on condition {
    custom "Spi_Init(null)"
    custom "Eep_Init(null)"
    custom "Fls_Init(null)"
    custom "NvM_Init(null)"
    SchMSwitch EcuMode : ECU_STARTUP_TWO
    custom "NvM_ReadAll()"
}

rule NvM_ReadAllFinished initially false {
    if ( NvM_ReadAllJobMode == NVM_REQ_OK && EcuMode == MDG_EcuMode.
        ECU_STARTUP_TWO ) {
        actionlist NvM_ReadAllFinishedActions
    }
}

actions NvM_ReadAllFinishedActions on condition {
    custom "Can_Init(null)"
}
```

```

custom "CanIf_Init (null) "
custom "CanSM_Init (null) "
custom "CanTp_Init (null) "
custom "Lin_Init (null) "
custom "LinIf_Init (null) "
custom "LinSM_Init (null) "
custom "LinTp_Init (null) "
custom "Fr_Init (null) "
custom "FrIf_Init (null) "
custom "FrSM_Init (null) "
custom "FrTp_Init (null) "
custom "PduR_Init (null) "
custom "CANNM_Init (null) "
custom "FrNM_Init (null) "
custom "NmIf_Init (null) "
custom "IpduM_Init (null) "
custom "COM_Init (null) "
custom "DCM_Init (null) "
custom "ComM_Init (null) "
custom "DEM_Init (null) "
custom "StartRte () "
SchMSwitch EcuMode : ECU_RUN
}

```

When the RTE is started the runnables will be started. Now it is up to the application to keep the ECU running. To achieve this the BswM can for example provide a `ModeRequestPort` as depicted in example 3.4. For the further reading is expected, that the application software requests the mode `APP1_ACTIVE` from the BswM. If this mode is requested the BswM shall not shutdown the ECU.

Listing 3.11: Application runs, enable communication

```

rule checkApp1Request initially false {
if ( App1ModeRequest == MDG_ApplicationModes.ModeA && EcuMode ==
    MDG_EcuMode.ECU_RUN) {
    actionlist checkApp1RequestTrueActions
  }
}

actions checkApp1RequestTrueActions on condition {
  ComMAllowCom MyComM.CanNet1 true
  SchMSwitch EcuMode : ECU_RUN
}

```

3.3.2 Run

As the BswM is a highly flexible module it depends to a high extend to the integrator, how it is determined if an ECU shall shut down or not. Many different variants are conceivable. This document proposes an approach, which is quite similar to the concept of the ECUM in AUTOSAR R3.1. The general concept is, that a ECU keeps running as long as at least one application software component requests the run state.

The information if an application can be shut down in a certain mode has to be provided by the software component developer. Example 3.12 shows a simplified rule for an ECU with one software component. If switches its mode to `INACTIVE` the BswM initiates the shutdown sequence.

Listing 3.12: Initiate shutdown, if no application wants to run any more

```
rule checkApplRequest initially false {
  if ( ApplModeRequest == MDG_ApplicationModes.APP_INACTIVE && EcuMode ==
    MDG_EcuMode.ECU_RUN) {
    actionlist checkApplRequestActions
  }
}

actions checkApplRequestActions on condition {
  ComMAllowCom ArMmExample.EcuC.MyComM.ComMChannel1 false
  SchMSwitch EcuMode : ECU_APP_POST_RUN
}
```

3.3.3 Shutdown

In state `ECU_APP_POST_RUN` the BswM waits until all channels report, that no requests are pending any more. The rule in listing 3.12 is triggered every time the mode of a ComM channel changes. If there are multiple ComM channels, they have to be combined to a single expression.

Listing 3.13: Shutdown sequence

```
rule InitiateShutdown initially false {
  if ( ComM_Mode_Channel1 == COMM_NO_COM_REQUEST_PENDING && EcuMode ==
    MDG_EcuMode.ECU_APP_POST_RUN) {
    actionlist InitiateShutdownActions
  }
}

actions InitiateShutdownActions on condition {
  custom "Dem_Shutdown(null) "
  custom "Rte_Stop() "
  custom "ComM_DeInit() "
  SchMSwitch EcuMode : ECU_GO_OFF_ONE
  custom "NvM_WriteAll() "
}

rule NvMWriteAllFinished initially false {
  if ( NvMWriteAllJobMode == NVM_BLK_OK && EcuMode == MDG_EcuMode.
    ECU_GO_OFF_ONE) {
    actionlist NvMWriteAllFinishedTrueActions
  }
}

actions NvMWriteAllFinishedTrueActions on condition {
  custom "EcuM_SelectShutdownCause(ECUM_CAUSE_ECU_STATE) "
  custom "EcuM_GoDown(MODULE_ID) "
}
```

Note that in the configuration of the ECUM the module id of the BswM has to be added as a valid user to `EcuMFlexUserConfig`.

3.3.4 Sleep

Entering a sleep state is similar to the shutdown sequence [3.12](#) except that `EcuM_GoHalt` resp. `EcuM_GoPoll` is called instead of `EcuM_GoDown`.

3.3.5 Wakeup

Example [3.14](#) shows a rule which starts the ECU only, if a certain wakeup event, identified by `EcuM_WakeupSource` has occurred. Otherwise the ECU will be immediately shut down.

Listing 3.14: start sequence with wakeup check

```
rule InitBlockII initially false {
    if ( EcuMode == MDG_EcuMode.ECU_STARTUP_ONE && EcuM_WakeupSource ==
        ECUM_WKSTATUS_VALIDATED) {
        actionlist InitBlockIITrueActions
    } else {
        actionlist InitBlockIIFalseActions
    }
}

actions InitBlockIITrueActions on condition {
    custom "Spi_Init(null)"
    custom "Eep_Init(null)"
    custom "Fls_Init(null)"
    custom "NvM_Init(null)"
    SchMSwitch EcuMode : ECU_STARTUP_TWO
    custom "NvM_ReadAll()"
}

actions InitBlockIIFalseActions on condition {
    custom "EcuM_GoDown(MODULE_ID)"
}
```

3.4 Communication Management

Besides parts of the ECU state management, the BswM is also responsible for parts of the communication management. This section describes the functionality of the BswM, which is related to the Communication Stack of AUTOSAR. This covers but is not restricted to the following use cases.

- Starting and stopping of IPDU Groups in general
- Partial Networking

- Diagnostic use cases which influence the communication of an ECU. e.g. it might be necessary to set the FlexRay State manager to passive mode via `FrSm_SetEcuPassive()` when requested by an application.

To fulfill the requested functionality the BswM has ModeRequestSources to

- the Communication Manager
- the bus state managers
- AUTOSAR COM

3.4.1 Startup and Shutdown

Besides the initialization of the communication stack the BswM can be configured to initialize further modules or execute customs actions depending on the ECU's needs. Due to the flexibility of the BswM it is also possible, that after a wake up event only a part of the communication stack is started.

Analogue to Startup, it is possible to configure additional actions to be executed on shutdown.

3.4.2 I-PDU Group Switching

For the I-PDU group switching it is expected that there exists for each channel a dedicated I-PDU group for outgoing and incoming I-PDUs in COM. AUTOSAR COM takes care that an I-PDU is active(started) if at least one I-PDU group containing this I-PDU is active.

To illustrate how the I-PDUs of an ECU can be managed the following scenario is created. The exemplary ECU shall have two CAN channels and three partial networks. The mode request ports for the channels are named `CanSM_Can1` and `CanSM_Can2`, the request sources for the partial networks are named `PNC1`, `PNC2` and `PNC3`.

I-PDUs of `PNC1` shall be communicated only over `Channel1`. I-PDUs of `PNC3` shall be communicated over `Channel1` and `Channel2`. I-PDUs of `PNC2` shall be communicated only over `Channel2`.

In case of an indication by a bus state manager the BswM shall check, which partial networks are requested.

Listing 3.15: Active wakeup on channel

```
rule activeWakeupChannel1 initially false {
  if ( CanSM_Can1 == CANSM_BSWM_FULL_COMMUNICATION) {
    actionlist activeWakeupChannel1Actions
  }
}
```

```
actions activeWakeupChannel1Actions on condition {
    rule pnc1requested
    rule pnc2requested
    rule pnc3requested
}
```

```
rule activeWakeupChannel2 initially false {
    if ( CanSM_Can2 == CANSM_BSWM_FULL_COMMUNICATION &&
        PNC2 != PNC_REQUESTED &&
        PNC3 != PNC_REQUESTED
    ) {
        actionlist activeWakeupChannel2Actions
    }
}
```

```
actions activeWakeupChannel2Actions on condition {
    rule pnc1requested
    rule pnc2requested
    rule pnc3requested
}
```

If a bus state manager reports that the bus is going silent the BswM stop the corresponding I-PDU groups. If the channel is part of a partial network the whole partial network has to be stopped.

Listing 3.16: CanSM reports SILENT_COMMUNICATION or NO_COMMUNICATION

```
rule stopComChannel1 initially false {
    if ( CanSM_Can1 == CANSM_BSWM_SILENT_COMMUNICATION ||
        CanSM_Can1 == CANSM_BSWM_NO_COMMUNICATION
    ) {
        actionlist stopComChannel1Actions
    }
}

actions stopComChannel1Actions on condition {
    PduGroupSwitch {
        init true
        disable ArMmExample.EcuC.MyCom.CAN1IPDUS, ArMmExample.EcuC.MyCom.
            PNC1IPDUS, ArMmExample.EcuC.MyCom.PNC2IPDUS
    }
}

rule stopChannel2 initially false {
    if ( CanSM_Can2 == CANSM_BSWM_SILENT_COMMUNICATION ||
        CanSM_Can2 == CANSM_BSWM_NO_COMMUNICATION
    ) {
        actionlist stopChannel2Actions
    }
}

actions stopChannel2Actions on condition {
    PduGroupSwitch {
        init true
```

```

        disable ArMmExample.EcuC.MyCom.CAN2IPDUS, ArMmExample.EcuC.MyCom.
        PNC2IPDUS, ArMmExample.EcuC.MyCom.PNC3IPDUS
    }
}

```

In case that a single partial network is going down the IPDU group representing this network has to be switched off.

Listing 3.17: PNC reports NO_COMMUNICATION

```

rule pnc1nocom initially false {
    if ( PNC1 == PNC_NO_COMMUNICATION ) {
        actionlist pnc1nocomTrueActions
    }
}

actions pnc1nocomActions on condition {
    PduGroupSwitch {
        init true
        disable ArMmExample.EcuC.MyCom.PNC1IPDUS
    }
    DeadlineMonitoring {
        disable ArMmExample.EcuC.MyCom.PNC1IPDUS
    }
}

rule pnc2nocom initially false {
    if ( PNC2 == PNC_NO_COMMUNICATION ) {
        actionlist pnc2nocomTrueActions
    }
}

actions pnc2nocomActions on condition {
    PduGroupSwitch {
        init true
        disable ArMmExample.EcuC.MyCom.PNC2IPDUS
    }
    DeadlineMonitoring {
        disable ArMmExample.EcuC.MyCom.PNC2IPDUS
    }
}

rule pnc3nocom initially false {
    if ( PNC3 == PNC_NO_COMMUNICATION ) {
        actionlist pnc3nocomActions
    }
}

actions pnc3nocomActions on condition {
    PduGroupSwitch {
        init true
        disable ArMmExample.EcuC.MyCom.PNC3IPDUS
    }
    DeadlineMonitoring {
        disable ArMmExample.EcuC.MyCom.PNC3IPDUS
    }
}

```

}

If a partial network is requested the IPDU group is turned on.

Listing 3.18: PNC reports PNC_REQUESTED or PNC_READY_SLEEP

```

rule pnc1requested initially false {
  if ( PNC1 == PNC_REQUESTED ||
      PNC1 == PNC_READY_SLEEP ) {
    actionlist pnc1requestedActions
  }
}

actions pnc1requestedActions on condition {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.PNC1IPDUS
  }
}

rule pnc2requested initially false {
  if ( PNC2 == PNC_REQUESTED ||
      PNC2 == PNC_READY_SLEEP ) {
    actionlist pnc2requestedActions
  }
}

actions pnc2requestedActions on condition {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.PNC2IPDUS
  }
}

rule pnc3requested initially false {
  if ( PNC3 == PNC_REQUESTED ||
      PNC3 == PNC_READY_SLEEP ) {
    actionlist pnc3requestedActions
  }
}

actions pnc3requestedActions on condition {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.PNC3IPDUS
  }
}

```

In case of an indication that the partial network statemachine has switched to the prepare sleep state only the deadline monitoring of the corresponding IPDU groups shall be turned off but the IPDUs are still transmitted until the state PNC_OFF is reached.

Listing 3.19: PNC reports PNC_PREPARE_SLEEP

```

rule pnc1preparesleep initially false {
  if (PNC1 == PNC_PREPARE_SLEEP)
  {
    actionlist pnc1preparesleepActions
  }
}

```

```

    }
}

actions pnc1preparesleepActions on condition {
    PduGroupSwitch {
        init true
        enable ArMmExample.EcuC.MyCom.PNC1IPDUS
    }
    DeadlineMonitoring {
        disable ArMmExample.EcuC.MyCom.PNC1IPDUS
    }
}

rule pnc2preparesleep initially false {
    if (PNC2 == PNC_PREPARE_SLEEP )
    {
        actionlist pnc2preparesleepActions
    }
}

actions pnc2preparesleepActions on condition {
    PduGroupSwitch {init true
        enable ArMmExample.EcuC.MyCom.PNC2IPDUS
    }
    DeadlineMonitoring {
        disable ArMmExample.EcuC.MyCom.PNC2IPDUS
    }
}

rule pnc3preparesleep initially false {
    if (PNC3 == PNC_PREPARE_SLEEP )
    {
        actionlist pnc3preparesleepActions
    }
}

actions pnc3preparesleepActions on condition {
    PduGroupSwitch {init true
        enable ArMmExample.EcuC.MyCom.PNC3IPDUS
    }
    DeadlineMonitoring {
        disable ArMmExample.EcuC.MyCom.PNC3IPDUS
    }
}

```

3.4.3 J1939 Networkmanagement

In contrast to current AUTOSAR network management, the task of J1939 network management is not to handle sleep and wake-up of ECUs, but to assign unique addresses to each node represented by an ECU.

This is achieved by sending the AddressClaimed (AC, 0x0EE00) parameter group at start-up, which announces the desired address. If another node claims the same address, and has higher priority, the node has to go silent after sending the Cannot-ClaimAddress parameter group (AC with null address as SA), or try to use another address.

To support this use case the BswM is extended to accept state change indications from the J1939Nm via the API function `BswM_J1939Nm_StateChangeNotification()` (see also [3.2.2.2.14](#)).

Depending on the state indicated by the network management the BswM needs to switch ComIPduGroups of COM, PduRRoutingPathGroups of PduR, and general request handling of the J1939Rm.

The first two actions are realized via `BswMPduGroupSwitch-` and `BswMPduRouterControl` -actions. The J1939 Request Manager shall be switched using the `BswMJ1939Rm` action.

COM is expected to have IPDU groups containing all locally received and transmitted I-PDUs for each network. The PduR shall be configured in the same way, having RoutingPathGroups for all locally received and transmitted IPDUs for each channel, excluding the received I-PDU for the Request message forwarded to the J1939Rm.

The BswM must then be configured to switch on and off the aforementioned IPDU groups and PduRRoutingPathGroups depending on the reported NM states, as well as general request handling of the J1939 Request Manager. The following rule shows the actions of the BswM depending on the NM states.

Listing 3.20: Rule to implement network management according to J1939²

```
rule J1939_nm_normal_operation initially false {
  if ( J1939NmState == NM_STATE_NORMAL_OPERATION ) {
    actionlist J1939NormalOperationActions
  }
}

actions J1939NormalOperationActions on condition {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.J1939IPDUS
  }
  PduRoute enable J1939_RoutingPath
  custom "J1939Rm_SetState(J1939RM_STATE_ONLINE) "
  custom "Xcp_SetTransmissionMode(CHANNEL1,XCP_TX_ON) "
}

rule J1939_nm_offline initially false {
  if ( J1939NmState != NM_STATE_NORMAL_OPERATION ) {
    actionlist J1939OfflineActions
  }
}

actions J1939OfflineActions on condition {
```



```
PduGroupSwitch {
    disable ArMmExample.EcuC.MyCom.J1939IPDUS
}
PduRoute disable J1939_RoutingPath
custom "_J1939Rm_SetState(J1939RM_STATE_OFFLINE)"
custom "Xcp_SetTransmissionMode(CHANNEL1,XCP_TX_OFF)"
}
```

3.4.4 J1939 diagnostic mode management

In addition to address assignment the BswM has also to supervise the sending of broadcast messages in a J1939 environment. Each IPDU group represents the broadcast messages (J1939 PGs with PDU2 format PGN or PDU1 format PGN and broadcast destination address) of one network.

For this purpose it is also expected that COM contains one IPDU group for each channel, which contains the broadcast messages of this ECU.

Listing 3.21: Rule to implement broadcast management according to J1939

```
rule J1939_broadcast_management initially false {
    if ( BswMJ1939DcmBroadcastStatus == NETWORK_ENABLED) {
        actionlist J1939ActivateBroadcastActions
    } else {
        actionlist J1939DeactivateBroadcastActions
    }
}

actions J1939ActivateBroadcastActions on condition {
    PduGroupSwitch {
        init true
        enable ArMmExample.EcuC.MyCom.J1939BroadcastIPDUS
    }
}

actions J1939DeactivateBroadcastActions on condition {
    PduGroupSwitch {
        disable ArMmExample.EcuC.MyCom.J1939BroadcastIPDUS
    }
}
```

3.4.5 Pretended Networking

When implementing the Pretended Networking concept, the BswM should be user-configured to support the mode management requirements. The following subchapters contain recommendations regarding the BswM configuration for Pretended Networking.

²It is recommended to use the BswMJ1939Rm action instead of the custom calls. The custom calls are only used in this listing as they are not supported in the current ARTtext version.

3.4.5.1 Activation of Pretended Networking

For the configuration of the activation of Pretended Networking the following aspects have to be considered:

- The BswM should be configured to arbitrate the Mode Request. If there are different ICOM Mode Requests received during the same arbitration cycle of the BswM, the request with the lowest ICOM Configuration ID should be used.
- The BswM should be configured to request FULL_COM in ComM in order to prevent ComM from deactivating the CAN transceiver when switching to Pretended Networking (transceiver stays in CANTRCV_NORMAL).
- Pretended Networking needs to be supported by the BswM on a per channel basis. For this, the BswM should be configured with separate sets of Requests/Rules/Actions for each channel.
- BswM should switch to Pretended Networking if and only if all SWCs affected by activation of Pretended Networking have requested a switch to Pretended Networking by a ModeRequest for this channel.
- The configured rules in the BswM should only take action on valid requested ICOM Configuration IDs. Therefore the BSW configurator should setup rules and actions which only react to valid ICOM IDs, such as in the following pseudo code sample:

```
if(IcomConfigId == 0) doActionList1;  
if(IcomConfigId == 1) doActionList2;  
//ignore all other IcomConfigIds
```

- BswM should be configured to stop all I-PDU groups for a channel to be switched to Pretended Networking.
- BswM should be configured to request activation of Pretended Networking in <bus>SM by calling <bus>SM_SetIcomConfiguration.
- BswM should be configured to handle a notification from <bus>SM (e.g. CanSm calls Bswm_CanSm_CurrentIcomConfiguration) if activation of Pretended Networking was successful. This can be performed by means of the ModeRequest-Source "BswMCanSMIcomIndication".
- The BswM should notify the affected SWCs when an ICOM configuration has been changed. In order to ensure this, the BswM should be configured to perform mode switch indications.
- Errors in case of failures in changing the ICOM configuration should be configured based on a sub state via a BswM action list. The error occurred can be accessed by evaluation of the BswMModeRequestSource "BswMCanSMIcomIndication".

3.4.5.2 Deactivation of Pretended Networking

For the configuration of the deactivation of Pretended Networking the following aspects have to be considered:

- The BswM should be configured to start the I-PDU groups assigned to a channel when Pretended Networking is deactivated for this channel.
- The BswM should be configured to call <bus>SM to deactivate Pretended Networking after the I-PDU groups have been started.
- The BswM should be configured to report an error to DEM in case a deactivation of Pretended Networking was not possible.
- The BswM should be configured to request new ICOM configurations from <bus>SM.
- The BswM should notify the affected SWCs when an ICOM configuration has been changed. In order to ensure this, the BswM should be configured to perform mode switch indications.
- Errors in case of failures in changing the ICOM configuration should be configured based on a sub state via a BswM action list. The error occurred can be accessed by evaluation of the BswMModeRequestSource "BswMCanSMIcomIndication".

3.5 Diagnostics

In AUTOSAR release 4.0.3 onwards the DCM is the overall mode manager for all diagnostic use cases. The BswM is responsible to change the state of the other basic software modules accordingly.

3.5.1 Diagnostic Session Control

For session control [[SWS_Dcm_00777](#)] in SWS_DiagnosticCommunicationManager [6] defines the following ModeDeclarationGroup as providedModeGroup **Note:** The mode names and values are derived from the Dcm configuration. This guide shows just an example.

Listing 3.22: ModeGroup for session control service of the DCM

```
modeGroup DcmDiagnosticSessionControl {
    DefaultSession,
    ProgrammingSession,
    ExtendedDiagnosticSession,
    SafetySystemDiagnosticSession,
    AllSessionLevel
}

interface modeSwitch MSIF_DcmDiagnosticSessionControl {
```

```
mode DcmDiagnosticSessionControl diagnosticSessionControl
}
```

The DCM acting as a [mode manager](#) can inform other BSW modules about the current mode of the session control service and if needed set the basic software in the corresponding mode. Listing 3.23 shows the corresponding mode switch interface.

Note that the same interface can also be used to inform the application software about the current diagnostic session.

Listing 3.23: ModeRequestPort for session control service of the DCM

```
request BswModeNotification DiagnosticSessionControl {
    source MSIF_DcmDiagnosticSessionControl.diagnosticSessionControl
    processing IMMEDIATE
    initialValue DefaultSession
}
```

3.5.2 ECU Reset

In case of ECU Reset, the interaction between DCM and BswM is more complex. The Specification of the Diagnostic Communication Manager [6] specifies for this purpose the interface as described in listing 3.24. Via this interface the DCM signals the BswM to

1. prepare the ECU to execute a specific reset.
2. to explicitly execute this reset.

Listing 3.24: Mode switch interface for ECU reset diagnostic service

```
modeGroup DcmEcuReset{
    NONE,
    HARD,
    KEYONOFF,
    SOFT,
    JUMPTOBOOTLOADER,
    JUMPTOSYSSUPPLIERBOOTLOADER ,
    EXECUTE
}

interface modeSwitch MSIF_DcmEcuReset {
    mode DcmEcuReset ecureset
}
```

[SWS_Dcm_00373] states that on reception of a request for UDS Service with the sub functions other than enableRapidPowerShutDown (0x04) or disableRapidPowerShutDown (0x05), the DCM module shall switch the ModeDeclarationGroupPrototype DcmEcuReset to the received resetType. After the mode switch is requested the DCM triggers the start of the positive response message transmission.

According to [SWS_Dcm_00594] on the transmit confirmation (call to Dcm_TpTxConfirmation) of the positive response, the DCM module shall trig-

ger the mode switch of ModeDeclarationGroupPrototype DcmEcuReset to EXECUTE. By this final mode switch the DCM request the BswM to finally shutdown the ECU and to perform the reset.

Listing 3.25 depicts how the different reset szenarios spezified in the DCM can be configured in the DCM. Note that in the running example of this document the overall EcuMode is used to signal to the DCM that the ECU is ready to be reset. Depending on the diagnostic service the DCM shall wait for this acknowledgment or switch immediately to the EXECUTE mode, which will cause the BswM to invoke EcuM_GoDown.

Listing 3.25: Ruleset to implement different reset szenarios

```

rule DcmEcuResetHard initially false {
  if ( DcmEcuResetMode == DcmEcuReset.HARD) {
    actionlist DcmEcuResetHardActions
  }
}

actions DcmEcuResetHardActions on condition {
  custom "EcuM_SelectShutdownTarget (ECU_RESET,_ECUM_RESET_IO) "
  custom "EcuM_SelectShutdownCause (ECUM_CAUSE_DCM) "
  SchMSwitch EcuMode : ECU_RESET_READY
}

rule DcmEcuResetKeyOnOff initially false {
  if ( DcmEcuResetMode == DcmEcuReset.KEYONOFF) {
    actionlist DcmEcuResetKeyOnOffActions
  }
}

actions DcmEcuResetKeyOnOffActions on condition {
  custom "EcuM_SelectShutdownTarget (ECU_RESET,ECUM_RESET_IO) "
  custom "EcuM_SelectShutdownCause (ECUM_CAUSE_DCM) "
  SchMSwitch EcuMode : ECU_RESET_READY
}

rule DcmEcuResetSoft initially false {
  if ( DcmEcuResetMode == DcmEcuReset.SOFT) {
    actionlist DcmEcuResetSoftActions
  }
}

actions DcmEcuResetSoftActions on condition {
  custom "EcuM_SelectShutdownTarget (ECU_RESET,_ECUM_RESET_MCU) "
  custom "EcuM_SelectShutdownCause (ECUM_CAUSE_DCM) "
  SchMSwitch EcuMode : ECU_RESET_READY
}

rule DcmEcuResetBootLoader initially false {
  if ( DcmEcuResetMode == DcmEcuReset.JUMPTOBOOTLOADER) {
    actionlist DcmEcuResetBootLoaderActions
  }
}

```

```

actions DcmEcuResetBootLoaderActions on condition {
    custom "EcuM_SelectShutdownTarget (ECU_RESET, _ECUM_RESET_MCU) "
    custom "EcuM_SelectShutdownCause (ECUM_CAUSE_DCM) "
    custom "EcuM_SelectBootTarget (ECUM_BOOT_TARGET_OEM_BOOTLOADER) "
    SchMSwitch EcuMode : ECU_RESET_READY
}

rule DcmEcuResetSupplierBootloader initially false {
    if ( DcmEcuResetMode == DcmEcuReset.JUMPTOSYSSUPPLIERBOOTLOADER ) {
        actionlist DcmEcuResetSupplierBootloaderActions
    }
}

actions DcmEcuResetSupplierBootloaderActions on condition {
    custom "EcuM_SelectShutdownTarget (ECU_RESET, _ECUM_RESET_MCU) "
    custom "EcuM_SelectShutdownCause (ECUM_CAUSE_DCM) "
    custom "EcuM_SelectBootTarget (ECUM_BOOT_TARGET_SYS_BOOTLOADER) "
    SchMSwitch EcuMode : ECU_RESET_READY
}

rule DcmEcuReset initially false {
    if ( DcmEcuResetMode == DcmEcuReset.EXECUTE ) {
        actionlist DcmEcuResetActions
    }
}

actions DcmEcuResetActions on condition {
    custom "EcuM_GoDown (MODULE_ID) "
}

```

3.5.3 Rapid Power Shutdown

On reception of a request for UDS Service with the sub functions enableRapidPowerShutdown (0x04) or disableRapidPowerShutdown (0x05), the DCM module triggers the mode switch of ModeDeclarationGroupPrototype DcmRapidPowerShutDown ENABLE_RAPIDPOWERSHUTDOWN or DISABLE_RAPIDPOWERSHUTDOWN.

In most use cases this information is interpreted by the application to reduce overrun times. Nevertheless it also can be provided to the BswM (listing 3.26) if different shutdown sequences shall be realized by the BswM.

Listing 3.26: Mode switch interface for rapid power shutdown

```

modeGroup DcmRapidPowerShutDown {
    ENABLE_RAPIDPOWERSHUTDOWN,
    DISABLE_RAPIDPOWERSHUTDOWN
}

interface modeSwitch MSIF_RapidPowerShutdown {
    mode DcmRapidPowerShutDown powerShutDown
}

```

3.5.4 Communication Control diagnostic service

If the DCM reports to the BswM that a specified communication control mode is entered, the BswM has to enable resp. disable the corresponding IPDU groups as shown in listing 3.27.

Listing 3.27: Ruleset for diagnostic communication control

```

rule communicationcontrol1 initially false on condition {
  if (Dcm_Communication_Control_CAN1 == DCM_ENABLE_RX_TX_NORM )
  {
    actionlist communicationcontrol_DCM_ENABLE_RX_TX_NORM
  }
}

actions communicationcontrol_DCM_ENABLE_RX_TX_NORM on trigger {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.CAN1IPDUS
  }
}
//-----
rule communicationcontrol2 initially false on condition {
  if (Dcm_Communication_Control_CAN1 == DCM_ENABLE_RX_DISABLE_TX_NORM )
  {
    actionlist communicationcontrol_DCM_ENABLE_RX_DISABLE_TX_NORM
  }
}
actions communicationcontrol_DCM_ENABLE_RX_DISABLE_TX_NORM on trigger {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.CAN1RXIPDUS
    disable ArMmExample.EcuC.MyCom.CAN1TXIPDUS
  }
}
//-----

rule communicationcontrol3 initially false on condition {
  if (Dcm_Communication_Control_CAN1 == DCM_DISABLE_RX_ENABLE_TX_NORM )
  {
    actionlist communicationcontrol_DCM_DISABLE_RX_ENABLE_TX_NORM
  }
}
actions communicationcontrol_DCM_DISABLE_RX_ENABLE_TX_NORM on trigger {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.CAN1TXIPDUS
    disable ArMmExample.EcuC.MyCom.CAN1RXIPDUS
  }
}
//-----

rule communicationcontrol5 initially false on condition {
  if (Dcm_Communication_Control_CAN1 == DCM_DISABLE_RX_TX_NORMAL )
  {
    actionlist communicationcontrol_DCM_DISABLE_RX_TX_NORMAL
  }
}

```

```

    }
}
actions communicationcontrol_DCM_DISABLE_RX_TX_NORMAL on trigger {
    PduGroupSwitch {
        init true
        disable ArMmExample.EcuC.MyCom.CAN1IPDUS
    }
}
//-----

rule communicationcontrol6 initially false on condition {
    if (Dcm_Communication_Control_CAN1 == DCM_ENABLE_RX_TX_NM )
    {
        actionlist communicationcontrol_DCM_ENABLE_RX_TX_NM
    }
}
actions communicationcontrol_DCM_ENABLE_RX_TX_NM on trigger {
    PduGroupSwitch {
        init true
        enable ArMmExample.EcuC.MyCom.CAN1NMIPDUS
    }
}
//-----

rule communicationcontrol7 initially false on condition {
    if (Dcm_Communication_Control_CAN1 == DCM_ENABLE_RX_DISABLE_TX_NM )
    {
        actionlist communicationcontrol_DCM_ENABLE_RX_DISABLE_TX_NM
    }
}
actions communicationcontrol_DCM_ENABLE_RX_DISABLE_TX_NM on trigger {
    PduGroupSwitch {
        init true
        enable ArMmExample.EcuC.MyCom.CAN1NMRXIPDUS
        disable ArMmExample.EcuC.MyCom.CAN1NMTXIPDUS
    }
}
//-----

rule communicationcontrol8 initially false on condition {
    if (Dcm_Communication_Control_CAN1 == DCM_DISABLE_RX_ENABLE_TX_NM )
    {
        actionlist communicationcontrol_DCM_DISABLE_RX_ENABLE_TX_NM
    }
}
actions communicationcontrol_DCM_DISABLE_RX_ENABLE_TX_NM on trigger {
    PduGroupSwitch {
        init true
        enable ArMmExample.EcuC.MyCom.CAN1NMTXIPDUS
        disable ArMmExample.EcuC.MyCom.CAN1NMRXIPDUS
    }
}
//-----

rule communicationcontrol9 initially false on condition {
    if (Dcm_Communication_Control_CAN1 == DCM_DISABLE_RX_TX_NM )

```



```

    {
        actionlist communicationcontrol_DCM_DISABLE_RX_TX_NM
    }
}
actions communicationcontrol_DCM_DISABLE_RX_TX_NM on trigger {
    PduGroupSwitch {
        init true
        disable ArMmExample.EcuC.MyCom.CAN1NMRXIPDUS, ArMmExample.EcuC.MyCom.
            CAN1NMTXIPDUS
    }
}
//-----

rule communicationcontrol10 initially false on condition {
    if (Dcm_Communication_Control_CAN1 == DCM_ENABLE_RX_TX_NORM_NM )
    {
        actionlist communicationcontrol_DCM_ENABLE_RX_TX_NORM_NM
    }
}
actions communicationcontrol_DCM_ENABLE_RX_TX_NORM_NM on trigger {
    PduGroupSwitch {
        init true
        enable ArMmExample.EcuC.MyCom.CAN1NMRXIPDUS, ArMmExample.EcuC.MyCom.
            CAN1NMTXIPDUS
    }
}
//-----

rule communicationcontrol11 initially false on condition {
    if (Dcm_Communication_Control_CAN1 == DCM_ENABLE_RX_DISABLE_TX_NORM_NM )
    {
        actionlist communicationcontrol_DCM_ENABLE_RX_DISABLE_TX_NORM_NM
    }
}
actions communicationcontrol_DCM_ENABLE_RX_DISABLE_TX_NORM_NM on trigger {
    PduGroupSwitch {
        init true
        enable ArMmExample.EcuC.MyCom.CAN1NMRXIPDUS, ArMmExample.EcuC.MyCom.
            CAN1RXIPDUS
        disable ArMmExample.EcuC.MyCom.CAN1NMTXIPDUS, ArMmExample.EcuC.MyCom.
            CAN1TXIPDUS
    }
}
//-----

rule communicationcontrol12 initially false on condition {
    if (Dcm_Communication_Control_CAN1 == DCM_DISABLE_RX_ENABLE_TX_NORM_NM )
    {
        actionlist communicationcontrol_DCM_DISABLE_RX_ENABLE_TX_NORM_NM
    }
}
actions communicationcontrol_DCM_DISABLE_RX_ENABLE_TX_NORM_NM on trigger {
    PduGroupSwitch {
        init true
        enable ArMmExample.EcuC.MyCom.CAN1NMTXIPDUS, ArMmExample.EcuC.MyCom.
            CAN1TXIPDUS
    }
}

```

```

        disable ArMmExample.EcuC.MyCom.CAN1NMRXIPDUS, ArMmExample.EcuC.MyCom.
            CAN1RXIPDUS
    }
}
//-----

rule communicationcontrol13 initially false on condition {
    if (Dcm_Communication_Control_CAN1 == DCM_DISABLE_RX_TX_NORM_NM )
    {
        actionlist communicationcontrol_DCM_DISABLE_RX_TX_NORM_NM
    }
}
actions communicationcontrol_DCM_DISABLE_RX_TX_NORM_NM on trigger {
    PduGroupSwitch {
        init true
        disable ArMmExample.EcuC.MyCom.CAN1NMTXIPDUS, ArMmExample.EcuC.MyCom.
            CAN1TXIPDUS, ArMmExample.EcuC.MyCom.CAN1NMRXIPDUS, ArMmExample.EcuC.
            MyCom.CAN1RXIPDUS
    }
}
//-----

```

3.5.5 Control DTC Setting

Listing 3.28: Mode switch interface for Control of DTC setting

```

modeGroup DcmControlDTCSetting {
    ENABLEDTCSETTING,
    DISABLEDTCSETTING
}

interface modeSwitch MSIF_DcmControlDtcSetting {
    mode DcmControlDTCSetting dtcSetting
}

```

3.5.6 Roe Status

The Dcm will switch the current status of the Roe per configured Roe Event via a mode switch of ModeDeclarationGroupPrototype DcmResponseOnEvent_<RoeEventID> switching the mode to EVENT_STARTED, EVENT_STOPPED and EVENT_CLEARED. The information is necessary mainly for applications that need to interact with the Dcm if the events shall be triggered from external.

Listing 3.29: Mode switch interface for Roe Status

```

ModeGroup DcmResponseOnEvent_<RoeEventID> {
    EVENT_STARTED,
    EVENT_STOPPED,
    EVENT_CLEARED
}

interface modeSwitch MSIF_DcmResponseOnEvent{
    mode DcmResponseOnEvent currentMode
}

```

}

4 Backward Compatibility

This chapter describes a setup to reuse software components (legacy SWCs), which are designed to work with the “ECU State Manager (EcuM) with fixed state machine” [1]. This means that a setup based on EcuM with flexible state machines and the BswM is described which emulates the behavior of the EcuM with a fixed state machine.

An overview of the architectural solution is shown in Figure 4.1. A new Software Component *EcuM Fixed Compatibility SWC* is added to build a wrapper that presents an interface of an EcuM with a fixed state machine to the legacy SWCs.




Figure 4.1: Use of SWCs designed to work with ECU State Manager with fixed state machine

Figure 4.2 depicts the behavioral aspects of the proposal. The small boxes represent the states of fixed EcuM. The green boxes mark the phases of the EcuM flexible. Application software will only notice changes during the UP phase.




Figure 4.2: Mapping: Phases of fixed EcuM to flexible EcuM

The result is that all states of the fixed EcuM in the UP phase have to be emulated using the BswM and the software component introduced for this scenario. This software component has to map modes reported by the BswM to modes defined in the interface of the EcuM with fixed statemachine.

According to [EcuM2762] it has to provide AUTOSAR ports for the following functionalities:

- requesting RUN
- releasing RUN
- requesting POST RUN
- releasing POST RUN

So the BswM is used to emulate the fixed EcuM. For a backward compatible configuration the BswM must be configured in such a way that it executes these actions.

This chapter describes a compatibility SWC and the modifications of the BswM configuration that are necessary. The following hints in this chapter for achieving backward compatibility are aligned along the phases of execution.

As most parts of the achievement of compatibility is done via BswM rules, this chapter shows only additional BswM rules and the modifications of the already introduced rules of chapter 3.

4.1 Startup

During startup phase the same BSW modules shall be initialized as the fixed EcuM does. This is implemented via BswM rules which are executed after initialization of EcuM and initialize these modules. The modules which are already initialized by flexible EcuM are omitted by BswM.

The changed BswM rules can be seen in Listing 4.1.

Listing 4.1: BswM configuration for fixed EcuM compatible startup

```
rule InitBlockII initially false {
  if ( EcuMode == MDG_EcuMode.ECU_STARTUP_ONE ) {
    actionlist InitBlockIITrueActions
  }
}

actions InitBlockIITrueActions on condition {
  custom "EcuMCompatibility_SetStartup(null)"
  custom "Port_Init(null)"
  custom "Dio_Init(null)"
  custom "Adc_Init(null)"
  custom "Spi_Init(null)"
  custom "Eep_Init(null)"
  custom "Fls_Init(null)"
  custom "NvM_Init(null)"
  SchMSwitch EcuMode : ECU_STARTUP_TWO
  custom "NvM_ReadAll()"
}
```

```

rule NvMReadAllFinished initially false {
  if ( NvMReadAllJobMode != NVM_REQ_PENDING && EcuMode == MDG_EcuMode.
    ECU_STARTUP_TWO) {
    actionlist NvMReadAllFinishedTrueActions
  }
}

actions NvMReadAllFinishedTrueActions on condition {
  custom "CanTrcv_Init (null) "
  custom "Can_Init (null) "
  custom "CanIf_Init (null) "
  custom "CanSM_Init (null) "
  custom "CanTp_Init (null) "
  custom "Lin_Init (null) "
  custom "LinIf_Init (null) "
  custom "LinSM_Init (null) "
  custom "LinTp_Init (null) "
  custom "FrTrcv_Init (null) "
  custom "Fr_Init (null) "
  custom "FrIf_Init (null) "
  custom "FrSM_Init (null) "
  custom "FrTp_Init (null) "
  custom "PduR_Init (null) "
  custom "CANNM_Init (null) "
  custom "FrNM_Init (null) "
  custom "NmIf_Init (null) "
  custom "IpduM_Init (null) "
  custom "COM_Init (null) "
  custom "DCM_Init (null) "
  custom "EcuMCompatibility_OnRteStartup() "
  custom "StartRte() "
  custom "ComM_Init (null) "
  custom "DEM_Init (null) "
  custom "FIM_Init (null) "
  custom "EcuMCompatibility_SetUp (null) "
  SchMSwitch EcuMode : ECU_RUN
}

```

4.2 Running

If the running phase is active, it is necessary for compatibility to emulate the interfaces of fixed EcuM as these are used by the legacy SWCs. There are two categories of interfaces: Those for getting the current mode and those for requesting a mode.

Firstly, in fixed EcuM the SWCs can get the current mode through the method *EcuM_CurrentMode()*. In this setup for compatibility, the legacy SWC does not use the method of EcuM but calls another method with the same name of the newly introduced EcuM Compatibility SWC which represents the wrapper. It gets the current

mode of the flexible EcuM and transforms it into a mode of fixed EcuM which is known by the legacy components.

The mapping of the flexible ECU modes into fixed modes can be found in Table 4.1.

Table 4.1: Mapping of modes from flexible EcuM to fixed EcuM

Modes reported by Compatibility SWC	Modes reported by BswM
ECUM_STATE_STARTUP_ONE	ECU_STARTUP_ONE
ECUM_STATE_STARTUP_TWO	ECU_STARTUP_TWO
ECUM_STATE_RUN	ECU_RUN
ECUM_STATE_APP_RUN	ECU_RUN
ECUM_STATE_APP_POST_RUN	ECU_POST_RUN
ECUM_STATE_GoSleep	ECU_GO_SLEEP
ECUM_STATE_SleepWaitForNvmWriteAll	ECU_GO_SLEEP
ECUM_STATE_GoOff1	ECU_GO_OFF_ONE
ECUM_STATE_GoOff2	ECU_GO_OFF_TWO

Secondly, legacy SWCs have to be able to request modes. Analogue to the approach sketched above, the legacy components do not communicate directly with the EcuM but with the compatibility SWC. The compatibility SWC offers the same interfaces as fixed EcuM and relays the request to flexible EcuM. The interface is called *EcuM_ModeRequest* and its methods to emulate are: *EcuM_RequestRUN()*, *EcuM_ReleaseRUN()*, *EcuM_RequestPOST_RUN()*, *EcuM_ReleasePOST_RUN()* and *EcuM_KillAllRunRequests()*.

For *each* fixed EcuM User the compatibility component needs an own *EcuM_ModeRequest*-Port as this would also be provided by fixed EcuM. The legacy SWC then gets connected to exactly that port which belongs to the requested user.

The needed configuration of BswM is shown in Listing 4.2. This includes the declaration of a mode group which represents the requested mode. This information is given to the BswM. The shown rule is responsible for activating the communication if running mode was requested.

Listing 4.2: BswM configuration for fixed EcuM compatible running mode

```
modeGroup EcuMCompatibilityMode {
    ECUMCOMPATIBILITY_Run,
    ECUMCOMPATIBILITY_PostRun,
    ECUMCOMPATIBILITY_Off
}
interface modeSwitch compatibilityModeSwitchInterface {
    mode EcuMCompatibilityMode compatibilityMode
}
```


The compatibility SWC has to take all requested modes of the legacy components and transform all requests into *one* mode which is given to the BswM. This consists of two steps:

1. Depending on the called wrapping-method choose a mode of the above stated flexible EcuM modes. The mapping is described in Table 4.2.
2. Determine the “highest” mode of all compatibility users and request that from the BswM where *ECUMCOMPATIBILITY_Run* has the highest priority and *ECUMCOMPATIBILITY_Off* has the lowest.

Table 4.2: Mapping of modes requests from flexible EcuM to fixed EcuM

Called Method	Mode
EcuM_RequestRUN()	ECUMCOMPATIBILITY_Run
EcuM_ReleaseRUN()	ECUMCOMPATIBILITY_Off
EcuM_RequestPOST_RUN()	ECUMCOMPATIBILITY_PostRun
EcuM_ReleasePOST_RUN()	ECUMCOMPATIBILITY_Run
EcuM_KillAllRunRequests()	ECUMCOMPATIBILITY_Off

If the method *EcuM_KillAllRunRequests()* is called, the compatibility component requests *ECUMCOMPATIBILITY_Off* from the BswM independent of other legacy SWC’s requests.

4.3 Shutdown

If no legacy SWC requested the running mode, the compatibility SWC signals that to the BswM via the mode *ECUMCOMPATIBILITY_Off* and BswM can decide whether it wants to keep the ECU running, shut it down or put it into sleep. If it shall be shut down or put into sleep, the BswM goes to post-run phase. During post-run phase a new request can bring the BswM into running mode again.

For that shutdown mechanism the BswM configuration of Listing 4.3 is responsible. The listed rules coordinate the post-run phase, deinitialize the modules and put the ECU into shut down or sleep. These rules execute the same callouts *EcuM_On<Mode>()* as it would happen with a fixed EcuM. As the callouts during startup and shutdown cannot be called by the compatibility SWC, they are executed by the BswM via `custom calls`.

Listing 4.3: BswM configuration for fixed EcuM compatible shutdown

```
rule checkEcuMCompatibilityModeRequest initially false {
  if ( EcuMode == MDG_EcuMode.ECU_APP_RUN) {
    actionlist checkEcuMCompatibilityModeRequestActions
  }
}
```

```

actions checkEcuMCompatibilityModeRequestActions on condition {
    ComMAllowCom MyComM.CanNet1 false
    SchMSwitch EcuMode :ECU_APP_POST_RUN
}

rule GoBackToRun initially false {
    if ( EcuMode == MDG_EcuMode.ECU_APP_POST_RUN) {
        actionlist GoBackToRunActions
    }
}

actions GoBackToRunActions on condition {
    SchMSwitch EcuMode :ECU_APP_RUN
}

rule PrepShutdown initially false {
    if ( ComM_Mode_Channell == COMM_NO_COM_REQUEST_PENDING && EcuMode ==
        MDG_EcuMode.ECU_APP_POST_RUN) {
        actionlist PrepShutdownActions
    }
}

actions PrepShutdownActions on condition {
    custom "EcuMCompatibility_OnPrepShutdown()"
    custom "Dem_Shutdown(null)"
    SchMSwitch EcuMode :ECU_GO_SLEEP
    SchMSwitch EcuMode :ECU_GO_OFF_ONE
}

rule GoSleep initially false {
    if ( ComM_Mode_Channell == COMM_NO_COM_REQUEST_PENDING && EcuMode ==
        MDG_EcuMode.ECU_GO_SLEEP) {
        actionlist GoSleepActions
    }
}

actions GoSleepActions on condition {
    custom "EcuMCompatibility_OnGoSleep()"
    SchMSwitch EcuMode : ECU_STARTUP_TWO
    custom "NvM_WriteAll()"
}

rule GoOff initially false {
    if ( ComM_Mode_Channell == COMM_NO_COM_REQUEST_PENDING && EcuMode ==
        MDG_EcuMode.ECU_GO_OFF_ONE) {
        actionlist GoOffActions
    }
}

actions GoOffActions on condition {
    custom "EcuMCompatibility_OnGoOffOne()"
    custom "Rte_stop(null)"
    custom "ComM_DeInit(null)"
    SchMSwitch EcuMode :ECU_GO_OFF_TWO
    custom "NvM_WriteAll()"
}

```

```

}

rule GoSleepNvMWriteAllFinished initially false {
    if ( NvMWriteAllJobMode != NVM_REQ_PENDING && EcuMode == MDG_EcuMode.
        ECU_SLEEP)
    {
        actionlist GoSleepNvMWriteAllFinishedActions
    }
}

actions GoSleepNvMWriteAllFinishedActions on condition {
    custom "EcuM_GoHalt()"
}

rule GoOff2 initially false {
    if ( NvMWriteAllJobMode == NVM_BLK_OK && EcuMode == MDG_EcuMode.
        ECU_GO_OFF_TWO) {
        actionlist GoOff2Actions
    }
}

actions GoOff2Actions on condition {
    custom "EcuMCompatibility_OnGoOffTwo()"
    custom "EcuM_GoDown()"
}

```

4.4 Wakeup

The functionality for correct wakeup from sleep mode has to be fully configured in the BswM. But as it does not need any adjustments for backward compatibility, there are no modifications to be done.

5 Acronyms and abbreviations

5.1 Technical Terms

All technical terms used throughout this document – except the ones listed here – can be found in the official AUTOSAR glossary [7] or the Software Component Template Specification [2].

Term	Description
mode	A Mode is a certain set of states of the various state machines (not only of the ECU State Manager) that are running in the vehicle and are relevant to a particular entity, an application or the whole vehicle
state	States are internal to their respective BSW component and thus not visible to the application. So they are only used by the BSW's internal state machine. The States inside the ECU State Manager build the phases and therefore handle the modes.
phase	A logical or temporal assembly of ECU Manager's actions and events, e.g. STARTUP, UP, SHUTDOWN, SLEEP, etc. Phases can consist of Sub-Phases which are often called Sequences if they above all exist to group sequences of executed actions into logical units. Phases in this context are not the phases of the AUTOSAR Methodology.
mode switch port	The port for receiving (or sending) a mode switch notification. For this purpose, a mode switch port is typed by a <code>ModeSwitchInterface</code> .
mode request interface	A <code>AUTOSAR SenderReceiverInterfaces</code> , which carries the requested mode in a <code>VariableDataPrototype</code> .
mode user	An <code>AUTOSAR SW-C</code> or <code>AUTOSAR Basic Software Module</code> that depends on modes by <code>ModeDisablingDependency</code> , <code>SwcModeSwitchEvent</code> , <code>BswModeSwitchEvent</code> , or simply by reading the current state of a mode is called a mode user . A mode user is defined by having a <code>require mode switch port</code> or a <code>requiredModeGroup ModeDeclarationGroupPrototype</code> . See also section refsec:concept .

mode manager	Entering and leaving modes is initiated by a mode manager. A mode manager is defined by having a provide mode switch port or a provided-ModeGroup ModeDeclarationGroupPrototype . A mode manager might be either an application mode manager or a Basic Software Module that provides a service including mode switches, like the ECU State Manager. See also section refsec:ModeManager .
application mode manager	An application mode manager is a AUTOSAR software-component that provides the service of switching modes. The modes of a application mode manager do not have to be standardized.
mode request	The communication of a mode request from the mode user to the mode manager using either the SenderReceiverInterface is called a mode request.
mode switch notification	The communication of a mode switch from the mode manager to the mode user using either the ModeSwitchInterface or providedModeGroupnd requiredModeGroup ModeDeclarationGroupPrototype is called mode switch notification.
mode machine instance	The instances of mode machines or ModeDeclarationGroups are defined by the ModeDeclarationGroupPrototypes of the mode manager . Since a mode switch is not executed instantaneously, the RTE or Basic Software Scheduler has to maintain it's own states. For each mode managers ModeDeclarationGroupPrototype , RTE or Basic Software Scheduler has one state machine. This state machine is called mode machine instance . For all mode users of the same mode managers ModeDeclarationGroupPrototype RTE and Basic Software Scheduler uses the same mode machine instance. See also section refsec:ModeManager .
common mode machine instance	A “common mode machine instance” is a special “mode machine instance” shared by BSW Modules and SW-Cs: The RTE Generator creates only one mode machine instance if a ModeDeclarationGroupPrototype instantiated in a port of a software-component is synchronized synchronized-ModeGroup of a

Mode Disabling Dependency	An RTEEvent and BswEvent that starts a RunnableEntity respectively a Basic Software Schedulable Entity can contain a disabledInMode association which references a ModeDeclaration. This association is called ModeDisablingDependency in this document.
mode disabling dependent ExecutableEntity	A mode disabling dependent RunnableEntity or a Basic Software Schedulable Entity is triggered by an RTEEvent respectively a BswEvent with a ModeDisablingDependency. RTE and Basic Software Scheduler prevent the start of those RunnableEntity or Basic Software Schedulable Entity by the RTEEvent / BswEvent, when the corresponding mode disabling is active. See also section refsec:ModeManager .
mode disabling	When a 'mode disabling' is active, RTE and Basic Software Scheduler disables the start of mode disabling dependent ExecutableEntities. The 'mode disabling' is active during the mode that is referenced in the mode disabling dependency and during the transitions that enter and leave this mode. See also section refsec:ModeManager .
OnEntry ExecutableEntity	A Runnable Entity or a Basic Software Schedulable Entity that is triggered by a SwcModeSwitchEvent respectively a BswModeSwitchEvent with ModeActivationKind 'entry' is triggered on entering the mode. It is called OnEntry ExecutableEntity. See also section refsec:ModeManager .
OnExit ExecutableEntity	A RunnableEntity or a Basic Software Schedulable Entity that is triggered by a SwcModeSwitchEvent respectively a BswModeSwitchEvent with ModeActivationKind 'exit' is triggered on exiting the mode. It is called OnExit ExecutableEntity. See also section refsec:ModeManager .
OnTransition ExecutableEntity	A RunnableEntity or a Basic Software Schedulable Entity that is triggered by a SwcModeSwitchEvent respectively a BswModeSwitchEvent with ModeActivationKind 'transition' is triggered on a transition between the two specified modes. It is called OnTransition ExecutableEntity. See also section refsec:ModeManager .

mode switch acknowledge ExecutableEntity	A RunnableEntity or a Basic Software Schedulable Entity that is triggered by a SwcModeSwitchedAckEvent respectively a BswModeSwitchedAckEvent connected to the mode manager's ModeDeclarationGroupPrototype. It is called mode switch acknowledge ExecutableEntity. See also section refsec:ModeManager .
server runnable	A server that is triggered by an OperationInvokedEvent. It has a mixed behavior between a runnable and a function call. In certain situations, RTE can implement the client server communication as a simple function call.
runnable activation	The activation of a runnable is linked to the RTEEvent that leads to the execution of the runnable. It is defined as the incident that is referred to by the RTEEvent. E.g., for a timing event, the corresponding runnable is activated, when the timer expires, and for a data received event, the runnable is activated when the data is received by the RTE.
Basic Software Schedulable Entity activation	The activation of a Basic Software Schedulable Entity is defined as the activation of the task that contains the Basic Software Schedulable Entity and eventually includes setting a flag that tells the glue code in the task which Basic Software Schedulable Entity is to be executed.
Runnable start	A runnable is started by the calling the C-function that implements the runnable from within a started task.
Basic Software Schedulable Entity start	A Basic Software Schedulable Entity is started by the calling the C-function that implements the Basic Software Schedulable Entity from within a started task.
Trigger Source	A Trigger Source administrate the particular Trigger and informs the RTE or Basic Software Scheduler if the Trigger is raised. A Trigger Source has dedicated provide trigger ports or / and releasedTrigger Triggers to communicate to the Trigger Sinks .
Trigger Sink	A Trigger Sink relies on the activation of Runnable Entities or Basic Software Schedulable Entities if a particular Trigger is raised. A Trigger Sink has a dedicated require trigger ports or / and requiredTrigger Triggers to communicate to the Trigger Sources .

Trigger port	A PortPrototype which is typed by an Trigger-Interface
triggered ExecutableEntity	A Runnable Entity or a Basic Software Schedulable Entity that is triggered at least by one ExternalTriggerOccurredEvent / BswExternalTriggerOccurredEvent or InternalTriggerOccurredEvent / BswInternalTriggerOccurredEvent. In particular cases, the Trigger Event Communication or the Inter Runnable Triggering is implemented by RTE or Basic Software Scheduler as a direct function call of the triggered ExecutableEntity by the triggering ExecutableEntity.
triggered runnable	A Runnable Entity that is triggered at least by one ExternalTriggerOccurredEvent or InternalTriggerOccurredEvent. In particular cases, the Trigger Event Communication or the Inter Runnable Triggering is implemented by RTE as a direct function call of the triggered runnable by the triggering runnable.
triggered Basic Software Schedulable Entity	A Basic Software Schedulable Entity that is triggered at least by one BswExternalTriggerOccurredEvent or BswInternalTriggerOccurredEvent. In particular cases, the Trigger Event Communication or the Inter Basic Software Schedulable Entity Triggering is implemented by Basic Software Scheduler as a direct function call of the triggered ExecutableEntity by the triggering ExecutableEntity.
execution-instance	An execution-instance of a ExecutableEntity is one instance or call context of an ExecutableEntity with respect to concurrent execution.
inter-ECU communication	The communication between ECUs, typically using COM is called inter-ECUcommunication in this document.
inter-partition communication	The communication within one ECU but between different partitions, represented by different OS applications, is called inter-partition communication in this document. It typically involves the use of OS mechanisms like IOC or trusted function calls. The partitions can be located on different cores or use different memory sections of the ECU.

intra-partition communication	The communication within one partition of one ECU is called intra-partition communication. In this case, RTE can make use of internal buffers and queues for communication.
intra-ECU communication	The communication within one ECU is called intra-ECU communication in this document. It is a super set of inter-partition communication and intra-partition communication.