

Document Title	Specification of Platform Health Management
Document Owner	AUTOSAR
Document Responsibility	AUTOSAR
Document Identification No	851

Document Status	published
Part of AUTOSAR Standard	Adaptive Platform
Part of Standard Release	R22-11

Document Change History				
Date	Release	Changed by	Description	
2022-11-24	R22-11	AUTOSAR Release Management	 Replaced Local Supervision with Elementary Supervision Rework of state machine for Global Supervision Status Removed API GetGlobalSupervisionStatus() from class RecoveryAction Introduction of PhmErrorDomain functions and PhmException Specification of Start and Stop of Supervisions 	



2021-11-25	R21-11	AUTOSAR Release Management	 Health Channels are set to obsolete Removed retry after failed notification to State Management Removed GetLocalSupervisionStatus() and GetGlobalSupervisionStatus() APIs from SupervisedEntity class Added Determination of Supervision Status from Foundation SWS_HealthMonitoring Added Mode Dependent Configuration Concept Alignment of Enumeration Literal Indices of SupervisionStatus with Classic Platform WdgM types Introduction of WatchdogInterface
2020-11-30	R20-11	AUTOSAR Release Management	 Changed role of PHM to a monitor who notifies State Management, thus rework of logic and interfaces. Integration of Identity and Access Management for PHM Moving specification of Health Channel Supervision from Foundation to Adaptive Platform Reintroduced Enum for Checkpoints and Health Status
2019-11-28	R19-11	AUTOSAR Release Management	 Added recovery action via application Usage of ara::core types in PHM APIs Set data types to uint32_t by default Editorial rework of chapters 7 and 8 Changed Document Status from Final to published
2019-03-29	19-03	AUTOSAR Release Management	 Modified the API for Supervised Entity and Health Channel Modified the interface with the Execution Manager
2018-10-31	18-10	AUTOSAR Release Management	 Described the interfaces with functional clusters execution management and state management



2018-03-29 18-03 AUTOSAR Release Management	Initial release
---	-----------------



Disclaimer

This work (specification and/or software implementation) and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the work.

The material contained in this work is protected by copyright and other types of intellectual property rights. The commercial exploitation of the material contained in this work requires a license to such intellectual property rights.

This work may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only. For any other purpose, no part of the work may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The work has been developed for automotive applications only. It has neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.



Contents

1	Introduction and functional overview			8	
2	Acronyms and Abbreviations				
3	Related documentation				
	3.1 3.2		cuments & related standards and norms	11 11	
4	Con	straints and	assumptions	13	
	4.1 4.2		mitations	13 14	
5	Dep	endencies t	to other Functional Clusters	15	
	5.1	5.1.1 5.1.2 5.1.3 5.1.4	dependenciesDependencies on Execution ManagementDependencies on State ManagementDependencies on Watchdog InterfaceDependencies on other Functional Clusterslayer dependencies	15 15 15 15 15 15	
6	Requirements Tracing 16				
7	Functional specification				
	7.1 7.2		description ion of Supervised Entities	23 23 25	
			Process	26	
	7.3		Supervision of processes started before Platform Health Management	27 27 28	
	7.4	7.3.2 7.3.3	Configuration of Health Channel	28 29 29	
	7.4	7.4.1	Effect of changing Mode	29 30	
	7.5		Determination of Elementary Supervision Status Determination of Global Supervision Status	32 32 37	
	7.6		actions	42	
		7.6.1 7.6.2 7.6.3	Notificaton to State Management	44 45 46	
	7.7		processes and multiple instances	47	
	7.8		al cluster life-cycle	48	



		7.8.1			48
		7.8.2		vn	48
		7.8.2	.1	Handling of watchdog during shutdown	 48
8	API	specification	n		49
	8.1	API Head	der files .		 49
		8.1.1		vised Entity	49
		8.1.2	-	Channel.	50
	8.2	API Com		а Турез	51
		8.2.1		ted Types	52
		8.2.1.		Enumeration for Checkpoint	52
		8.2.1.	.2	Enumeration for Health Status	53
		8.2.2	Non-ge	nerated types	54
		8.2.2		ElementarySupervisionStatus	54
		8.2.2	.2	GlobalSupervisionStatus	54
		8.2.2	.3	SupervisedEntity	55
		8.2.2	.4	HealthChannel	55
		8.2.2	.5	RecoveryAction	56
		8.2.2	.6	HealthChannelAction	56
		8.2.2	.7	TypeOfSupervision	56
		8.2.2	.8	Daisy Chaining Related Types (Non-generated)	57
		8.2.2	.9	Error and Exception Types	57
		8.2.2	.10	E2E Related Data Types	 57
	8.3	API Refe	rence .		 57
		8.3.1	Supervi	sedEntity API	 57
		8.3.1.	.1	SupervisedEntity::SupervisedEntity	 58
		8.3.1.	.2	SupervisedEntity::ReportCheckpoint	 58
		8.3.1.	.3	SupervisedEntity::~SupervisedEntity	 59
		8.3.1.	.4	SupervisedEntity::Operator=	 59
		8.3.2	HealthC	hannel API	 60
		8.3.2	.1	HealthChannel::HealthChannel	 60
		8.3.2	.2	HealthChannel::ReportHealthStatus	 61
		8.3.2	.3	HealthChannel::~HealthChannel	 61
		8.3.2	.4	HealthChannel::Operator=	 62
		8.3.3	Recove	ryAction API	62
		8.3.3	.1	RecoveryAction::RecoveryAction	62
		8.3.3	.2	RecoveryAction::Operator=	 63
		8.3.3	.3	RecoveryAction::~RecoveryAction	64
		8.3.3	.4	RecoveryAction::RecoveryHandler	 64
		8.3.3	.5	RecoveryAction::Offer	65
		8.3.3		RecoveryAction::StopOffer	65
		8.3.4		ChannelAction API	65
		8.3.4		HealthChannelAction::HealthChannelAction	65
		8.3.4		HealthChannelAction::Operator=	66
		8.3.4	.3	HealthChannelAction::~HealthChannelAction	 67
		8.3.4	.4	HealthChannelAction::RecoveryHandler	 67



		8.3.4. 8.3.4.		68 68
				69
	8.4	8.3.5 API Error	Forward supervision state (daisy-chain)	69
	••••	8.4.1	PhmErrc	69
			GetPhmDomain	69
			MakeErrorCode	70
			PhmException Class	70
		8.4.4.		70
		8.4.5	PhmErrorDomain Class	71
		8.4.5.		71
		8.4.5.	2 PhmErrorDomain::Exception	72
		8.4.5.	3 PhmErrorDomain::PhmErrorDomain	72
		8.4.5.	4 PhmErrorDomain::Name	72
		8.4.5.	5 PhmErrorDomain::Message	73
		8.4.5.	6 PhmErrorDomain::ThrowAsException	73
9	Serv	vice Interfac	es	74
Α	Men	tioned Mani	fest Elements	75
В	Inter	faces to oth	er Functional Clusters (informative)	87
	B.1	Overview		87
С			ion API (normative)	88
0				
	C.1			88
			WatchdogInterface::AliveNotification	88
		C.1.2	WatchdogInterface::FireWatchdogReaction	88
D	Not	applicable re	equirements	89
Е	Cha	nge History		90
	E.1	Change I	History of this document according to AUTOSAR Release	
		R21-11.		90
		E.1.1	Added Traceables in R21-11	90
		E.1.2	Changed Traceables in R21-11	91
		E.1.3	Deleted Traceables in R21-11	92
	E.2	Change I	History of this document according to AUTOSAR Release	
		R22-11.		93
		E.2.1	Added Traceables in R22-11	93
		E.2.2	Changed Traceables in R22-11	95
		E.2.3	Deleted Traceables in R22-11	96



1 Introduction and functional overview

This document is the software specification of the Platform Health Management functional cluster within the Adaptive Platform [1].

The specification implements the requirements specified in [2, RS Platform Health Management].

It also implements the general functionality described in the Foundation documents [3, RS Health Monitoring] and [4, ASWS Health Monitoring]. In addition to the functionality specified in [4], this document also defines Health Channel Supervision.

Health Monitoring is required by [5, ISO 26262:2018] (under the terms control flow monitoring, external monitoring facility, watchdog, logical monitoring, temporal monitoring, program sequence monitoring) and this specification is supposed to address all relevant requirements from this standard.



2 Acronyms and Abbreviations

The glossary below includes acronyms and abbreviations relevant to the specification or implementation of Health Monitoring that are not included in the [6, AUTOSAR glossary].

Abbreviation:	Description:
E2E	AUTOSAR End to End communication protection mechanism
PHM	Platform Health Management
SE	Supervised Entity

Acronym:	Description:
Alive Supervision	Mechanism to check the timing constraints of cyclic Supervised Entitys to be within the configured min and max limits.
ara::com	Communication middleware for the AUTOSAR Adaptive Platform
AUTOSAR Adaptive Platform	see [6] AUTOSAR Glossary
Checkpoint	A point in the control flow of a Supervised Entity where the activity is reported.
Daisy chaining	Chaining multiple instances of Health Monitoring
Deadline Supervision	Mechanism to check that the timing constraints for execution of the transition from a Deadline Start Checkpoint to a cor- responding Deadline End Checkpoint are within the config- ured min and max limits.
Elementary Supervision Status	Status that represents the current state of an Alive Supervi- sion, Deadline Supervision or Logical Supervision, based on the evaluation (correct/incorrect) of the supervision.
Function Group	A Function Group is a set of coherent Processs, which need to be controlled consistently. Depending on the state of the Function Group, Processes are started or terminated.
Global Supervision Status	Status that summarizes the Elementary Supervision Sta- tus of a set of supervisions within a Function Group.
Health Channel	Channel providing information about the Health Status of a (sub)system. This might be the Global Supervision Status of an application, the result any test routine or the status reported by a (sub)system (e.g. voltage monitoring, OS kernel, ECU status,).
Health Channel Supervision	Check if the health indicators registered by the supervised software are within the tolerances/limits.
Health Monitoring	Supervision of the software behaviour for correct timing and se- quence.



Health Status	A set of states that are relevant to the supervised software (e.g. the Global Supervision Status of an application, a Voltage State, an application state, the result of a RAM monitoring algorithm).
Logical Supervision	Kind of online supervision of software that checks if the software (Supervised Entity or set of Supervised Entities) is executed in the sequence defined by the programmer (by the developed code).
Platform Health Management	Health Monitoring for the Adaptive Platform
Process	A Process is a loaded instance of an executable to be executed on a machine.
Supervised Entity	A whole or part of a SwComponentType which is included in the supervision. A Supervised Entity denotes a collection of Checkpoints within the corresponding SwComponentType. A SwComponentType can include zero, one or more Supervised Entities. A Supervised Entity may be instantiated multiple times, in which case each instance is independently supervised.
Supervision Mode	State of a machine or Function Group in which Supervised Entity Instances are to be monitored with a specific set of con- figuration parameters. Supervision parameters differ from one mode to other as the behavior (timing or sequence) of Super- vised Entity changes from one mode to other. Modes are mutually exclusive. A mode can be "Normal", "Degradation".

Table 2.1: Acronyms



3 Related documentation

3.1 Input documents & related standards and norms

- [1] Explanation of Adaptive Platform Design AUTOSAR_EXP_PlatformDesign
- [2] Requirements on Platform Health Management AUTOSAR_RS_PlatformHealthManagement
- [3] Requirements on Health Monitoring AUTOSAR_RS_HealthMonitoring
- [4] Specification of Health Monitoring AUTOSAR_ASWS_HealthMonitoring
- [5] ISO 26262:2018 (all parts) Road vehicles Functional Safety http://www.iso.org
- [6] Glossary AUTOSAR_TR_Glossary
- [7] General Specification of Basic Software Modules AUTOSAR_SWS_BSWGeneral
- [8] Specification of Adaptive Platform Core AUTOSAR_SWS_AdaptivePlatformCore
- [9] Specification of State Management AUTOSAR_SWS_StateManagement
- [10] Specification of Execution Management AUTOSAR_SWS_ExecutionManagement
- [11] Specification of Intrusion Detection System Manager for Adaptive Platform AUTOSAR_SWS_AdaptiveIntrusionDetectionSystemManager
- [12] Specification of Manifest AUTOSAR_TPS_ManifestSpecification
- [13] Explanation of Adaptive Platform Software Architecture AUTOSAR_EXP_SWArchitecture
- [14] Guidelines for using Adaptive Platform interfaces AUTOSAR_EXP_AdaptivePlatformInterfacesGuidelines

3.2 Further applicable specification

AUTOSAR provides a general specification [7, SWS_BSWGeneral] which is also applicable for Platform Health Management. The specification SWS General shall be



considered as additional and required specification for implementation of Platform Health Management.

AUTOSAR provides a core specification [8] which is also applicable for Platform Health Management. The chapter "General requirements for all FunctionalClusters" of this specification shall be considered as an additional and required specification for implementation of Platform Health Management.



4 Constraints and assumptions

4.1 Known limitations

- Daisy chaining (i.e. forwarding Supervision Status, Checkpoint or Health Channel information to an entity external to PHM or another PHM instance) is currently not supported in this document release.
- Interface with the Diagnostic Manager is not specified in this release.
- Health Channels (HealthChannelExternalStatus) is set to obsolete. Note: It is not intended to remove this feature from AUTOSAR Adaptive Platform overall. Rather, it is an architectural question to which Functional Cluster this feature belongs to, that is expected to be resolved for the next release.
- The configuration attribute for the alive notification cycle time (with respect to PHM sending AliveNotification to watchdog interface) is not specified for this release.
- A change in the value of Supervision (Alive/Deadline/Logical) configuration parameters between two Function Group states wherein the process being supervised continues to execute on switching between these states is not considered. The Supervision continues as per configuration in the Supervision Mode corresponding to old Function Group state.
- Similar to above limitation, dynamic change between Supervision exclusion (disable) and Supervision inclusion (enable) on Function Group state change wherein the process under consideration continues to execute on change in Function Group state is not supported. Supervision exclusion or inclusion can be applied starting with the Function Group state in which execution of the process begins and the same is applied until termination of the process.
- Currently specified mechanism of Notifying State Management on Global Supervision Status reaching state kStopped is insufficient in case of multiple failures. It could happen that the Global Supervision Status remains in state kStopped without further notification to State Management about successive failures. Thereby the recovery might be hindered.
- "PowerMode" dependent Supervision configuration is not supported in this release. See [9] for information on "PowerMode".
- Supervision is not supported for non-reporting processes (for information regarding what is a non-reporting process, please refer [10]). Rationale: Supervision depends on process states. Non-reporting process is not expected to report its Execution State to Execution Management. Hence, Platform Health Management cannot be informed about the necessary process states by Execution Management.
- Handling of multiple hardware watchdog instances is up to implementation and not standardized in the specification.



• State machine of Elementary Supervision Status is not specified for inter process supervisions (inter process Deadline Supervision and Logical Supervision) in this release.

4.2 Applicability to car domains

No restriction



5 Dependencies to other Functional Clusters

5.1 Platform dependencies

The interfaces within AUTOSAR Adaptive Platform are not standardized.

5.1.1 Dependencies on Execution Management

The Platform Health Management functional cluster is dependent on the Execution Management Interface [10].

Following process state information is needed from Execution Management with respect to processes for which supervision is configured:

- process reporting Execution State kRunning,
- process terminated,
- process is about to be informed by Execution Management to terminate.

5.1.2 Dependencies on State Management

The Platform Health Management functional cluster has an interface also with the State Management: If a failure is detected within a Supervised Entity or via Health Channel, Platform Health Management notifies State Management on this failure.

5.1.3 Dependencies on Watchdog Interface

The Platform Health Management functional cluster is dependent also on the Watchdog Interface.

5.1.4 Dependencies on other Functional Clusters

It is possible for all functional clusters to use the Supervision mechanisms provided by the Platform Health Management by using Checkpoints and the Health Channels as the other Applications.

5.2 Protocol layer dependencies

None.



6 Requirements Tracing

The following tables reference the requirements specified in [2] and links to the fulfillment of these. Please note that if column "Satisfied by" is empty for a specific requirement this means that this requirement is not fulfilled by this document.

Requirement	Description	Satisfied by
[RS_AP_00119]	Return values / application	[SWS_PHM_01240]
	errors.	[SWS PHM 01241]
		[SWS_PHM_01242]
		[SWS_PHM_01243]
		[SWS_PHM_01244]
		[SWS_PHM_01245]
		[SWS_PHM_01246]
		[SWS_PHM_01247]
		[SWS_PHM_01248]
		[SWS_PHM_01249]
		[SWS_PHM_01250]
		[SWS_PHM_01251]
[RS_AP_00127]	Usage of ara::core types.	[SWS_PHM_01245]
		[SWS_PHM_01246]
[RS_AP_00132]	noexcept behavior of API	[SWS_PHM_01243]
	functions	[SWS_PHM_01244]
		[SWS_PHM_01247]
		[SWS_PHM_01248]
		[SWS_PHM_01249]
		[SWS_PHM_01251]
[RS_HM_09125]	Health Monitoring shall provide	[SWS_PHM_01253]
	an Alive Supervision	[SWS_PHM_01254]
		[SWS_PHM_01331]
		[SWS_PHM_01332]
		[SWS_PHM_01333]
		[SWS_PHM_01335]
		[SWS_PHM_01336]
		[SWS_PHM_01337]
	Liesth Meritering shall be able	[SWS_PHM_01338]
[RS_HM_09159]	Health Monitoring shall be able	[SWS_PHM_00101]
	to report supervision errors.	[SWS_PHM_00102]
		[SWS_PHM_00104]
		[SWS_PHM_01147] [SWS_PHM_01148]
[RS HM 09222]	Health Monitoring shall provide	[SWS_PHM_01253]
[110_110]03222]	a Logical Supervision	[SWS_PHM_01253]
[RS_HM_09226]	Health Monitoring shall be able	[SWS_PHM_00104]
[to wrongly trigger the serviced	[SWS_PHM_00105]
	watchdogs.	[SWS_PHM_00106]
[RS_HM_09235]	Health Monitoring shall provide	[SWS_PHM_01253]
[a Deadline Supervision	[SWS PHM 01254]
[RS_HM_09237]	Health Monitoring shall provide	[SWS_PHM_00100]
····	an interface to Supervised	[SWS_PHM_01137]
	Entities informing them about	[SWS_PHM_01358]
	their Supervision State.	[
[RS_HM_09244]	Health Monitoring shall support	[SWS_PHM_01252]
	timeout watchdogs.	
	timeout watehoogs.	



Requirement	Description	Satisfied by			
[RS HM 09245]	Health Monitoring shall support	[SWS PHM 01252]			
· ·	window watchdogs.				
[RS_HM_09246]	Health Monitoring shall support	[SWS_PHM_01252]			
· ·	question-answer watchdogs.				
[RS_HM_09249]	Health Monitoring shall support	[SWS_PHM_00010]			
· ·	building safety-related systems.	SWS_PHM_00100			
		SWS PHM 00101			
		SWS PHM 00102			
		[SWS_PHM_00104]			
		[SWS_PHM_00105]			
		[SWS_PHM_00106]			
		[SWS_PHM_01252]			
		[SWS_PHM_01331]			
		[SWS_PHM_01332]			
		[SWS_PHM_01333]			
		[SWS_PHM_01334]			
		[SWS_PHM_01335]			
		[SWS_PHM_01336]			
		[SWS_PHM_01337]			
		[SWS_PHM_01338]			
[RS_HM_09254]	Health Monitoring shall provide	[SWS_PHM_00424]			
	an interface to Supervised	[SWS_PHM_00425]			
	Entities to report the currently	[SWS_PHM_00426]			
	reached Checkpoint.	[SWS_PHM_01123]			
		[SWS_PHM_01127]			
		[SWS_PHM_01132]			
		[SWS_PHM_01211]			
		[SWS_PHM_01212]			
		[SWS_PHM_01213]			
		[SWS_PHM_01214]			
		[SWS_PHM_01215]			
		[SWS_PHM_01229]			
		[SWS_PHM_01334] [SWS_PHM_01341]			
[RS_IAM_00002]	Position of Policy Enforcement	[SWS_PHM_01341] [SWS_PHM_01229]			
		[SWS_PHM_01229] [SWS_PHM_01330]			
		[SWS_PHM_01330] [SWS_PHM_01339]			
[RS_IAM_00010]	Adaptive applications shall only	[SWS_FHM_01339]			
	be able to use AUTOSAR	[SWS_FHM_01229] [SWS_PHM_01330]			
	Resources when authorized	[SWS_PHM_01339]			
[RS_lds_00810]	Basic SW security events	[SWS_PHM_01339]			
	Dasic OW Security Events				



Requirement	Description	Satisfied by				
[RS_PHM_00001]	The Platform Health	[SWS_PHM_00457]				
	Management shall provide a	[SWS_PHM_01002]				
	standardized header file	[SWS_PHM_01020]				
	structure for each service.	[SWS_PHM_01114]				
		[SWS_PHM_01115]				
		[SWS_PHM_01122]				
		[SWS_PHM_01123]				
		[SWS_PHM_01127]				
		[SWS_PHM_01128]				
		[SWS_PHM_01132]				
		[SWS_PHM_01211]				
		[SWS_PHM_01212]				
		[SWS_PHM_01213]				
		[SWS_PHM_01214]				
		[SWS_PHM_01215]				
		[SWS_PHM_01221]				
		[SWS_PHM_01222]				
		[SWS_PHM_01223]				
		[SWS_PHM_01224]				
	The comice beeder files shall	[SWS_PHM_01225]				
[RS_PHM_00002]	The service header files shall	[SWS_PHM_00457]				
	define the namespace for the	[SWS_PHM_01005]				
	respective service.	[SWS_PHM_01113] [SWS_PHM_01122]				
		[SWS_FHM_01122] [SWS_PHM_01123]				
		[SWS_PHM_01127]				
		[SWS_PHM_01128]				
		[SWS_PHM_01132]				
		[SWS PHM 01211]				
		[SWS PHM 01212]				
		[SWS PHM 01213]				
		[SWS_PHM_01214]				
		[SWS PHM 01215]				
		[SWS_PHM_01221]				
		[SWS_PHM_01222]				
		[SWS_PHM_01223]				
		[SWS_PHM_01224]				
		[SWS_PHM_01225]				



Requirement	Description	Satisfied by
[RS_PHM_00003]	The Platform Health	[SWS_PHM_00424]
	Management shall define how	[SWS_PHM_00425]
	language specific data types are	[SWS_PHM_00426]
	derived from modeled data	[SWS_PHM_01118]
	types.	[SWS_PHM_01119]
		[SWS_PHM_01122]
		[SWS_PHM_01129]
		SWS_PHM_01132]
		[SWS_PHM_01138]
		[SWS_PHM_01139]
		[SWS_PHM_01140]
		[SWS_PHM_01141]
		[SWS_PHM_01142]
		[SWS_PHM_01143]
		[SWS_PHM_01144]
		[SWS_PHM_01145]
		[SWS_PHM_01149]
		[SWS_PHM_01150]
		[SWS_PHM_01151]
		[SWS_PHM_01152]
		[SWS_PHM_01231]
		[SWS_PHM_01232]
		[SWS_PHM_01233]
		[SWS_PHM_01234]
		[SWS_PHM_01235]
		[SWS_PHM_01236]
		[SWS_PHM_01237]
		[SWS_PHM_01238]
		[SWS_PHM_01239]
[RS_PHM_00101]	Platform Health	[SWS_PHM_00424]
	Management shall provide a	[SWS_PHM_00425]
	standardized C++ interface for	[SWS_PHM_00426]
	the reporting of Checkpoints.	[SWS_PHM_01123]
		[SWS_PHM_01127]
		[SWS_PHM_01132]
		[SWS_PHM_01211]
		[SWS_PHM_01212]
		[SWS_PHM_01213]
		[SWS_PHM_01214]
		[SWS_PHM_01215]
		[SWS_PHM_01229]
		[SWS_PHM_01341]



Requirement	Description	Satisfied by		
[RS_PHM_00102]	Platform Health	[SWS_PHM_00457]		
	Management shall provide a	[SWS_PHM_01118]		
	standardized C++ interface for	[SWS_PHM_01119]		
	the reporting of Health	[SWS_PHM_01122]		
	Channel.	[SWS_PHM_01128]		
		[SWS_PHM_01129]		
		[SWS_PHM_01221]		
		[SWS_PHM_01222]		
		[SWS_PHM_01223]		
		[SWS_PHM_01224]		
		[SWS_PHM_01225]		
		[SWS_PHM_01328]		
		[SWS_PHM_01329]		
		[SWS_PHM_01330]		
[RS_PHM_00104]	Platform Health	[SWS_PHM_00240]		
	Management shall derive the	[SWS_PHM_00241]		
	Supervision Mode from Function	[SWS_PHM_00242]		
	Group State(s).	[SWS_PHM_00243]		
		[SWS_PHM_00244]		
		[SWS_PHM_00245]		
		[SWS_PHM_01351]		
		[SWS_PHM_01352]		
		[SWS_PHM_01353]		
		[SWS_PHM_01354]		
		[SWS_PHM_01355]		
		[SWS_PHM_01356]		
[RS_PHM_00108]	Platform Health	[SWS_PHM_NA]		
	Management shall provide a			
	standardized interface between			
	Platform Health			
	Management components used			
	in a daisy chain.			
[RS_PHM_00109]	Platform Health	[SWS_PHM_NA]		
	Management shall provide the			
	Daisy chaining interface			
	over ara::com.			



Requirement	Description	Satisfied by			
[RS PHM 00111]	Platform Health	[SWS_PHM_00216]			
[Management shall determine	[SWS PHM 00217]			
	Supervision status	[SWS PHM 00218]			
		[SWS PHM 00219]			
		[SWS_PHM_00220]			
		[SWS_PHM_00221]			
		[SWS_PHM_00222]			
		[SWS_PHM_00223]			
		[SWS_PHM_00224]			
		[SWS_PHM_00225]			
		[SWS PHM 00226]			
		[SWS_PHM_00227]			
		[SWS PHM 00228]			
		[SWS PHM 00229]			
		[SWS PHM 00230]			
		· ·			
		[SWS_PHM_00231]			
		[SWS_PHM_00232]			
		[SWS_PHM_00233]			
		[SWS_PHM_00234]			
		[SWS_PHM_00237]			
		[SWS_PHM_00238]			
		[SWS_PHM_00239]			
		[SWS PHM 01342]			
		[SWS_PHM_01343]			
		[SWS_PHM_01344]			
		[SWS_PHM_01345]			
		[SWS PHM 01346]			
		[SWS PHM 01347]			
		[SWS_PHM_01348]			
		[SWS_PHM_01349]			
		[SWS_PHM_01350]			
		[SWS_PHM_01351]			
		[SWS_PHM_01352]			
		[SWS_PHM_01353]			
		[SWS_PHM_01354]			
		[SWS_PHM_01355]			
		[SWS_PHM_01356]			
		[SWS_PHM_01357]			
[RS_PHM_00112]	Platform Health	[SWS_PHM_00224]			
	Management shall provide	[SWS_PHM_00225]			
	configurable delays of error	[SWS_PHM_00228]			
	reactions.	[SWS_PHM_00229]			
		[SWS PHM 00230]			
		[SWS PHM 00231]			
		[SWS_PHM_00238]			
		[SWS_PHM_00239]			
[RS_PHM_09240]	Platform Health	[SWS_PHM_01123]			
	Management shall support	[SWS_PHM_01211]			
	multiple occurrences of the	[SWS_PHM_01212]			
	same Supervised Entity.	[SWS_PHM_01213]			
		[SWS_PHM_01214]			
		[SWS_PHM_01215]			
L	1	· · · ·			



Requirement	Description	Satisfied by
[RS_PHM_09241]	Health Monitoring shall support	[SWS_PHM_00424]
	multiple instances of	[SWS PHM 00425]
	Checkpoints in a Supervised	[SWS_PHM_00426]
	Entity occurrence.	
[RS_PHM_09255]	Platform Health	[SWS_PHM_00010]
	Management shall provide an	[SWS_PHM_00102]
	interface to receive Health	
	Channel supervision status	
[RS_PHM_09257]	Platform Health	[SWS_PHM_00457]
	Management shall provide an	[SWS_PHM_01118]
	interface to Supervised Entities	[SWS_PHM_01119]
	to report their health status.	[SWS_PHM_01122]
		[SWS_PHM_01128]
		[SWS_PHM_01129]
		[SWS_PHM_01221]
		[SWS_PHM_01222]
		[SWS_PHM_01223]
		[SWS_PHM_01224]
		[SWS_PHM_01225]
		[SWS_PHM_01328]
		[SWS_PHM_01329]
		[SWS_PHM_01330]



7 Functional specification

7.1 General description

The Platform Health Management monitors applications with respect to timing constraints (Alive Supervision and Deadline Supervision) and logical program sequence (Logical Supervision) as well as platform health (Health Channel Supervision). In case of a detected failure, Platform Health Management notifies State Management. As coordinator of the platform, State Management can decide how to handle the error and trigger a suitable recovery action.

Platform Health Management has also an interface to the hardware watchdog and can trigger a watchdog reaction in case of a critical failure where a notification to State Management is not sufficient.

All the algorithms and the procedures for the Platform Health Management are described in the Autosar Foundation document [4] and are not specified here: only the Autosar Adaptive specificities, including the interfaces with the other functional clusters, are shown here below.

The interfaces of Health Management to other Functional Clusters are only informative and are not standardized.

7.2 Supervision of Supervised Entities

State Management coordinates the platform through Function Groups [9]. Within a Function Group, there may be multiple Processes running.

Platform Health Management monitors Supervised Entitys. Each Supervised Entity maps to whole or part of a Process. The monitoring is active as long as the corresponding Process is active.

Platform Health Management provides three kinds of supervisions to monitor a Supervised Entity: Alive Supervision, Deadline Supervision and Logical Supervision. The supervision algorithms are described in [4]. Only details specific for Adaptive Platform are described in this document.

The results of the supervisions of a Supervised Entity Instance are reflected in the Elementary Supervision Status. The status of elementary supervisions within a Function Group is conglomerated in the corresponding Global Supervision Status.

[SWS_PHM_00100]{DRAFT} **Scope of Global Supervision** [The Platform Health Management shall support one or a few GlobalSupervision for a Function Group.](*RS_HM_09237, RS_HM_09249*)

As described in [4], the supervisions are based on checkpoints which are reported by the Supervised Entity Instance.



[SWS_PHM_01341]{DRAFT} Reporting of Supervision Checkpoint mapped to No Supervision provision [If a SupervisionCheckpoint reported to Platform Health Management Via ReportCheckpoint is

- configured to (referenced in) NoCheckpointSupervision or
- the corresponding Supervised Entity instance is configured to NoSupervision

in the Supervision Mode corresponding to the Function Group State in which the process is executing, then Platform Health Management shall ignore the reporting of the SupervisionCheckpoint for evaluation of supervisions (Alive, Deadline and Logical). (*RS_PHM_00101, RS_HM_09254*)

Note: The behavior in case of reported, undefined checkpoints is currently not specified. This will be specified in the next release.

[SWS_PHM_01229]{DRAFT} **Restricted access on reporting of Checkpoints** [The Platform Health Management shall ignore the execution of ReportCheckpoint for evaluation of Alive, Deadline and Logical Supervision if the reporting process does not correspond to the reported SupervisionCheckpoint, i.e. reporting process is not the same as reported SupervisionCheckpoint.process.](*RS_PHM_00101, RS_HM_09254, RS_IAM_00002, RS_IAM_00010*)

Example: Consider SupervisionCheckpoint SV_CP_A is referencing Process Proc_A through attribute SupervisionCheckpoint.process in the manifest and it is referenced in AliveSupervision through attribute AliveSupervision.checkpoint. In runtime, if a process other than Proc_A (e.g: Proc_B) reports SV_CP_A, then this reporting is not to be considered for evaluation of Alive Supervision.

If a checkpoint is reported by the "'wrong"' process, this is considered as access violation and a potential security threat.

[SWS_PHM_01339]{DRAFT} Reporting access violation w.r.t. checkpoints to IdsM [Security event PHM_SEV_ACCESSVIOLATION_CHECKPOINT with the context data given in table 7.1 shall be reported to IdsM (see [11]) if it occurs that the reported SupervisionCheckpoint does not correspond to the process reporting it, i.e. reporting process is not the same as reported SupervisionCheckpoint.process.] (RS_IAM_00002, RS_IAM_00010, RS_Ids_00810)



SEV component	Description			
Name	PHM_SEV_ACCESSVIOLATION_CHECKPOINT			
Description	Access violation with respect to reporting of checkpoint			
SEV ID	65			
Context Data	Identity of the process which is violating the access permissions			
	 Function Group State in which process is executing when there is this violation 			
	Which SupervisionCheckpoint is getting reported			

Table 7.1: Checkpoint Access Violation SEV

7.2.1 Start and Stop of Supervisions

[SWS_PHM_01331]{DRAFT} **Start of Alive Supervision** [The Platform Health Management shall start the first aliveReferenceCycle of a configured AliveSupervision of a Supervised Entity Instance as soon as the corresponding process reports Execution State kRunning.] (*RS_HM_09125, RS_HM_09249*)

Rationale: Cyclic execution is expected only after process reached state kRunning. Execution Management monitors that the process reaches state kRunning within a configured timeout.

The information of process reporting Execution state kRunning is to be provided by Execution Management. through a vendor specific Inter Functional Cluster Interface.

[SWS_PHM_01332]{DRAFT} Checkpoints corresponding to Alive Supervision before kRunning [With respect to Alive Supervision, Platform Health Management shall ignore Checkpoints reported by a Supervised Entity Instance before the corresponding process reaches state kRunning.](*RS_HM_09125, RS_-HM_09249*)

Implementation hint: The same time base should be used between Execution Management and Platform Health Management to synchronize the kRunning state with the start of the Alive Supervision. See [SWS_PHM_01334] for details.

Note: The start of intra-process Deadline Supervision and Logical Supervision (i.e. Logical and Deadline Supervision with all referenced SupervisionCheckpoints corresponding to a single process) does not depend on the process reporting Execution State kRunning. That is, the Deadline Supervision and Logical Supervision can start even before the process reaching state kRunning. Please refer [4] for details of Deadline Supervision and Logical Supervision.

[SWS_PHM_01333]{DRAFT} **Termination of Supervised Processes** [As soon as Platform Health Management receives the information from Execution Management that a supervised process is about to be notified to terminate (by issuing SIGTERM) or the process is terminated (considering the case of process terminat-



ing abruptly, i.e. without SIGTERM issued by Execution Management), Platform Health Management shall stop all intra-process supervisions corresponding to the process (that is stop all Alive, Deadline and Logical Supervision involving SupervisionCheckpoints of the corresponding process only).](*RS_HM_09125, RS_HM_09249*)

Rationale: Process is expected to start terminating on receiving SIGTERM from Execution Management. Execution Management monitors the termination timeout once it issues SIGTERM to the process. Considering this, additional monitoring of the process by Platform Health Management via Supervisions is considered to be not necessary.

[SWS_PHM_01334]{DRAFT} **Time Source for Supervisions** [All timing aspects related to Platform Health Management shall be measured in the context of the reporting process using the same time source.](*RS_HM_09254, RS_HM_09249*)

To avoid effect of delays and jitter in the inter-process communication to Platform Health Management, timing aspects related to Platform Health Management (i.e. synchronization of kRunning state between Execution Management and Platform Health Management, the timestamp w.r.t reporting of checkpoints (consider Deadline Supervision)) shall be taken in the context of the reporting process using the same time source.

Implementation Hint: ara::core::SteadyClock could be used to obtain time stamp (in other words, for time keeping).

7.2.1.1 Stopping of Alive Supervision for Self Terminating Process

In case of a Self-Terminating Process, the process can intentionally terminate even without SIGTERM being issued by Execution Management. Hence, it is necessary to mark the point in time at which the process starts to (self-) terminate so that the Alive Supervision could be stopped. This is intended to be achieved by process reporting a checkpoint named as terminatingCheckpoint. Additionally, a timeout (configurable) has to be monitored by Platform Health Management to check that the process terminates within this duration since reporting of terminatingCheckpoint. This timeout check is to monitor that the process is not stuck in its execution and therefore is not terminating.

Note: Unless SIGTERM is issued to the process by Execution Management, Execution Management will not monitor for process termination timeout.

Platform Health Management is to be informed by Execution Management regarding the termination of the process.

[SWS_PHM_01335]{DRAFT} Stopping of Alive Supervision for Self-Terminating Process [In case of Self-Terminating Process, Alive Supervision shall be stopped on reporting of terminatingCheckpoint by the process or as soon as Platform Health Management receives the information from Execution Manage-



ment that the process will be notified to terminate (by issuing SIGTERM), whichever is earlier.](*RS_HM_09125, RS_HM_09249*)

[SWS_PHM_01336]{DRAFT} Timeout monitoring for termination of Self-Terminating Process [On reporting of terminatingCheckpoint by a Self-Terminating Process, Platform Health Management shall start monitoring the timeout. That is, Platform Health Management shall monitor that the process terminates within terminatingCheckpointTimeoutUntilTermination since reporting of terminatingCheckpoint. In case the process takes longer than terminatingCheckpointTimeoutUntilTermination, this shall be notified as failure to State Management.](*RS_HM_09125, RS_HM_09249*)

[SWS_PHM_01337]{DRAFT} Unintended termination of Self-Terminating Process [If an Alive Supervision is configured for a Self Terminating Process and if the process terminates without reporting terminatingCheckpoint and no SIGTERM was issued to the process by Execution Management, then Platform Health Management shall notify a failure of Alive Supervision to State Management via ara::phm::RecoveryAction::RecoveryHandler.](RS_HM_-09125, RS_HM_09249)

[SWS_PHM_01338]{DRAFT} Avoid redundant Monitoring of Termination for Self-Terminating Process [If an Alive Supervision is configured for a Self Terminating Process and if after reporting of terminatingCheckpoint and before terminatingCheckpointTimeoutUntilTermination is elapsed Platform Health Management receives the information from Execution Management that the process will be notified to terminate via SIGTERM, then Platform Health Management shall stop monitoring the timeout. [(RS_HM_09125, RS_HM_09249)

This is because, once SIGTERM is issued by Execution Management to the process, Execution Management will monitor the process termination timeout.

7.2.2 Supervision of processes started before Platform Health Management

Start of Supervision (Alive Supervision/Deadline Supervision/Logical Supervision) in case of processes that are started before Platform Health Management process (e.g, process corresponding to Execution Management) is not standardized. It is up to Adaptive Platform Vendor specific decision.

7.3 Health Channel Supervision

Using Health Channel Supervision the system integrator can hook external supervision results to the Platform Health Management. External supervision can be routines like RAM test, ROM test, kernel status, voltage monitoring etc. The external supervision performs the monitoring and debouncing. The determined result is



classified according to the possible Health Status values and sent to Platform Health Management.

A Health Channel can be

- the Global supervision status of the software under supervision.
- the result of an environment monitoring algorithm. e.g. Voltage Monitoring, Temperature Monitoring.
- the result of a memory integrity test routine, e.g. RAM test, ROM test.
- the status of the operating system or Kernel. e.g. OS Status, Kernel Status.
- the status of another platform instance or Virtual Machine or ECU.

The various external monitoring routines shall report their result or status in the form of defined Health Statuses to the Platform Health Management. The Health Status of a Health Channel is the abstract format of the information that a Health Channel provides to the Platform Health Management. Two different Health Channels may have same Health Status names to represent its result, e.g. high, low, normal.

If a reaction on a determined Health Status is necessary, Platform Health Management reports the status to State Management.

7.3.1 Health Status after Initialization

The Health Status after initialization is controlled by the configuration container HealthStatusInitValue. This parameter may be configured once for each Health Channel in the configuration.

[SWS_PHM_00010]{OBSOLETE} **Not initialized Health Channel** [If the container HealthStatusInitValue does not exist or the Health Channel does not already have an initial value, the Platform Health Management shall treat the corresponding Health Status as undefined and not use it until the corresponding Health Channel has been updated for the first time.] (*RS_PHM_09255, RS_HM_09249*)

7.3.2 Configuration of Health Channel

A Health Channel has the following configuration options:

- 1. Name: Globally unique name identifier, used by Applications.
- 2. ID: Globally unique identifier (number)
- 3. HealthStatusInitValue: Initial value of the corresponding Health Status.

A Health Status represents a possible value of the Health Channel and has the following options:



- 1. Name: used by Applications, unique within the Health Channel
- 2. ID: Identifier of the Health Status, unique within the Health Channel.




Figure 7.1: Health Channel configuration

7.3.3 Reporting of Health Channel

The current Health Status is reported to Platform Health Management via the method ReportHealthStatus.

[SWS_PHM_01328]{OBSOLETE} Consistency of Health Status Identifier [The value of healthStatusId reported via ReportHealthStatus shall match the declared statusId of the respective PhmHealthChannelInterface.status.](RS_-PHM_00102 , RS_PHM_09257)

[SWS_PHM_01329]{OBSOLETE} Reporting of undefined Health Status Identifier [If a healthStatusId is reported to Platform Health Management and no corresponding PhmHealthChannelStatus is configured in the context of the reporting PhmHealthChannelInterface, PHM shall ignore the reporting of healthStatus.] (RS_PHM_00102, RS_PHM_09257)

[SWS_PHM_01330]{OBSOLETE} Restricted access on reporting of Health Status [The execution of ReportHealthStatus shall be prevented (i.e, shall not be considered for notifying State Management) if the reporting process is not the same as the reported HealthChannelExternalStatus.process.](*RS_PHM_00102, RS_*-*PHM_09257, RS_IAM_00002, RS_IAM_00010*)

7.4 Supervision Modes

Expected execution (timing or sequence) of the Software can change based on certain conditions. Hence, the value of the Supervision (Alive/Deadline/Logical) parameters might have to be changed based on conditions. For each such condition a mode called a Supervision Mode can be configured. Currently, this condition can be configured based on Function Group State.



Note: It is possible to exclude (disable) Supervision for a Supervised Entity Instance in a Supervision Mode. This can be achieved by configuring NoSupervision for the Supervised Entity Instance in the Supervision Mode.

7.4.1 Effect of changing Mode

In AUTOSAR Adaptive Platform, Supervision Mode changes on Function Group State change.

Function Group State change has following impact on processes:

- Certain processes are terminated.
- Certain processes are newly started.
- Certain processes are restarted.
- Remaining processes continue to execute.

Supervisions (Alive, Deadline and Logical) of the Supervised Entitys corresponding to the processes shall be handled as follows.

[SWS_PHM_00240]{DRAFT} **Supervisions on termination of process** [Alive Supervision, Deadline Supervision and Logical Supervision shall be stopped on termination of the corresponding process. Results of Alive, Deadline and Logical Supervision shall be set to correct.](*RS_PHM_00104*)

The termination of the process could be due to various reasons. It could be due to change in Function Group State (the process is not configured to be executed in the new Function Group State), a self-terminating process is terminating on its own or abrupt termination of a process (e.g. due to out of bound memory access).

Note:

- 1. On termination of process, Elementary Supervision Status of the corresponding Supervised Entity Instance will be set to kDEACTIVATED.
- 2. For a process, monitoring is active when the process is executing (that is, when the Execution state of the process is "Initializing" or "Running" or "Terminating"). It is deactivated (stopped) when the process is terminated.

[SWS_PHM_00241]{DRAFT} **Supervisions on Start of Process** [On start of the process for which a Supervision (Alive Supervision, Deadline Supervision and/or Logical Supervision) is configured in the new Function Group State, the Supervision (Alive Supervision, Deadline Supervision and/or Logical Supervision) shall be performed as per the configured Supervision parameter values in the Supervision Mode corresponding to new Function Group State.] *(RS_PHM_00104)*

[SWS_PHM_00244]{DRAFT} NoSupervision on Start of Process [On start of the process in the new Function Group State, if NoSupervision is configured for



a Supervised Entity Instance corresponding to the process in the Supervision Mode corresponding to the new Function Group State, then no Supervision (no Alive Supervision, Deadline Supervision Or Logical Supervision) shall be performed for the Supervised Entity Instance in the Supervision Mode corresponding to new Function Group State.](*RS_PHM_00104*)

Note: Even though it is supported to exclude (disable) Supervision in a particular Supervision Mode, dynamic change between Supervision inclusion (enable) and exclusion (disable) during execution of Process is not supported. Supervision exclusion can be applied starting from the Supervision Mode corresponding to the Function Group state in which the execution of the process is started. Supervision exclusion continues until the termination of the process. The same principle applies to a change in supervision parameters.

FunctionG state	roup	off		state-A		state-B		state-C
Process state	Terminated Running Idle						_/	
	Legend	Function Group state is in transition						

Figure 7.2: Supervision Exclusion and change of Function Group State

Figure 7.2 shows an example: If Supervision is excluded in Function Group state-A, same will continue in Function Group state-B. Supervision can be applied again in state-C wherein the process is restarted (but not in state-B).

[SWS_PHM_00242]{DRAFT} **Supervisions on Restart of Process** [Supervisions on restart of a process due to Function Group State change shall be handled as termination of process (see [SWS_PHM_00240]) followed by start of process (see [SWS_PHM_00241]).](*RS_PHM_00104*)

[SWS_PHM_00243]{DRAFT} **Continuation of Supervisions** [Supervisions (Alive, Deadline and Logical) shall be continued with same values of Supervision parameters if the corresponding process continues to execute on Function Group State change.](*RS_PHM_00104*)

[SWS_PHM_00245]{DRAFT} Continuation of NoSupervision (Supervision Exclusion) [If NoSupervision is configured for a Supervised Entity Instance in the Supervision Mode corresponding to the Function Group State, in which the execution of the corresponding process starts, then no Supervision (no Alive Supervision, Deadline Supervision Or Logical Supervision) shall be continued on change in Function Group State to a new state if the process continues to execute on Function Group State change.](*RS_PHM_00104*)



7.5 Determination of Supervision Status

Based on the results of Alive Supervision, Deadline Supervision and Logical Supervision the Elementary Supervision Status and Global Supervision Status are determined. Please refer [4] for details of these Supervisions.

7.5.1 Determination of Elementary Supervision Status

The Elementary Supervision Status state machine determines the status of an individual Alive Supervision, Deadline Supervision and Logical Supervision. This is done based on the following:

- 1. Previous value of the Elementary Supervision Status,
- 2. Current values of the result (correct/incorrect) of the corresponding Alive Supervision, Deadline Supervision and Logical Supervision

The state machine is initialized at the initialization of the Platform Health Management. Note: In this release, only state machine for Elementary Supervision Status for intra process supervision is specified.

[SWS_PHM_01342]{DRAFT} **Tracking of Elementary Supervision Status** [The Platform Health Management shall track the Elementary Supervision Status of each Alive Supervision, Deadline Supervision and Logical Supervision.](*RS_PHM_00111*)

Figure 7.3 shows the state machine for Elementary Supervision Status of a supervision with all possible states.

[SWS_PHM_01343]{DRAFT} States of state machine for Elementary Supervision Status [The Platform Health Management shall have the Elementary Supervision Statuses kOK, kDEACTIVATED, kEXPIRED and kFAILED.](*RS_PHM_-00111*) See also figure 7.3 and ara::phm::ElementarySupervisionStatus.

Please note that the status **kFAILED** is only relevant for Alive Supervision.






Figure 7.3: Elementary Supervision Status

For the transitions between the states of the Elementary Supervision Status the following rules apply:

[SWS_PHM_01344]{DRAFT} Initialization of state machine for Elementary Supervision Status [On start of Platform Health Management all state machines for Elementary Supervision Status shall be initialized to kDEACTIVATED and for Alive Supervision the counter for failed Alive Supervision reference cycles shall be set to zero (0).](*RS_PHM_00111*) See transition (1) in figure 7.3.

[SWS_PHM_01345]{DRAFT} Keep Elementary Supervision Status kOK [If the Elementary Supervision Status is kOK and the results of the corresponding supervision are correct, i.e. all checkpoints are reported according to configuration and in case of Alive Supervision the counter for failed Alive Supervision reference cycles is zero, then the Platform Health Management shall keep the supervision in the Elementary Supervision Status kOK.](*RS_PHM_00111*)

[SWS_PHM_01346]{DRAFT} Switch Elementary Supervision Status from kOK to kEXPIRED [If the Elementary Supervision Status is kOK AND in case the Elementary Supervision Status corresponds to

1. Alive Supervision a permanent failure is detected, i.e. the counter for failed Alive Supervision reference cycles exceeds failure tolerance failedReferenceCyclesTolerance) OR



2. Deadline Supervision or Logical Supervision the result of the supervision is incorrect

THEN the Platform Health Management shall change the Elementary Supervision Status to kEXPIRED and stop the corresponding supervision.](*RS_PHM_-00111*) See transition (2) in figure 7.3.

The below requirements show the important difference of Alive Supervision versus Deadline Supervision and Logical Supervision: the Alive Supervision has an error tolerance for failed reference cycles.

[SWS_PHM_01347]{DRAFT} Switch Elementary Supervision Status from kOK to kFAILED [If Elementary Supervision Status is kOK AND the corresponding supervision is Alive Supervision AND a temporary failure is detected, i.e. the counter for failed Alive Supervision reference cycles is greater than zero but does not exceed failure tolerance failedReferenceCyclesTolerance, THEN the Platform Health Management shall change the Elementary Supervision Status to kFAILED.] (*RS_PHM_00111*) See transition (3) in figure 7.3.

[SWS_PHM_01348]{DRAFT} Keep Elementary Supervision Status kFAILED [If the Elementary Supervision Status is kFAILED AND the counter for failed Alive Supervision reference cycles is greater than zero but does not exceed failure tolerance failedReferenceCyclesTolerance THEN the Platform Health Management shall keep the Elementary Supervision Status kFAILED.](RS_-PHM_00111)

[SWS_PHM_01349]{DRAFT} Switch Elementary Supervision Status from **kFAILED to kOK** [If the Elementary Supervision Status is kFAILED AND there is no failure present in the Alive Supervision, i.e. the counter for failed Alive Supervision reference cycles is zero, THEN the Platform Health Management shall change the Elementary Supervision Status to kOK.](*RS_PHM_00111*) See transition (5) in figure 7.3.

[SWS_PHM_01350]{DRAFT} Switch Elementary Supervision Status from **kFAILED to kEXPIRED** [If the Elementary Supervision Status is kFAILED AND if the Alive Supervision has a permanent failure, i.e. the counter for failed Alive Supervision reference cycles exceeds failure tolerance failedReferenceCyclesTolerance, THEN the Platform Health Management shall change the Elementary Supervision Status to kEXPIRED and stop the corresponding supervision.](*RS_PHM_00111*) See transition (6) in figure 7.3.

[SWS_PHM_01351]{DRAFT} Switch Elementary Supervision Status from kOK to kDEACTIVATED [If the Elementary Supervision Status is kOK AND Platform Health Management receives the information from Execution Management that the corresponding process is about to be notified to terminate (by issuing SIGTERM) or the process is terminated (considering the case of process terminating abruptly, i.e. without SIGTERM issued by Execution Management), THEN the Platform Health Management shall change the Elementary Supervision Status to kDEACTIVATED



and for Alive Supervision the counter for failed Alive Supervision reference cycles shall be set to zero (0).](*RS_PHM_00111, RS_PHM_00104*) See transition (7) in figure 7.3.

[SWS_PHM_01352]{DRAFT} Switch Elementary Supervision Status from **kFAILED to kDEACTIVATED** [If the Elementary Supervision Status is kFAILED AND Platform Health Management receives the information from Execution Management that the corresponding process is about to be notified to terminate (by issuing SIGTERM) or the process is terminated (considering the case of process terminating abruptly, i.e. without SIGTERM issued by Execution Management), THEN the Platform Health Management shall change the Elementary Supervision Status to kDEACTIVATED and the counter for failed Alive Supervision reference cycles shall be set to zero (0).](*RS_PHM_00111, RS_PHM_00104*) See transition (8) in figure 7.3.

[SWS_PHM_01353]{DRAFT} Keep Elementary Supervision Status kDEACTIVATED [If the Elementary Supervision Status is kDEACTIVATED then, unless there is a switch to a Supervision Mode (due to change in corresponding Function Group State) in which the corresponding supervision is configured to be monitored AND

- for Alive Supervision: the corresponding Process reports Execution State kRunning
- for Deadline Supervision and Logical Supervision: any checkpoint corresponding to the supervision is reported

the Platform Health Management shall not perform the supervision and keep the Elementary Supervision Status kDEACTIVATED.](RS_PHM_00111, RS_PHM_00104)

[SWS_PHM_01354]{DRAFT} Switch Elementary Supervision Status from kDE-ACTIVATED to kOK [If the Elementary Supervision Status is kDEACTIVATED AND there is a switch to a Supervision Mode (due to change in corresponding Function Group State) in which the Supervised Entity Instance is configured to be monitored AND

- for Alive Supervision: the corresponding Process reports Execution State kRunning
- for Deadline Supervision: when first time the checkpoint of the Supervision is reported
- for Logical Supervision: when first time the checkpoint of the Supervision is reported and the supervision result for reporting of this checkpoint is correct

THEN Platform Health Management shall change the Elementary Supervision Status to kOK.](*RS_PHM_00111, RS_PHM_00104*) See transition (9) in figure 7.3.



[SWS_PHM_01355]{DRAFT} **Switch Elementary Supervision Status from kEX-PIRED to kDEACTIVATED** [If the Elementary Supervision Status does not correspond to Operating System, Execution Management or State Management AND Platform Health Management receives the information from Execution Management that the corresponding process is about to be notified to terminate (by issuing SIGTERM) or the process is terminated (considering the case of process terminating abruptly, i.e. without SIGTERM issued by Execution Management), THEN the Platform Health Management shall change the Elementary Supervision Status to kDEACTIVATED and for Alive Supervision the counter for failed Alive Supervision reference cycles shall be set to zero (0).] (RS_PHM_00111, RS_PHM_00104) See transition (4) in figure 7.3.

Note: Transition (4) is not applicable in case of Elementary Supervision Status corresponding to supervision of Operating System, Execution Management or State Management reaches kEXPIRED. In this case, recovery (state change from kEXPIRED to kDEACTIVATED) is intended to be through watchdog action (see [SWS_PHM_00105]).

Note: How to determine whether a supervision corresponds to Execution Management/Operating System is not standardized. A relation to State Management can be determined via the attribute functionClusterAffiliation in the configuration of Process:

Configuration of Supervisions (AliveSupervision/DeadlineSupervision/LogicalSupervision) have reference to SupervisionCheckpoint which in turn refers Process in SupervisionCheckpoint.process.

This Process contains the attribute Process.functionClusterAffiliation and one of the values standardized for this attribute by AUTOSAR is "STATE_MANAGEMENT". In this way it is possible to Identify which Supervisions correspond to State Management.

[SWS_PHM_01356]{DRAFT} **Keep Elementary Supervision Status kEXPIRED** [If the Elementary Supervision Status is kEXPIRED then, unless Platform Health Management receives the information from Execution Management that the corresponding process is about to be notified to terminate (by issuing SIGTERM) or the process is terminated (considering the case of process terminating abruptly, i.e. without SIGTERM issued by Execution Management), the Platform Health Management shall not perform the supervision and keep the Elementary Supervision Status kEXPIRED.](*RS_PHM_00111, RS_PHM_00104*)

[SWS_PHM_01357]{DRAFT} Switch Elementary Supervision Status from kDEAC-TIVATED to kEXPIRED [If the Elementary Supervision Status is kDEACTI-VATED and it corresponds to Logical Supervision, when first time the checkpoint of the supervision is reported and the supervision result for reporting of this checkpoint is incorrect, then Platform Health Management shall change the Elementary Supervision Status to kEXPIRED and stop the corresponding supervision.](RS_-PHM_00111) See transition (10) in figure 7.3.



Note: Transition (10) is applicable for Elementary Supervision Status of Logical Supervision only.

7.5.2 Determination of Global Supervision Status

The Global Supervision Status is determined based on the Elementary Supervision Status of a set of Alive, Deadline and/or Logical Supervisions within a Function Group which are configured as part of a single GlobalSupervision. Global Supervision Status is "worst-of" all included Elementary Supervision Statuses.

The Global Supervision Status has similar values as the Elementary Supervision Status. The main differences are the addition of the kSTOPPED value. Figure 7.4 shows the values and transitions between them.

The Platform Health Management reports a detected failure to State Management as soon as state <code>kEXPIRED</code> is reached. State <code>kSTOPPED</code> is used only for critical failures which need a direct reaction via hardware watchdog. From AUTOSAR point of view, this is relevant for failures in supervisions corresponding to Operating System, State Management or Execution Management. Platform Health Management triggers the watchdog reaction by not setting a correct watchdog trigger condition as soon as state <code>kSTOPPED</code> is reached, see [SWS_PHM_00105]. This transition and therefore the reaction can be postponed for a configurable amount of time, named <code>expiredSupervisionTolerance</code>. This could be used to allow clean-up activities before a watchdog reset, e.g. writing the error cause, writing NVRAM data.

The expiredSupervisionTolerance is implemented within the state machine of the Global Supervision Status. The defined state machine is in the state kEX-PIRED while the error reaction is postponed. Since the transition to state kSTOPPED is only applicable for supervisions triggering a watchdog reaction, the parameter expiredSupervisionTolerance is only relevant in this case. That means, it is mandatory to configure expiredSupervisionTolerance only in case of Global Supervision corresponding to Operating System, State Management or Execution Management. A constraint in this regard is not added in [12] as Execution Management is not a modelled process and Operating System is not represented in the model.

A change in Global Supervision Status can be logged by Platform Health Management for test/debugging purposes.

[SWS_PHM_00219]{DRAFT} Calculation of Global Supervision Status [The Platform Health Management shall calculate the Global Supervision Status of each configured GlobalSupervision.](RS_PHM_00111)

Whether the evaluation of Global Supervision Status and the Elementary Supervision Status that it aggregates is time triggered (periodic evaluation) or event triggered (on availability of a new result for Alive Supervision / Deadline



Supervision / Logical Supervision) is up to Adaptive Platform Vendor's decision.

[SWS_PHM_00216]{DRAFT} States of the state machine for Global Supervision Status [The Platform Health Management shall have the Global Supervision Statuses kOK, kDEACTIVATED, kFAILED, kEXPIRED and kSTOPPED, see ara::phm::GlobalSupervisionStatus.](*RS_PHM_00111*) See also figure 7.4.




Figure 7.4: Global Supervision Status

[SWS_PHM_00217]{DRAFT} One Global Supervision Status per Global Supervision [The Platform Health Management shall have one Global Supervision Status per GlobalSupervision configured.](RS_PHM_00111)



Each GlobalSupervision is a set of Alive Supervision, Deadline Supervision and/or Logical Supervision corresponding to a single Function Group. There can be one or more GlobalSupervision per Function Group. But a GlobalSupervision does not span across multiple Function Groups.

[SWS_PHM_00218]{DRAFT} **Initialization of Global Supervision Status** [The Global Supervision Status shall be initialized with kDEACTIVATED.](*RS_PHM_00111*) See transition (1) in figure 7.4.

The Platform Health Management provides a feature to postpone the error reaction (the error reaction being not setting a correct watchdog trigger condition) for a configurable amount of time, named expiredSupervisionTolerance.

[SWS_PHM_00220]{DRAFT} Switch Global Supervision Status from kDEACTI-VATED to kOK [If the Global Supervision Status is kDEACTIVATED, the Elementary Supervision Status of at least one Alive, Deadline or Logical Supervision is kOK and no supervision is in Elementary Supervision Status kFAILED or kEXPIRED, then the Platform Health Management shall change the Global Supervision Status to kOK.](RS_PHM_00111) See transition (2) in figure 7.4.

[SWS_PHM_00221]{DRAFT} Keep Global Supervision Status kOK [If the Global Supervision Status is kOK, the Elementary Supervision Status of at least one Alive, Deadline or Logical Supervision is kOK and no supervision is in Elementary Supervision Status kFAILED or kEXPIRED, then the Platform Health Management shall keep the Global Supervision Status kOK.](RS_-PHM_00111)

[SWS_PHM_00222]{DRAFT} Switch Global Supervision Status from kOK to kDE-ACTIVATED [If the Global Supervision Status is kOK or kFAILED or kEX-PIRED AND the Elementary Supervision Status of all Alive, Deadline and Logical Supervisions is kDEACTIVATED, then the Platform Health Management shall set the Global Supervision Status to kDEACTIVATED and stop measuring Expired Supervision Time.](*RS_PHM_00111*) See transitions (6), (14) and (15) in figure 7.4.

[SWS_PHM_00223]{DRAFT} Switch Global Supervision Status from koK to kFAILED [If the Global Supervision Status is kOK, the Elementary Supervision Status of at least one Alive, Deadline or Logical Supervision is kFAILED and no supervision is in Elementary Supervision Status kEXPIRED, then the Platform Health Management shall change the Global Supervision Status to kFAILED.](*RS_PHM_00111*) See transition (7) in figure 7.4.

[SWS_PHM_00224]{DRAFT} Switch Global Supervision Status from kok to kEX-PIRED for SM/EM/OS supervision [If the Global Supervision Status is kOK, the Elementary Supervision Status of at least one Alive, Deadline or Logical Supervision is kEXPIRED and in case the GlobalSupervision corresponds to Operating System, Execution Management or State Management the expiredSupervisionTolerance is configured to a value larger than zero, then the Platform



Health Management shall change the Global Supervision Status to kEX-PIRED and start measuring Expired Supervision Time.](*RS_PHM_00111, RS_PHM_00112*) See transition (8) in figure 7.4.

Note: expiredSupervisionTolerance and hence the Expired Supervision Time are applicable in case of Global Supervision Status corresponding to Operating System, Execution Management or State Management only.

[SWS_PHM_00225]{DRAFT} Switch Global Supervision Status from kOK to kSTOPPED [If the Global Supervision Status is kOK, the Elementary Supervision Status of at least one Alive, Deadline or Logical Supervision is kEXPIRED, the expiredSupervisionTolerance is configured to zero and the GlobalSupervision corresponds to Operating System, Execution Management or State Management, then the Platform Health Management shall change the Global Supervision Status to kSTOPPED.](*RS_PHM_00111, RS_PHM_00112*) See transition (9) in figure 7.4.

[SWS_PHM_00226]{DRAFT} Keep Global Supervision Status kFAILED [If the Global Supervision Status is kFAILED, the Elementary Supervision Status of at least one Alive, Deadline or Logical Supervision is kFAILED and no supervision is in Elementary Supervision Status kEXPIRED, then the Platform Health Management shall keep the Global Supervision Status kFAILED.] (RS_PHM_00111)

[SWS_PHM_00227]{DRAFT} Switch Global Supervision Status from kFAILED to kOK [If the Global Supervision Status is kFAILED, the Elementary Supervision Status of at least one Alive, Deadline or Logical Supervision is kOK and no supervision is in Elementary Supervision Status kFAILED or kEXPIRED, then the Platform Health Management shall change the Global Supervision Status to kOK.] (RS_PHM_00111) See transition (10) in figure 7.4.

[SWS_PHM_00228]{DRAFT} Switch Global Supervision Status from kFAILED to kEXPIRED [If the Global Supervision Status is kFAILED, the Elementary Supervision Status of at least one Alive, Deadline or Logical Supervision is kEX-PIRED and in case the GlobalSupervision corresponds to Operating System, Execution Management or State Management the expiredSupervisionTolerance is configured to a value larger than zero, then the Platform Health Management shall change the Global Supervision Status to kEXPIRED and start measuring Expired Supervision Time.]*(RS_PHM_00111, RS_PHM_00112)* See transition (11) in figure 7.4.

[SWS_PHM_00229]{DRAFT} Switch Global Supervision Status from kFAILED to kSTOPPED [If the Global Supervision Status is kFAILED, the Elementary Supervision Status of at least one Alive, Deadline or Logical Supervision is kEXPIRED, the expiredSupervisionTolerance is configured to zero and the GlobalSupervision corresponds to Operating System, Execution Management or State Management, then the Platform Health Management shall change



the Global Supervision Status to kSTOPPED.](*RS_PHM_00111, RS_PHM_00112*) See transition (12) in figure 7.4.

[SWS_PHM_00230]{DRAFT} Keep Global Supervision Status **kEXPIRED** [If the Global Supervision Status is kEXPIRED,

- the GlobalSupervision corresponds to Operating System, Execution Management or State Management and the measured Expired Supervision Time is less than the configured expiredSupervisionTolerance OR
- the GlobalSupervision DOES NOT correspond to Operating System, Execution Management or State Management and the Elementary Supervision Status of at least one corresponding Alive, Deadline or Logical Supervision is kEXPIRED,

then the Platform Health Management shall keep the Global Supervision Status kEXPIRED.](RS_PHM_00111, RS_PHM_00112)

[SWS_PHM_00231]{DRAFT} Switch Global Supervision Status from kEXPIRED to kSTOPPED [If the Global Supervision Status is kEXPIRED,GlobalSupervision corresponds to Operating System, Execution Management or State Management, the Elementary Supervision Status of at least one Alive, Deadline or Logical Supervision is kEXPIRED and the measured Expired Supervision Time is equal to or greater than the configured expiredSupervisionTolerance, then the Platform Health Management shall change the Global Supervision Status to kSTOPPED.] (*RS_PHM_00111, RS_PHM_00112*) See transition (13) in figure 7.4.

Note: Transition (13) in figure 7.4 is only applicable for GlobalSupervision that does correspond to Operating System, Execution Management or State Management.

[SWS_PHM_00232]{DRAFT} Keep Global Supervision Status kSTOPPED [If the Global Supervision Status is kSTOPPED, the Elementary Supervision Status of at least one Alive, Deadline or Logical Supervision is kEXPIRED and the GlobalSupervision corresponds to Operating System, Execution Management or State Management, then the Platform Health Management shall keep the Global Supervision Status kSTOPPED.](*RS_PHM_00111*)

[SWS_PHM_00233]{DRAFT} Switch Global Supervision Status from kEXPIRED to kOK [If the Global Supervision Status is kEXPIRED, the Elementary Supervision Status of at least one Alive, Deadline or Logical Supervision is kOK and no supervision is in Elementary Supervision Status kFAILED or KEXPIRED, then the Platform Health Management shall change the Global Supervision Status to kOK.](*RS_PHM_00111*) See transition (16) in figure 7.4.

[SWS_PHM_00234]{DRAFT} Switch Global Supervision Status from kEXPIRED to kFAILED [If the Global Supervision Status is kEXPIRED, the Elementary Supervision Status of at least one Alive, Deadline or Logical Supervision is kFAILED and no supervision is in Elementary Supervision Status kEXPIRED, then the Platform Health Management shall change the Global Supervision Status to kFAILED.](*RS_PHM_00111*) See transition (17) in figure 7.4.



Note: Transitions (15), (16) and (17) in figure 7.4 is not applicable in case of Global-Supervision corresponding to Operating System, Execution Management or State Management as Elementary Supervision Status of supervisions corresponding to these is not allowed to leave the state <code>kEXPIRED</code> until watchdog action is taken (see [SWS_PHM_00105]).

[SWS_PHM_00237]{DRAFT} Switch Global Supervision Status from kDEACTI-VATED to kFAILED [If the Global Supervision Status is kDEACTIVATED, the Elementary Supervision Status of at least one Alive, Deadline or Logical Supervision is kFAILED and no supervision is in Elementary Supervision Status kEXPIRED, then the Platform Health Management shall change the Global Supervision Status to kFAILED.](*RS_PHM_00111*) See transition (3) in figure 7.4.

[SWS_PHM_00238]{DRAFT} Switch Global Supervision Status from kDEACTI-VATED to kEXPIRED [If the Global Supervision Status is kDEACTIVATED, the Elementary Supervision Status of at least one Alive, Deadline or Logical Supervision is kEXPIRED and in case the GlobalSupervision corresponds to Operating System, Execution Management or State Management the expiredSupervisionTolerance is configured to a value larger than zero, then the Platform Health Management shall change the Global Supervision Status to kEX-PIRED and start measuring Expired Supervision Time.](RS_PHM_00111, RS_PHM_-00112) See transition (4) in figure 7.4.

[SWS_PHM_00239]{DRAFT} Switch Global Supervision Status from kDEACTI-VATED to kSTOPPED [If the Global Supervision Status is kDEACTIVATED, the Elementary Supervision Status of at least one Alive, Deadline or Logical Supervision is kEXPIRED, the expiredSupervisionTolerance is configured to zero and the GlobalSupervision corresponds to Operating System, Execution Management or State Management, then the Platform Health Management shall change the Global Supervision Status to kSTOPPED.](*RS_PHM_00111, RS_PHM_-00112*) See transition (5) in figure 7.4.

Note: How to distinguish whether a GlobalSupervision corresponds to Execution Management/State Management/Operating System is not standardized.

7.6 Recovery actions

The scope of Platform Health Management is to monitor the safety relevant Processes on the platform and report detect failures to State Management. If a failure in State Management is detected, Platform Health Management can trigger a reaction via hardware watchdog.



Specification of Platform Health Management AUTOSAR AP R22-11




Figure 7.5: Platform Health Management and the environment



7.6.1 Notificaton to State Management

The Platform Health Management debounces the failures of Supervised Entitys, see the Elementary Supervision Status kFAILED in chapter 7.5. After the debouncing, a recovery action is necessary. Thus, Platform Health Management notifies State Management. State Management as a coordinator of the platform can decide how a detected failure shall be handled and can trigger corresponding recovery actions. In most cases this might include switching the faulty Function Group to another state.

According to ISO 26262, it has to be ensured that a reaction is triggered after a safetyrelevant failure occurred. Therefore, Platform Health Management has to make sure that State Management receives the notification on a detected failure. The Platform Health Management monitors the return of the RecoveryHandler with a configurable timeout. If State Management will not regularly return from the RecoveryHandler in time, the PHM will do its own countermeasures by wrongly triggering or stop triggering the serviced watchdog.

[SWS_PHM_00101]{DRAFT} Notification to State Management due to Supervision failure [If the status of the mapped GlobalSupervision via RecoveryNotificationToPPortPrototypeMapping switches to state kEXPIRED, the Platform Health Management shall notify State Management via the method RecoveryHandler. The parameter executionError shall contain the corresponding Function Group and the current ProcessExecutionError. The parameter supervision shall contain the TypeOfSupervision which causes the transition to state kEXPIRED.] (RS_HM_09159, RS_HM_09249)

Note: A GlobalSupervision corresponds to whole or part of a Function Group, i.e. for each GlobalSupervision always the same Function Group is reported. The ProcessExecutionError is defined within the StartupConfig, wherefore the executionError.executionError depends on the current used StartupConfig.

[SWS_PHM_00102]{OBSOLETE} Notification to State Management due to Health Status [If the Health Status of a Health Channel switches and a reaction of State Management is required, i.e. PhmHealthChannelStatus.triggersRecov-eryNotification equals true for the corresponding PhmHealthChannelStatus.statusId, the Platform Health Management shall notify State Management via the method RecoveryHandler. The parameter healthStatusId shall be passed from the method ReportHealthStatus.](RS_HM_09159, RS_HM_09249, RS_PHM_-09255)

This means that the information about whether a reaction is required has to be configured for Platform Health Management.

[SWS_PHM_00104]{DRAFT} Reaction on timeout for notification to State Management [If after sending a notification on a failure to State Management via the method RecoveryHandler no acknowledgment by State Management is received before RecoveryNotification.recoveryNotificationTimeout, Platform



Health Management shall stop calling WatchdogInterface::AliveNotification and call WatchdogInterface::FireWatchdogReaction.](RS_HM_09159, RS_HM_09249, RS_HM_09226)

[SWS_PHM_01147]{DRAFT} **Enable handler** [Platform Health Management shall enable potential invocations of RecoveryHandler when Offer is called.](*RS_HM_09159*)

[SWS_PHM_01148]{DRAFT} **Disable handler** [Platform Health Management shall disable invocations of RecoveryHandler when StopOffer is called.](*RS_HM_09159*)

7.6.2 Handling of Hardware Watchdog

The Platform Health Management is the only Functional Cluster with an interface to the hardware watchdog. Therefore, the watchdog supervises Platform Health Management and PHM can initiate a reaction of the watchdog by stop triggering or by sending a false trigger. Since this reaction means usually a reset of the machine, it has an impact on all functions and should be used only as a last resort in order to ensure freedom from interference. Failures that require a watchdog reaction are supervision failures in State Management and Execution Management since in these cases a recovery action via State Management as described in section 7.6.1 is not possible.

Platform Health Management handles the hardware watchdog via the WatchdogInterface. PHM indicates aliveness to WatchdogInterface cyclically. WatchdogInterface will trigger the hardware watchdog correctly as long as PHM indicates aliveness. If PHM does not report aliveness in configured time, WatchdogInterface shall initiate watchdog reaction.

In case a critical failure is detected, PHM can trigger recovery action through WatchdogInterface.

[SWS_PHM_00106]{DRAFT} Recovery Action for Failures in Execution or State Management [As long as no Global Supervision Status corresponding to State Management or Execution Management has reached state kSTOPPED and Notification to State Management has not failed, Platform Health Management shall call WatchdogInterface::AliveNotification periodically.](*RS_HM_09249*, *RS_HM_09226*)

[SWS_PHM_00105]{DRAFT} Recovery Action for Failures in Execution Management or State Management [If the Global Supervision Status corresponding to State Management or Execution Management switches to kSTOPPED, Platform Health Management shall stop calling WatchdogInterface::AliveNotification and call WatchdogInterface::FireWatchdogReaction.](RS_HM_09249, RS_HM_09226)



7.6.3 Configuration Parameters

Configuration of recovery actions within Platform Health Management has one parameter:


1. recoveryNotificationTimeout: the maximum acceptable amount of time Platform Health Management waits for an acknowledgment by State Management after sending the notification.



7.7 Multiple processes and multiple instances

During the application deployment phase, a single Supervised Entity or a single Health Channel may be instanciated several times: this happens for example when the same C++ object class representing a Supervised Entity or a Health Channel is explicitly instanciated inside the code or when the same executable containing the Supervised Entity or the Health Channel is started/run multiple times. In such a case, each instance of the Supervised Entity is individually supervised, each Alive Supervision, Deadline Supervision and Logical Supervision generating an instance of Elementary Supervision Status.

A specific instance of a Supervised Entity or Health Channel identifies itself at run time via an InstanceSpecifier. The API usage of the ara::core::InstanceSpecifier is specified in SWS_CORE_10200 and chapter "'InstanceSpecifier data type"' in [8]. The modelling relation of the InstanceSpecifier and its usage in PHM is explained in detail in the chapter "'Supervised Entities and Checkpoints"' in [12].






Figure 7.6: Example of multiple instance of the same Supervised Entity

Figure 7.6 shows an example of a single Supervised Entity (called SE_A) belonging to a unique SW Component (SWComponent_X in the example). SWComponent_X is instanciated explicitly twice in the same process (Process 1) and another time in a different process/application (process 2). In such a case, three instances of the Port Prototype representing the Supervised Entity are created.



7.8 Functional cluster life-cycle

7.8.1 Startup

[SWS_PHM_01252]{DRAFT} Handling of Watchdog after Startup [Platform Health Management shall call WatchdogInterface::AliveNotification before reporting kRunning to Execution Management using the method ara::exec::ExecutionClient::ReportExecutionState.](RS_HM_09249, RS_HM_09244, RS_HM_09245, RS_HM_09246)

The intention is to take over the control of the HW watchdog as early as possible.

More information on the machine startup sequence can be found in [13].

7.8.2 Shutdown

It is the integrators responsibility to make correct use of the shutdown mechanism. Details for ensuring safe execution are given in [14]. Details on the sequence of machine shutdown can be found in [13].

[SWS_PHM_01253]{DRAFT} Termination of Supervisions at SIGTERM [Platform Health Management shall stop all configured supervisions (eg: delete all supervision objects) after receiving SIGTERM.](*RS_HM_09222, RS_HM_09125, RS_HM_09235*)

[SWS_PHM_01254]{DRAFT} Global Supervision Status at SIGTERM [Platform Health Management shall change all Global Supervision Statuses to DE-ACTIVATED after receiving SIGTERM.](*RS_HM_09222, RS_HM_09125, RS_HM_09235*)

7.8.2.1 Handling of watchdog during shutdown

Handling of watchdog during and after Shutdown of Platform Health Management will not be specified.

Note: Platform Health Management will no more be able to handle the servicing of the watchdog once it is shutdown.



8 API specification

8.1 API Header files

This section describes the header files of the ara::phm API.

The generated header files provide the generated types for Supervised Entitys and Health Channels.

8.1.1 Supervised Entity

For each Supervised Entity, a separate namespace is generated.

Namespaces are used to separate the definition of services from each other to prevent name conflicts and they allow to use reasonably short names. It is recommended to define the namespace unique, e.g. by using the company domain name.

[SWS_PHM_01005] Namespace of generated header files for a Supervised Entity [Based on the symbol attributes of the ordered SymbolProps aggregated by PhmSupervisedEntityInterface, the C++ namespace of a Supervised Entity shall be:

```
1 namespace ara {
2 namespace phm {
3
4 namespace supervised entities {
5
6 namespace <PhmSupervisedEntityInterface.namespace[0].symbol> {
7 namespace <PhmSupervisedEntityInterface.namespace[1].symbol> {
8 namespace <...> {
9 namespace <PhmSupervisedEntityInterface.namespace[n].symbol> {
10
11 namespace <PhmSupervisedEntityInterface.shortName> {
12
  . . .
13 } // namespace <PhmSupervisedEntityInterface.shortName>
14
15 } // namespace <PhmSupervisedEntityInterface.namespace[n].symbol>
16 } // namespace <...>
  } // namespace <PhmSupervisedEntityInterface.namespace[1].symbol>
17
  } // namespace <PhmSupervisedEntityInterface.namespace[0].symbol>
18
19
20 } // namespace supervised_entities
21
22 } // namespace phm
23 } // namespace ara
```

with all namespace names converted to lower-case letters. These namespaces are taken from namespace attribute configured under PhmSupervisedEntityInterface. Also, see "Namespace" under "Service Interface" chapter in [12].](*RS_PHM_-00002*)



So an example namespace could be e.g.

ara::phm::supervised_entities::oem:body::headlights::low_beam

with low_beam being the name of the Supervised Entity and body, headlights and low_beam are namespaces used to organize and uniquely identify the Supervised Entity.

[SWS_PHM_01020] Folder structure for Supervised Entity files [The generated header files defined by [SWS_PHM_01002] shall be located within the folder:

<folder>/ara/phm/supervised_entities/<namespace[0]>/.../<namespace[n]>/

where:

<folder> is the start folder for the ara::phm header files specific for a project or platform vendor,

<namespace[0]> ... <namespace[n]> are the namespace names as defined in [SWS_PHM_01005]. (*RS_PHM_00001*)

[SWS_PHM_01002] Generated header files for Supervised Entitys [The Platform Health Management shall provide one Supervised Entity header file for each PhmSupervisedEntityInterface defined in the input by using the file name <name>.h, where <name> is the PhmSupervisedEntityInterface. shortName](RS_PHM_00001)

So effectively, for each Supervised Entity, there is a separate generated file. There can be several Supervised Entitys in the same namespace, which results with several files in the same folder.

8.1.2 Health Channel

The generation of files/namespaces for Health Channels is similar to the one of Supervised Entitys.

[SWS_PHM_01113]{OBSOLETE} Namespace of generated header files for a Health Channel [Based on the symbol attributes of the ordered SymbolProps aggregated by PhmHealthChannelInterface, the C++ namespace of the Health Channel shall be:

```
1 namespace ara {
2 namespace phm {
3 namespace health_channels {
4
5 namespace <PhmHealthChannelInterface.namespace[0].symbol> {
6 namespace <PhmHealthChannelInterface.namespace[1].symbol> {
7 namespace <...> {
8 namespace <PhmHealthChannelInterface.namespace[n].symbol> {
9
10 namespace <PhmHealthChannelInterface.shortName> {
11 ...
12 } // namespace <PhmHealthChannelInterface.shortName> 13
```



```
14 } // namespace <PhmHealthChannelInterface.namespace[n].symbol>
15 } // namespace <...>
16 } // namespace <PhmHealthChannelInterface.namespace[1].symbol>
17 } // namespace <PhmHealthChannelInterface.namespace[0].symbol>
18
19 } // namespace health_channels
20
21 } // namespace phm
22 } // namespace ara
```

with all namespace names converted to lower-case letters. These namespaces are taken from namespace attribute configured under PhmHealthChannelInterface. Also, see "Namespace" under "Service Interface" chapter in [12]. (*RS_PHM_00002*)

So an example namespace could be e.g.

ara::phm::health_channels::oem::drivetrain::wheels:pressure

with pressure being the name of the Health Channel and oem, drivetrain and wheels are namespaces used to organize and uniquely identify the Health Channel.

[SWS_PHM_01114]{OBSOLETE} **Folder structure for Health Channel files** [The generated header files defined by [SWS_PHM_01002] shall be located within the folder:

<folder>/ara/phm/health_channels/<namespace[0]>/.../<namespace[n]>/

where:

<folder> is the start folder for the ara::phm header files specific for a project or platform vendor,

<namespace[0]> ... <namespace[n]> are the namespace names as defined in [SWS_PHM_01113]. (*RS_PHM_00001*)

[SWS_PHM_01115]{OBSOLETE} Generated header files for Health Channels [The Platform Health Management shall provide one Health Channel header file for each HealthChannel defined in the input by using the file name <name>.h, where <name> is the HealthChannel.shortName | (RS_PHM_00001)

So effectively, for each Health Channel, there is a separate generated file. There can be several Health Channels in the same namespace, which results with several files in the same folder.

8.2 API Common Data Types

This chapter describes the standardized types provided by the ara::phm API. The ara::phm API is based on the ara::core types defined in [8].



8.2.1 Generated Types

This chapter describes the types used by Platform Health Management which are generated dependent on the input configuration.

An Enumeration is not a plain primitive data type, but a structural description defined with a set of custom identifiers known as *enumerators* representing the possible values. In C++, an enumeration is a first-class object and can take any of these enumerators as a value.

8.2.1.1 Enumeration for Checkpoint

For each Supervised Entity, an enumeration is generated containing the corresponding Checkpoints.

[SWS_PHM_00424] Enumeration for Supervised Entity [For each PhmSupervisedEntityInterface, there shall exist the corresponding type declaration as:

```
enum class Checkpoints : std::uint32_t {
    <enumerator-list>
```

};

where <enumerator-list> are the enumerators as defined by
[SWS_PHM_00425].](RS_PHM_00003, RS_PHM_00101, RS_HM_09254, RS_PHM_09241)

[SWS_PHM_00425] Definition of enumerators of Supervised Entitys [For each PhmCheckpoint contained in the PhmSupervisedEntityInterface, there shall exist the corresponding enumeration nested in the declaration defined by [SWS_PHM_00424] as:

```
<enumeratorLiteral> = <initializer><suffix>,
```

where:

<enumeratorLiteral> is PhmCheckpoint.shortName

<initializer> is the PhmCheckpoint.checkpointId

<suffix> shall be "U".

(*RS_PHM_00003*, *RS_PHM_00101*, *RS_HM_09254*, *RS_PHM_09241*)

For example, this can generate:



[SWS_PHM_00426] Namespace for Checkpoints [The enumeration containing Checkpoints specified in [SWS_PHM_00424] shall be generated in the namespace of the corresponding PhmSupervisedEntityInterface described in [SWS_PHM_01005].](*RS_PHM_00003, RS_PHM_00101, RS_HM_09254, RS_-PHM_09241*)

8.2.1.2 Enumeration for Health Status

The generation for Health Channels is similar to the one of Supervised Entitys.

For each Health Channel, an enumeration is generated containing the corresponding Health Statuses.

[SWS_PHM_01118]{OBSOLETE} **Enumeration for Health Channel** [For each PhmHealthChannelInterface, there shall exist the corresponding type declaration as:

```
enum class HealthStatuses : uint32_t {
        <enumerator-list>
```

};

where <enumerator-list> are the enumerators as defined by [SWS_PHM_01119]]
(RS_PHM_00003, RS_PHM_00102, RS_PHM_09257)

[SWS_PHM_01119]{OBSOLETE} Definition of enumerators of Health Channels [For each PhmHealthChannelStatus contained in the PhmHealthChannelInterface, there shall exist the corresponding enumeration nested in the declaration defined by [SWS_PHM_01118] as:

<enumeratorLiteral> = <initializer><suffix>,

where:

<enumeratorLiteral> is PhmHealthChannelStatus.shortName

<initializer> is the PhmHealthChannelStatus.statusId

<suffix> shall be "U".

(*RS_PHM_00003*, *RS_PHM_00102*, *RS_PHM_09257*)

For example, this can generate:

```
enum class HealthStatuses : uint32_t
{
    Low = 0U,
    High = 1U,
    Ok = 2U,
    VeryLow = 3U,
    VeryHigh = 4U
}
```



[SWS_PHM_01129]{OBSOLETE} **Enumeration for Health Channel** [The enumeration containing Health Statuses specified in [SWS_PHM_01118] shall be generated in the namespace of the corresponding PhmHealthChannelInterface described in [SWS_PHM_01113]](*RS_PHM_00003, RS_PHM_00102, RS_PHM_09257*)

8.2.2 Non-generated types

This section defines the types that are non-generated.

8.2.2.1 ElementarySupervisionStatus

[SWS_PHM_01358]{DRAFT} [

Kind:	enumeration		
Symbol:	ElementarySupervisionStatus	ElementarySupervisionStatus	
Scope:	namespace ara::phm		
Underlying type:	std::uint32_t		
Syntax:	<pre>enum class ElementarySupervisionStatus : std::uint32_t {};</pre>		
Values:	kOK= 0 Supervision is active and no failure is present.		
	kFailed= 1	A failure was detected but still within tolerance/ debouncing.	
	kExpired= 2 A failure was detected and qualified.		
	kDeactivated= 4	Supervision is not active.	
Header file:	#include "ara/phm/supervised_entity.h"		
Description:	Enumeration of elementary supervision status. Scoped Enumeration of uint32_t.		

](RS_HM_09237)

8.2.2.2 GlobalSupervisionStatus

[SWS_PHM_01137]{DRAFT} [

Kind:	enumeration	
Symbol:	GlobalSupervisionStatus	
Scope:	namespace ara::phm	
Underlying type:	std::uint32_t	
Syntax:	<pre>enum class GlobalSupervisionStatus : std::uint32_t {};</pre>	
Values:	kOK= 0	At least one Elementary Supervision corresponding to the Global Supervision is in status kOK and none in status kFailed or kExpired.



	•
/	/

	kFailed= 1	At least one Elementary Supervision corresponding to the Global Supervision is in status kFailed but none in status kExpired.
	kExpired= 2	At least one Elementary Supervision corresponding to the Global Supervision is in status kExpired but the time elapsed since reaching kExpired has not exceeded the tolerance.
	kStopped= 3	At least one Elementary Supervision corresponding to the Global Supervision is in status kExpired and the time elapsed since reaching kExpired has exceeded the tolerance.
	kDeactivated= 4	All Elementary Supervisions corresponding to the Global Supervision are in status kDeactivated.
Header file:	#include "ara/phm/supervised_entity.h"	
Description:	Enumeration of global supervision status	. Scoped Enumeration of uint32_t.

](RS_HM_09237)

8.2.2.3 SupervisedEntity

[SWS_PHM_01132] [

Kind:	class	
Symbol:	SupervisedEntity	
Scope:	namespace ara::phm	
Syntax:	<pre>template <typename enumt=""> class ara::phm::SupervisedEntity {};</typename></pre>	
Template param:	typename EnumT An enum type that contains a list of checkpoint identifier	
Header file:	#include "ara/phm/supervised_entity.h"	
Description:	SupervisedEntity Class.	

](*RS_PHM_00003, RS_PHM_00101, RS_HM_09254, RS_PHM_00001, RS_PHM_00002*)

8.2.2.4 HealthChannel

[SWS_PHM_01122]{OBSOLETE} [

Kind:	class	
Symbol:	HealthChannel	
Scope:	namespace ara::phm	
Syntax:	<pre>template <typename enumt=""> class ara::phm::HealthChannel {};</typename></pre>	
Template param:	typename EnumT An enum type that contains health status Identifier	
Header file:	#include "ara/phm/health_channel.h"	
Description:	HealthChannel Class.	



](*RS_PHM_00003*, *RS_PHM_00102*, *RS_PHM_09257*, *RS_PHM_00001*, *RS_PHM_00002*)

8.2.2.5 RecoveryAction

[SWS_PHM_01140]{DRAFT} [

Kind:	class
Symbol:	RecoveryAction
Scope:	namespace ara::phm
Syntax:	<pre>class ara::phm::RecoveryAction {};</pre>
Header file:	#include "ara/phm/recovery_action.h"
Description:	RecoveryAction abstract class.

](RS_PHM_00003)

8.2.2.6 HealthChannelAction

[SWS_PHM_01139]{OBSOLETE} [

Kind:	class	class	
Symbol:	HealthChannelAction		
Scope:	namespace ara::phm	namespace ara::phm	
Syntax:	template <typename enumt=""> class ara::phm::HealthChannelA</typename>	<pre>template <typename enumt=""> class ara::phm::HealthChannelAction {};</typename></pre>	
Template param:	typename EnumT	typename EnumT An enum type that contains checkpoint identifier	
Header file:	#include "ara/phm/health_channel_action	#include "ara/phm/health_channel_action.h"	
Description:	HealthChannelAction abstract class.		

](RS_PHM_00003)

8.2.2.7 TypeOfSupervision

[SWS_PHM_01138]{DRAFT} [

Kind:	enumeration	
Symbol:	TypeOfSupervision	
Scope:	namespace ara::phm	
Underlying type:	std::uint32_t	
Syntax:	<pre>enum class TypeOfSupervision : std::uint32_t {};</pre>	
Values:	AliveSupervision= 0	Supervision is of type AliveSupervision.
	DeadlineSupervision= 1	Supervision is of type DeadlineSupervision.
	LogicalSupervision= 2	Supervision is of type LogicalSupervision.

 \bigtriangledown



	\triangle
Header file:	#include "ara/phm/recovery_action.h"
Description:	Enumeration of type of supervision. Scoped Enumeration of uint32_t.

](*RS_PHM_00003*)

8.2.2.8 Daisy Chaining Related Types (Non-generated)

Daisy chaining is not supported in this AUTOSAR release.

8.2.2.9 Error and Exception Types

The ara::phm API does not explicitly make use of C++ exceptions. The AUTOSAR implementer is free to provide an exception-free implementation or an implementation that uses Unchecked Exceptions. The implementer is however not allowed to define Checked Exceptions.

ara::phm API builds upon a clean separation of exception types into Unchecked Exceptions and Checked Exceptions.

The former ones (i.e., Unchecked Exceptions) can basically occur in *any* ara::phm API call, are not formally modeled in the Manifest, and are fully implementation specific.

The latter ones (i.e., Checked Exceptions) are not used by Health Management API.

8.2.2.10 E2E Related Data Types

The usage of E2E communication protection for Health Management is not standardized.

8.3 API Reference

8.3.1 SupervisedEntity API

SupervisedEntity API can be used to report Checkpoints or to query the status of a SupervisedEntity.



8.3.1.1 SupervisedEntity::SupervisedEntity

[SWS_PHM_01123] [

Kind:	function	
Symbol:	SupervisedEntity(const ara::core::InstanceSpecifier &instance)	
Scope:	class ara::phm::SupervisedEntity	
Syntax:	<pre>explicit ara::phm::SupervisedEntity< EnumT >::SupervisedEntity (const ara::core::InstanceSpecifier &instance);</pre>	
Parameters (in):	instance instance specifier of the supervised entity.	
Header file:	#include "ara/phm/supervised_entity.h"	
Description:	Creation of a SupervisedEntity.	

](RS_PHM_00101, RS_HM_09254, RS_PHM_09240, RS_PHM_00001, RS_PHM_00002)

Note that additionally process Identification information is necessary. This has to be obtained by the constructor.

[SWS_PHM_01212] [

Kind:	function
Symbol:	SupervisedEntity(const SupervisedEntity &se)
Scope:	class ara::phm::SupervisedEntity
Syntax:	<pre>ara::phm::SupervisedEntity< EnumT >::SupervisedEntity (const SupervisedEntity &se)=delete;</pre>
Header file:	#include "ara/phm/supervised_entity.h"
Description:	The copy constructor for SupervisedEntity shall not be used.

](RS_PHM_00101, RS_HM_09254, RS_PHM_09240, RS_PHM_00001, RS_PHM_-00002)

[SWS_PHM_01214] [

Kind:	function	
Symbol:	SupervisedEntity(SupervisedEntity &&se)	
Scope:	class ara::phm::SupervisedEntity	
Syntax:	<pre>ara::phm::SupervisedEntity< EnumT >::SupervisedEntity (Supervised Entity &&se) noexcept;</pre>	
Parameters (in):	se The SupervisedEntity object to be moved.	
Exception Safety:	noexcept	
Header file:	#include "ara/phm/supervised_entity.h"	
Description:	Move constructor for SupervisedEntity.	

](RS_PHM_00101, RS_HM_09254, RS_PHM_09240, RS_PHM_00001, RS_PHM_-00002)

8.3.1.2 SupervisedEntity::ReportCheckpoint



[SWS_PHM_01127] [

Kind:	function		
Symbol:	ReportCheckpoint(EnumT checkpointId)		
Scope:	class ara::phm::SupervisedEntity		
Syntax:	<pre>void ara::phm::SupervisedEntity< EnumT >::ReportCheckpoint (EnumT checkpointId) noexcept;</pre>		
Parameters (in):	checkpointId checkpoint identifier.		
Return value:	None		
Exception Safety:	noexcept		
Header file:	#include "ara/phm/supervised_entity.h"		
Description:	Reports an occurrence of a Checkpoint.	Reports an occurrence of a Checkpoint.	

](RS_PHM_00101, RS_HM_09254, RS_PHM_00001, RS_PHM_00002)

8.3.1.3 SupervisedEntity::~SupervisedEntity

[SWS_PHM_01211] [

Kind:	function
Symbol:	~SupervisedEntity()
Scope:	class ara::phm::SupervisedEntity
Syntax:	<pre>ara::phm::SupervisedEntity< EnumT >::~SupervisedEntity () noexcept;</pre>
Exception Safety:	noexcept
Header file:	#include "ara/phm/supervised_entity.h"
Description:	Destructor of a SupervisedEntity.

](RS_PHM_00101, RS_HM_09254, RS_PHM_09240, RS_PHM_00001, RS_PHM_00002)

8.3.1.4 SupervisedEntity::Operator=

[SWS_PHM_01213] [

Kind:	function	
Symbol:	operator=(const SupervisedEntity &se)	
Scope:	class ara::phm::SupervisedEntity	
Syntax:	<pre>SupervisedEntity& ara::phm::SupervisedEntity< EnumT >::operator= (const SupervisedEntity &se)=delete;</pre>	
Header file:	#include "ara/phm/supervised_entity.h"	
Description:	The copy assignment operator for SupervisedEntity shall not be used.	

](*RS_PHM_00101, RS_HM_09254, RS_PHM_09240, RS_PHM_00001, RS_PHM_00002*)



[SWS_PHM_01215] [

Kind:	function	
Symbol:	operator=(SupervisedEntity &&se)	
Scope:	class ara::phm::SupervisedEntity	
Syntax:	<pre>SupervisedEntity& ara::phm::SupervisedEntity< EnumT >::operator= (SupervisedEntity &&se) noexcept;</pre>	
Parameters (in):	se	The SupervisedEntity object to be moved.
Return value:	SupervisedEntity &	The moved SupervisedEntity object.
Exception Safety:	noexcept	
Header file:	#include "ara/phm/supervised_entity.h"	
Description:	Move assignment operator for SupervisedEntity.	

](RS_PHM_00101, RS_HM_09254, RS_PHM_09240, RS_PHM_00001, RS_PHM_00002)

8.3.2 HealthChannel API

8.3.2.1 HealthChannel::HealthChannel

[SWS_PHM_00457]{OBSOLETE}

Kind:	function	
Symbol:	HealthChannel(const ara::core::InstanceSpecifier &instance)	
Scope:	class ara::phm::HealthChannel	
Syntax:	<pre>explicit ara::phm::HealthChannel< EnumT >::HealthChannel (const ara::core::InstanceSpecifier &instance);</pre>	
Parameters (in):	instance instance specifier of the health channel	
Header file:	#include "ara/phm/health_channel.h"	
Description:	Creation of a HealthChannel.	

](RS_PHM_00102, RS_PHM_09257, RS_PHM_00001, RS_PHM_00002)

Note that additionally process Identification information is necessary. This has to be obtained by the constructor.

[SWS_PHM_01222]{OBSOLETE} [

Kind:	function	
Symbol:	HealthChannel(const HealthChannel &channel)	
Scope:	class ara::phm::HealthChannel	
Syntax:	<pre>ara::phm::HealthChannel< EnumT >::HealthChannel (const HealthChannel &channel)=delete;</pre>	
Header file:	#include "ara/phm/health_channel.h"	
Description:	The copy constructor for HealthChannel shall not be used.	

](*RS_PHM_00102*, *RS_PHM_09257*, *RS_PHM_00001*, *RS_PHM_00002*)



[SWS_PHM_01224]{OBSOLETE} [

Kind:	function	
Symbol:	HealthChannel(HealthChannel &&channel)	
Scope:	class ara::phm::HealthChannel	
Syntax:	<pre>ara::phm::HealthChannel< EnumT >::HealthChannel (HealthChannel &&channel) noexcept;</pre>	
Parameters (in):	channel	The HealthChannel object to be moved.
Exception Safety:	noexcept	
Header file:	#include "ara/phm/health_channel.h"	
Description:	Move constructor for HealthChannel.	

](RS_PHM_00102, RS_PHM_09257, RS_PHM_00001, RS_PHM_00002)

8.3.2.2 HealthChannel::ReportHealthStatus

[SWS_PHM_01128]{OBSOLETE}

Kind:	function	
Symbol:	ReportHealthStatus(EnumT healthStatusId)	
Scope:	class ara::phm::HealthChannel	
Syntax:	<pre>void ara::phm::HealthChannel< EnumT >::ReportHealthStatus (EnumT healthStatusId) noexcept;</pre>	
Parameters (in):	healthStatusId	The identifier representing the Health Status. The mapping is implementation specific.
Return value:	None	
Exception Safety:	noexcept	
Header file:	#include "ara/phm/health_channel.h"	
Description:	Reports a Health Status.	

](RS_PHM_00102, RS_PHM_09257, RS_PHM_00001, RS_PHM_00002)

8.3.2.3 HealthChannel::~HealthChannel

[SWS_PHM_01221]{OBSOLETE} [

Kind:	function
Symbol:	~HealthChannel()
Scope:	class ara::phm::HealthChannel
Syntax:	<pre>ara::phm::HealthChannel< EnumT >::~HealthChannel () noexcept;</pre>
Exception Safety:	noexcept
Header file:	#include "ara/phm/health_channel.h"
Description:	Destructor of a HealthChannel.

](*RS_PHM_00102*, *RS_PHM_09257*, *RS_PHM_00001*, *RS_PHM_00002*)



8.3.2.4 HealthChannel::Operator=

[SWS_PHM_01223]{OBSOLETE} [

Kind:	function	
Symbol:	operator=(const HealthChannel &channel)	
Scope:	class ara::phm::HealthChannel	
Syntax:	<pre>HealthChannel& ara::phm::HealthChannel< EnumT >::operator= (const HealthChannel &channel)=delete;</pre>	
Header file:	#include "ara/phm/health_channel.h"	
Description:	The copy assignment operator for HealthChannel shall not be used.	

](RS_PHM_00102, RS_PHM_09257, RS_PHM_00001, RS_PHM_00002)

[SWS_PHM_01225]{OBSOLETE}

Kind:	function		
Symbol:	operator=(HealthChannel &&channel)		
Scope:	class ara::phm::HealthChannel		
Syntax:	<pre>HealthChannel& ara::phm::HealthChannel< EnumT >::operator= (Health Channel &&channel) noexcept;</pre>		
Parameters (in):	channel	channel The HealthChannel object to be moved.	
Return value:	HealthChannel & The moved HealthChannel object.		
Exception Safety:	noexcept		
Header file:	#include "ara/phm/health_channel.h"		
Description:	Move assignment operator for HealthChannel.		

](RS_PHM_00102, RS_PHM_09257, RS_PHM_00001, RS_PHM_00002)

8.3.3 RecoveryAction API

8.3.3.1 RecoveryAction::RecoveryAction

[SWS_PHM_01141]{DRAFT}

Kind:	function	
Symbol:	RecoveryAction(const ara::core::InstanceSpecifier &instance)	
Scope:	class ara::phm::RecoveryAction	
Syntax:	<pre>explicit ara::phm::RecoveryAction::RecoveryAction (const ara::core::InstanceSpecifier &instance);</pre>	
Parameters (in):	instance instance specifier to the PPortPrototype of a Phm RecoveryActionInterface	
Header file:	#include "ara/phm/recovery_action.h"	
Description:	Creation of an RecoveryAction.	

](RS_PHM_00003)

Note that additionally process Identification information is necessary. This has to be obtained by the constructor.



[SWS_PHM_01149]{DRAFT} [

Kind:	function		
Symbol:	RecoveryAction(RecoveryAction &&ra)		
Scope:	class ara::phm::RecoveryAction		
Syntax:	<pre>ara::phm::RecoveryAction::RecoveryAction (RecoveryAction &&ra) noexcept;</pre>		
Parameters (in):	ra The RecoveryAction object to be moved.		
Exception Safety:	noexcept		
Header file:	#include "ara/phm/recovery_action.h"		
Description:	Move constructor for RecoveryAction.		

](RS_PHM_00003)

[SWS_PHM_01150]{DRAFT} [

Kind:	function
Symbol:	RecoveryAction(const RecoveryAction &)
Scope:	class ara::phm::RecoveryAction
Syntax:	<pre>ara::phm::RecoveryAction::RecoveryAction (const RecoveryAction &)=delete;</pre>
Header file:	#include "ara/phm/recovery_action.h"
Description:	The copy constructor for RecoveryAction shall not be used.

](RS_PHM_00003)

8.3.3.2 RecoveryAction::Operator=

[SWS_PHM_01151]{DRAFT} [

Kind:	function		
Symbol:	operator=(RecoveryAction &&ra)		
Scope:	class ara::phm::RecoveryAction		
Syntax:	<pre>RecoveryAction& ara::phm::RecoveryAction::operator= (RecoveryAction &&ra) noexcept;</pre>		
Parameters (in):	ra The RecoveryAction object to be moved.		
Return value:	RecoveryAction & The moved RecoveryAction object.		
Exception Safety:	noexcept		
Header file:	#include "ara/phm/recovery_action.h"		
Description:	Move assignment operator for RecoveryAction.		

](RS_PHM_00003)

$\textbf{[SWS_PHM_01152]} \{ \text{DRAFT} \} \ \lceil$

Kind:	function
Symbol:	operator=(const RecoveryAction &)
Scope:	class ara::phm::RecoveryAction



 \triangle

Syntax:	<pre>RecoveryAction& ara::phm::RecoveryAction::operator= (const Recovery Action &)=delete;</pre>
Header file:	#include "ara/phm/recovery_action.h"
Description:	The copy assignment operator for RecoveryAction shall not be used.

](*RS_PHM_00003*)

8.3.3.3 RecoveryAction::~RecoveryAction

[SWS_PHM_01145]{DRAFT} [

Kind:	function
Symbol:	~RecoveryAction()
Scope:	class ara::phm::RecoveryAction
Syntax:	<pre>virtual ara::phm::RecoveryAction::~RecoveryAction () noexcept;</pre>
Exception Safety:	noexcept
Header file:	#include "ara/phm/recovery_action.h"
Description:	Destructor for RecoveryAction.

](*RS_PHM_00003*)

8.3.3.4 RecoveryAction::RecoveryHandler

[SWS_PHM_01142]{DRAFT} [

Kind:	function	function	
Symbol:	RecoveryHandler(const ara::exec::Exect supervision)	RecoveryHandler(const ara::exec::ExecutionErrorEvent &executionError, TypeOfSupervision supervision)	
Scope:	class ara::phm::RecoveryAction	class ara::phm::RecoveryAction	
Syntax:	<pre>virtual void ara::phm::RecoveryAction::RecoveryHandler (const ara::exec::ExecutionErrorEvent &executionError, TypeOfSupervision supervision)=0;</pre>		
Parameters (in):	executionError	Information on detected error, shall give further information for error recovery.	
	supervision	The type of elementary supervision which failed.	
Return value:	None	None	
Header file:	#include "ara/phm/recovery_action.h"	#include "ara/phm/recovery_action.h"	
Description:	RecoveryHandler to be invoked by PHM	RecoveryHandler to be invoked by PHM.	
	The handler invocation needs to be enabled before by a call of RecoveryAction::Offer.		

](RS_PHM_00003)



8.3.3.5 RecoveryAction::Offer

[SWS_PHM_01143]{DRAFT} [

Kind:	function	
Symbol:	Offer()	
Scope:	class ara::phm::RecoveryAction	
Syntax:	<pre>ara::core::Result<void> ara::phm::RecoveryAction::Offer ();</void></pre>	
Return value:	ara::core::Result< void > A Result, being either empty or containing any of the errors defined below.	
Errors:	ara::phm::phmErrc::kOfferFailed Returned if service could not be offered due to failure of communication with PHM daemon	
Header file:	#include "ara/phm/recovery_action.h"	
Description:	Enables potential invocations of RecoveryHandler.	

](RS_PHM_00003)

8.3.3.6 RecoveryAction::StopOffer

[SWS_PHM_01144]{DRAFT} [

Kind:	function	
Symbol:	StopOffer()	
Scope:	class ara::phm::RecoveryAction	
Syntax:	<pre>void ara::phm::RecoveryAction::StopOffer ();</pre>	
Return value:	None	
Header file:	#include "ara/phm/recovery_action.h"	
Description:	Disables invocations of RecoveryHandler.	

](RS_PHM_00003)

8.3.4 HealthChannelAction API

8.3.4.1 HealthChannelAction::HealthChannelAction

[SWS_PHM_01231]{OBSOLETE} [

Kind:	function
Symbol:	HealthChannelAction(const ara::core::InstanceSpecifier &instance)
Scope:	class ara::phm::HealthChannelAction
Syntax:	<pre>explicit ara::phm::HealthChannelAction< EnumT >::HealthChannelAction (const ara::core::InstanceSpecifier &instance);</pre>

 \bigtriangledown



/	Λ.
_	_

Parameters (in):	instance	instance specifier to the PPortPrototype of a Phm HealthChannelActionInterface
Header file:	#include "ara/phm/health_channel_action.h"	
Description:	Creation of an HealthChannelAction.	

](RS_PHM_00003)

Note that additionally process Identification information is necessary. This has to be obtained by the constructor.

[SWS_PHM_01233]{OBSOLETE} [

Kind:	function	
Symbol:	HealthChannelAction(HealthChannelAction &&hca)	
Scope:	class ara::phm::HealthChannelAction	
Syntax:	<pre>ara::phm::HealthChannelAction< EnumT >::HealthChannelAction (Health ChannelAction &&hca) noexcept;</pre>	
Parameters (in):	hca The HealthChannelAction object to be moved.	
Exception Safety:	noexcept	
Header file:	#include "ara/phm/health_channel_action.h"	
Description:	Move constructor for HealthChannelAction.	

](RS_PHM_00003)

[SWS_PHM_01234]{OBSOLETE} [

Kind:	function	
Symbol:	HealthChannelAction(const HealthChannelAction &)	
Scope:	class ara::phm::HealthChannelAction	
Syntax:	<pre>ara::phm::HealthChannelAction< EnumT >::HealthChannelAction (const HealthChannelAction &)=delete;</pre>	
Header file:	#include "ara/phm/health_channel_action.h"	
Description:	The copy constructor for HealthChannelAction shall not be used.	

](RS_PHM_00003)

8.3.4.2 HealthChannelAction::Operator=

[SWS_PHM_01235]{OBSOLETE} [

Kind:	function		
Symbol:	operator=(HealthChannelAction &&hca)	operator=(HealthChannelAction &&hca)	
Scope:	class ara::phm::HealthChannelAction	class ara::phm::HealthChannelAction	
Syntax:	-	<pre>HealthChannelAction& ara::phm::HealthChannelAction< EnumT >::operator= (HealthChannelAction &&hca) & noexcept;</pre>	
Parameters (in):	hca	The HealthChannelAction object to be moved.	
Return value:	HealthChannelAction &	The moved HealthChannelAction object.	
$\overline{\nabla}$			



 \triangle

Exception Safety:	noexcept
Header file:	#include "ara/phm/health_channel_action.h"
Description:	Move assignment operator for HealthChannelAction.

](RS_PHM_00003)

[SWS_PHM_01236]{OBSOLETE} [

Kind:	function	
Symbol:	operator=(const HealthChannelAction &)	
Scope:	class ara::phm::HealthChannelAction	
Syntax:	<pre>HealthChannelAction& ara::phm::HealthChannelAction< EnumT >::operator= (const HealthChannelAction &)=delete;</pre>	
Header file:	#include "ara/phm/health_channel_action.h"	
Description:	The copy assignment operator for HealthChannelAction shall not be used.	

](RS_PHM_00003)

8.3.4.3 HealthChannelAction::~HealthChannelAction

[SWS_PHM_01232]{OBSOLETE} [

Kind:	function
Symbol:	~HealthChannelAction()
Scope:	class ara::phm::HealthChannelAction
Syntax:	<pre>virtual ara::phm::HealthChannelAction< EnumT >::~HealthChannelAction () noexcept;</pre>
Exception Safety:	noexcept
Header file:	#include "ara/phm/health_channel_action.h"
Description:	Destructor for HealthChannelAction.

(RS_PHM_00003)

8.3.4.4 HealthChannelAction::RecoveryHandler

[SWS_PHM_01237]{OBSOLETE} [

Kind:	function
Symbol:	RecoveryHandler(EnumT healthStatusId)
Scope:	class ara::phm::HealthChannelAction
Syntax:	<pre>virtual void ara::phm::HealthChannelAction< EnumT >::RecoveryHandler (EnumT healthStatusId)=0;</pre>
\bigtriangledown	



\bigtriangleup			
Parameters (in):	healthStatusId The identifier representing the Health Status. The mapping is implementation specific.		
Return value:	None		
Header file:	#include "ara/phm/health_channel_action.h"		
Description:	RecoveryHandler to be invoked by PHM.		
	The handler invocation needs to be enabled before by a call of HealthChannelAction::Offer.		

](*RS_PHM_00003*)

8.3.4.5 HealthChannelAction::Offer

[SWS_PHM_01238]{OBSOLETE} [

Kind:	function	
Symbol:	Offer()	
Scope:	class ara::phm::HealthChannelAction	
Syntax:	<pre>ara::core::Result<void> ara::phm::HealthChannelAction< EnumT >::Offer ();</void></pre>	
Return value:	ara::core::Result< void >	A Result, being either empty or containing any of the errors defined below.
Errors:	ara::phm::phmErrc::kOfferFailed	Returned if service could not be offered due to failure of communication with PHM daemon
Header file:	#include "ara/phm/health_channel_action.h"	
Description:	Enables potential invocations of RecoveryHandler.	

](RS_PHM_00003)

8.3.4.6 HealthChannelAction::StopOffer

[SWS_PHM_01239]{OBSOLETE} [

Kind:	function
Symbol:	StopOffer()
Scope:	class ara::phm::HealthChannelAction
Syntax:	<pre>void ara::phm::HealthChannelAction< EnumT >::StopOffer ();</pre>
Return value:	None
Header file:	#include "ara/phm/health_channel_action.h"
Description:	Disables invocations of RecoveryHandler.

](RS_PHM_00003)



8.3.5 Forward supervision state (daisy-chain)

This feature is not supported by this AUTOSAR release.

8.4 API Errors

The Platform Health Management cluster implements an error handling based on ara::core::Result. The errors supported by the Platform Health Management cluster are listed in section 8.4.1.

8.4.1 PhmErrc

[SWS_PHM_01240]{DRAFT} [

Kind:	enumeration	
Symbol:	PhmErrc	
Scope:	namespace ara::phm	
Underlying type:	ara::core::ErrorDomain::CodeType	
Syntax:	<pre>enum class PhmErrc : ara::core::ErrorDomain::CodeType {};</pre>	
Values:	kOfferFailed= 2 Service could not be offered due to failure of communication with Phm daemon.	
Header file:	#include "ara/phm/phm_error_domain.h"	
Description:	Defines an enumeration class for the Platform Health Management error codes.	

](*RS_AP_00119*)

8.4.2 GetPhmDomain

[SWS_PHM_01251]{DRAFT} [

Kind:	function	
Symbol:	GetPhmDomain()	
Scope:	namespace ara::phm	
Syntax:	<pre>constexpr const ara::core::ErrorDomain& ara::phm::GetPhmDomain () noexcept;</pre>	
Return value:	const ara::core::ErrorDomain &	The global PhmErrorDomain object.
Exception Safety:	noexcept	
Thread Safety:	re-entrant	
Header file:	#include "ara/phm/phm_error_domain.h"	
Description:	Returns the global PhmErrorDomain object.	

](*RS_AP_00119*, *RS_AP_00132*)



8.4.3 MakeErrorCode

[SWS_PHM_01244]{DRAFT} [

Kind:	function	
Symbol:	MakeErrorCode(PhmErrc code, ara::core::ErrorDomain::SupportDataType data)	
Scope:	namespace ara::phm	
Syntax:	<pre>constexpr ara::core::ErrorCode ara::phm::MakeErrorCode (PhmErrc code, ara::core::ErrorDomain::SupportDataType data) noexcept;</pre>	
Parameters (in):	code	Error code number.
	data	Vendor defined data associated with the error.
Return value:	ara::core::ErrorCode	An ErrorCode object.
Exception Safety:	noexcept	
Thread Safety:	re-entrant	
Header file:	#include "ara/phm/phm_error_domain.h"	
Description:	Creates an error code.	

](*RS_AP_00119*, *RS_AP_00132*)

8.4.4 PhmException Class

There are no standardized exceptions w.r.t Platform Health Management. But the API is added to be in sync with the base class from ara::core.

[SWS_PHM_01242]{DRAFT} [

Kind:	class	
Symbol:	PhmException	
Scope:	namespace ara::phm	
Base class:	ara::core::Exception	
Syntax:	<pre>class ara::phm::PhmException : public ara::core::Exception {};</pre>	
Header file:	#include "ara/phm/phm_error_domain.h"	
Description:	Exception type thrown by Platform Health Management.	

](*RS_AP_00119*)

8.4.4.1 PhmException::PhmException

[SWS_PHM_01243]{DRAFT} [

Kind:	function	
Symbol:	PhmException(ara::core::ErrorCode errorCode)	
Scope:	class ara::phm::PhmException	
Syntax:	<pre>explicit ara::phm::PhmException::PhmException (ara::core::ErrorCode errorCode) noexcept;</pre>	

 \bigtriangledown



Δ		
Parameters (in):	errorCode	The error code.
Exception Safety:	noexcept	
Header file:	#include "ara/phm/phm_error_domain.h"	
Description:	Construct a new PlatformHealthManagement exception object containing an error code.	

](*RS_AP_00119*, *RS_AP_00132*)

8.4.5 PhmErrorDomain Class

The error handling requires an ara::core::ErrorDomain, which can be used to check the errors returned via ara::core::Result.

Kind: class Symbol: PhmErrorDomain Scope: namespace ara::phm Base class: ara::core::ErrorDomain Syntax: class ara::phm::PhmErrorDomain final : public ara::core::ErrorDomain {...}; Unique ID: 0x8000'0000'0602 Header file: #include "ara/phm/phm_error_domain.h"

Defines the error domain for Platform Health Management.

[SWS_PHM_01241]{DRAFT} [

](RS_AP_00119)

Description:

8.4.5.1 PhmErrorDomain::Errc

[SWS_PHM_01245]{DRAFT} [

Kind:	type alias	
Symbol:	Errc	
Scope:	class ara::phm::PhmErrorDomain	
Derived from:	PhmErrc	
Syntax:	<pre>using ara::phm::PhmErrorDomain::Errc = PhmErrc;</pre>	
Header file:	#include "ara/phm/phm_error_domain.h"	
Description:	Alias for the error code value enumeration.	

](*RS_AP_00119*, *RS_AP_00127*)



8.4.5.2 PhmErrorDomain::Exception

[SWS_PHM_01246]{DRAFT} [

Kind:	type alias	
Symbol:	Exception	
Scope:	class ara::phm::PhmErrorDomain	
Derived from:	PhmException	
Syntax:	<pre>using ara::phm::PhmErrorDomain::Exception = PhmException;</pre>	
Header file:	#include "ara/phm/phm_error_domain.h"	
Description:	Alias for the exception base class.	

](*RS_AP_00119*, *RS_AP_00127*)

8.4.5.3 PhmErrorDomain::PhmErrorDomain

[SWS_PHM_01247]{DRAFT} [

Kind:	function
Symbol:	PhmErrorDomain()
Scope:	class ara::phm::PhmErrorDomain
Syntax:	ara::phm::PhmErrorDomain::PhmErrorDomain () noexcept;
Exception Safety:	noexcept
Thread Safety:	no
Header file:	#include "ara/phm/phm_error_domain.h"
Description:	Creates a PhmErrorDomain instance.

](*RS_AP_00119*, *RS_AP_00132*)

8.4.5.4 PhmErrorDomain::Name

[SWS_PHM_01248]{DRAFT} [

Kind:	function	
Symbol:	Name()	
Scope:	class ara::phm::PhmErrorDomain	
Syntax:	<pre>const char* ara::phm::PhmErrorDomain::Name () const noexcept override;</pre>	
Return value:	const char *	"Phm".
Exception Safety:	noexcept	
Thread Safety:	re-entrant	
Header file:	#include "ara/phm/phm_error_domain.h"	
Description:	Returns the name of the error domain.	

](*RS_AP_00119*, *RS_AP_00132*)



8.4.5.5 PhmErrorDomain::Message

[SWS_PHM_01249]{DRAFT} [

Kind:	function				
Symbol:	Message(CodeType errorCode)				
Scope:	class ara::phm::PhmErrorDomain				
Syntax:	<pre>const char* ara::phm::PhmErrorDomain::Message (CodeType errorCode) const noexcept override;</pre>				
Parameters (in):	errorCode	The error code number.			
Return value:	const char *	The message associated with the error code.			
Exception Safety:	noexcept				
Thread Safety:	no				
Header file:	#include "ara/phm/phm_error_domain.h"				
Description:	Returns the message associated with the	error code.			

](*RS_AP_00119*, *RS_AP_00132*)

8.4.5.6 PhmErrorDomain::ThrowAsException

There are no standardized exceptions w.r.t Platform Health Management. But these are added to be in sync with the base class from ara::core().

[SWS_PHM_01250]{DRAFT} [

Kind:	function				
Symbol:	ThrowAsException(const ara::core::Error	Code &errorCode)			
Scope:	class ara::phm::PhmErrorDomain				
Syntax:	<pre>void ara::phm::PhmErrorDomain::ThrowAsException (const ara::core::ErrorCode &errorCode) const override;</pre>				
Parameters (in):	errorCode	The error to throw.			
Return value:	None				
Thread Safety:	no				
Header file:	#include "ara/phm/phm_error_domain.h"				
Description:	Throws the exception associated with the	error code.			

](*RS_AP_00119*)



9 Service Interfaces

Platform Health Management does not specify any AUTOSAR Adaptive Platform Service Interface.



A Mentioned Manifest Elements

For the sake of completeness, this chapter contains a set of class tables representing meta-classes mentioned in the context of this document but which are not contained directly in the scope of describing specific meta-model semantics. For further details, please refer chapters corresponding to below mentioned tables in [12].

Chapter is generated.

Class	AliveSupervision						
Package	M2::AUTOSARTemplates::AdaptivePlatform::PlatformModuleDeployment::PlatformHealthManagement						
Note	Defines an AliveSupervisi	on for one	checkpo	int.			
	Tags:atp.Status=draft						
Base	ARObject, Identifiable, Mi	ultilanguag	geReferra	ble, PhmSupervision, Referrable			
Aggregated by	GlobalSupervision.aliveSu	upervision					
Attribute	Туре	Mult.	Kind	Note			
aliveReference Cycle	TimeValue	01	attr	Time period at which the Alive Supervision mechanism compares the amount of received Alive Indications for the SupervisionCheckpoint against the expectedAlive Indications.			
				Tags:atp.Status=draft			
checkpoint	SupervisionCheckpoint	01	ref	Reference to a checkpoint in the context of Alive Supervision.			
				Tags:atp.Status=draft			
expectedAlive Indications	PositiveInteger	01	attr	Defines the amount of expected Alive Indications of the SupervisionCheckpoint within the aliveReferenceCycle.			
				Tags:atp.Status=draft			
failedReference Cycles	PositiveInteger	01	attr	This attribute defines the acceptable amount of alive ReferenceCycles with incorrect/failed AliveSupervision.			
Tolerance				Tags:atp.Status=draft			
maxMargin	PositiveInteger	01	attr	Defines the amount of Alive Indications of the Supervision Checkpoint that are acceptable to be additional to the expectedAliveIndications within the aliveReferenceCycle.			
				Tags:atp.Status=draft			
minMargin	PositiveInteger	01	attr	Defines the amount of Alive Indications of the Supervision Checkpoint that are acceptable to be missing to the expectedAliveIndications within the aliveReferenceCycle.			
				Tags:atp.Status=draft			
terminating Checkpoint	SupervisionCheckpoint	01	ref	Reference to the SupervisionCheckpoint which is defined as the terminating checkpoint of this AliveSupervision.			
				Tags:atp.Status=draft			
terminating Checkpoint TimeoutUntil	TimeValue	01	attr	Defines the time a process shall terminate after it has announced its start of termination by reporting terminatingCheckpoint.			
Termination				Tags:atp.Status=draft			

Table A.1: AliveSupervision



Class	DeadlineSupervision					
Package	M2::AUTOSARTemplates	:Adaptive	Platform::	PlatformModuleDeployment::PlatformHealthManagement		
Note	Defines an DeadlineSupe	rvision for	one trans	ition.		
	Tags:atp.Status=draft					
Base	ARObject, Identifiable, M	ultilanguag	geReferra	ble, PhmSupervision, Referrable		
Aggregated by	GlobalSupervision.deadlin	neSupervi	sion			
Attribute	Type Mult. Kind Note					
maxDeadline	TimeValue	01	attr	Defines the longest time span before which the deadline is considered to be met for transition.		
				Tags:atp.Status=draft		
minDeadline	TimeValue	01	attr	Defines the shortest time span after which the deadline is considered to be met for transition.		
				Tags:atp.Status=draft		
transition	CheckpointTransition	01	ref	Reference to the transition in the context of a Deadline Supervision.		
				Tags:atp.Status=draft		

Table A.2: DeadlineSupervision

Class	GlobalSupervision					
Package	M2::AUTOSARTemplates::AdaptivePlatform::PlatformModuleDeployment::PlatformHealthManagement					
Note	This element defines a c in order to provide an ag			ervisions, DeadlineSupervisions, and LogicalSupervisions n state.		
	Tags:atp.Status=draft					
Base	ARObject, Identifiable, N	lultilanguag	geReferra	ble, Referrable		
Aggregated by	PlatformHealthManagem	entContrib	ution.glob	alSupervision		
Attribute	Туре	Mult.	Kind	Note		
alive Supervision	AliveSupervision	*	aggr	Collection of AliveSupervisions in the context of this GlobalSupervision.		
				Tags:atp.Status=draft		
deadline Supervision	DeadlineSupervision	*	aggr	Collection of DeadlineSupervisions in the context of this GlobalSupervision.		
				Tags:atp.Status=draft		
logical Supervision	LogicalSupervision	*	aggr	Collection of LogicalSupervisions in the context of this GlobalSupervision.		
				Tags:atp.Status=draft		
noCheckpoint	NoCheckpoint	*	aggr	Definition of No Checkpoint Supervision.		
Supervision	Supervision			Tags:atp.Status=draft		
noSupervision	NoSupervision	*	aggr	Collection of NoSupervisions in the context of this Global Supervision.		
				Tags:atp.Status=draft		
supervision Mode	SupervisionMode	*	aggr	Collection of SupervisionModes in the context of this GlobalSupervision.		
				Stereotypes: atpSplitable Tags: atp.Splitkey=supervisionMode.shortName atp.Status=draft		

 \bigtriangledown



/	\
L	

Class	GlobalSupervision				
transition	CheckpointTransition	*	aggr	Collection of CheckpointTransitions in the context of this GlobalSupervision. Tags:atp.Status=draft	

Table A.3: GlobalSupervision

Class	HealthChannel (abstract)					
Package	M2::AUTOSARTemplates:	:Adaptive	Platform::	PlatformModuleDeployment::PlatformHealthManagement		
Note	This element defines the s	source of a	a health c	hannel.		
	Tags:atp.Status=draft					
Base	ARObject, Identifiable, Mu	ultilanguag	geReferra	ble, Referrable		
Subclasses	HealthChannelExternalStatus, HealthChannelSupervision					
Aggregated by	PlatformHealthManageme	entContrib	ution.heal	thChannel		
Attribute	Type Mult. Kind Note					
recovery	RecoveryNotification	RecoveryNotification 01 ref Defines the RecoveryNotification for this HealthChannel.				
Notification				Tags:atp.Status=draft		

Table A.4: HealthChannel

Class	HealthChannelExternalStatus					
Package	M2::AUTOSARTemplates:	:Adaptive	Platform::	PlatformModuleDeployment::PlatformHealthManagement		
Note	This element defines a he	alth chanr	nel repres	enting the status of an external health channel.		
	Tags:atp.Status=draft					
Base	ARObject, HealthChannel	, Identifia	ble, Multil	anguageReferrable, Referrable		
Aggregated by	PlatformHealthManagementContribution.healthChannel					
Attribute	Type Mult. Kind Note					
healthChannel	RPortPrototype	01	iref	Refers to the HealthChannel.		
				Stereotypes: atpUriDef Tags:atp.Status=draft InstanceRef implemented by:RPortPrototypeIn ExecutableInstanceRef		
notifiedStatus	HealthChannelExternal ReportedStatus	*	aggr	This is a list of statuses which shall trigger the Recovery Notification of this HealthChannelExternalStatus.		
	Tags:atp.Status=draft					
process	Process	01	ref	Defines the Process this Health Channel shall be monitored.		
				Tags:atp.Status=draft		

Table A.5: HealthChannelExternalStatus

Class	ImplementationProps (abstract)
Package	M2::AUTOSARTemplates::CommonStructure::Implementation
Note	Defines a symbol to be used as (depending on the concrete case) either a complete replacement or a prefix when generating code artifacts.
Base	ARObject, Referrable

 ∇



Δ						
Class	ImplementationProps (ImplementationProps (abstract)				
Subclasses	BswSchedulerNamePref SymbolicNameProps	BswSchedulerNamePrefix, ExecutableEntityActivationReason, SectionNamePrefix, SymbolProps, SymbolicNameProps				
Attribute	Туре	Type Mult. Kind Note				
symbol	Cldentifier	01	attr	The symbol to be used as (depending on the concrete case) either a complete replacement or a prefix.		

Table A.6: ImplementationProps

Class	LogicalSupervision					
Package	M2::AUTOSARTemplates	:Adaptive	Platform::	PlatformModuleDeployment::PlatformHealthManagement		
Note	Defines a LogicalSupervis	sion graph	consistin	g of transitions, initial- and final checkpoints.		
	Tags:atp.Status=draft					
Base	ARObject, Identifiable, M	ultilanguag	geReferra	ble, PhmSupervision, Referrable		
Aggregated by	GlobalSupervision.logical	Supervisio	on			
Attribute	Type Mult. Kind Note					
finalCheckpoint	SupervisionCheckpoint	*	ref	Reference to the final Checkpoint(s) for this Logical Supervision.		
				Tags: atp.Status=draft xml.sequenceOffset=20		
initialCheckpoint	SupervisionCheckpoint	*	ref	Reference to the initial Checkpoint(s) for this Logical Supervision.		
				Tags: atp.Status=draft xml.sequenceOffset=10		
transition	CheckpointTransition	*	ref	Reference to the transitions for this LogicalSupervision.		
				Tags: atp.Status=draft xml.sequenceOffset=30		

Table A.7: LogicalSupervision

Class	NoCheckpointSupervision						
Package	M2::AUTOSARTemplates	::Adaptive	Platform::	PlatformModuleDeployment::PlatformHealthManagement			
Note	Defines explicitly that NO supervision shall be applied for a set of SupervisionCheckpoints.						
	Tags:atp.Status=draft	Tags:atp.Status=draft					
Base	ARObject, Identifiable, MultilanguageReferrable, PhmSupervision, Referrable						
Aggregated by	GlobalSupervision.noChe	ckpointSu	pervision				
Attribute	Туре	Mult.	Kind	Note			
checkpoint	SupervisionCheckpoint	*	ref	Reference to the set of SupervisionCheckpoints which shall not be considered for any kind of supervision.			
				Tags:atp.Status=draft			

Table A.8: NoCheckpointSupervision



Class	NoSupervision					
Package	M2::AUTOSARTemplates:	:Adaptive	Platform::	PlatformModuleDeployment::PlatformHealthManagement		
Note	Defines explicitly that NO	supervisio	on shall be	e applied for a specific Supervised Entity instance.		
	Tags:atp.Status=draft					
Base	ARObject, Identifiable, MultilanguageReferrable, PhmSupervision, Referrable					
Aggregated by	GlobalSupervision.noSup	GlobalSupervision.noSupervision				
Attribute	Туре	Mult.	Kind	Note		
process	Process	01	ref	Reference to the Process this NoSupervision applies to.		
				Tags:atp.Status=draft		
targetPhm Supervised	RPortPrototype	01	iref	Instance reference to the RPortPrototype which represents the Supervised Entity instance.		
Entity				Stereotypes: atpUriDef Tags:atp.Status=draft InstanceRef implemented by:RPortPrototypeIn ExecutableInstanceRef		

Table A.9: NoSupervision

Class	PhmCheckpoint						
Package	M2::AUTOSARTemplates:	:Adaptive	Platform::	ApplicationDesign::PortInterface			
Note	This meta-class provides the ability to implement a checkpoint for interaction with the Platform Health Management Supervised Entity.						
	Tags:atp.Status=draft						
Base	ARObject, AtpFeature, Identifiable, MultilanguageReferrable, Referrable						
Aggregated by	AtpClassifier.atpFeature,	PhmSupe	rvisedEnt	ityInterface.checkpoint			
Attribute	Туре	Mult.	Kind	Note			
checkpointId	PositiveInteger	01	attr	Defines the numeric value which is used to indicate the reporting of this Checkpoint to the Phm.			
				Tags:atp.Status=draft			

Table A.10: PhmCheckpoint

Class	PhmHealthChannelInterface						
Package	M2::AUTOSARTemplates	::Adaptive	Platform::	ApplicationDesign::PortInterface			
Note	This meta-class provides the ability to implement a PortInterface for interaction with the Platform Health Management Health Channel.						
	Tags: atp.Status=draft atp.recommendedPackage=PlatformHealthManagementInterfaces						
Base	ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, PlatformHealthManagementInterface, Port Interface, Referrable						
Aggregated by	ARPackage.element						
Attribute	Туре	Mult.	Kind	Note			
status	PhmHealthChannel * aggr Defines the possible set of status information a the health channel.						
				Tags:atp.Status=draft			

Table A.11: PhmHealthChannelInterface



Class	PhmHealthChannelStatus						
Package	M2::AUTOSARTemplates:	:Adaptive	Platform::	ApplicationDesign::PortInterface			
Note	The PhmHealthChannelS	tatus spec	ifies one	possible status of the health channel.			
	Tags:atp.Status=draft						
Base	ARObject, AtpFeature, Ide	entifiable,	Multilang	uageReferrable, Referrable			
Aggregated by	AtpClassifier.atpFeature, PhmHealthChannelInterface.status						
Attribute	Туре	Mult.	Kind	Note			
statusId	PositiveInteger	01	attr	Defines the numeric value which is used to indicate the indication of this status the Phm.			
				Tags:atp.Status=draft			
triggers Recovery Notification	Boolean	01	attr	Defines whether this PhmHealthChannelStatus shall cause the Phm to trigger the Health Channel recovery notification.			
				True: Indicates unhealthy state. Phm to trigger the Health Channel recovery notification when the Health channel status changes to this state.			
				False: Indicates healthy state. Phm not to trigger the Health Channel recovery notification when the Health channel status changes to this state.			
				Tags:atp.Status=draft			

Table A.12: PhmHealthChannelStatus

Class	PhmSupervisedEntityInt	PhmSupervisedEntityInterface					
Package	M2::AUTOSARTemplates:	:Adaptive	Platform::	ApplicationDesign::PortInterface			
Note	This meta-class provides the ability to implement a PortInterface for interaction with the Platform Health Management Supervised Entity.						
	Tags: atp.Status=draft atp.recommendedPackage=PlatformHealthManagementInterfaces						
Base	ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, PlatformHealthManagementInterface, Port Interface, Referrable						
Aggregated by	ARPackage.element						
Attribute	Туре	Mult.	Kind	Note			
checkpoint	PhmCheckpoint	*	aggr	Defines the set of checkpoints which can be reported on this supervised entity.			
				Tags:atp.Status=draft			

Table A.13: PhmSupervisedEntityInterface

Class	PortInterface (abstract)
Package	M2::AUTOSARTemplates::SWComponentTemplate::PortInterface
Note	Abstract base class for an interface that is either provided or required by a port of a software component.
Base	ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable
Subclasses	AbstractRawDataStreamInterface, AbstractSynchronizedTimeBaseInterface, ClientServerInterface, CryptoInterface, DataInterface, DiagnosticPortInterface, FirewallStateSwitchInterface, LogAndTrace Interface, ModeSwitchInterface, PersistencyInterface, PlatformHealthManagementInterface, Security EventReportInterface, ServiceInterface, StateManagementPortInterface, TriggerInterface
Aggregated by	ARPackage.element

 \bigtriangledown



			\triangle	
Class	PortInterface (abstra	act)		
Attribute	Туре	Mult.	Kind	Note
namespace (ordered)	SymbolProps	*	aggr	This represents the SymbolProps used for the definition of a hierarchical namespace applicable for the generation of code artifacts out of the definition of a ServiceInterface.
				Stereotypes: atpSplitable Tags: atp.Splitkey=namespace.shortName atp.Status=draft

Table A.14: PortInterface

Class	Process							
Package	M2::AUTOSARTemplates::AdaptivePlatform::ExecutionManifest							
Note	This meta-class provides information required to execute the referenced executable.							
	Tags: atp.Status=draft atp.recommendedPackag	e=Process	ses					
Base				ntext, AtpClassifier, CollectableElement, Identifiable, ont, Referrable, UploadablePackageElement				
Aggregated by	ARPackage.element							
Attribute	Туре	Mult.	Kind	Note				
design	ProcessDesign	01	ref	This reference represents the identification of the design-time representation for the Process that owns the reference.				
				Tags:atp.Status=draft				
executable	Executable	01	ref	Reference to executable that is executed in the process.				
				Stereotypes: atpUriDef Tags:atp.Status=draft				
functionCluster Affiliation	String	01	attr	This attribute specifies which functional cluster the process is affiliated with.				
				Tags:atp.Status=draft				
numberOf RestartAttempts	PositiveInteger	01	attr	This attribute defines how often a process shall be restarted if the start fails.				
				numberOfRestartAttempts = "0" OR Attribute not existing, start once				
				numberOfRestartAttempts = "1", start a second time				
				Tags:atp.Status=draft				
preMapping	Boolean	01	attr	This attribute describes whether the executable is preloaded into the memory.				
				Tags:atp.Status=draft				
processState	ModeDeclarationGroup	01	aggr	Set of Process States that are defined for the process.				
Machine	Prototype			Tags:atp.Status=draft				
securityEvent	SecurityEventDefinition	*	ref	The reference identifies the collection of SecurityEvents that can be reported by the enclosing SoftwareCluster.				
				Stereotypes: atpSplitable; atpUriDef Tags: atp.Splitkey=securityEvent atp.Status=draft				
stateDependent	StateDependentStartup	*	aggr	Applicable startup configurations.				
StartupConfig	Config			Tags:atp.Status=draft				

Table A.15: Process



Class	ProcessExecutionError				
Package	M2::AUTOSARTemplates	::Adaptive	Platform::	ExecutionManifest	
Note	This meta-class has the ability to describe the value of a execution error along with a documentation of its semantics. Tags: atp.Status=draft atp.recommendedPackage=ProcessExecutionErrors				
Base	ARElement, ARObject, CollectableElement, Identifiable, MultilanguageReferrable, Packageable Element, Referrable, UploadablePackageElement				
Aggregated by	ARPackage.element				
Attribute	Туре	Mult.	Kind	Note	
executionError	PositiveInteger	01	attr	This attribute defines the numeric value which Execution Management and Platform Health Management reports to State Management if the Process terminates unexpectedly or violates its supervision. It shall give further error information for error recovery.	
				Tags:atp.Status=draft	

Class	RecoveryNotification				
Package	M2::AUTOSARTemplates	::Adaptive	Platform::	PlatformModuleDeployment::PlatformHealthManagement	
Note	This meta-class represents a PHM action that can trigger a recovery operation inside a piece of State Management software. Tags: atp.Status=draft atp.recommendedPackage=RecoveryNotifications				
Base	ARElement, ARObject, CollectableElement, Identifiable, MultilanguageReferrable, Packageable Element, Referrable, UploadablePackageElement				
Aggregated by	ARPackage.element				
Attribute	Туре	Mult.	Kind	Note	
recovery Notification Timeout	TimeValue	01	attr	The maximum acceptable amount of time (in seconds), Platform Health Management waits for an acknowledgement by State Management after sending the notification.	
				Tags:atp.Status=draft	

Table A.17: RecoveryNotification

Class	RecoveryNotificationToPPortPrototypeMapping					
Package	M2::AUTOSARTemplates::AdaptivePlatform::PlatformModuleDeployment::PlatformHealthManagement					
Note	This meta-class represents the ability to associate a RecoveryNotification to a PPortPrototype while also being able to identify the respective Process in which the actual recovery executes.					
	Tags: atp.Status=draft atp.recommendedPackage=RecoveryNotificationMappings					
Base	ARElement, ARObject, CollectableElement, Identifiable, MultilanguageReferrable, Packageable Element, Referrable, UploadablePackageElement					
Aggregated by	ARPackage.element					
Attribute	Type Mult. Kind Note					



			\triangle	
Class	RecoveryNotificationTo	PPortProt	otypeMa	pping
process	Process	01	ref	Reference to the process which represents the State Management instance that the recovery notification shall be applied to.
				Tags:atp.Status=draft
recoveryAction	PPortPrototype	01	iref	This reference identifies the PortPrototype to be addressed as part of a PHM recovery.
				Tags:atp.Status=draft InstanceRef implemented by:PPortPrototypeIn ExecutableInstanceRef
recovery Notification	RecoveryNotification	01	ref	This reference identifies the applicable Recovery Notification to be mapped.
				Tags:atp.Status=draft

Table A.18: RecoveryNotificationToPPortPrototypeMapping

Class	Referrable (abstract)						
Package	M2::AUTOSARTemplates::GenericStructure::GeneralTemplateClasses::Identifiable						
Note	Instances of this class car	n be referr	ed to by t	neir identifier (while adhering to namespace borders).			
Base	ARObject						
Subclasses	AtpDefinition, BswDistinguishedPartition, BswModuleCallPoint, BswModuleClientServerEntry, Bsw VariableAccess, CouplingPortTrafficClassAssignment, CppImplementationDataTypeContextTarget, DiagnosticEnvModeElement, EthernetPriorityRegeneration, ExclusiveAreaNestingOrder, HwDescription Entity, ImplementationProps, ModeTransition, MultilanguageReferrable, NmNetworkHandle, Pnc MappingIdent, SingleLanguageReferrable, SoConIPduIdentifier, SocketConnectionBundle, Someip RequiredEventGroup, TimeSyncServerConfiguration, TpConnectionIdent						
Attribute	Туре	Mult.	Kind	Note			
shortName	Identifier	1	attr	This specifies an identifying shortName for the object. It needs to be unique within its context and is intended for humans but even more for technical reference.			
				Stereotypes: atpldentityContributor Tags: xml.enforceMinMultiplicity=true xml.sequenceOffset=-100			
shortName Fragment	ShortNameFragment	*	aggr	This specifies how the Referrable.shortName is composed of several shortNameFragments.			
				Tags:xml.sequenceOffset=-90			

Table A.19: Referrable

Class	StartupConfig	StartupConfig				
Package	M2::AUTOSARTemplates::	Adaptive	Platform::	ExecutionManifest		
Note	This meta-class represents	s a reusal	ble startur	o configuration for processes		
	Tags: atp.Status=draft atp.recommendedPackage=StartupConfigs					
Base	ARElement, ARObject, CollectableElement, Identifiable, MultilanguageReferrable, Packageable Element, Referrable					
Aggregated by	ARPackage.element					
Attribute	Type Mult. Kind Note					
	· ·		∇			



			\bigtriangleup	
Class	StartupConfig			
environment Variable	TagWithOptionalValue	*	aggr	This aggregation represents the collection of environment variables that shall be added to the respective Process's environment prior to launch.
				Tags:atp.Status=draft
executionError	ProcessExecutionError	01	ref	this reference is used to identify the applicable execution error
				Tags:atp.Status=draft
process Argument (ordered)	ProcessArgument	*	aggr	This aggregation represents the collection of command-line arguments applicable to the enclosing StartupConfig.
				Tags:atp.Status=draft
scheduling Policy	String	01	attr	This attribute represents the ability to define the scheduling policy for the initial thread of the application.
				Tags:atp.Status=draft
scheduling Priority	Integer	01	attr	This is the scheduling priority requested by the application itself.
				Tags:atp.Status=draft
termination Behavior	TerminationBehavior Enum	01	attr	This attribute defines the termination behavior of the Process.
				Tags:atp.Status=draft
timeout	EnterExitTimeout	01	aggr	This aggregation can be used to specify the timeouts for launching and terminating the process depending on the StartupConfig.
				Tags:atp.Status=draft

Table A.20: StartupConfig

Class	SupervisionCheckpoint								
Package	M2::AUTOSARTemplates::AdaptivePlatform::PlatformModuleDeployment::PlatformHealthManagement								
Note	This element contains Health Management.	This element contains an instance reference to a RPortPrototype representing a checkpoint for Platform Health Management.							
	Tags:atp.Status=draft								
Base	ARObject, Identifiable,	, Multilangua	geReferra	ble, Referrable					
Aggregated by	PlatformHealthManage	ementContrib	ution.che	ckpoint					
Attribute	Туре	Mult.	Kind	Note					
checkpointId	PositiveInteger	01	attr	Defines the numeric value which is used to identify the reporting of this SupervisionCheckpoint to the Phm.					
				Tags:atp.Status=draft					
phmCheckpoint	PhmCheckpoint	01	iref	Instance reference to the PhmCheckpoint defined in the context of a PortInterface.					
				Stereotypes: atpUriDef Tags:atp.Status=draft InstanceRef implemented by:PhmCheckpointIn ExecutableInstanceRef					
process	Process	01	ref	Reference to the Process this checkoint shall be monitored.					
				Tags:atp.Status=draft					

Table A.21: SupervisionCheckpoint



Class	SupervisionMode					
Package	M2::AUTOSARTemplates::AdaptivePlatform::PlatformModuleDeployment::PlatformHealthManagement					
Note	This element defines a Su	pervision	Mode.			
	Tags:atp.Status=draft					
Base	ARObject, Identifiable, M	ultilanguag	geReferra	ble, Referrable		
Aggregated by	GlobalSupervision.superv	isionMode)			
Attribute	Туре	Mult.	Kind	Note		
active Supervision	PhmSupervision	*	ref	The reference defines which PhmSupervisions shall be active in this specific SupervisionMode.		
expired Supervision Tolerance	TimeValue	01	attr	Tags:atp.Status=draft Defines in this SupervisionMode the acceptable amount of time with EXPIRED supervision status of the enclosing GlobalSupervision before it is considered STOPPED.		
				Tags:atp.Status=draft		
modeCondition	SupervisionMode Condition	01	ref	Reference to SupervisionModeCondition (Condition under which the configuration made under this SupervisionMode are to be applied).		
1				Tags:atp.Status=draft		

Table A.22: SupervisionMode

Class	SwComponentType (abstract)							
Package	M2::AUTOSARTemplates::SWComponentTemplate::Components							
Note	Base class for AUTOSAR	software	compone	nts.				
Base	ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable							
Subclasses	AdaptiveApplicationSwCo ParameterSwComponent		ype, Ator	nicSwComponentType, CompositionSwComponentType,				
Aggregated by	ARPackage.element							
Attribute	Туре	Mult.	Kind	Note				
port	PortPrototype	*	aggr	The PortPrototypes through which this SwComponent Type can communicate.				
				The aggregation of PortPrototype is subject to variability with the purpose to support the conditional existence of PortPrototypes.				
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=port.shortName, port.variationPoint.short Label vh.latestBindingTime=preCompileTime				
portGroup	PortGroup	*	aggr	A port group being part of this component.				
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=portGroup.shortName, portGroup.variation Point.shortLabel vh.latestBindingTime=preCompileTime				

 \bigtriangledown



			\triangle	
Class	SwComponentType (a	abstract)		
swComponent Documentation	SwComponent Documentation	01	aggr	This adds a documentation to the SwComponentType. Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=swComponentDocumentation, sw ComponentDocumentation.variationPoint.shortLabel vh.latestBindingTime=preCompileTime xml.sequenceOffset=-10

Table A.23: SwComponentType

Class	SymbolProps	SymbolProps			
Package	M2::AUTOSARTemplates:	:SWComp	onentTer	nplate::Components	
Note	This meta-class represent	s the abili	ty to conti	ibute a part of a namespace.	
Base	ARObject, Implementation	ARObject, ImplementationProps, Referrable			
Aggregated by	CppImplementationDataTy	Allocator.namespace, ApApplicationErrorDomain.namespace, <i>AtomicSwComponentType</i> .symbolProps, <i>CppImplementationDataType</i> .namespace, ImplementationDataType.symbolProps, <i>PortInterface</i> . namespace, SecurityEventDefinition.eventSymbolName			
Attribute	Туре	Type Mult. Kind Note			
-	-	-	_	-	

Table A.24: SymbolProps



B Interfaces to other Functional Clusters (informative)

B.1 Overview

AUTOSAR decided not to standardize interfaces which are exclusively used between Functional Clusters (on platform-level only), to allow efficient implementations, which might depend e.g. on the used Operating System.

This chapter provides informative guidelines how the interaction between Functional Clusters looks like, by clustering the relevant requirements of this document to describe Inter-Functional Cluster (IFC) interfaces. In addition, the standardized public interfaces which are accessible by user space applications (see chapters 8 and 9) can also be used for interaction between Functional Clusters.

The goal is to provide a clear understanding of Functional Cluster boundaries and interaction, without specifying syntactical details. This ensures compatibility between documents specifying different Functional Clusters and supports parallel implementation of different Functional Clusters. Details of the interfaces are up to the platform provider. Additional interfaces, parameters and return values can be added.



C Platform Extension API (normative)

The focus of the APIs in this section are for OEM-specific platform extensions. The abstraction of the interfaces is lower which could lead to a higher machine dependency.

C.1 WatchdogInterface

This chapter lists the required APIs for PHM to interact with the hardware watchdog.

C.1.1 WatchdogInterface::AliveNotification

Kind:	function
Symbol:	AliveNotification()
Syntax:	<pre>void AliveNotification ();</pre>
Return value:	None
Description:	Called cyclically by PHM in configurable cycle time. Note: This time might differ from the cycle time of triggering the "real" hardware watchdog.
	If PHM does not report aliveness in configured time, WatchdogInterface shall initiate watchdog reaction.

Table C.1: WatchdogInterface::AliveNotification

C.1.2 WatchdogInterface::FireWatchdogReaction

Kind:	function
Symbol:	FireWatchdogReaction()
Syntax:	<pre>void FireWatchdogReaction ();</pre>
Return value:	None
Description:	Interface to fire an error reaction of the hardware watchdog.

Table C.2: WatchdogInterface::FireWatchdogReaction



Specification of Platform Health Management AUTOSAR AP R22-11

D Not applicable requirements

[SWS_PHM_NA]{DRAFT} [These requirements are not applicable as they are not within the scope of this release.] (*RS_PHM_00108, RS_PHM_00109*)



E Change History

Please note that the lists in this chapter also include specification items that have been removed from the specification in a later version. These constraints and specification items do not appear as hyperlinks in the document.

E.1 Change History of this document according to AUTOSAR Release R21-11

E.1.1 Added Traceables in R21-11

Number	Heading
[SWS_PHM_00106]	Recovery Action for Failures in Execution or State Management
[SWS_PHM_00201]	
[SWS_PHM_00202]	
[SWS_PHM_00203]	
[SWS_PHM_00204]	
[SWS_PHM_00205]	
[SWS_PHM_00206]	
[SWS_PHM_00207]	
[SWS_PHM_00208]	
[SWS_PHM_00209]	
[SWS_PHM_00210]	
[SWS_PHM_00211]	
[SWS_PHM_00212]	
[SWS_PHM_00213]	
[SWS_PHM_00214]	
[SWS_PHM_00215]	
[SWS_PHM_00216]	
[SWS_PHM_00217]	
[SWS_PHM_00218]	
[SWS_PHM_00219]	
[SWS_PHM_00220]	
[SWS_PHM_00221]	
[SWS_PHM_00222]	
[SWS_PHM_00223]	
[SWS_PHM_00224]	
[SWS_PHM_00225]	
[SWS_PHM_00226]	



1	
<i>L</i>	

Number	Heading
[SWS_PHM_00227]	
[SWS_PHM_00228]	
[SWS_PHM_00229]	
[SWS_PHM_00230]	
[SWS_PHM_00231]	
[SWS_PHM_00232]	
[SWS_PHM_00233]	
[SWS_PHM_00234]	
[SWS_PHM_00235]	
[SWS_PHM_00236]	
[SWS_PHM_00237]	
[SWS_PHM_00238]	
[SWS_PHM_00239]	
[SWS_PHM_00240]	Supervisions on termination of process
[SWS_PHM_00241]	Supervisions on Start of Process
[SWS_PHM_00242]	Supervisions on Restart of Process
[SWS_PHM_00243]	Continuation of Supervisions
[SWS_PHM_00244]	NoSupervision on Start of Process
[SWS_PHM_00245]	Continuation of NoSupervision (Supervision Exclusion)
[SWS_PHM_01240]	
[SWS_PHM_01241]	

Table E.1: Added Traceables in R21-11

E.1.2 Changed Traceables in R21-11

Number	Heading
[SWS_PHM_00101]	Notification to State Management due to Supervision failure
[SWS_PHM_00104]	Reaction on timeout for notification to State Management
[SWS_PHM_00105]	Recovery Action for Failures in Execution Management or State Management
[SWS_PHM_01005]	Namespace of generated header files for a Supervised Entity
[SWS_PHM_01113]	Namespace of generated header files for a Health Channel
[SWS_PHM_01127]	
[SWS_PHM_01128]	
[SWS_PHM_01132]	
[SWS_PHM_01136]	

 ∇



1	$^{\prime}$
L	

Number	Heading
[SWS_PHM_01137]	
[SWS_PHM_01142]	
[SWS_PHM_01143]	
[SWS_PHM_01146]	
[SWS_PHM_01149]	
[SWS_PHM_01150]	
[SWS_PHM_01151]	
[SWS_PHM_01152]	
[SWS_PHM_01212]	
[SWS_PHM_01213]	
[SWS_PHM_01214]	
[SWS_PHM_01215]	
[SWS_PHM_01222]	
[SWS_PHM_01223]	
[SWS_PHM_01224]	
[SWS_PHM_01225]	
[SWS_PHM_01227]	Consistency of Checkpoint Identifier
[SWS_PHM_01228]	Reporting of undefined Checkpoint Identifier
[SWS_PHM_01229]	Restricted access on reporting of Checkpoints
[SWS_PHM_01233]	
[SWS_PHM_01234]	
[SWS_PHM_01235]	
[SWS_PHM_01236]	
[SWS_PHM_01238]	
[SWS_PHM_01328]	Consistency of Health Status Identifier
[SWS_PHM_01329]	Reporting of undefined Health Status Identifier
[SWS_PHM_01330]	Restricted access on reporting of Health Status

Table E.2: Chang	ed Traceables in R21-11
------------------	-------------------------

E.1.3 Deleted Traceables in R21-11

Number	Heading
[SWS_PHM_00103]	Timeout Monitoring for notification to State Management
[SWS_PHM_00321]	Underlying data types
[SWS_PHM_00458]	Creation of PHM service interface
[SWS_PHM_01010]	PHM Class

 \bigtriangledown



Specification of Platform Health Management AUTOSAR AP R22-11

\triangle

Number	Heading
[SWS_PHM_01013]	Header file existence
[SWS_PHM_01018]	Header file namespace
[SWS_PHM_01101]	Folder structure for header files
[SWS_PHM_01116]	Definition of an identifier for a Supervised Entity
[SWS_PHM_01120]	Definition of an identifier for a Health Channel
[SWS_PHM_01121]	Definition of an identifier for a Health Channel Prototype
[SWS_PHM_01124]	Copy constructor for the use by SupervisedEntity and by HealthChannel
[SWS_PHM_01125]	The Platform Health Management shall provide a protected method ReportCheckpoint, provided by PHM
[SWS_PHM_01126]	The Platform Health Management shall provide a protected method ReportHealthStatus, provided by PHM
[SWS_PHM_01131]	Identifier Identifier Class Template
[SWS_PHM_01133]	Definition of an identifier for a Supervised Entity Prototype
[SWS_PHM_01134]	
[SWS_PHM_01135]	
[SWS_PHM_01160]	Restricted access on GetLocalSupervisionsStatus
[SWS_PHM_01161]	Restricted access on GetGlobalSupervisionStatus

Table E.3: Deleted Traceables in R21-11

E.2 Change History of this document according to AUTOSAR Release R22-11

E.2.1 Added Traceables in R22-11

Number	Heading
[SWS_PHM_01242]	
[SWS_PHM_01243]	
[SWS_PHM_01244]	
[SWS_PHM_01245]	
[SWS_PHM_01246]	
[SWS_PHM_01247]	
[SWS_PHM_01248]	
[SWS_PHM_01249]	
[SWS_PHM_01250]	
[SWS_PHM_01251]	
[SWS_PHM_01252]	Handling of Watchdog after Startup

 ∇



\triangle

Number	Heading
[SWS_PHM_01253]	Termination of Supervisions at SIGTERM
[SWS_PHM_01254]	Global Supervision Status at SIGTERM
[SWS_PHM_01331]	Start of Alive Supervision
[SWS_PHM_01332]	Checkpoints corresponding to Alive Supervision before kRunning
[SWS_PHM_01333]	Termination of Supervised Processes
[SWS_PHM_01334]	Time Source for Supervisions
[SWS_PHM_01335]	Stopping of Alive Supervision for Self-Terminating Process
[SWS_PHM_01336]	Timeout monitoring for termination of Self-Terminating Process
[SWS_PHM_01337]	Unintended termination of Self-Terminating Process
[SWS_PHM_01338]	Avoid redundant Monitoring of Termination for Self-Terminating Process
[SWS_PHM_01339]	Reporting access violation w.r.t. checkpoints to IdsM
[SWS_PHM_01341]	Reporting of Supervision Checkpoint mapped to No Supervision provision
[SWS_PHM_01342]	Tracking of Elementary Supervision Status
[SWS_PHM_01343]	States of state machine for Elementary Supervision Status
[SWS_PHM_01344]	Initialization of state machine for Elementary Supervision Status
[SWS_PHM_01345]	Keep Elementary Supervision Status ROK
[SWS_PHM_01346]	Switch Elementary Supervision Status from KOK to KEXPIRED
[SWS_PHM_01347]	Switch Elementary Supervision Status from KOK to KFAILED
[SWS_PHM_01348]	Keep Elementary Supervision Status kFAILED
[SWS_PHM_01349]	Switch Elementary Supervision Status from kFAILED to kOK
[SWS_PHM_01350]	Switch Elementary Supervision Status from kFAILED to kEXPIRED
[SWS_PHM_01351]	Switch Elementary Supervision Status from KOK to KDEACTIVATED
[SWS_PHM_01352]	Switch Elementary Supervision Status from kFAILED to kDEACTIVATED
[SWS_PHM_01353]	Keep Elementary Supervision Status kDEACTIVATED
[SWS_PHM_01354]	Switch Elementary Supervision Status from kDEACTIVATED to KOK
[SWS_PHM_01355]	Switch Elementary Supervision Status from KEXPIRED to KDEACTIVATED
[SWS_PHM_01356]	Keep Elementary Supervision Status kEXPIRED
[SWS_PHM_01357]	Switch Elementary Supervision Status from kDEACTIVATED to kEXPIRED
[SWS_PHM_01358]	

Table E.4: Added Traceables in R22-11



E.2.2 Changed Traceables in R22-11

Number	Heading
[SWS_PHM_00101]	Notification to State Management due to Supervision failure
[SWS_PHM_00105]	Recovery Action for Failures in Execution Management or State Management
[SWS_PHM_00106]	Recovery Action for Failures in Execution or State Management
[SWS_PHM_00216]	States of the state machine for Global Supervision Status
[SWS_PHM_00217]	One Global Supervision Status per Global Supervision
[SWS_PHM_00218]	Initialization of Global Supervision Status
[SWS_PHM_00220]	Switch Global Supervision Status from kDEACTIVATED to KOK
[SWS_PHM_00221]	Keep Global Supervision Status KOK
[SWS_PHM_00222]	Switch Global Supervision Status from KOK to KDEACTIVATED
[SWS_PHM_00223]	Switch Global Supervision Status from KOK to KFAILED
[SWS_PHM_00224]	Switch Global Supervision Status from KOK to KEXPIRED for SM/EM/OS supervision
[SWS_PHM_00225]	Switch Global Supervision Status from KOK to KSTOPPED
[SWS_PHM_00226]	Keep Global Supervision Status kFAILED
[SWS_PHM_00227]	Switch Global Supervision Status from kFAILED to kOK
[SWS_PHM_00228]	Switch Global Supervision Status from kFAILED to KEXPIRED
[SWS_PHM_00229]	Switch Global Supervision Status from kFAILED to kSTOPPED
[SWS_PHM_00230]	Keep Global Supervision Status kEXPIRED
[SWS_PHM_00231]	Switch Global Supervision Status from kexpired to kstopped
[SWS_PHM_00232]	Keep Global Supervision Status kSTOPPED
[SWS_PHM_00233]	Switch Global Supervision Status from kexpired to kok
[SWS_PHM_00234]	Switch Global Supervision Status from kexpired to kFAILED
[SWS_PHM_00237]	Switch Global Supervision Status from kDEACTIVATED to kFAILED
[SWS_PHM_00238]	Switch Global Supervision Status from kDEACTIVATED to kEXPIRED
[SWS_PHM_00239]	Switch Global Supervision Status from kDEACTIVATED to kSTOPPED
[SWS_PHM_00424]	Enumeration for Supervised Entity
[SWS_PHM_00457]	
[SWS_PHM_01123]	
[SWS_PHM_01137]	
[SWS_PHM_01229]	Restricted access on reporting of Checkpoints
[SWS_PHM_01240]	
[SWS_PHM_01241]	

Table E.5: Changed Traceables in R22-11



E.2.3 Deleted Traceables in R22-11

Number	Heading
[SWS_PHM_00201]	
[SWS_PHM_00202]	
[SWS_PHM_00203]	
[SWS_PHM_00204]	
[SWS_PHM_00205]	
[SWS_PHM_00206]	
[SWS_PHM_00207]	
[SWS_PHM_00208]	
[SWS_PHM_00209]	
[SWS_PHM_00210]	
[SWS_PHM_00211]	
[SWS_PHM_00212]	
[SWS_PHM_00213]	
[SWS_PHM_00214]	
[SWS_PHM_00215]	
[SWS_PHM_00235]	
[SWS_PHM_00236]	
[SWS_PHM_01136]	
[SWS_PHM_01146]	
[SWS_PHM_01227]	Consistency of Checkpoint Identifier
[SWS_PHM_01228]	Reporting of undefined Checkpoint Identifier

Table E.6: Deleted Traceables in R22-11